



Prisma II Platform







System Guide - System Release 2.03

For Your Safety

Explanation of Warning and Caution Icons

Avoid personal injury and product damage! Do not proceed beyond any symbol until you fully understand the indicated conditions.

The following warning and caution icons alert you to important information about the safe operation of this product:

-  You may find this symbol in the document that accompanies this product. This symbol indicates important operating or maintenance instructions.
-  You may find this symbol affixed to the product. This symbol indicates a live terminal where a dangerous voltage may be present; the tip of the flash points to the terminal device.
-  You may find this symbol affixed to the product. This symbol indicates a protective ground terminal.
-  You may find this symbol affixed to the product. This symbol indicates a chassis terminal (normally used for equipotential bonding).
-  You may find this symbol affixed to the product. This symbol warns of a potentially hot surface.
-  You may find this symbol affixed to the product and in this document. This symbol indicates an infrared laser that transmits intensity-modulated light and emits invisible laser radiation or an LED that transmits intensity-modulated light.

Important

Please read this entire guide. If this guide provides installation or operation instructions, give particular attention to all safety statements included in this guide.

Notices

Trademark Acknowledgments

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of cisco trademarks, go to this URL: www.cisco.com/go/trademarks.

Third party trademarks mentioned are the property of their respective owners.

The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Publication Disclaimer

Cisco Systems, Inc. assumes no responsibility for errors or omissions that may appear in this publication. We reserve the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

Copyright

© 2008, 2012 Cisco and/or its affiliates. All rights reserved. Printed in the United States of America.

Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Cisco Systems, Inc.

Contents

Prisma II Product Notices	xiii
Important Safety Instructions	xv
Laser Safety	xxv
Warning Labels	xxvii
Chapter 1 Quick Start Guide	1
Step 1: Install the Chassis in a Rack.....	2
To Install the Chassis in a Rack.....	2
Step 2: Make Chassis-to-Chassis ICIM2 Connections.....	3
Chassis-to-Chassis ICIM2 Connections	3
ICIM IN and ICIM OUT Connectors.....	3
To Make ICIM IN and ICIM OUT Cable Connections	3
ICIM IN and ICIM OUT Cables	5
Step 3: Make Electrical Power Connections	6
Electrical Power Connections.....	6
Chassis Wiring and Fusing.....	6
DC Power Inlet Illustration	8
To Install the DC Power Cord.....	9
To Install the AC Power Cord.....	10
To Install the Power Supply in the Chassis.....	10
Step 4: Install the ICIM2.....	12
To Install the ICIM2.....	12
Step 5: Set Network Parameters from the Command Line Interface (CLI)	13
Step 6: Connect the ICIM2 to the Network	17
To Set Up a Telnet CLI Session	17
Step 7: Install Modules in the Chassis.....	18
To Install the Module	18
Step 8: Set Additional Parameters via CLI (Optional)	20
To Set Additional Users for ICIM2 or ICIM2-XD Access.....	20
Step 9: Set and Verify SNMP Community Strings	21
Step 10: Perform Chassis-to-Chassis ICIM2 Activation (Optional)	23
Step 11: Make Changes to Traps and Enterprise MIBs.....	24
MIB Software	24
Trap Overview	24
Step 12: Make Physical Connections to Modules	26
To Connect Optical Cables	26

To Connect RF Cables	26
Step 13: Verify System Release and Module Firmware Versions	27
Step 14: Install and Use the Firmware Update (SOUP) Utility (Optional)	28
To Install the SOUP on Windows.....	28
To Use the SOUP Utility	28
To Uninstall the SOUP on Windows.....	28

Chapter 2 Introduction 31

Related Publications	33
Prisma II Platform Description	34
Prisma II Platform Components	34
Prisma II Fan Tray	35
Prisma II Power Supplies.....	35
ICIM2.....	35
Prisma II Application Modules.....	35
Prisma II Chassis.....	36
Chassis Configuration.....	36
Typical Chassis Block Diagram	37
Front-Access Chassis.....	38
Chassis Front Panel Features.....	38
Chassis Back Plane Bus	39
Prisma II Power Supplies.....	40
Back Plane Bus Connectors	40
Prisma II Fan Tray	41
Fan Tray Configuration.....	41
Fan Tray Installation.....	41
Fan Tray Illustration (Top View)	42
Fan Tray Front Panel Features	42
Prisma II Power Supply	43
Electrical Input Voltages	43
Power Inlets	43
Power Supply Block Diagram.....	44
Power Supply Front Panel Illustrations.....	44
Power Supply Front Panel Features.....	45
Prisma II ICIM2.....	46
ICIM2 Block Diagram.....	46
ICIM2 Illustration (Front Panel)	47
ICIM2 Front Panel Features.....	47
Module Back Panel	48
Back Panel Connectors.....	48
Power and Communications Connector	48

Chapter 3 Hardware Installation	49
Before You Begin.....	50
Unpacking and Inspecting the Chassis.....	50
Required Equipment and Tools.....	50
Site Requirements	51
Operating Environment.....	51
Chassis Wiring and Fusing.....	51
Rack Location Requirements.....	53
Unused Slots.....	53
Mounting the Chassis in a Rack.....	54
To Install the Chassis in a Rack.....	54
Chassis Dimensions.....	55
Connector Interface Panel.....	56
Connector Interface Panel Illustration.....	56
Connecting the ICIM2 to Additional Chassis	58
To Make ICIM IN and ICIM OUT Cable Connections	58
ICIM IN and ICIM OUT Connectors.....	60
ICIM IN and ICIM OUT Cables.....	60
Chassis-to-Chassis ICIM2 Activation.....	60
External Alarms Connections.....	62
Master-Slave Operation	62
ALARM IN and OUT Connections	62
Master-Slave Illustration.....	63
ALARMS IN Connector	63
ALARMS OUT Connector	63
Fan Tray.....	64
To Remove the Fan Tray	64
Chassis Fan Filter	65
To Remove Chassis Fan Filter	65
Installing the Power Supplies.....	67
Space Requirements	67
Electrical Power Connections.....	67
To Install the AC Power Cord.....	68
To Install the DC Power Cord.....	69
To Install the Power Supply in the Chassis.....	69
Power Supply Cooling Fans.....	70
To Monitor the Power Supply.....	71
Installing the ICIM2.....	72
To Install the ICIM2.....	72
Installing the Module in the Chassis.....	74
To Install the Module	74
Cleaning Optical Connectors	77
Recommended Equipment.....	77
Tips for Optimal Fiber-Optic Connector Performance.....	77

To Clean Optical Connectors	78
Fiber Optic Connector Cleaning Instructions	78
Connecting Optical Cables	81
To Connect Optical Cables	81
Connecting RF Cables	82
To Connect RF Cables	82

Chapter 4 Equipment Configuration 83

HyperTerminal Session Setup.....	84
To Set Up a HyperTerminal Serial Port Session.....	84
CLI Parameters.....	87
Login.....	87
To Set the Clock.....	88
To Set Additional Users for ICIM2 or ICIM2-XD Access.....	88
To Set and Verify SNMP Community Strings	89
Telnet Session	90
To Set Up a Telnet CLI Session	90
SNMP Parameters.....	92
Using the ICIM Web Interface	93
Login Settings.....	93
To Log In.....	93
To Log Out.....	94

Chapter 5 ICIM2 Operation 97

Platform Configuration.....	98
Operating the ICIM2	99
ICIM2 Illustration (Front Panel)	99
ICIM2 Front Panel Features.....	99
ICIM2 LCD.....	100
ICIM2 Keypad	100
To Adjust the ICIM2 LCD Contrast	101
Prisma II MAIN Menu and ICIM Menu Structure.....	102
Configuring for Remote Network Access	104
Preliminary Steps for SNMP	104
To Configure the ICIM2 for SNMP	104
To Restart the ICIM2	106
Using ICIM2 with the Fan Tray	107
Fan Tray Menu Structure.....	107
To Check Operating Status.....	107
Fan Tray STATUS Menus	108
To Check Alarms.....	108
Fan Tray ALARMS Menus	109
To Check Fan Tray Manufacturing Data	109
Fan Tray MFG. DATA Menus.....	111

Using ICIM2 with Power Supply 1	112
Power Supply 1 Menu Structure	112
To Check Operating Status.....	112
Power Supply 1 STATUS Menus.....	113
To Check Alarms.....	113
Power Supply 1 ALARMS Menus	114
To Check Power Supply 1 Manufacturing Data.....	115
Power Supply 1 MFG. DATA Menu	116
Using ICIM2 with Power Supply 3	117
Power Supply 3 Menu Structure	117
To Check Operating Status.....	117
Power Supply 3 STATUS Menus.....	118
To Check Alarms.....	118
Power Supply 3 ALARMS Menus.....	119
To Check Power Supply 3 Manufacturing Data.....	120
Power Supply 3 MFG. DATA Menu	121

Chapter 6 Operation using LCI 123

LCI Introduction	124
System Requirements	125
Computer Requirements.....	125
Cable Requirements.....	125
Installing LCI.....	126
To Install the LCI Software.....	126
Connecting Your Computer to the Chassis.....	129
To Connect a Computer to the Chassis.....	129
Starting LCI Software	130
To Start LCI Software	130
LCI Module Tree	132
Module Tree.....	132
Accessing the Module Detail Information	133
Module Details Window	133
To Access the Module Details, Double-Click the Chassis.....	134
To Access the Module Details, Right-Click the Chassis	135
To Access the Module Details, Double-Click the Module	137
To Access the Module Details, Right-Click the Module.....	138
Checking the Operating Status	139
To Check the Operating Status using LCI.....	139
Checking the Module Alarms using LCI.....	140
To Check Alarms using LCI.....	140
Modifying Module Alarm Limits using LCI.....	142
To Modify Alarm Limits using LCI.....	142
Checking Manufacturing Data using LCI	144
To Check Manufacturing Data using LCI	144

Chapter 7 User Management	145
Introduction.....	146
User Accounts	146
Usernames.....	146
Passwords	147
Security Levels	147
Account Enable or Disable	147
Login Thresholds	147
User Lockout	148
Inactivity Timeout.....	148
Replacing the Default Admin Account.....	149
To Replace the Default Admin Account.....	149
Working With User Accounts	153
To Add a New User.....	153
To Change a User Password	154
To Change a User Security Level.....	155
To Change User Account Status	156
To Unlock User Accounts	157
To Delete a User Account	157
To List All Currently Logged In Users	158
User Lockout.....	160
To View the Current Lockout Interval.....	160
To Specify a New Lockout Interval.....	161
To View Locked-Out Users	162
To View Lockout Time Remaining by User	163
To Unlock a Locked-Out User.....	163
Chapter 8 Event Log	165
Introduction.....	166
Event Log Fields.....	166
Event Action IDs	167
Viewing the Event Log.....	169
To View the Event Log through the CLI	169
To View the Event Log through the Web Interface	170
Clearing the Event Log.....	171
To Clear the Event Log through the CLI	171
To Clear the Event Log through the Web Interface	171
Setting Event Log Filter Parameters.....	172
To View Filter Parameters through the CLI.....	172
To Set Filter Parameters through the CLI.....	172
To View Filter Parameters through the Web Interface.....	173
To Set Filter Parameters through the Web Interface.....	173

Event Log-Related Traps	174
Example: 80% Full Trap	174
Example: 100% Full Trap	175
Downloading and Viewing the Event Log Remotely	176
To Download the Event Log File	176

Chapter 9 SNMP Management 179

Introduction	180
Prisma II Enterprise MIBs	180
ICIM MIB	181
To View the ICIM MIB	181
ICIM MIB Elements	181
Event Log File Management	195
SNTP Time Synchronization	198
Trap Handling	201
Trap Recv Table	202
Trap Logging Auxiliaries	206
Trap Logging Table	206
Module MIB	211
Module MIB Tables	211
Module Table	212
Module Alarm Table	220
Alarm Severity Mappings	225
Current Alarm Table	226
Module Monitor Table	229
Module Control Table	232
Insert Module Table	235
Remove Module Table	235
Remote Reboot of ICIM2 and Modules	238
To Reboot the ICIM2 via SNMP	238
To Reboot a Module via SNMP	238
Prisma II Traps	239
About Traps	239
Trap Receiving Configuration	240
To Configure Trap Destination	241
Trap Types	242
Enhanced Trap Binding Information	253
Enhanced Trap Alarms	257
Enhanced Trap Events	260
Alarm Threshold Modification	277
System Behavior	279
ICIM2 as Proxy for Module Information	279
Delay in the Discovery Process	279
Module Removal and Enhanced Traps	279

Frequently Asked Questions.....	280
How do I configure trap destination?.....	280
Why do the same alarm values represent different conditions?.....	280
How do Enhanced Traps differ from other trap types?.....	281
When do traps associated with module insertion, removal, and alarms occur?.....	281
Where can I find trap definitions?.....	282
What is the Trap Logging Table?.....	282

Chapter 10 Remote Firmware Download Feature 283

Installing the SOUP.....	284
To Install SOUP on Windows.....	284
To Uninstall the SOUP on Windows.....	284
Concepts.....	285
The Chassis and the ICIM2.....	285
Release Files.....	285
Active and Inactive Flash.....	285
Concurrency.....	286
Integration with an NMS (Optional).....	286
Usage.....	287
Launching Standalone (Windows Only).....	287
SOUP Main Screen.....	289
Firmware Upgrade Process.....	291
FTP Settings.....	292
SNMP Settings.....	293
FTP Server.....	295
Firmware Updates.....	296

Chapter 11 Maintenance and Troubleshooting 299

Maintenance.....	301
Maintenance Record.....	301
Troubleshooting.....	302
Chassis Troubleshooting.....	302
Alarm Troubleshooting.....	303
Additional Assistance.....	303
FansOk Alarm.....	304
FansOk Alarm Parameters.....	304
Suggested Actions.....	304
ChasTemp Alarm.....	305
ChasTemp Alarm Parameters.....	305
Suggested Actions.....	305
Ps1PwrIn Alarm.....	307
Ps1PwrIn Alarm Parameters.....	307
Suggested Actions.....	307

Ps1+24 Alarm	308
Ps1+24 Alarm Parameters.....	308
Suggested Actions.....	308
Ps1+5VDC Alarm.....	309
Ps1+5VDC Alarm Parameters.....	309
Suggested Actions.....	309
Ps1-5VDC Alarm.....	310
PS1-5VDC Alarm Parameters	310
Suggested Actions.....	310
Ps3PwrIn Alarm.....	311
Ps3PwrIn Alarm Parameters	311
Suggested Actions.....	311
Ps3+24 Alarm	312
Ps3+24 Alarm Parameters.....	312
Suggested Actions.....	312
Ps3+5VDC Alarm.....	313
Ps3+5VDC Alarm Parameters.....	313
Suggested Actions.....	313
Ps3-5VDC Alarm.....	314
PS3-5VDC Alarm Parameters	314
Suggested Actions.....	314
Cleaning Optical Connectors	315
Recommended Equipment.....	315
Tips for Optimal Fiber-Optic Connector Performance.....	315
To Clean Optical Connectors	316
Fiber Optic Connector Cleaning Instructions	316
Connecting Optical Cables	319
To Connect Optical Cables	319

Chapter 12 Customer Support Information	321
Appendix A Prisma II Permitted CLI Commands	323
From CLI	324
From ICIM.....	325
From */* MODULE	331
From TERMINAL	334
Appendix B Features Available via Remote User Interface	335
Overview	336
ICIM Data.....	337
Module Data	340
Current Alarms	341
Module Alarms	342
Module Controls	343
Module Monitors	344
System Information	345
User Management.....	346
Appendix C Module Parameter Descriptions	347
Prisma II Chassis Parameters	348
Prisma II Chassis Configurable Parameters.....	348
Prisma II Chassis Alarm Data Parameters	348
Prisma II Chassis Operating Status Parameters	348
Prisma II Chassis Manufacturing Data Parameters	349
Glossary	351
Index	357

Prisma II Product Notices

System Release

The information in this guide pertains to System Release 2.03 of the Prisma II Platform.

Operating Temperature



CAUTION:

The warranty may be voided and the equipment damaged if you operate the equipment above the specified temperature limits (131°F/55°C for post-amplifiers, 149°F/65°C for other products). Specification temperature limits are measured in the air stream at the fan tray inlet and may be higher than room ambient temperature.



CAUTION:

Do not operate post-amplifiers at air inlet temperature above 30°C for extended periods or repetitively. Extended or repetitive operation above 30°C will reduce amplifier useful life and increase amplifier failure rate.

Important Safety Instructions

Read and Retain Instructions

Carefully read all safety and operating instructions before operating this equipment, and retain them for future reference.

Follow Instructions and Heed Warnings

Follow all operating and use instructions. Pay attention to all warnings and cautions in the operating instructions, as well as those that are affixed to this equipment.

Terminology

The terms defined below are used in this document. The definitions given are based on those found in safety standards.

Service Personnel - The term *service personnel* applies to trained and qualified individuals who are allowed to install, replace, or service electrical equipment. The service personnel are expected to use their experience and technical skills to avoid possible injury to themselves and others due to hazards that exist in service and restricted access areas.

User and Operator - The terms *user* and *operator* apply to persons other than service personnel.

Ground(ing) and Earth(ing) - The terms *ground(ing)* and *earth(ing)* are synonymous. This document uses *ground(ing)* for clarity, but it can be interpreted as having the same meaning as *earth(ing)*.

Electric Shock Hazard

This equipment meets applicable safety standards.



WARNING:

To reduce risk of electric shock, perform only the instructions that are included in the operating instructions. Refer all servicing to qualified service personnel only.

Electric shock can cause personal injury or even death. Avoid direct contact with dangerous voltages at all times. The protective ground connection, where provided, is essential to safe operation and must be verified before connecting the power supply.

Know the following safety warnings and guidelines:

- Dangerous Voltages

Important Safety Instructions

- Only qualified service personnel are allowed to perform equipment installation or replacement.
- Only qualified service personnel are allowed to remove chassis covers and access any of the components inside the chassis.
- **Grounding**
 - Prisma II equipment is suitable for installation as part of the common bonding network (CBN).
 - Do not violate the protective grounding by using an extension cable, power cable, or autotransformer without a protective ground conductor.
 - Take care to maintain the protective grounding of this equipment during service or repair and to re-establish the protective grounding before putting this equipment back into operation.

Note: See the Installation section of this document for specific information regarding the AC and DC power, wiring, fusing, and grounding requirements for this product.

Installation Site

When selecting the installation site, comply with the following:

- **Protective Ground** - The protective ground lead of the building's electrical installation should comply with national and local requirements.
- **Environmental Condition** - The installation site should be dry, clean, and ventilated. Do not use this equipment where it could be at risk of contact with water. Ensure that this equipment is operated in an environment that meets the requirements as stated in this equipment's technical specifications, which may be found on this equipment's data sheet.

Installation Requirements



WARNING:

Allow only qualified service personnel to install this equipment. The installation must conform to all local codes and regulations.

Equipment Placement



WARNING:

Avoid personal injury and damage to this equipment. An unstable mounting surface may cause this equipment to fall.

Prisma II equipment is suitable for installation in network telecommunications facilities.

To protect against equipment damage or injury to personnel, comply with the following:

- Install this equipment in a restricted access location.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other equipment (including amplifiers) that produce heat.
- Place this equipment close enough to a DC input voltage source to accommodate the length of this equipment's power cord.
- Route all power cords so that people cannot walk on, place objects on, or lean objects against them. This may pinch or damage the power cords. Pay particular attention to power cords at plugs, outlets, and the points where the power cords exit this equipment.
- Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with this equipment.
- Make sure the mounting surface or rack is stable and can support the size and weight of this equipment.
- The mounting surface or rack should be appropriately anchored according to manufacturer's specifications. Ensure this equipment is securely fastened to the mounting surface or rack where necessary to protect against damage due to any disturbance and subsequent fall.

Ventilation

This equipment has openings for ventilation to protect it from overheating. To ensure equipment reliability and safe operation, do not block or cover any of the ventilation openings. Install the equipment in accordance with the manufacturer's instructions.

Rack Mounting Safety Precautions

Mechanical Loading

Make sure that the rack is placed on a stable surface. If the rack has stabilizing devices, install these stabilizing devices before mounting any equipment in the rack.



WARNING:

Avoid personal injury and damage to this equipment. Mounting this equipment in the rack should be such that a hazardous condition is not caused due to uneven mechanical loading.

Important Safety Instructions

Reduced Airflow

When mounting this equipment in the rack, do not obstruct the cooling airflow through the rack. Be sure to mount the blanking plates to cover unused rack space. Additional components such as combiners and net strips should be mounted at the back of the rack, so that the free airflow is not restricted.



CAUTION:

Installation of this equipment in a rack should be such that the amount of airflow required for safe operation of this equipment is not compromised.

Elevated Operating Ambient Temperature

Only install this equipment in a humidity- and temperature-controlled environment that meets the requirements given in this equipment's technical specifications.



CAUTION:

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient temperature. Therefore, install this equipment in an environment compatible with the manufacturer's maximum rated ambient temperature.

Handling Precautions

When moving a cart that contains this equipment, check for any of the following possible hazards:



WARNING:




Avoid personal injury and damage to this equipment! Move any equipment and cart combination with care. Quick stops, excessive force, and uneven surfaces may cause this equipment and cart to overturn.

- Use caution when moving this equipment/cart combination to avoid injury from tip-over.
- If the cart does not move easily, this condition may indicate obstructions or cables that may need to be disconnected before moving this equipment to another location.
- Avoid quick stops and starts when moving the cart.
- Check for uneven floor surfaces such as cracks or cables and cords.

Grounding

If this equipment is equipped with an external grounding terminal, attach one end of an 18-gauge wire (or larger) to the grounding terminal; then, attach the other end of the wire to a ground, such as a grounded equipment rack.

Equipotential Bonding

If this equipment is equipped with an external chassis terminal marked with the IEC 60417-5020 chassis icon () , the installer should refer to CENELEC standard EN 50083-1 or IEC standard IEC 60728-11 for correct equipotential bonding connection instructions.

Connection to IT Power Systems

This equipment has been tested for IT power systems 240 VAC phase-to-phase.

Connection to -48 V DC/-60 V DC Power Sources

If this equipment is DC-powered, refer to the specific installation instructions in this manual or in companion manuals in this series for information on connecting this equipment to nominal -48 V DC/-60 V DC power sources.

Circuit Overload

Know the effects of circuit overloading before connecting this equipment to the power supply.



CAUTION:

Consider the connection of this equipment to the supply circuit and the effect that overloading of circuits might have on overcurrent protection and supply wiring. Refer to the information on the equipment-rating label when addressing this concern.

General Servicing Precautions



WARNING:

Avoid electric shock! Opening or removing this equipment's cover may expose you to dangerous voltages.



CAUTION:

These servicing precautions are for the guidance of qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

Be aware of the following general precautions and guidelines:

- **Servicing** - Servicing is required when this equipment has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into this equipment, this equipment has been exposed to rain or moisture, does not operate normally, or has been dropped.
- **Wristwatch and Jewelry** - For personal safety and to avoid damage of this

Important Safety Instructions

equipment during service and repair, do not wear electrically conducting objects such as a wristwatch or jewelry.

- **Lightning** - Do not work on this equipment, or connect or disconnect cables, during periods of lightning.
- **Labels** - Do not remove any warning labels. Replace damaged or illegible warning labels with new ones.
- **Covers** - Do not open the cover of this equipment and attempt service unless instructed to do so in the instructions. Refer all servicing to qualified service personnel only.
- **Moisture** - Do not allow moisture to enter this equipment.
- **Cleaning** - Use a damp cloth for cleaning.
- **Safety Checks** - After service, assemble this equipment and perform safety checks to ensure it is safe to use before putting it back into operation.

Electrostatic Discharge

Electrostatic discharge (ESD) results from the static electricity buildup on the human body and other objects. This static discharge can degrade components and cause failures.

Take the following precautions against electrostatic discharge:

- Use an anti-static bench mat and a wrist strap or ankle strap designed to safely ground ESD potentials through a resistive element.
- Keep components in their anti-static packaging until installed.
- Avoid touching electronic components when installing a module.

Fuse Replacement

To replace a fuse, comply with the following:

- Disconnect the power before changing fuses.
- Identify and clear the condition that caused the original fuse failure.
- Always use a fuse of the correct type and rating. The correct type and rating are indicated on this equipment.

Batteries

This product may contain batteries. Special instructions apply regarding the safe use and disposal of batteries:

Safety

- Insert batteries correctly. There may be a risk of explosion if the batteries are incorrectly inserted.
- Do not attempt to recharge 'disposable' or 'non-reusable' batteries.
- Please follow instructions provided for charging 'rechargeable' batteries.
- Replace batteries with the same or equivalent type recommended by manufacturer.
- Do not expose batteries to temperatures above 100°C (212°F).

Disposal

- The batteries may contain substances that could be harmful to the environment
- Recycle or dispose of batteries in accordance with the battery manufacturer's instructions and local/national disposal and recycling regulations.



廢電池請回收

- The batteries may contain perchlorate, a known hazardous substance, so special handling and disposal of this product might be necessary. For more information about perchlorate and best management practices for perchlorate-containing substance, see www.dtsc.ca.gov/hazardouswaste/perchlorate.

Modifications

This equipment has been designed and tested to comply with applicable safety, laser safety, and EMC regulations, codes, and standards to ensure safe operation in its intended environment. Refer to this equipment's data sheet for details about regulatory compliance approvals.

Do not make modifications to this equipment. Any changes or modifications could void the user's authority to operate this equipment.

Modifications have the potential to degrade the level of protection built into this equipment, putting people and property at risk of injury or damage. Those persons making any modifications expose themselves to the penalties arising from proven non-compliance with regulatory requirements and to civil litigation for compensation in respect of consequential damages or injury.

Accessories

Use only attachments or accessories specified by the manufacturer.

Electromagnetic Compatibility Regulatory Requirements

This equipment meets applicable electromagnetic compatibility (EMC) regulatory requirements. Refer to this equipment's data sheet for details about regulatory compliance approvals. EMC performance is dependent upon the use of correctly shielded cables of good quality for all external connections, except the power source, when installing this equipment.

- Ensure compliance with cable/connector specifications and associated installation instructions where given elsewhere in this manual.

Otherwise, comply with the following good practices:

- Multi-conductor cables should be of single-braided, shielded type and have conductive connector bodies and backshells with cable clamps that are conductively bonded to the backshell and capable of making 360° connection to the cable shielding. Exceptions from this general rule will be clearly stated in the connector description for the excepted connector in question.
- Ethernet cables should be of single-shielded or double-shielded type.
- Coaxial cables should be of the double-braided shielded type.

EMC Compliance Statements

Where this equipment is subject to USA FCC and/or Industry Canada rules, the following statements apply:

FCC Statement for Class A Equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case users will be required to correct the interference at their own expense.

Industry Canada - Industrie Canadienne Statement

This apparatus complies with Canadian ICES-003.
Cet appareil est conforme à la norme NMB-003 du Canada.

CENELEC/CISPR Statement with Respect to Class A Information Technology Equipment

This is a Class A equipment. In a domestic environment this equipment may cause radio interference in which case the user may be required to take adequate measures.

Laser Safety

Introduction

This equipment contains an infrared laser that transmits intensity-modulated light and emits invisible radiation.

Warning: Radiation



WARNING:

- **Avoid personal injury! Use of controls, adjustments, or procedures other than those specified herein may result in hazardous radiation exposure.**
 - **Avoid personal injury! The laser light source on this equipment (if a transmitter) or the fiber cables connected to this equipment emit invisible laser radiation. Avoid direct exposure to the laser light source.**
 - **Avoid personal injury! Viewing the laser output (if a transmitter) or fiber cable with optical instruments (such as eye loupes, magnifiers, or microscopes) may pose an eye hazard.**
- Do not apply power to this equipment if the fiber is unmated or unterminated.
 - Do not stare into an unmated fiber or at any mirror-like surface that could reflect light emitted from an unterminated fiber.
 - Do not view an activated fiber with optical instruments (e.g., eye loupes, magnifiers, microscopes).
 - Use safety-approved optical fiber cable to maintain compliance with applicable laser safety requirements.

Warning: Fiber Optic Cables



WARNING:

Avoid personal injury! Qualified service personnel may only perform the procedures in this manual. Wear safety glasses and use extreme caution when handling fiber optic cables, particularly during splicing or terminating operations. The thin glass fiber core at the center of the cable is fragile when exposed by the removal of cladding and buffer material. It easily fragments into glass splinters. Using tweezers, place splinters immediately in a sealed waste container and dispose of them safely in accordance with local regulations.

Safe Operation for Software Controlling Optical Transmission Equipment

If this manual discusses software, the software described is used to monitor and/or control ours and other vendors' electrical and optical equipment designed to transmit video, voice, or data signals. Certain safety precautions must be observed when operating equipment of this nature.

For equipment specific safety requirements, refer to the appropriate section of the equipment documentation.

For safe operation of this software, refer to the following warnings.



WARNING:

- **Ensure that all optical connections are complete or terminated before using this equipment to remotely control a laser device. An optical or laser device can pose a hazard to remotely located personnel when operated without their knowledge.**
- **Allow only personnel trained in laser safety to operate this software. Otherwise, injuries to personnel may occur.**
- **Restrict access of this software to authorized personnel only.**
- **Install this software in equipment that is located in a restricted access area.**

Warning Labels

The following illustration displays the warning label on this equipment.



TP492

1

Quick Start Guide

Introduction

This chapter provides streamlined step-by-step instructions for installing and configuring the platform hardware and firmware. Later chapters of this guide provide more detailed information on platform design, operation, and maintenance.

In This Chapter

■ Step 1: Install the Chassis in a Rack.....	2
■ Step 2: Make Chassis-to-Chassis ICIM2 Connections.....	3
■ Step 3: Make Electrical Power Connections	6
■ Step 4: Install the ICIM2.....	12
■ Step 5: Set Network Parameters from the Command Line Interface (CLI)	13
■ Step 6: Connect the ICIM2 to the Network	17
■ Step 7: Install Modules in the Chassis.....	18
■ Step 8: Set Additional Parameters via CLI (Optional).....	20
■ Step 9: Set and Verify SNMP Community Strings	21
■ Step 10: Perform Chassis-to-Chassis ICIM2 Activation (Optional)	23
■ Step 11: Make Changes to Traps and Enterprise MIBs.....	24
■ Step 12: Make Physical Connections to Modules	26
■ Step 13: Verify System Release and Module Firmware Versions.....	27
■ Step 14: Install and Use the Firmware Update (SOUP) Utility (Optional).....	28

Step 1: Install the Chassis in a Rack

To Install the Chassis in a Rack



WARNING:

The Prisma II Chassis weighs approximately 30 lbs. empty and 60 lbs. fully loaded. To avoid personal injury and equipment damage, use safe handling and lifting practices in accordance with your organization's procedures.

Complete the following steps to mount the chassis in the rack.

- 1 If necessary, remove and reattach the chassis mounting brackets. The chassis ships from the factory with brackets installed for a 19-inch rack. When using a 23-inch rack, remove the mounting brackets and reattach them so that the wider bracket section protrudes from the chassis. Use a torque wrench to tighten the bracket mounting screws to 12 to 14 in-lbs (1.36 to 1.58 Nm).
- 2 Position the chassis in the rack with the fan tray installed, but otherwise empty.
- 3 Insert a mounting screw through each of at least four mounting holes on chassis front panel, and then into the rack.



- 4 Use a medium-sized Phillips-head screwdriver to tighten each mounting screw until it is tight.
- 5 Install additional cable and fiber management hardware as needed, in accordance with local practice.

Note: The instructions and illustration above describe a typical installation in a 19-inch rack. Installation details may vary depending on the mechanical configuration of the chassis mounting accessories.

Step 2: Make Chassis-to-Chassis ICIM2 Connections

Chassis-to-Chassis ICIM2 Connections

This platform allows an ICIM2 or ICIM2-XD located in one chassis to monitor and control application modules located in several other chassis. To establish chassis-to-chassis ICIM2 communication, use the **ICIM IN** and **ICIM OUT** connectors located on the chassis interface panel.

Complete the following steps to establish chassis-to-chassis ICIM2 communication:

- 1 Connect a cable from ICIM OUT on the chassis containing the ICIM2 or ICIM2-XD to ICIM IN on the second chassis.
- 2 If required, connect a second cable from ICIM OUT on the second chassis to ICIM IN on the third chassis.
- 3 If required, connect a third cable from ICIM OUT on the third chassis to ICIM IN on the fourth chassis.

Note: An ICIM2 or ICIM2-XD can control up to 64 application modules in a chassis daisy-chain of no more than 4 chassis.

ICIM IN and ICIM OUT Connectors

Every chassis has a DB9 **ICIM IN** and a DB9 **ICIM OUT** connector for the purpose of chassis-to-chassis ICIM2 connections. **ICIM IN** is a female connector and **ICIM OUT** is a male connector.




To Make ICIM IN and ICIM OUT Cable Connections

Complete the following steps to make chassis-to-chassis **ICIM IN** and **ICIM OUT** connections.

- 1 Connect the serial extension cable from the **ICIM OUT** of the chassis containing the ICIM2 or ICIM2-XD to the **ICIM IN** connector of the second chassis.
- 2 Change the chassis ID numbers as needed to give each chassis an appropriate unique ID number. See **To Change the Chassis ID Number** below for further details.
- 3 Connect a serial extension cable from the **ICIM OUT** of the second chassis to the **ICIM IN** of the third chassis.
- 4 Continue this daisy-chain connection until all chassis are connected.

- 5 The ICIM OUT port of the last chassis in the daisy-chain must be terminated with an ICIM OUT terminator, part number 4013014, which ships with the ICIM2 or ICIM2-XD.



Note:

- All chassis connected in this daisy-chain must be powered and have a fan tray or fan assembly installed. For correct operation, proper cooling of the chassis must be maintained over the specified temperature range.
- A single chassis equipped with an ICIM2 or ICIM2-XD must also have its ICIM OUT port terminated with an ICIM OUT terminator, part number 4013014. The ICIM OUT terminator ships with the ICIM2 or ICIM2-XD.

To Change the Chassis ID Number

The number that appears in the chassis ID switch on the front panel of the chassis in which the ICIM2 or ICIM2-XD is installed indicates the value for the chassis ID. Valid chassis ID values are 00 to 99 inclusive. However, the use of 00 as the chassis ID value is not recommended in some circumstances, as the following caution explains.

CAUTION:

Setting the chassis ID to 00 is not recommended as it causes the entity MIB to violate RFC-2737 by creating an invalid object identifier. This may affect operation with some management systems that use the entity MIB. In particular, attempts to access the fans (in virtual slot 0) in chassis 00 will fail if made via serial TNCS (or ROSA-EM) or LCI.

Complete the following steps to change the chassis ID number.

Step 2: Make Chassis-to-Chassis ICIM2 Connections

- 1 Locate the chassis ID number at upper right on the front panel of each chassis. The chassis ID number is on a pushbutton scroll that can be used to set the number to a two-digit value from 01 to 99.



- 2 Use the pushbutton scroll as needed to set each chassis ID number to a unique value.

Note: The chassis numbering scheme used is discretionary, except that each interconnected chassis must have a unique ID number.

ICIM IN and ICIM OUT Cables

The cable required for both **ICIM IN** and **ICIM OUT** connections is a shielded 9-wire serial extension cable, DB9 Female to DB9 Male. This cable can be purchased locally or from the factory. The chassis data sheet lists the part number for a 6-foot DB9 Female to DB9 Male serial extension cable. The connectors are a serial 9-pin D-shell (EIA 574/232).

Step 3: Make Electrical Power Connections

Electrical Power Connections

Electrical power is supplied to the chassis through one or two power supplies that install from the front. AC or DC power supplies are available, allowing the chassis to operate from either utility AC power or from -48 VDC supplied by a battery room or other source.

Note: The DC return terminal of the power supplies is isolated, i.e., not connected to the chassis framework.

Important: Tie the system to earth ground via the ground stud.

Chassis Wiring and Fusing

Important: All chassis configurations require an external fuse or circuit breaker and #16 AWG wiring for both power and grounding. AC and DC current ratings differ, as further explained below.

AC Power Systems

Power for AC power supplies enters the chassis via a dedicated IEC power inlet for each power supply module.

Confirm that the IEC power cord or cords supplied with the chassis have the correct plug configuration for the country of use.

The voltage input range for AC systems is 100 to 240 VAC, single phase, 50-60 Hz.

AC input current is 14 A maximum. The chassis should be connected to a single outlet circuit with fuse or circuit breaker overcurrent protection rated 15 A minimum.

Important:

- Use only a grounded electrical outlet when connecting the unit to a power source. If you do not know whether the outlet is grounded, consult with a qualified electrician.
- Maintain reliable earth grounding of rack-mounted equipment. Pay particular attention to supply and ground connections made via power strips or any method other than direct connection to the branch circuit.

DC Power Systems

External -48 VDC operating power for each DC power supply module enters the chassis via a dedicated DC power inlet.


The voltage input range for DC power systems is -40 VDC to -72 VDC.

Use #16 AWG wire for DC field wiring. The #16 AWG wiring from the external -48 VDC supply is attached to a 3-pin terminal block which, in turn, plugs into the DC power inlet.

Insert the bare end of an insulated wire into each inlet on the terminal block and tighten the corresponding screw to capture the wire in the terminal block.

After terminating the cable, twist the conductors loosely (a full turn every few inches is sufficient).

As installed in the DC power connector, the top pin of the terminal block carries -48 VDC, the middle pin is the return, and the bottom pin is chassis ground.



Connect the chassis to a reliably grounded DC power source that is electrically isolated from the AC power source.

Important:

- Branch circuit overcurrent protection must be provided by a fuse or circuit breaker with a voltage rating of 72 VDC minimum and a current rating of 18 A maximum.
- The DC field wiring must include a readily accessible disconnect device that is suitably approved and rated.

Earth-Grounding Conditions


The chassis is designed to permit connection of the earthed conductor of the DC supply circuit to chassis ground. Before making this connection, confirm that all of the following conditions are met:

- The chassis is connected directly to the DC supply system earthing electrode conductor or to a bonding jumper from an earthing terminal bar or bus to which the DC supply system earthing electrode conductor is connected.
- The chassis is located in the same immediate area as other equipment connected between the earthed conductor of the same DC supply circuit and earthing conductor, such as in an adjacent cabinet. Also, the point of earthing of the DC system must not be earthed elsewhere.
- The DC power source is located within the same premises as the chassis.
- There are no switching or disconnecting devices in the earthed circuit conductor between the DC source and the point of connection of the earthing electrode conductor.

DC Power Inlet Illustration


The power supplies receive electrical power through the power inlets installed in the chassis. All power inlets are installed at the factory.

The following illustration shows the location of DC power inlets on the front-access chassis.



T13624

The following illustration shows the location of AC power inlets on the rear-access chassis.




T11424

To Install the DC Power Cord

Complete the following steps to install the DC power cord for each DC power supply.

- 1 Locate the DC wire terminal block(s) either pre-installed in each DC power inlet or in a bag with the chassis documentation.
- 2 Remove the terminal block and note the locations of the top, middle, and bottom terminals as shown below.



T12358

- 3 Attach a #12 AWG power cable from the fuse panel to the DC wire terminal block that was shipped with the chassis. Attach the conductors to the terminal block as follows:
 - Top terminal: -48 VDC conductor
 - Middle terminal: Return conductor
 - Bottom terminal: Not used

Note: The DC return terminal of the power supplies is isolated, i.e., not connected to the chassis framework.

Important: Tie the system to earth ground via the ground stud.

To Install the AC Power Cord

There is a separate and independent AC inlet for each power supply slot in the chassis. Therefore, for operation of dual AC power supplies, two AC power cords must be installed.


Complete the following steps to install the AC power cord(s).

- 1 Locate the AC power inlet(s) on the chassis.
- 2 Plug the female end of the power cable that was shipped with the power supply into the AC power inlet.
- 3 Attach the male end of the power cord(s) to the electrical source(s).

To Install the Power Supply in the Chassis

This procedure assumes that the power inlet has been installed, the appropriate power cord has been connected, and power has been applied to the chassis.

- 1 Facing the front of the chassis, position the bottom of the power supply on the module guide of slot 1 (extreme left) of the chassis.
- 2 Align the top and bottom ridges on the power supply with the module guide slots in the chassis. You should be able to see the fiber guides at the bottom of the chassis and the module guide slots as shown below.



Module Guide Slots

T11423

- 3 Locate the two ejector levers on the left of the power supply module. Swing the ejectors out so they are perpendicular to the module front panel.

Step 3: Make Electrical Power Connections


- 4 Gently slide the power supply into the chassis until its power and communications connections join connectors on the back plane bus. *Do not force the module into the chassis.* If properly aligned, it should slide in with minimal force.
- 5 Slowly press the module ejector levers toward the chassis so that their jaws engage with the mounting flange in the chassis. Confirm that the ejectors pull the power supply toward the mounting flange so that its back-panel connectors mate with the connectors at the rear of the chassis. Continue pressing the ejectors until they both lie parallel to the module front panel.
- 6 If you are installing a second power supply into slot 3, repeat steps 1 through 5, then continue with step 7.
- 7 Verify that the green LED illuminates, indicating that the power supply is now operating.
- 8 Confirm that the fan tray is operational. The fans should be audible once the power supply is operating.
- 9 Hand-tighten the screw at the top of the power supply to secure it in the chassis. Use a 3/8-in. flat-blade screwdriver to secure. *Do not over-tighten.*

Step 4: Install the ICIM2

To Install the ICIM2

Complete the following steps to install the ICIM2 in the chassis.

- 1 Facing the front of the chassis, position the bottom of the ICIM2 on the slide of slot 15 (extreme right) of the chassis.
- 2 Align the top and bottom ridges on the ICIM2 with the module guide slots in the chassis.
- 3 Locate the two ejector levers on the left of the ICIM2. Swing the ejectors out so they are perpendicular to the module front panel.



T13609

Fiber Guides

Module Guide Slots


- 4 Gently slide the ICIM2 into the chassis until its power and communications connections join connectors on the back plane bus. *Do not force the ICIM2 into the chassis.* If properly aligned, it should slide in with minimal force.
- 5 Slowly press the ICIM2 ejector levers toward the chassis so that their jaws engage with the mounting flange in the chassis. Confirm that the ejectors pull the ICIM2 toward the mounting flange so that its back-panel connectors mate with the connectors at the rear of the chassis. Continue pressing the ejectors until they both lie parallel to the module front panel.
- 6 Hand-tighten the screw at the top of the ICIM2 to secure it in the chassis. Use a 3/8-in. flat-blade screwdriver to secure. *Do not over-tighten.*

Step 5: Set Network Parameters from the Command Line Interface (CLI)

- 1 Connect one end of a DB-9 to DB-9 straight-through serial cable to an available COM port on the personal computer, and the other end to the ICIM2 front-panel serial port.
- 2 Open a HyperTerminal session on your laptop (or desktop) PC that you will use to connect to the ICIM2. The HyperTerminal program is typically found at:

`Start\All Programs\Accessories\Communication\Hyperterminal`

The new Connection Description dialog box appears.




- 3 Type in a name for the connection, select an icon of your choice, and click **OK**. The Connect To dialog box appears.




- 4 In the Connect Using field, click the drop-down arrow and select the serial port that you will use for the connection, and then click **OK**. The COM Properties dialog box appears.

Note: For most applications, the serial port is COM1 or COM2.

- 5 Set the following port setting in the COM Properties dialog box.



- 6 Click **OK**. The HyperTerminal main program window appears.



Step 5: Set Network Parameters from the Command Line Interface (CLI)

- 7 On the File menu, click **Save** to save the settings.
- 8 Wait for the ICIM2 boot to finish. Once finished, press **Enter** to display the ICIM2 login prompt:

```
Unauthorized or improper use of this system may result in
administrative disciplinary action and civil or criminal penalties.
By continuing to use this system you indicate your awareness of and
consent to these terms and conditions of use. LOG OFF IMMEDIATELY
if you do not agree to the conditions stated in this warning.
```

```
login:
```

- 9 Log in using the default username **Administrat0r** and the default password **AdminPassw0rd**. Note the 0 (zero) character in each string.

```
login: Administrat0r
Password: AdminPassw0rd
```

Successful login will return the following prompt:

```
login: Administrat0r
Password:
User Administrat0r logged in successfully on 11/13/06 at 15:25:35
Previous successful login was on 11/13/06 at 15:22:16
There were no failed attempts to login with this user id previously
CLI>
```

- 10 Enter the ICIM submenu by typing **icim** at the CLI> prompt.

```
CLI> icim
```

Successful entry into the ICIM menu tree will return the following prompt:

```
ICIM>
```

- 11 Configure the shelf (chassis) IP address, subnet mask, gateway, and clock using the following commands:

```
set ip xxx.xxx.xxx.xxx
set subnet xxx.xxx.xxx.xxx
set gateway xxx.xxx.xxx.xxx
set clock "month/day/year hour:minute:second"
```

Note:

- Be sure to include the quote symbols, e.g., `set clock "3/15/2006 13:09:51"`.
- Clock time is in the 24-hour format.

- 12 To enable these changes, reboot the ICIM2 or ICIM2-XD as follows:

```
ICIM> reboot
```

- 13 After the ICIM2 or ICIM2-XD reboots, repeat the login steps described above to return to the ICIM command prompt. Then use the show command to verify each of the above changes, as follows:

```
show ip
show subnet
show gateway
show clock
```

- 14 Type **logout**, and then press **Enter** to exit the session.

- 15 Remove the serial cable. It is no longer required.

Important:

- For Telnet operation, the computer you are using must have a network

connection through which it can reach the ICIM2 or ICIM2-XD at its IP address.

- No more than four Telnet sessions are allowed at one time.



CAUTION:

Always use the Logout command to close a serial port or Telnet CLI session. Closing a serial port session without issuing the Logout command leaves the session open for a possible future connection. This may allow unauthorized access by a new user if the previous user had a higher authorization privilege level.

Step 6: Connect the ICIM2 to the Network

- 1 Using a Category 5 Ethernet (CAT5) cable, connect the front panel Ethernet port of the ICIM2 or ICIM2-XD to your local network.
- 2 Verify connectivity by pinging the ICIM2 or ICIM2-XD IP address. For example:

```
c:\> ping 172.18.50.100
```

Note: The ICIM2 or ICIM2-XD must have an IP address assigned as directed in *Step 5: Set Network Parameters from the Command Line Interface (CLI)* (on page 13). If not completed already, perform this step before continuing with these instructions.
- 3 Follow the steps described in *To Set Up a Telnet CLI Session* (on page 17) to set up a Telnet session with the ICIM2 or ICIM2-XD.

To Set Up a Telnet CLI Session


Complete the following steps to initiate a CLI session with the ICIM2 using Telnet.

Important: The ICIM2 must have an IP address assigned before performing this procedure.

- 1 Open a DOS window on the PC that you will use to connect to the ICIM2.
- 2 At the DOS command prompt, type:

```
telnet <IP address>
```

where *<IP address>* is the IP address of the ICIM2. The session starts and the Telnet login: prompt appears.



```

-----
W A R N I N G
-----
Unauthorized or improper use of this system may result in
administrative disciplinary action and civil or criminal penalties.
By continuing to use this system you indicate your awareness of and
consent to these terms and conditions of use.  LOG OFF IMMEDIATELY
if you do not agree to the conditions stated in this warning.

login: Administrat0r
Password:

User Administrat0r logged in successfully on 12/05/06 at 09:08:13
Previous successful login was on 12/05/06 at 08:51:47
There were no failed attempts to login with this user id previously

CLI> _

```

- 3 At the login: prompt, type **Administrat0r** (note the zero character in the string), and then press **Enter**.
- 4 At the Password: prompt, type **AdminPassw0rd** (note the zero character in the string), and then press **Enter**. The CLI> command prompt appears.

Step 7: Install Modules in the Chassis

To Install the Module



WARNING:

Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.




CAUTION:

Before removing a transmitter module from a Prisma II Chassis under power: 1) Disable the transmitter output by setting TxEnable=0 (Disable) from CLI or your network management system; and 2) Detach the fiber optic jumper from the transmitter output port. Failure to perform both steps may result in damage to downstream amplifier modules due to higher than normal transmitter output.

Complete the following steps to install the module in the chassis.


- 1 Locate the fiber guides at the bottom of the chassis and the module guide slots inside the chassis as shown in the following illustration.



- 2 Align the top and bottom on the module with the module guide slots on the chassis.
- 3 Locate the two ejector levers on the left of the module. Swing the ejectors out so they are perpendicular to the module front panel.

Step 7: Install Modules in the Chassis

- 4 Gently slide the module into the chassis until its power and communications connections join connectors on the back plane bus. *Do not force the module into the chassis.* If properly aligned, it should slide in with minimal force.



- 5 Slowly press the module ejector levers toward the chassis so that their jaws engage with the mounting flange in the chassis. Confirm that the ejectors pull the module toward the mounting flange so that its back-panel connectors mate with the connectors at the rear of the chassis. Continue pressing the ejectors until they both lie parallel to the module front panel.
- 6 Hand-tighten the screw at the top of the module to secure it in the chassis. Use a 3/8-in. flat-blade screwdriver to secure. *Do not over-tighten.*
- 7 Fill any unused chassis slots with module blanks to guarantee proper cooling air flow.

Step 8: Set Additional Parameters via CLI (Optional)

Additional parameters may be set as needed from the command line interface (CLI) for each application module installed.

Refer to *Prisma II Permitted CLI Commands* (on page 323) and the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477 for information and additional instructions on available commands and using the CLI.

The following CLI commands are pertinent to most installations.

To Set Additional Users for ICIM2 or ICIM2-XD Access

Refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477 for CLI and ICIM Web Interface login settings information.

Note: It is strongly recommended that a new administrator login be created and that the default administrator login be removed.

The table below lists the ICIM mode CLI commands for setting user login parameters.

Commands	Description
ICIM > show user	Shows all users
ICIM > user change password [user name]	Changes user password
ICIM > user add [user name] [access level] enable	Adds a user
ICIM > user delete [user name]	Deletes a user

Note: User names and passwords must be 6 to 14 characters long, and must include at least 1 number.

Step 9: Set and Verify SNMP Community Strings

At the CLI ICIM> command prompt, use the **set** command to change the SNMP Community write, read, and trap strings to corresponding user-defined strings to allow for remote monitoring and control via a network management system (NMS). After entering these commands, use the **info** command to verify the new settings.

The sample dialog below shows how to enter these commands. In the example below:

- myCommWriteString is the user-defined community write string.
- myCommReadString is the user-defined community read string.
- myCommTrapString is the user-defined community trap string.

Refer to *SNMP Management* (on page 179) for SNMP parameter information.

From the CLI command prompt, switch to ICIM command mode and define SNMP Read, Write, and Trap Community strings, as shown below.

```
CLI> icim

ICIM> set commwrite "myCommWriteString"
NOTE: This change will not fully take effect until the ICIM is restarted.
Until that time, some operations will not perform as expected.

SUCCESS!

ICIM> set commread "myCommReadString"
NOTE: This change will not fully take effect until the ICIM is restarted.
Until that time, some operations will not perform as expected.

SUCCESS!

ICIM> set commtrap "myCommTrapString"
NOTE: This change will not fully take effect until the ICIM is restarted.
Until that time, some operations will not perform as expected.

SUCCESS!
```

You can then verify the community string settings, as follows.

```
ICIM> info commread commwrite commtrap

COMMREAD          COMMWRITE          COMMTRAP
myCommReadString  myCommWriteString  myCommTrapString

SUCCESS!

ICIM>
```

Note:

- It is strongly recommended that the ICIM2 or ICIM2-XD be restarted after changing any of the community strings. Otherwise, some operations will continue to work normally, while others will appear to fail.
- It is strongly recommended that new SNMP community strings be created and the default SNMP community strings be removed. Default SNMP community string values are listed below.

SNMP Community String	Default Value
Read Community	public
Write Community	private
Trap Community	SNMP_traps

Step 10: Perform Chassis-to-Chassis ICIM2 Activation (Optional)

Once the chassis are interconnected, the shared ICIM2 or ICIM2-XD should be forced to search for all new modules, rather than be allowed to find them incrementally over the course of a polling cycle.

The recommended method for forcing a search for new modules is to reboot the ICIM2 or ICIM2-XD. This can be accomplished either by physically removing and reinserting the ICIM2 or by issuing a **reboot** command to the ICIM2 via the CLI interface.

To reboot the ICIM2 or ICIM2-XD via CLI, open a console or Telnet session and type the following commands at the CLI prompt.

```
CLI> icim
ICIM> reboot
```

The response will be:

```
The ICIM2 is about to reboot. This will end all current login and web sessions
Are you sure you want to proceed (Yes/No)> yes
```

```
SUCCESS!
ICIM>
```

```
-----
W A R N I N G
-----
```

```
Unauthorized or improper use of this system may result in
administrative disciplinary action and civil or criminal penalties.
By continuing to use this system you indicate your awareness of and
consent to these terms and conditions of use. LOG OFF IMMEDIATELY
if you do not agree to the conditions stated in this warning.
```

```
login:
```

Each of the additional modules will then be added to the ICIM2 or ICIM2-XD polling cycle.

Note: Use of the CLI **reboot** command is preferred over the **updateid** command in this case because a reboot will maintain synchronization with the element management system.

Step 11: Make Changes to Traps and Enterprise MIBs

Trap settings and other parameters can be set in one of several ways:

- Using Simple Network Management Protocol (SNMP) commands. Refer to *SNMP Management* (on page 179) for details on accessing the ICIM MIB tables.
- Using the Command Line Interface (CLI) Traps Enable command. Refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477 for details on using the Traps Enable command.
- Using the ICIM Web Interface, which requires no knowledge of SNMP or CLI. For further information, refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477.

Once this is accomplished, changes can be made to the ICIM Trap tables, of which there are 10 entries (one for each destination IP address).

Following are the objects in the p2TrapRecvEntry table that should be set.

MIB Object	Value
p2TrapRecvEnable	1-disabled; 2-enabled
p2TrapRecvAddr	IP address of trap receiver
p2TrapRecvTelcoAlarm	1-disabled; 2-enabled

MIB Software

MIBs associated with the software system release are available and should be compiled in your SNMP tool. They are labeled as follows:

- SCIATL-PRISMAII-ICIM-MIB.mib
- SCIATL-PRISMAII-MODULE-MIB.mib

Trap Overview

The Prisma II system can be configured to provide various alarm and warning conditions to an NMS or system monitor application.

There are nine different trap categories that can be independently enabled to provide the desired level of information on events occurring in a system. These traps can be forwarded to up to 10 different IP addresses. The trap filtering can be configured uniquely for each user.

See *SNMP Management* (on page 179) for trap details.

Step 11: Make Changes to Traps and Enterprise MIBs

Note: All trap types (module insertion, alarm events, etc.) are reported through the Enhanced Alarm trap. Therefore, only the Enhanced Alarm traps are enabled by default, and this is the recommended configuration.

Step 12: Make Physical Connections to Modules

Once all configuration changes are complete, you are ready to make fiber-optic and RF cable connections for each module as appropriate.

To Connect Optical Cables



CAUTION:

High power density exists on fiber when optical power is present. To avoid microscopic damage to fiber mating surfaces, turn off optical power or reduce power below 15 dBm before making or breaking optical connections.

Complete the following steps for each optical cable connection to be made and on every module to be installed.

- 1 Clean the end of the fiber to be connected as described in *Cleaning Optical Connectors* (on page 315).
- 2 Connect the optical cable to the module connector.
- 3 Route the cable to the appropriate destination.
- 4 Clean the remaining cable end, and then connect the cable to the mating module connector.

Note: Remember to observe minimum bend radius and other accepted handling practices when working with fiber-optic cables.

- 5 After cable installation is complete, return the module control settings to their original states.

To Connect RF Cables

Complete the following steps for each RF cable connection to be made.

- 1 Connect the RF cable to the appropriate connector on the connector interface panel.
- 2 Route the cable to the appropriate destination.

Step 13: Verify System Release and Module Firmware Versions

To check the current firmware revision levels in all modules in the ICIM2 or ICIM2-XD domain, enter the following CLI command at the ICIM> prompt:

```
ICIM> show domain
```

A column labeled `ACTIVEREV` in the response lists the active firmware revision numbers for each module in the domain. Each module firmware revision should be compatible with the revision number of the system release firmware. For information on module and system release firmware compatibility, contact your customer serviced representative.

If any modules report a firmware version that is not compatible with the system release firmware, use the procedures described in the next step to update the module firmware.

Step 14: Install and Use the Firmware Update (SOUP) Utility (Optional)

The Prisma II Software Upgrade Program (SOUP) is a user-friendly utility that allows users to perform firmware upgrades on Prisma II modules. The SOUP utility simplifies the firmware upgrade process by providing a graphical user interface (GUI) that is easy to use and requires little training.

When connected to a chassis, the SOUP utility shows the user the current versions of firmware on all modules and allows the user to download and activate other versions from system release files. The SOUP works together with the ICIM2 or ICIM2-XD to send the binary image files and appropriate commands to the modules to upgrade their firmware. As the modules are being upgraded, the SOUP displays relevant progress information to the user.

To Install the SOUP on Windows

Complete the following steps to install the Prisma II SOUP on Windows.

- 1 Download the Prisma II SOUP installation file to your Windows desktop.
- 2 Double-click the Prisma II SOUP installation icon to start the installation.
- 3 Follow the instructions of the installation wizard.

After the installation is complete, you will have an icon on the desktop to launch the SOUPLauncher application. There will also be a program group called Prisma II SOUP on your Start button menu.

To Use the SOUP Utility

After the SOUP utility is launched through SOUPLauncher, it attempts to connect to the ICIM and retrieve information about all the modules it manages. After retrieving the module information, the SOUP connects to the FTP server holding the system release files and retrieves the firmware versions available for each module. This information is then displayed to the user in the application main screen.

For additional details on using SOUP, see *Remote Firmware Download Feature* (on page 283).

To Uninstall the SOUP on Windows

Complete the following steps to remove the Prisma II SOUP from your computer.

- 1 Open the **Control Panel** from the Windows Start menu.
- 2 From the Control Panel, open the **Add or Remove Programs** application.

Step 14: Install and Use the Firmware Update (SOUP) Utility (Optional)

- 3 Find and choose the **Prisma II SOUP** entry in the list of installed programs. If the entry is not present, the program is not installed on the computer or was not installed properly.
- 4 Click the **Change/Remove** button.
- 5 Follow the instructions of the uninstall wizard.

2

Introduction

Overview

This guide describes the Prisma II™ Platform and application modules. The Prisma II Chassis, Power Supplies, Fan Tray, application modules, and external control systems make up the Prisma II Platform.

Purpose

This guide provides the requirements for implementing the Prisma II Platform components and external control systems.

Who Should Use This Document

This document is intended for authorized service personnel who have experience working with similar equipment. The service personnel should have appropriate background and knowledge to complete the procedures described in this document.

Qualified Personnel



WARNING:

Allow only qualified and skilled personnel to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.

Only appropriately qualified and skilled personnel should attempt to install, operate, maintain, and service this product.

Scope

This guide discusses the following topics.

- Descriptions of Prisma II Platform chassis and application modules
- Installation procedures
- Configuring the equipment
- Local and remote system management
- User management
- Remote software download and firmware update
- CLI command reference
- Descriptions of module parameters

Document Version

This is the first release of this guide (Rev A).

In This Chapter

■ Related Publications	33
■ Prisma II Platform Description	34
■ Prisma II Chassis	36
■ Prisma II Fan Tray	41
■ Prisma II Power Supply	43
■ Prisma II ICIM2	46
■ Module Back Panel	48

Related Publications

You may find the following publications useful as you implement the procedures in this document.

- *Prisma II Platform Remote User Interface Guide, System Release 2.03, part number 4025477*
- *Prisma II High Power Optical Amplifiers Installation and Operation Guide, part number 4010846*
- *Prisma II 1550 nm Gain-Flattened Optical Amplifier Installation and Operation Guide, part number 4000067*
- *Prisma II 1550 nm FTTx Transmitter Installation and Operation Guide, part number 4008715*
- *Prisma II 1550 nm Transmitters Installation and Operation Guide, part number 739259*
- *Prisma II Optical Amplifiers Installation and Operation Guide, part number 739260*
- *Prisma II Forward and Reverse Headend Driver Amplifiers Installation and Operation Guide, part number 4006323*
- *Prisma II Optical Switch Installation and Operation Guide, part number 715188*
- *Prisma II Forward Receiver Installation and Operation Guide, part number 713376*
- *Prisma and Prisma II Platform Maintenance and Troubleshooting Service Guide, part number 4000326*
- *Prisma II 1310 nm Reverse Transmitter Installation and Operation Guide, part number 715190*
- *Prisma II Forward and Reverse Headend Driver Amplifier Installation and Operation Guide, part number 715189*
- *Prisma II Reverse Data Receiver and Reverse Video Receiver Installation and Operation Guide, part number 713378*
- *Prisma II™ High Density Dual Reverse Receiver Installation and Operation Guide, part number 4015908*
- *Prisma II™ High Density Forward Receiver Installation and Operation Guide, part number 4020002*
- *Prisma II™ 1310 nm High Density Transmitter Installation and Operation Guide, part number 4009700*
- *Prisma II™ Multi-Wavelength High Density Transmitter Installation and Operation Guide, part number 4023013*

Prisma II Platform Description

The Prisma II Platform is a configurable and expandable system for providing amplification, transmission, and switching functions to fiber-optic communications networks. The Prisma II Platform can be configured for use in a variety of environments, from CATV headends and hubs to telecommunications central offices.

Key features of the Prisma II Platform include the following:

- High module density
- Broad operating temperature range
- Optimized design for rapid installation and setup
- Support for local and remote system monitoring and control

In addition, Prisma II Platform chassis can be used together with Prisma II XD Platform chassis in the same network. A single Intelligent Control Interface Module 2 (ICIM2) can be used to control this network, whether it is an ICIM2 installed in a Prisma II Platform chassis or an ICIM2-XD installed in a Prisma II XD chassis.

Prisma II Platform Components

The Prisma II Platform consists of the following standard and optional products.

- Prisma II Chassis
 - Front-access chassis (standard)
 - Rear-access chassis (optional)
- Prisma II Fan Tray
- Prisma II Power Supplies
- Prisma II Intelligent Communications Interface Module 2 (ICIM2)
- Prisma II application modules

Note: The ICIM2 can control up to 64 application modules in a chassis daisy-chain of up to 4 chassis. The daisy-chain can include both Prisma II and Prisma II XD chassis, provided that it does not exceed the maximum number of chassis or application modules.

The Prisma II chassis houses the other system components. A back plane bus at the rear of the chassis distributes electrical power to all modules and transports communication and control signals from the application modules to the ICIM2.

Prisma II Fan Tray

The chassis uses a negative pressure fan system that pulls input cooling air from the ambient environment. The fans are housed in a removable fan tray located at the top of the chassis for ease of maintenance.

A fan tray interface connects the back plane bus and the fan tray interconnect. A blind mate connector system is used to connect the fan tray to the back plane bus.

Prisma II Power Supplies

One or two Prisma II Power Supplies may be used. The power supplies are installed from the front of the chassis.



WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

Power supplies are available for operation from AC utility power or from a nominal -48 VDC power source.



WARNING:

Any external power supply must provide proper electrical components to power the chassis or risk serious equipment damage or personal injury. Do not use any external power supply to power this product unless it has been approved by Customer Service.

ICIM2

The Prisma II Intelligent Communications Interface Module 2 (ICIM2) provides users with read-only access to monitor application module configuration settings, status monitoring, and alarm monitoring.

In addition, the ICIM2 front panel allows the user to enable and disable Service mode on certain Prisma II application modules.

Prisma II Application Modules

Prisma II application modules perform a prescribed set of independent functions such as transmitting, receiving, or amplifying. These modules are installed from the front of the chassis, are hot-swappable, and have plug-and-play capability.

Prisma II Chassis

The Prisma II Chassis houses the Fan Tray, one or two Prisma II Power Supplies, all application modules, and the ICIM2. It distributes electrical power to all modules, and provides strain relief and routing for optical cables connected to the various modules.

The chassis also transports communication and control signals from the application modules to the ICIM2. These signals enable system management via the ICIM2 front panel and by command line interface (CLI), hypertext transfer protocol (HTTP), Local Craft Interface (LCI), and Simple Network Management Protocol (SNMP) commands.

Through a common back plane bus, the chassis provides modules with electrical power, a common serial bus, a high-speed data bus to the ICIM2, and up to four RF connections to each module. An inter-module bus enables the application modules to be replaced even when the system is powered and fully operational.

Chassis Configuration

The chassis has 16 slots that can be populated with any of the following combinations:

- 1 power supply (occupies 2 slots) and up to 13 single-slot application modules
- 2 power supplies (occupies 4 slots) and up to 12 single-slot application modules
- 1 power supply (occupies 2 slots), 1 ICIM2 (occupies 2 slots), and up to 11 single-slot application modules
- 2 power supplies (occupies 4 slots), 1 ICIM2 (occupies 2 slots), and up to 10 single-slot application modules


Note: In single power supply configurations, slot 3 is open but cannot be used by an application module. Instead, a power supply module blank must be installed in slot 3 to maintain proper air flow inside the chassis.

The chassis supports the entire family of Prisma II modules including primary and redundant power supplies, the ICIM2, pre-amplifiers, hybrid amplifiers, optical transmitters, optical receivers, and an optical switch. The chassis accepts full-height application modules directly, and half-height high density modules through the use of a host module.

A chassis fan filter is located below the fiber guide (fiber routing tray). It is recommended that this filter be replaced yearly. The service interval can be adjusted depending on the equipment environment.

Typical Chassis Block Diagram


The block diagram below shows a typical Prisma II Chassis configuration with two power supplies, an ICIM2, and several application modules installed.



T13679

Front-Access Chassis

The illustration below shows a front-access chassis with two power supplies and the ICIM2 installed. The I/O connectors, RF connectors, and power inlets are located on the recessed bottom of the connector interface panel.



The front-access chassis configuration accommodates back-to-back installations, remote terminal (RT) installations, or other space limitations.

Chassis Front Panel Features

Part	Function
(Power) ON LED	Illuminates when power is applied to the chassis.
ALARM LED	Illuminates if there is a failure in the fan tray of the chassis.
LCI Port	Provides an RS-232 serial local craft interface for an installed ICIM2


Part	Function
Chassis ID Switch	<p>Located at the top right of the front panel, allows the operator to assign an identification number to every chassis for addressing via the ICIM2 or through CLI or SNMP commands. When using the ICIM2, this number is referred to as the Shelf number.</p> <p>Note: Each chassis connected to an individual ICIM2 must have a unique chassis ID number.</p>
ESD Jack	ESD (electrostatic discharge) jack, to be used prior to touching any modules.
ALARMS IN/ALARMS OUT	Allows for an ALARM OUT connection and an ALARM IN connection for each module slot in the chassis.
ICIM IN/ICIM OUT	Allows one ICIM2 to control and monitor modules in more than one chassis. The ICIM IN and ICIM OUT connectors are located on the connector interface panel of the chassis.
EM IN/EM OUT	An RS-485 bus that enables serial communication with the ICIM2 using Transmission Network Control System (TNCS) or another element management system.
Power Supply Inlets	Either AC or DC power supplies can be installed in the chassis when the proper power inlets are installed. Primary and (optional) secondary power supplies are inserted from the front of the chassis. The power supply connectors mate with the factory-installed power inlet connectors on the back plane bus. The inlets differ with the type of power supply (AC or DC) used.
Ground Studs	Grounding studs
RF Connectors	Up to four RF connectors per chassis slot may be mounted on the connector panel. The numbers 2 and 4-16 across the top of the panel identify the corresponding chassis slot number. The letters A-D near the right edge of the panel identify the possible connector positions for each slot, with "A" indicating the primary RF input/output port.

Chassis Back Plane Bus

The chassis back plane bus consists of the inside and the outside rear panel of the chassis through which power and communication signals are connected and distributed.

In addition to distributing electrical power and providing a common serial bus, the back plane bus also connects 4 RF ports (2 connectors are standard, 2 others are optional) to each of the 14 module connectors. The chassis is also available without RF ports.

The chassis back plane bus layout is shown below.



Prisma II Power Supplies

One or two Prisma II Power Supplies may be used. The power supplies are installed from the front of the chassis.

WARNING:
Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

Power supplies are available for operation from AC utility power or from a nominal -48 VDC power source.

WARNING:
Any external power supply must provide proper electrical components to power the chassis or risk serious equipment damage or personal injury. Do not use any external power supply to power this product unless it has been approved by Customer Service.

Back Plane Bus Connectors

Module connectors inside the chassis accommodate electrical power, digital signals, and analog signals. The connectors are self-guiding and allow a blind mate connection.

Prisma II Fan Tray

The Prisma II Fan Tray houses the fans that cool the chassis and its application modules. The fan tray also contains the sensor circuits that provide temperature and power supply status information to monitoring devices.

Fan Tray Configuration

The chassis ships with a rear-exhaust fan tray, which has its air exhaust ports on the back panel and a solid front panel.

A front-exhaust version of the fan tray is also available from the factory. Both configurations are accessed from the front of the chassis.

Fan Tray Installation

The fan tray is installed in the top of the chassis at the factory. It can be removed for maintenance or inspection by loosening the two screws located on either side of the front panel.


Important: Do not operate any chassis without a fan tray installed. For correct operation, proper cooling of the chassis must be maintained over the specified temperature range.



WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

Fan Tray Illustration (Top View)



Fan Tray Front Panel Features

Part	Function
Alarm Indicator	Red ON - Major Alarm active
	Red Blinking - Minor Alarm active
	Red OFF - No Alarm active
On Indicator	Green ON - Power applied
	Green OFF - Power not applied

Prisma II Power Supply

The Prisma II Power Supply converts incoming utility power (AC or DC, depending on model) to the DC operating voltages needed by the application modules.

The Prisma II Platform is designed to accommodate up to two power supplies. The two power supply slots, 1 and 3, are located on the left side of the chassis.

In normal operation, the two power supplies share the load. If one power supply should fail, the remaining power supply will take the full load.



WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

Electrical Input Voltages

- The -48 VDC power supply accepts DC input in the range of -40 to -72 V DC.
- The AC power supply accepts AC input in the range of 90 to 265 V AC.
- Both types convert input power to three DC output power buses at +24 V, +5 V, and -5 V.

Power Inlets

Two power inlets are installed on the chassis connector interface panel at the factory to match the electrical power source at the installation site.

There are three power inlet options available:

- -48 VDC
- AC - 3 prong - Class I
- AC - 2 prong - Class II (CE)


DC power inlets are provided with wire terminal blocks. These are inserted either in the power inlets themselves or in a bag with the chassis documentation.

Important: Use an equipotential bonding conductor to make a connection from the chassis ground stud to a reliable earthing mechanism at the installation site. For additional information, refer to EN 50083-1/A1:1977.


Note: The chassis ships with a fan tray installed, but without a power supply or any application modules inserted.

Power Supply Block Diagram

A block diagram of the Prisma II Power Supply module (AC or DC input) is shown below.



Power Supply Front Panel Illustrations



Power Supply Front Panel Features

Part	Function
Alarm Indicator	Red ON - Major Alarm active
	Red Blinking - Minor Alarm active
	Red OFF - No Alarm active
On Indicator	Green ON - Power applied
	Green Blinking - Communicating with ICIM2
	Green OFF - Power not applied

Prisma II ICIM2

The ICIM2 provides a front-panel user interface to the Prisma II application modules. It also provides the interface between the modules and command line interface (CLI) or Simple Network Management Protocol (SNMP) remote management systems.


The ICIM2 can control up to 64 application modules through a daisy-chain of up to 4 chassis. The daisy chain can include both Prisma II Platform chassis and Prisma II XD Platform chassis in any combination within the maximum number of modules and chassis.

Important:


- All chassis in a daisy-chain must be internally or externally powered and have a fan tray or fan assembly installed.
- All chassis in a daisy-chain must have a unique chassis identification (ID) number.
- To ensure communications with all application modules, only one ICIM2 or ICIM2-XD module may be installed per daisy-chain configuration.

ICIM2 Block Diagram

The ICIM2 is illustrated in the block diagram below.



ICIM2 Illustration (Front Panel)



ICIM2 Front Panel Features

Part	Function
LCD screen	Displays the ICIM2 menus, alarms, and status information.
12-key numeric keypad	Used to navigate the ICIM2 menus.
Ethernet connector	Directly connects the ICIM2 to an IP network. The ICIM2 Ethernet port is suitable for connection to intra-building wiring, non-exposed wiring or cabling only.
RS232 connector	Used to connect a co-located PC to the Prisma II system for CLI communication and setup.

Module Back Panel

Back Panel Connectors

Blind-mate connectors make it easy to install Prisma II modules. The push-on connector on the back of the module mates with the back plane bus connector inside the chassis. This 110-pin connector provides the following:

- RF signal input connection (transmitter module only)
- Electrical power input connection
- Alarm communications
- Status-monitoring communications
- Communications and control connections

Power and Communications Connector

The power and communications connector on the back of the module mates with a connector inside the chassis and supplies power from the chassis to the module. This 110-pin connector also routes alarm and status-monitoring information from the module to the chassis.

3

Hardware Installation

Introduction

This chapter describes site requirements, equipment, tools needed, and instructions for installation of the chassis and its application modules.

In This Chapter

■ Before You Begin.....	50
■ Site Requirements	51
■ Mounting the Chassis in a Rack.....	54
■ Connector Interface Panel.....	56
■ Connecting the ICIM2 to Additional Chassis	58
■ External Alarms Connections	62
■ Fan Tray	64
■ Chassis Fan Filter	65
■ Installing the Power Supplies	67
■ Installing the ICIM2.....	72
■ Installing the Module in the Chassis.....	74
■ Cleaning Optical Connectors	77
■ Connecting Optical Cables	81
■ Connecting RF Cables	82

Before You Begin

The chassis ships from the factory with a front-access connector interface panel mounted on the lower front of the chassis. This connector panel makes the I/O connectors, RF ports, and power inlets available at the front of the chassis.

Chassis with a rear-access connector interface panel are also available from the factory to meet a variety of configuration and space requirements.

Unpacking and Inspecting the Chassis

As you unpack the chassis, inspect it for shipping damage. If you find any damage, contact Customer Service. Refer to *Customer Support Information* (on page 321) for information on contacting Customer Service. Record the chassis serial number and date of installation for future reference.

Required Equipment and Tools

Before you begin, gather the equipment and tools listed in the following table.

You need . . .	To . . .
a medium-sized Phillips-head screwdriver	tighten the screws that secure the chassis to the equipment rack.
a mounting bracket. The chassis ships from the factory with gray mounting ears set for a 19-inch wide rack. If you are using a 23-inch wide rack, invert the ears to make the wider connection.	secure the chassis to the rack.

Site Requirements

This section describes environmental, physical, and wiring requirements to be met prior to equipment installation. Before you begin, make certain that your installation site meets the requirements discussed in this section.

Operating Environment

**CAUTION:**

Avoid damage to this product! Operating this product outside the specified operating temperature limits voids the warranty.

Follow these recommendations to maintain an acceptable operating temperature of the equipment.

- Keep cooling vents clear and free of obstructions.
- Provide ventilation as needed using air-deflecting baffles, forced-air ventilation, or air outlets above enclosures, either alone or in combination.
- Temperature at the air inlet must be between -40°C and 65°C (-40°F and 149°F). For chassis with one or more Prisma II Post-Amplifier FTTP modules installed, air inlet temperature must be between -5°C and 55°C (23°F and 131°F).

Note: Refer to the module data sheet and the product guide for product-specific temperature specifications.

Chassis Wiring and Fusing

Important: All chassis configurations require an external fuse or circuit breaker and #16 AWG wiring for both power and grounding. AC and DC current ratings differ, as further explained below.

AC Power Systems

Power for AC power supplies enters the chassis via a dedicated IEC power inlet for each power supply module.

Confirm that the IEC power cord or cords supplied with the chassis have the correct plug configuration for the country of use.

The voltage input range for AC systems is 100 to 240 VAC, single phase, 50-60 Hz.

AC input current is 14 A maximum. The chassis should be connected to a single outlet circuit with fuse or circuit breaker overcurrent protection rated 15 A minimum.

Important:

- Use only a grounded electrical outlet when connecting the unit to a power source. If you do not know whether the outlet is grounded, consult with a qualified electrician.
- Maintain reliable earth grounding of rack-mounted equipment. Pay particular attention to supply and ground connections made via power strips or any method other than direct connection to the branch circuit.

DC Power Systems

External -48 VDC operating power for each DC power supply module enters the chassis via a dedicated DC power inlet.


The voltage input range for DC power systems is -40 VDC to -72 VDC.

Use #16 AWG wire for DC field wiring. The #16 AWG wiring from the external -48 VDC supply is attached to a 3-pin terminal block which, in turn, plugs into the DC power inlet.

Insert the bare end of an insulated wire into each inlet on the terminal block and tighten the corresponding screw to capture the wire in the terminal block.

After terminating the cable, twist the conductors loosely (a full turn every few inches is sufficient).

As installed in the DC power connector, the top pin of the terminal block carries -48 VDC, the middle pin is the return, and the bottom pin is chassis ground.



Connect the chassis to a reliably grounded DC power source that is electrically isolated from the AC power source.

Important:

- Branch circuit overcurrent protection must be provided by a fuse or circuit breaker with a voltage rating of 72 VDC minimum and a current rating of 18 A maximum.
- The DC field wiring must include a readily accessible disconnect device that is suitably approved and rated.

Earth-Grounding Conditions

The chassis is designed to permit connection of the earthed conductor of the DC supply circuit to chassis ground. Before making this connection, confirm that all of the following conditions are met:

- The chassis is connected directly to the DC supply system earthing electrode conductor or to a bonding jumper from an earthing terminal bar or bus to which the DC supply system earthing electrode conductor is connected.
- The chassis is located in the same immediate area as other equipment connected between the earthed conductor of the same DC supply circuit and earthing conductor, such as in an adjacent cabinet. Also, the point of earthing of the DC system must not be earthed elsewhere.
- The DC power source is located within the same premises as the chassis.
- There are no switching or disconnecting devices in the earthed circuit conductor between the DC source and the point of connection of the earthing electrode conductor.

Rack Location Requirements

Follow these recommendations when installing the chassis in the rack.

- Locate the rack away from strong RF radiation and line transients that can damage the equipment.
- The front-access chassis provides access to all connectors from the front of the chassis. If you have a rear-access chassis, be sure to locate the rack in an area that permits access to connectors on the rear of the chassis.

Unused Slots

Important: All unused slots in the chassis need to be filled with a module blank.

- Module blanks, part number 716307, are available in packs of six.
- Power supply blanks, part number 716308, are available in packs of six.

Mounting the Chassis in a Rack

To Install the Chassis in a Rack




WARNING:

The Prisma II Chassis weighs approximately 30 lbs. empty and 60 lbs. fully loaded. To avoid personal injury and equipment damage, use safe handling and lifting practices in accordance with your organization's procedures.

Complete the following steps to mount the chassis in the rack.

- 1 If necessary, remove and reattach the chassis mounting brackets. The chassis ships from the factory with brackets installed for a 19-inch rack. When using a 23-inch rack, remove the mounting brackets and reattach them so that the wider bracket section protrudes from the chassis. Use a torque wrench to tighten the bracket mounting screws to 12 to 14 in-lbs (1.36 to 1.58 Nm).
- 2 Position the chassis in the rack with the fan tray installed, but otherwise empty.
- 3 Insert a mounting screw through each of at least four mounting holes on chassis front panel, and then into the rack.



- 4 Use a medium-sized Phillips-head screwdriver to tighten each mounting screw until it is tight.
- 5 Install additional cable and fiber management hardware as needed, in accordance with local practice.

Note: The instructions and illustration above describe a typical installation in a 19-inch rack. Installation details may vary depending on the mechanical configuration of the chassis mounting accessories.

Chassis Dimensions

Use the dimensions given below to determine clearance requirements for installing the chassis in the rack.


Configuration	Dimensions
Front access	17 in. W x 11 in. max. D x 13.97 in. H 43.2 cm W x 27.9 cm max. D x 35.5 cm H
Rear access	17 in. W x 19 in. max. D x 10.47 in. H 43.2 cm W x 48.3 cm max. D x 26.6 cm H

Connector Interface Panel

Connector Interface Panel Illustration


Electrical and interface connections are made at the connector interface panel.

The following illustration shows the connector interface panel for a front-access chassis with DC power connectors. (AC power connectors are also available.)



T13624

The following illustration shows the connector interface panel for a rear-access chassis with AC power connectors. (DC power connectors are also available.)



T11424

Note: The preceding illustrations show chassis configured with two RF connectors per application module slot. Other configuration options are available. Contact the factory for details.

Connecting the ICIM2 to Additional Chassis

This platform allows an ICIM2 or ICIM2-XD located in one chassis to monitor and control application modules located in several other chassis. To establish chassis-to-chassis ICIM2 communication, use the **ICIM IN** and **ICIM OUT** connectors located on the chassis interface panel.

Complete the following steps to establish chassis-to-chassis ICIM2 communication:

- 1 Connect a cable from **ICIM OUT** on the chassis containing the ICIM2 or ICIM2-XD to **ICIM IN** on the second chassis.
- 2 If required, connect a second cable from **ICIM OUT** on the second chassis to **ICIM IN** on the third chassis.
- 3 If required, connect a third cable from **ICIM OUT** on the third chassis to **ICIM IN** on the fourth chassis.


Note: An ICIM2 or ICIM2-XD can control up to 64 application modules in a chassis daisy-chain of no more than 4 chassis.

To Make ICIM IN and ICIM OUT Cable Connections

Complete the following steps to make chassis-to-chassis **ICIM IN** and **ICIM OUT** connections.

- 1 Connect the serial extension cable from the **ICIM OUT** of the chassis containing the ICIM2 or ICIM2-XD to the **ICIM IN** connector of the second chassis.
- 2 Change the chassis ID numbers as needed to give each chassis an appropriate unique ID number. See **To Change the Chassis ID Number** below for further details.
- 3 Connect a serial extension cable from the **ICIM OUT** of the second chassis to the **ICIM IN** of the third chassis.
- 4 Continue this daisy-chain connection until all chassis are connected.

- The ICIM OUT port of the last chassis in the daisy-chain must be terminated with an ICIM OUT terminator, part number 4013014, which ships with the ICIM2 or ICIM2-XD.



Note:

- All chassis connected in this daisy-chain must be powered and have a fan tray or fan assembly installed. For correct operation, proper cooling of the chassis must be maintained over the specified temperature range.
- A single chassis equipped with an ICIM2 or ICIM2-XD must also have its ICIM OUT port terminated with an ICIM OUT terminator, part number 4013014. The ICIM OUT terminator ships with the ICIM2 or ICIM2-XD.

To Change the Chassis ID Number

The number that appears in the chassis ID switch on the front panel of the chassis in which the ICIM2 or ICIM2-XD is installed indicates the value for the chassis ID. Valid chassis ID values are 00 to 99 inclusive. However, the use of 00 as the chassis ID value is not recommended in some circumstances, as the following caution explains.

CAUTION:

Setting the chassis ID to 00 is not recommended as it causes the entity MIB to violate RFC-2737 by creating an invalid object identifier. This may affect operation with some management systems that use the entity MIB. In particular, attempts to access the fans (in virtual slot 0) in chassis 00 will fail if made via serial TNCS (or ROSA-EM) or LCI.

Complete the following steps to change the chassis ID number.

- 1 Locate the chassis ID number at upper right on the front panel of each chassis. The chassis ID number is on a pushbutton scroll that can be used to set the number to a two-digit value from 01 to 99.



- 2 Use the pushbutton scroll as needed to set each chassis ID number to a unique value.

Note: The chassis numbering scheme used is discretionary, except that each interconnected chassis must have a unique ID number.

ICIM IN and ICIM OUT Connectors

Every chassis has a DB9 **ICIM IN** and a DB9 **ICIM OUT** connector for the purpose of chassis-to-chassis ICIM2 connections. **ICIM IN** is a female connector and **ICIM OUT** is a male connector.



ICIM IN and ICIM OUT Cables

The cable required for both **ICIM IN** and **ICIM OUT** connections is a shielded 9-wire serial extension cable, DB9 Female to DB9 Male. This cable can be purchased locally or from the factory. The chassis data sheet lists the part number for a 6-foot DB9 Female to DB9 Male serial extension cable. The connectors are a serial 9-pin D-shell (EIA 574/232).

Chassis-to-Chassis ICIM2 Activation

Once the chassis are interconnected, the shared ICIM2 or ICIM2-XD should be forced to search for all new modules, rather than be allowed to find them incrementally over the course of a polling cycle.

The recommended method for forcing a search for new modules is to reboot the ICIM2 or ICIM2-XD. This can be accomplished either by physically removing and reinserting the ICIM2 or by issuing a **reboot** command to the ICIM2 via the CLI interface.

To reboot the ICIM2 or ICIM2-XD via CLI, open a console or Telnet session and type the following commands at the CLI prompt.

```
CLI> icim
ICIM> reboot
```

The response will be:

```
The ICIM2 is about to reboot. This will end all current login and web sessions
Are you sure you want to proceed (Yes/No)> yes
```

```
SUCCESS!
ICIM>
```

```
-----
W A R N I N G
-----
```

```
Unauthorized or improper use of this system may result in
administrative disciplinary action and civil or criminal penalties.
By continuing to use this system you indicate your awareness of and
consent to these terms and conditions of use. LOG OFF IMMEDIATELY
if you do not agree to the conditions stated in this warning.
```

```
login:
```

Each of the additional modules will then be added to the ICIM2 or ICIM2-XD polling cycle.

Note: Use of the CLI **reboot** command is preferred over the **updateid** command in this case because a reboot will maintain synchronization with the element management system.

External Alarms Connections

This platform supports hardware redundancy through external alarm connections provided on each chassis. This feature can be used to set up a "master-slave" relationship between a primary set of modules in one chassis and a backup set of similar modules located in a separate chassis.

Master-Slave Operation

All Prisma II modules ship from the factory configured for independent operation, referred to as Single mode. For redundant operation, these modules can be reconfigured to operate in Master mode or Slave mode through the command line interface (CLI) or ICIM Web Interface.

The chassis allows for local hard-wired redundancy by using the ALARM IN and ALARM OUT connectors on the connector interface panel. With these connectors, a Master-Slave pair of modules can be configured so that if the Master fails, the Slave takes over.

ALARM IN and OUT Connections

The chassis provides two sets of connections for external alarms to and from each module slot. These alarm connections are provided via a pair of connectors labeled ALARM IN and ALARM OUT on the chassis back panel.


When a critical alarm occurs in a master module, the master turns off and the slave (redundant module) is enabled. To make this happen, the pin representing the master module slot in the ALARM OUT connector must be wired to the pin representing the slave module slot in the ALARM IN connector.

Master and slave modules can be installed either in the same chassis or in different chassis, as long as the modules are correctly configured and interconnected.


Note:

- After setting up the modules, it is important to ensure that they are not moved to different slots. Otherwise, the ALARM IN and OUT connections will have to be rearranged.
- A module cannot act as both a master and a slave. Accordingly, any module configured as a master ignores its own ALARM IN contacts.
- To verify proper wiring and redundant configuration, unplug the master device and confirm that the slave module turns on as a result.

Master-Slave Illustration



ALARMS IN Connector




ALARMS OUT Connector



Fan Tray

To Remove the Fan Tray

The fan tray is installed in the top of the Prisma II chassis at the factory. It can be removed for maintenance or inspection by loosening the two screws located on either side of the front panel.




Important: Do not operate any chassis without a fan tray installed. For correct operation, proper cooling of the chassis must be maintained over the specified temperature range.

WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

Chassis Fan Filter

A chassis fan filter is located on the floor of the chassis behind the fiber routing tray (rear access chassis) or guide bracket (front access chassis), if either one is installed.



**Fan filter located under chassis
behind cable management tray**

T13625

It is recommended that filters be replaced yearly. The service interval can be adjusted based on the equipment operating environment.


To Remove Chassis Fan Filter

Complete the following steps to remove the chassis fan filter.

- 1 From the front of the chassis, locate the fan filter behind the fiber guide bracket (if installed).

Chapter 3 Hardware Installation

- 2 Locate the two pivot clips holding the front edge of the filter in place. Turn the clips approximately 90 degrees. The filter will drop down.



T12744

- 3 With the filter removed, install a clean filter, noting the air movement direction (arrow) on the filter. Install the filter with the arrow pointing up.
- 4 Locate the two pins that secure the rear of the filter. Install the new filter above the pins, and then push upward.
- 5 Press the filter upward.
- 6 Rotate the two pivot clips to secure the front edge of the filter.

Installing the Power Supplies

Space Requirements


Each Prisma II Power Supply is a double-width module. Two power supply slots (slot 1 and slot 3) are located on the left side of the chassis.

Electrical Power Connections

AC Power

The AC power supplies receive electrical input power through Class I AC power inlets. All AC power inlets are installed at the factory.

The following illustration shows the location of the AC power inlets on the rear-access chassis.



DC Power


The DC power supplies receive -48 VDC electrical input power through DC power inlets installed in the chassis. All DC power inlets are installed at the factory.

Note: The DC return terminal of the power supplies is isolated, i.e., not connected to the chassis framework.

Important: Tie the system to earth ground via the ground stud.

One power inlet is installed for each power supply ordered. A wire terminal block is provided for each power outlet installed. Supplied wire terminal blocks can be found either in the power inlet itself or in the same bag that contains the chassis documentation.

The following illustration shows the location of the DC power inlets for the front-access chassis.



To Install the AC Power Cord

There is a separate and independent AC inlet for each power supply slot in the chassis. Therefore, for operation of dual AC power supplies, two AC power cords must be installed.


Complete the following steps to install the AC power cord(s).

- 1 Locate the AC power inlet(s) on the chassis.
- 2 Plug the female end of the power cable that was shipped with the power supply into the AC power inlet.
- 3 Attach the male end of the power cord(s) to the electrical source(s).

To Install the DC Power Cord

Complete the following steps to install the DC power cord for each DC power supply.

- 1 Locate the DC wire terminal block(s) either pre-installed in each DC power inlet or in a bag with the chassis documentation.
- 2 Remove the terminal block and note the locations of the top, middle, and bottom terminals as shown below.



- 3 Attach a #12 AWG power cable from the fuse panel to the DC wire terminal block that was shipped with the chassis. Attach the conductors to the terminal block as follows:
 - Top terminal: -48 VDC conductor
 - Middle terminal: Return conductor
 - Bottom terminal: Not used

Note: The DC return terminal of the power supplies is isolated, i.e., not connected to the chassis framework.


Important: Tie the system to earth ground via the ground stud.

To Install the Power Supply in the Chassis

This procedure assumes that the power inlet has been installed, the appropriate power cord has been connected, and power has been applied to the chassis.

- 1 Facing the front of the chassis, position the bottom of the power supply on the module guide of slot 1 (extreme left) of the chassis.

- 2 Align the top and bottom ridges on the power supply with the module guide slots in the chassis. You should be able to see the fiber guides at the bottom of the chassis and the module guide slots as shown below.



Module Guide Slots

T11423

- 3 Locate the two ejector levers on the left of the power supply module. Swing the ejectors out so they are perpendicular to the module front panel.
- 4 Gently slide the power supply into the chassis until its power and communications connections join connectors on the back plane bus. *Do not force the module into the chassis.* If properly aligned, it should slide in with minimal force.
- 5 Slowly press the module ejector levers toward the chassis so that their jaws engage with the mounting flange in the chassis. Confirm that the ejectors pull the power supply toward the mounting flange so that its back-panel connectors mate with the connectors at the rear of the chassis. Continue pressing the ejectors until they both lie parallel to the module front panel.
- 6 If you are installing a second power supply into slot 3, repeat steps 1 through 5, then continue with step 7.
- 7 Verify that the green LED illuminates, indicating that the power supply is now operating.
- 8 Confirm that the fan tray is operational. The fans should be audible once the power supply is operating.
- 9 Hand-tighten the screw at the top of the power supply to secure it in the chassis. Use a 3/8-in. flat-blade screwdriver to secure. *Do not over-tighten.*

Power Supply Cooling Fans

Each power supply module has internal fans that provide airflow for cooling.

To Monitor the Power Supply

Prisma II Power Supplies may be monitored locally via the ICIM2 front panel or remotely via CLI or SNMP commands. Power supply status and alarm information is routed, monitored, and addressed through the Prisma II Fan Tray.

Use any of the following methods to monitor power supply operational and alarm status.

- LEDs at the top of each power supply module indicate its operational and alarm status. The ON LED monitors electrical power into the module, and the ALARM LED monitors alarms in module temperature or module failure.
- The front panel display (LCD) on the ICIM2 module may be set by the user to display power supply status information which is routed to the ICIM2 through the fan tray.
- Command Line Interface (CLI) commands may be used to obtain power supply or other module status information either through an attached personal computer or over a network.
- Simple Network Management Protocol (SNMP) commands also may be used to obtain power supply or other module status information remotely.

For information on power supply monitoring using CLI commands or the ICIM Web Interface, refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477. For information on power supply monitoring using SNMP commands, refer to *SNMP Management* (on page 179).


Installing the ICIM2

Note: To ensure communications with all application modules, install the ICIM2 in slot 15, and install only one ICIM2 or ICIM2-XD per daisy-chain configuration.

To Install the ICIM2

Complete the following steps to install the ICIM2 in the chassis.

- 1 Facing the front of the chassis, position the bottom of the ICIM2 on the slide of slot 15 (extreme right) of the chassis.
- 2 Align the top and bottom ridges on the ICIM2 with the module guide slots in the chassis.
- 3 Locate the two ejector levers on the left of the ICIM2. Swing the ejectors out so they are perpendicular to the module front panel.



- 4 Gently slide the ICIM2 into the chassis until its power and communications connections join connectors on the back plane bus. *Do not force the ICIM2 into the chassis.* If properly aligned, it should slide in with minimal force.
- 5 Slowly press the ICIM2 ejector levers toward the chassis so that their jaws engage with the mounting flange in the chassis. Confirm that the ejectors pull the ICIM2 toward the mounting flange so that its back-panel connectors mate with the connectors at the rear of the chassis. Continue pressing the ejectors until they both lie parallel to the module front panel.

- 6 Hand-tighten the screw at the top of the ICIM2 to secure it in the chassis. Use a 3/8-in. flat-blade screwdriver to secure. *Do not over-tighten.*

Installing the Module in the Chassis

All Prisma II application modules are hot-swappable and plug-and-play. This means that they can be installed or replaced without removing power from the chassis, and without affecting the operation of other modules installed in the chassis.

Important:

- The following procedure assumes that the chassis is mounted in a rack. This procedure applies to both front access and rear access chassis styles.
- When a module (power supply or application module) is inserted into the chassis, one or more alarms may be generated momentarily while the module powers up. This will be briefly indicated on the module LED and may also generate an alarm in the Event Log. This is normal and does not indicate a module problem.

To Install the Module



WARNING:

Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.




CAUTION:

Before removing a transmitter module from a Prisma II Chassis under power: 1) Disable the transmitter output by setting TxEnable=0 (Disable) from CLI or your network management system; and 2) Detach the fiber optic jumper from the transmitter output port. Failure to perform both steps may result in damage to downstream amplifier modules due to higher than normal transmitter output.


Complete the following steps to install the module in the chassis.

- 1 Locate the fiber guides at the bottom of the chassis and the module guide slots inside the chassis as shown in the following illustration.



- 2 Align the top and bottom on the module with the module guide slots on the chassis.
- 3 Locate the two ejector levers on the left of the module. Swing the ejectors out so they are perpendicular to the module front panel.

- 4 Gently slide the module into the chassis until its power and communications connections join connectors on the back plane bus. *Do not force the module into the chassis.* If properly aligned, it should slide in with minimal force.



T13611

- 5 Slowly press the module ejector levers toward the chassis so that their jaws engage with the mounting flange in the chassis. Confirm that the ejectors pull the module toward the mounting flange so that its back-panel connectors mate with the connectors at the rear of the chassis. Continue pressing the ejectors until they both lie parallel to the module front panel.
- 6 Hand-tighten the screw at the top of the module to secure it in the chassis. Use a 3/8-in. flat-blade screwdriver to secure. *Do not over-tighten.*
- 7 Fill any unused chassis slots with module blanks to guarantee proper cooling air flow.

Cleaning Optical Connectors

Cleaning fiber-optic connectors can help prevent interconnect problems and aid system performance. When optical connectors are disconnected or reconnected, the fiber surface can become dirty or scratched. If not addressed, this dirt or damage may lead to interconnect problems and reduced system performance.

Fiber-optic connectors should be inspected prior to mating and cleaned as needed to remove all dust and contaminants without leaving any residue. Connectors should be visually inspected after cleaning to confirm that they are clean and undamaged.

Note: The optimum procedure for cleaning depends on the connector type. The information given below is for use in the absence of more specific instructions tailored for your location. Always follow local procedures when available.

Recommended Equipment

The following equipment is recommended to clean the ends of fiber-optic connectors.

- CLETOP or OPTIPOP ferrule cleaner (CLETOP Type A for SC, Type B for LC)
- Compressed air (also called “canned air”)
- Lint-free wipes moistened with optical-grade (99%) isopropyl alcohol
- Bulkhead swabs for LC or SC type connectors (choose appropriate type)
- Optical connector scope

Tips for Optimal Fiber-Optic Connector Performance

Follow these guidelines to ensure optimal connector performance.

- Do not connect or disconnect optical connectors while optical power is present.
- Always use compressed air before cleaning the fiber-optic connectors.
- Always use end caps on connectors when they are not in use.
- Always use compressed air to clean the end caps.
- If you have any degraded signal problems, clean the fiber-optic connector.
- Advance a clean portion of the ferrule cleaner reel for each cleaning.
- Turn off optical power before making or breaking optical connections in order to avoid microscopic damage to fiber mating surfaces.

To Clean Optical Connectors

Note: The best procedure for cleaning depends on the connector type. Use your company-approved procedure, if there is one. The procedure given below is for use only in the absence of approved company-specific instructions.



WARNING:

- **Avoid personal injury! Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.**
 - **Avoid personal injury! The laser light source on this equipment emits invisible laser radiation. Avoid direct exposure to the laser light source.**
 - **Avoid personal injury! Viewing the laser output with optical instruments (such as eye loupes, magnifiers, or microscopes) may pose an eye hazard.**
- Connect or disconnect fiber *only* when equipment is OFF or in Service mode.
 - Do not apply power to this equipment if the fiber is unmated or unterminated.
 - Do not look into an unmated fiber or at any mirror-like surface that could reflect light that is emitted from an unterminated fiber.
 - Do not view an activated fiber with optical instruments such as eye loupes, magnifiers, or microscopes.
 - Use safety-approved optical fiber cable to maintain compliance with applicable laser safety requirements.

Fiber Optic Connector Cleaning Instructions

Connector cleanliness is crucially important for optimum results in fiber-optic communications links. Even the smallest amount of foreign material can make it impossible to obtain the expected insertion and return losses. This can reduce the range of the equipment, shorten its expected service life, and possibly prevent the link from initializing at all.

New equipment is supplied with clean optical connectors and bulkheads. All optical connectors (bulkheads and jumpers) should be inspected using an appropriate optical scope prior to connector mating. If endface contamination is observed, the connector should be cleaned and then re-inspected to verify cleaning.

Connectors and Bulkheads

Most fiber-optic connectors are of the physical contact (PC) type. PC type connectors are designed to touch their mating connectors, thereby preventing air gaps which cause reflections. For optimum performance, *all* dirt must be removed.

Bulkheads can also become dirty enough to affect performance, either from airborne dust or from contamination introduced by connectors.

**WARNING:**

Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.

Important! Read the above warning before performing cleaning procedures.

Cleaning Connectors

Important!

- All external jumper connectors must be cleaned before inserting them into the optical module.
- Before you begin, remove optical power from the module or ensure that optical power has been removed.

Complete the following steps to clean fiber-optic connectors that will be connected to the optical module.

- 1 Inspect the connector through an optical connector scope. If the connector is damaged, e.g., scratched, burned, etc., replace the jumper.
- 2 If the connector is dirty but otherwise undamaged, clean the connector as follows:
 - a Make several swipes across the face of the connector with the appropriate ferrule cleaner. This will remove dust and some films.
 - b Listen for a slight "squeak" typically generated during this process, indicating a clean connector.
 - c Inspect the connector again through the scope to confirm that it is clean.
- 3 If a second inspection indicates that further cleaning is needed:
 - a Use 99% isopropyl alcohol and a lint-free wipe to clean the connector.
 - b Use the appropriate ferrule cleaner again to remove any film left over from the alcohol.
 - c Inspect the connector again through the scope and confirm that it is clean.
- 4 If necessary, repeat steps 3a-3c until the connector is clean.

Cleaning Bulkheads

Important!

- Do not detach the bulkhead from the module front panel for cleaning under any circumstances. There is little or no slack in the fiber attached to the bulkhead, and any attempt to remove the bulkhead will risk damage to the fiber.
- It is generally more difficult to clean bulkhead connectors and verify their condition due to the inaccessibility of the fiber end face. For this reason, you should *only* attempt to clean a bulkhead connector when a dirty connector is indicated.

Complete the following steps to clean the bulkhead.



WARNING:

- **Avoid personal injury! Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.**
- **Avoid personal injury! The laser light source on this equipment emits invisible laser radiation. Avoid direct exposure to the laser light source.**
- **Avoid personal injury! Viewing the laser output with optical instruments (such as eye loupes, magnifiers, or microscopes) may pose an eye hazard.**

- 1 Insert a dry bulkhead swab into the bulkhead and rotate the swab several times.
- 2 Remove the swab and discard.

Important! Swabs may be used only once.

- 3 Check the bulkhead optical surface with a fiber connector scope to confirm that it is clean. If further cleaning is needed:
 - a Moisten a new bulkhead swab using a lint-free wipe moistened with optical-grade (99%) isopropyl alcohol.
 - b With the connector removed, fully insert the bulkhead swab into the bulkhead and rotate the swab several times.
 - c Remove the swab and discard. Swabs may be used only once.
 - d Repeat steps 1 and 2 with a new dry bulkhead swab to remove any excess alcohol or residue.
 - e Check with a fiber connector scope again to confirm that there is no dirt or alcohol residue on the optical surface.
 - f If any alcohol residue remains, repeat steps 3d-3f.
- 4 Mate all connectors to bulkheads and proceed to **Verifying Equipment Operation** below.
- 5 It is also recommended that all connectors be visually inspected after cleaning to verify the connector is clean and undamaged.

Verifying Equipment Operation

Perform circuit turn-up. If the equipment does not come up, i.e., fails verification or indicates a reflection problem, clean the connectors and bulkheads again.

For Further Assistance

If you have any questions or concerns about cleaning fiber-optic connectors, contact Customer Service using the contact information provided in *Customer Support Information* (on page 321).

Connecting Optical Cables

Important:

- Make all connections with the optical power off. This will reduce the risk of damage to fiber-optic connectors.
- Clean the optical connectors as needed before making optical connections. See *Cleaning Optical Connectors* (on page 315) for instructions.

Note: Observe laser safety precautions. Refer to *Laser Safety* (on page xxv) for further information.

To Connect Optical Cables



CAUTION:

High power density exists on fiber when optical power is present. To avoid microscopic damage to fiber mating surfaces, turn off optical power or reduce power below 15 dBm before making or breaking optical connections.

Complete the following steps for each optical cable connection to be made and on every module to be installed.

- 1 Clean the end of the fiber to be connected as described in *Cleaning Optical Connectors* (on page 315).
- 2 Connect the optical cable to the module connector.
- 3 Route the cable to the appropriate destination.
- 4 Clean the remaining cable end, and then connect the cable to the mating module connector.

Note: Remember to observe minimum bend radius and other accepted handling practices when working with fiber-optic cables.

- 5 After cable installation is complete, return the module control settings to their original states.

Connecting RF Cables

The chassis connector interface panel can have one or more RF connectors, labeled A through D, for each application module slot. Each set of RF connectors is numbered 2-16 to show its corresponding slot number.

Note: The application module installed in each chassis slot determines whether and how the two RF channels are used. See the appropriate application module documentation for further information.

To Connect RF Cables

Complete the following steps for each RF cable connection to be made.

- 1 Connect the RF cable to the appropriate connector on the connector interface panel.
- 2 Route the cable to the appropriate destination.

4

Equipment Configuration

Introduction

This chapter provides instructions for configuring the chassis and application modules for remote management.

There are several different ways to configure the equipment. This chapter presents one approach for configuration.

Refer to *Prisma II Permitted CLI Commands* (on page 323) for a complete list of CLI commands.

For further information on configuration using the CLI or ICIM Web Interface, see the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477.

In This Chapter

■ HyperTerminal Session Setup.....	84
■ CLI Parameters.....	87
■ Telnet Session	90
■ SNMP Parameters.....	92
■ Using the ICIM Web Interface	93

HyperTerminal Session Setup

HyperTerminal is a terminal emulation program that is included with the Microsoft Windows operating system.

The following equipment is required to perform this procedure.

- A personal computer (preferably a laptop computer for a local connection)
- A terminal emulation program such as Windows HyperTerminal or a remote terminal emulation program such as Telnet
- A DB-9 to DB-9 straight-through serial cable

You can use HyperTerminal to initiate a direct-connect communications session with an ICIM2 through its front-panel serial port.


To Set Up a HyperTerminal Serial Port Session

Complete the following steps to set up the HyperTerminal emulation program.

- 1 Connect one end of a DB-9 to DB-9 straight-through serial cable to an available COM port on the personal computer, and the other end to the ICIM2 or ICIM2-XD front-panel serial port.
- 2 Open a HyperTerminal session on your laptop (or desktop) PC that you will use to connect to the ICIM2 or ICIM2-XD. The HyperTerminal program is typically found at:

`Start\All Programs\Accessories\Communication\Hyperterminal`

The new Connection Description dialog box appears.




- 3 Type in a name for the connection, select an icon of your choice, and click **OK**. The Connect To dialog box appears.



- 4 In the Connect Using field, click the drop-down arrow and select the serial port that you will use for the connection, and then click **OK**. The COM Properties dialog box appears.


Note: For most applications, the serial port is COM1 or COM2.

- 5 Set the following port setting in the COM Properties dialog box.



Chapter 4 Equipment Configuration

- 6 Click **OK**. The HyperTerminal main program window appears.



- 7 On the File menu, click **Save** to save the settings.

CLI Parameters

Additional parameters may be set as needed from the command line interface (CLI) for each application module installed.

Refer to *Prisma II Permitted CLI Commands* (on page 323) and the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477 for information and additional instructions on available commands and using the CLI.

Following are examples of parameters available through the CLI.

Login

- 1 Log in using the default username **Administrat0r** and the default password **AdminPassw0rd**. Note the 0 (zero) character in each string.

```
login: Administrat0r
Password: AdminPassw0rd
```

Successful login will return the following prompt:

```
login: Administrat0r
Password:
User Administrat0r logged in successfully on 11/13/06 at 15:25:35
Previous successful login was on 11/13/06 at 15:22:16
There were no failed attempts to login with this user id previously
CLI>
```

- 2 Enter the ICIM submenu by typing **icim** at the CLI> prompt.

```
CLI> icim
```

Successful entry into the ICIM menu tree will return the following prompt:

```
ICIM>
```

- 3 Configure the shelf (chassis) IP address, subnet mask, gateway, and clock using the following commands:

```
set ip xxx.xxx.xxx.xxx
set subnet xxx.xxx.xxx.xxx
set gateway xxx.xxx.xxx.xxx
set clock "month/day/year hour:minute:second"
```

Note:

- Be sure to include the quote symbols, e.g., `set clock "3/15/2006 13:09:51"`.
- Clock time is in the 24-hour format.

- 4 To enable these changes, reboot the ICIM2 or ICIM2-XD as follows:

```
ICIM> reboot
```

- 5 After the ICIM2 or ICIM2-XD reboots, repeat the login steps described above to return to the ICIM command prompt. Then use the show command to verify each of the above changes, as follows:

```
show ip
show subnet
show gateway
show clock
```

- 6 Type **logout**, and then press **Enter** to exit the session.
- 7 Remove the serial cable. It is no longer required.

Important:

- For Telnet operation, the computer you are using must have a network connection through which it can reach the ICIM2 or ICIM2-XD at its IP address.
- No more than four Telnet sessions are allowed at one time.

**CAUTION:**

Always use the Logout command to close a serial port or Telnet CLI session. Closing a serial port session without issuing the Logout command leaves the session open for a possible future connection. This may allow unauthorized access by a new user if the previous user had a higher authorization privilege level.

To Set the Clock

From the CLI command prompt, switch to ICIM command mode and set the date and time for the ICIM2, as shown below.

```
CLI> icim
ICIM> set clock "10/10/2005 15:50:00"
MM-DD-YYYY  HH:mm:ss
10-10-2005  15:50:00
Mon, 10 Oct 2005 15:50:00 EST
SUCCESS!
```

To Set Additional Users for ICIM2 or ICIM2-XD Access

Refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477 for CLI and ICIM Web Interface login settings information.

Note: It is strongly recommended that a new administrator login be created and that the default administrator login be removed.

The table below lists the ICIM mode CLI commands for setting user login parameters.

Commands	Description
ICIM > show user	Shows all users
ICIM > user change password [user name]	Changes user password
ICIM > user add [user name] [access level] enable	Adds a user
ICIM > user delete [user name]	Deletes a user

Note: User names and passwords must be 6 to 14 characters long, and must include at least 1 number.

To Set and Verify SNMP Community Strings

From the CLI command prompt, switch to ICIM command mode and define SNMP Read, Write, and Trap Community strings, as shown below.

```
CLI> icim

ICIM> set commwrite "myCommWriteString"
NOTE: This change will not fully take effect until the ICIM is restarted.
Until that time, some operations will not perform as expected.

SUCCESS!

ICIM> set commread "myCommReadString"
NOTE: This change will not fully take effect until the ICIM is restarted.
Until that time, some operations will not perform as expected.

SUCCESS!

ICIM> set commtrap "myCommTrapString"
NOTE: This change will not fully take effect until the ICIM is restarted.
Until that time, some operations will not perform as expected.

SUCCESS!
```

You can then verify the community string settings, as follows.

```
ICIM> info commread commwrite commtrap

COMMREAD          COMMWRITE          COMMTRAP
myCommReadString  myCommWriteString  myCommTrapString

SUCCESS!

ICIM>
```

Note:

- It is strongly recommended that the ICIM2 or ICIM2-XD be restarted after changing any of the community strings. Otherwise, some operations will continue to work normally, while others will appear to fail.
- It is strongly recommended that new SNMP community strings be created and the default SNMP community strings be removed. Default SNMP community string values are listed below.

SNMP Community String	Default Value
Read Community	public
Write Community	private
Trap Community	SNMP_traps

Telnet Session

Telnet is a remote terminal emulation program included with the Microsoft Windows operating system. In the absence of a network management system, you can use Telnet to initiate a remote communications session with an ICIM2 or ICIM2-XD and configure the equipment in the domain using CLI commands.

Important:

- For Telnet operation, the computer you are using must have a network connection through which it can reach the ICIM2 or ICIM2-XD at its IP address.
- No more than four Telnet sessions are allowed at one time.



CAUTION:

Always use the Logout command to close a serial port or Telnet CLI session. Closing a serial port session without issuing the Logout command leaves the session open for a possible future connection. This may allow unauthorized access by a new user if the previous user had a higher authorization privilege level.

To Set Up a Telnet CLI Session

Complete the following steps to initiate a CLI session with the ICIM2 using Telnet.

Important: The ICIM2 must have an IP address assigned before performing this procedure.

- 1 Open a DOS window on the PC that you will use to connect to the ICIM2.
- 2 At the DOS command prompt, type:

```
telnet <IP address>
```

where <IP address> is the IP address of the ICIM2. The session starts and the Telnet login: prompt appears.

```

-----
W A R N I N G
-----
Unauthorized or improper use of this system may result in
administrative disciplinary action and civil or criminal penalties.
By continuing to use this system you indicate your awareness of and
consent to these terms and conditions of use. LOG OFF IMMEDIATELY
if you do not agree to the conditions stated in this warning.

login: Administrat0r
Password:

User Administrat0r logged in successfully on 12/05/06 at 09:08:13
Previous successful login was on 12/05/06 at 08:51:47
There were no failed attempts to login with this user id previously

CLI> _

```

- 3 At the login: prompt, type **Administrat0r** (note the zero character in the string), and then press **Enter**.

- 4 At the Password: prompt, type **AdminPassw0rd** (note the zero character in the string), and then press **Enter**. The CLI> command prompt appears.

SNMP Parameters

Trap settings and other parameters can be set in one of several ways:

- Using Simple Network Management Protocol (SNMP) commands. Refer to *SNMP Management* (on page 179) for details on accessing the ICIM MIB tables.
- Using the Command Line Interface (CLI) Traps Enable command. Refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477 for details on using the Traps Enable command.
- Using the ICIM Web Interface, which requires no knowledge of SNMP or CLI. For further information, refer to the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477.

Once this is accomplished, changes can be made to the ICIM Trap tables, of which there are 10 entries (one for each destination IP address).

Following are the objects in the p2TrapRecvEntry table that should be set.

MIB Object	Value
p2TrapRecvEnable	1-disabled; 2-enabled
p2TrapRecvAddr	IP address of trap receiver
p2TrapRecvTelcoAlarm	1-disabled; 2-enabled

Using the ICIM Web Interface

You can also use the ICIM Web Interface to configure equipment in the domain of the ICIM2 or ICIM2-XD. The ICIM Web Interface is menu-based and requires no knowledge of CLI or SNMP commands.

This section describes the steps for logging in and out of the Web Interface. For additional details, see the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477.

Login Settings

To use the Web Interface, you must enter a valid user name and password. The default user name and password are given below.

- User name: **Administrat0r**
- Password: **AdminPassw0rd**

Note:

- Both the default user name and the default password have a zero (0) in place of the expected "o" character.
- For security reasons, it is recommended that the default user name be changed immediately. For additional information, see **User Management** in the appropriate system guide.

To Change Login Defaults

Complete the following steps to change the default user name and password.

- 1 Add a new user having Admin Level privileges.
- 2 Log out of the default user account, and then log back in using the new Admin level account.
- 3 Locate the original default user name in the list of users. Click the **Delete** button beside the default user name to delete it from the list.

Important: Note your new login defaults for future reference. Failure to remember your new user ID and password may result in being locked out of the ICIM2 or ICIM2-XD permanently. You cannot revert to the default user name and password once they are deleted.


To Log In

Complete the following steps to log into the ICIM2 or ICIM2-XD.

- 1 Confirm that your web browser is set up as described in the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477.

Chapter 4 Equipment Configuration


- 2 Obtain the actual IP address of the Web Interface Login page from your system administrator.
- 3 Open your web browser and type the IP address of the ICIM2 (e.g., **172.8.50.151**) in the browser address bar.
- 4 Press the **Enter** key or click the **Go** button. The ICIM Login page appears as shown below.



ICIM Login - 1 / 17
(IP: 172.18.50.151)

User	<input type="text"/>
Password	<input type="password"/>

- 5 Type your **User** name and **Password** in the fields provided, and then click the **Login** button. The ICIM Welcome page appears as shown below.



ICIM Welcome - 1 / 17
(IP: 172.18.50.151)


User	AdministratOr
Last Login	12/04/2007 21:37:39
Failed Logins	0

- 6 Use one of the following navigation methods as appropriate:
 - Click **Next** to go to the System View page. Or, wait 10 seconds to be taken to System View automatically.
 - Use the menu at the left of the screen to go directly to System View or to choose another page of interest.

To Log Out

Complete the following steps to log out of the Web Interface.

- 1 Click **Logout** in the main menu. The Web Interface Logout page appears as shown below.



You are now logged out

Please close your browser for security

[Login to ICIM](#)

- 2 Close your browser window as a security precaution.



CAUTION:

Before closing the browser or tab in which the Web Interface session is running, be sure to log out of the Web Interface using the Logout link at the bottom left of the navigation pane.

If you close the browser or tab before logging out, the session will hang open for the duration of a timeout interval. This may prevent access to the ICIM2 through either the CLI or the Web Interface by you or other users. This may also create a breach of security by enabling unauthorized users to access the Web Interface at the previous user authorization level by opening a new browser tab.

5

ICIM2 Operation

Introduction


This chapter describes the ICIM2 and ICIM2-XD software interface for platform configuration, monitoring, and control. It also describes the ICIM2 LCD and keypad front-panel interface for performing these functions.

For detailed information on system parameters, see *Module Parameter Descriptions* (on page 347).

In This Chapter

- Platform Configuration..... 98
- Operating the ICIM2 99
- Configuring for Remote Network Access 104
- Using ICIM2 with the Fan Tray 107
- Using ICIM2 with Power Supply 1 112
- Using ICIM2 with Power Supply 3 117


Platform Configuration



Operating the ICIM2

Once the ICIM2 module is installed, it runs without the aid of an operator. Unless alarms are generated or your system configuration changes, you should not need to make any adjustments to the module beyond the initial setup.

ICIM2 Illustration (Front Panel)



ICIM2 Front Panel Features


Part	Function
LCD screen	Displays the ICIM2 menus, alarms, and status information.
12-key numeric keypad	Used to navigate the ICIM2 menus.
Ethernet connector	Directly connects the ICIM2 to an IP network. The ICIM2 Ethernet port is suitable for connection to intra-building wiring, non-exposed wiring or cabling only.

Part	Function
RS232 connector	Used to connect a PC to the Prisma II Enhanced system for CLI communication and setup.

ICIM2 LCD

The ICIM2 LCD gives the operator a visual link to the ICIM2 firmware. When the ICIM2 is installed and powered up, the MAIN menu appears on the LCD.

The following illustration shows the MAIN menu.








TP011




ICIM2 Keypad

The ICIM2 keypad has 12 keys for monitoring parameters. The table below lists each key and briefly describes its function.

Button	Function
STAT	Displays status information for the selected module.
CFG	Displays configuration information for the selected module.
ALRM	Displays all of the parameters in alarm for a selected module.
▲	Moves the menu selection area up.
▼	Moves the menu selection area down.
SEL	Selects the highlighted parameter.
ICIM	Displays ICIM2 module information such as firmware version and serial number.

Button	Function
	Shifts function of a keypad button to the function or number label just above that button.
	Decreases numerical readings of selected configuration parameters.
	Increases numerical readings of selected configuration parameters.
	Enters input data (if valid).
	Exits the current menu and displays the MAIN menu.


To Adjust the ICIM2 LCD Contrast

To access the ICIM2 LCD contrast control from the MAIN menu, press the  key. Use the  key to increase or the  key to decrease ICIM2 display contrast.

Note: Do not hold down the ICIM key while adjusting the LCD contrast.

Prisma II MAIN Menu and ICIM Menu Structure

Pressing the **MAIN** key initiates the MAIN menu. Pressing the **ICIM** key initiates the ICIM menu. The MAIN and ICIM menu structures are shown below.




TP100

MAIN Menu

A few seconds after power-up, the MAIN menu (shown below) appears. Press the **SEL** key to select the specific option.

Display	Description
Offline	Indicates communication status between the ICIM2 and TNCS.
Modules	Indicates the number of modules in the ICIM2 domain.
Alarms	Displays the number of modules that are in alarm. Selecting this option allows scrolling through all modules in alarm condition.
Scroll	Allows scrolling through all modules in the ICIM2 domain.
Module Shelf Slot	Allows selection of a specific module in the ICIM2 domain.




TP011

ICIM2 Menu

To display the ICIM2 menu, press the **ICIM** key. The ICIM menu (shown below) appears. Press the **SEL** key to select the specific option.

Display	Description
Shelf Slot	Displays the location of the ICIM2. Shelf = Chassis ID number on the front of the chassis. Slot = Slot number within the chassis.
Mfg Data	Displays manufacturing data about the ICIM2.
IP Setup	Press the SEL key to view the IP Address, IP Subnet, and Gateway IP of the ICIM2. These values are read-only via the ICIM2 front panel, but can be changed via the CLI interface.



TP099

Configuring for Remote Network Access

The ICIM2 has an IP Setup menu that lets you enter an IP address, IP subnet, and gateway IP to configure the ICIM2 for remote monitoring and control by an SNMP network management system (NMS).

This section explains the use of the IP Setup menu in configuring the ICIM2 for SNMP. For additional information on SNMP, see *SNMP Management* (on page 179).




Preliminary Steps for SNMP

Take the following initial steps when implementing SNMP.

- Confirm that the NMS is installed behind a firewall to prevent access to and tampering with the ICIM2 by unauthorized persons with an SNMP manager.
- Make the SNMP connection through the Ethernet port on the front of the ICIM2 or ICIM2-XD. Use a 10BaseT cable with an RJ-45 connector.
- Monitor the ICIM2 response time for possible slow response to both SNMP control and front-panel input, especially during periods of heavy network traffic. If required, reduce the update rate of the SNMP manager.

To Configure the ICIM2 for SNMP

Complete the following steps to set up ICIM2 IP configuration parameters.

- 1 Press the  key. The ICIM menu appears.
- 2 Select the Password menu and enter the User Password. The ICIM2 will now permit configuration changes for 10 minutes.
- 3 Press the  key. The ICIM menu appears.
- 4 Use the  key to move the highlight down to the IP Setup menu item.

- 5 Press the key. The IP Setup menu appears, as shown in the following illustration.

ICIM	
Shelf	7
Slot	15

IP Address	
172.18.9	
.227	
IP Subnet	
255.255	
.255.0	
Gateway IP	
172.18.9	
.254	

TP534






- 6 Use the and keys to scroll to and highlight the IP address configuration parameter.
- 7 Press the key. The Adjust menu for the IP address parameter appears as shown in the following illustration.

ICIM	
Shelf	7
Slot	15

Adjust	
IP Address	
172.18.9	
.227	

TP535

- 8 Change each segment of the IP address to the desired value. You can do this in one of two ways:

- a Use the  and  keys to increase or decrease the currently highlighted address segment. When finished, press the  key to accept your entry and move to the next address segment.
 - b Press the  key to change to numeric entry mode, and then type the desired value for the highlighted address segment. When typing the IP address, the cursor moves to the next address segment to the right automatically after you enter the last digit. Note, however, that you must use leading zeros as needed to enter three digits per address segment.
- 9 After changing all address segments, press the  key to return to the IP Setup menu.
 - 10 Repeat Steps 6-9 above as needed to change the IP subnet and gateway IP address.
 - 11 Restart the ICIM2 as described next.

To Restart the ICIM2

Complete the following steps to restart the ICIM2.


- 1 Fully loosen the captive screw holding the ICIM2 in the chassis.
- 2 Unlock the top and bottom ejector levers near the left side of the ICIM2.
- 3 Pull the ejector levers out and away from the front panel to disconnect the ICIM2 from the chassis backplane connector.
- 4 Pull the ICIM2 at least 1.5 inches (3.81 cm) out from the front of the chassis to ensure that it is fully separated from the chassis backplane connector.
- 5 Reinsert the ICIM2 into the chassis until the ejector levers insert into their respective slots in the chassis.
- 6 Push the ejector levers in and flat against the ICIM2 front panel to reconnect the ICIM2 to the backplane connector until the ejector levers lock in place.
- 7 Fully tighten in the captive screw to secure the ICIM2 in the chassis.

Using ICIM2 with the Fan Tray

Fan Tray Menu Structure

From the MAIN or SCROLL menus, you can navigate to the MODULE menu. From the MODULE menu, press the **STAT** or **ALRM** key to display the desired parameter menu.

Note: All parameters may be monitored in the STATUS menu. Because the ICIM2 front panel is read-only for all fan tray parameters, no instructions are provided here for navigating the CONFIG menu.






To Check Operating Status

Using the ICIM2, you can check the status of all operating parameters of this module. All status information is displayed on the ICIM2 LCD.

Complete the following steps to monitor operating parameters.

- 1 At the MAIN menu, press the **▼** key to highlight the **Shelf** and **Slot** fields.
- 2 Press the **SEL** key to address the **Shelf** number. Then press the **+** key or the **-** key to scroll to the number of the desired shelf.
- 3 Press the **ENTER** key. The **Slot** field is highlighted.
- 4 Press the **+** key or the **-** key to scroll to the number of the desired slot.
- 5 Press the **ENTER** key. The ICIM2 displays the MODULE menu.
- 6 Press the **STAT** key.





- 7 Press the  key or the  key to scroll through the monitored parameters until you find the parameter of interest.
- 8 Check the status of the desired parameter or select other parameters to monitor.
When finished, press the  key to return to the MAIN menu.

Fan Tray STATUS Menus

When the STATUS menu is selected, press the  key or the  key to scroll through the parameters. Some typical STATUS menus are shown below.

STATUS	STATUS
Shelf 0	Shelf 0
Slot 0	Slot 0

Fan Tray	Fan Tray

Ps1Inst Yes	Chas-5V -5.047 V
Ps3Inst Yes	ChasTemp 32.28 degC
 	 

TP383

Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

To Check Alarms

If the Alarm LED on the front panel is blinking, a minor alarm condition is indicated. If the Alarm LED on the front panel is illuminated, a major alarm condition is indicated.

Alarms fall into one of the following categories.

- Major low
- Minor low
- Minor high
- Major high
- Fault

Complete the following steps to check alarm conditions.

- 1 From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.

- 2 Press the **SEL** key to address the **Shelf** number. Then press the **+** key or the **-** key to scroll to the number of the desired shelf.
- 3 Press the **ENTER** key. The **Slot** field is highlighted.
- 4 Press the **+** key or the **-** key to scroll to the number of the desired slot.
- 5 Press the **ENTER** key. The ICIM2 displays the MODULE menu.
- 6 Press the **ALRM** key. Module alarm conditions display.
- 7 Use the **▲** key or the **▼** key to scroll through alarm conditions until the desired alarm is displayed.
- 8 Monitor the alarm condition(s). Take appropriate action. Verify that all settings and thresholds relating to the alarm indication are set correctly to rule out an unintended alarm.
- 9 When finished, press the **MAIN** key to return to the MAIN menu.

Fan Tray ALARMS Menus

After selecting the ALARMS menu function, press the **▲** key or the **▼** key to scroll through the modules in alarm. Some typical ALARMS menus are shown below.

ALARMS		ALARMS	
Shelf	0	Shelf	0
Slot	0	Slot	0
Fan Tray		Fan Tray	
FansOk Fault		ChasTemp MajorLow	
▲ ▼		▲ ▼	












TP165





Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

To Check Fan Tray Manufacturing Data

The Manufacturing Data information can be displayed on the ICIM menu.



Complete the following steps to access the module manufacturing data.









- 1 From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
- 2 Press the  key to address the **Shelf** number. Then press the  key or the  key to scroll to the number of the desired shelf.
- 3 Press the  key. The **Slot** field is highlighted.
- 4 Press the  key or the  key to scroll to the number of the desired slot.
- 5 Press the  key. The MODULE menu for this module will be selected, as shown on the left below. Press the  key to enter the start of the MFG. DATA screens, as shown on the right below.
- 6 The  and  keys allow you to scroll through the manufacturing data.

MODULE	MFG. DATA
Shelf 0	Shelf 0
Slot 0	Slot 0
Fan Tray	Fan Tray
Alarms 1	Module Type
Mfg. Data	5000
 	 

TP545

Fan Tray MFG. DATA Menus

When the MFG. DATA menu is selected, the  key or the  key allows you to scroll through the manufacturing parameters specific to this module. Sample MFG. DATA menus are shown below.

MFG. DATA	MFG. DATA	MFG. DATA	MFG. DATA
Shelf 0 Slot 0	Shelf 0 Slot 0	Shelf 0 Slot 0	Shelf 0 Slot 0
Fan Tray	Fan Tray	Fan Tray	Fan Tray
Module Type 5000	Serial # ~AANJYZD Date Code J04	SW Ver 1.01.08	In Service Hours 45
 	 	 	 

TP542


Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

Using ICIM2 with Power Supply 1

Power Supply 1 Menu Structure

From the MAIN or SCROLL menus, you can navigate to the MODULE menu. From the MODULE menu, press the **STAT** or **ALRM** key to display the desired parameter menu.

Note: All parameters may be monitored in the STATUS menu. Because the ICIM2 front panel is read-only for all power supply 1 parameters, no instructions are provided here for navigating the CONFIG menu.



Because the power supplies are double-wide modules, the ICIM2 addresses the power supply installed in slots 1 and 2 as Ps1. Ps3 refers to the power supply installed in slots 3 and 4.

To Check Operating Status

Using the ICIM2, you can check the status of all operating parameters of this module. All status information is displayed on the ICIM2 LCD.

Complete the following steps to monitor operating parameters.

- 1 At the MAIN menu, press the **▼** key to highlight the **Shelf** and **Slot** fields.
- 2 Press the **SEL** key to address the **Shelf** number. Then press the **+** key or the **-** key to scroll to the number of the desired shelf.
- 3 Press the **ENTER** key. The **Slot** field is highlighted.
- 4 Press the **+** key or the **-** key to scroll to the number of the desired slot.
- 5 Press the **ENTER** key. The ICIM2 displays the MODULE menu.

- 6 Press the **STAT** key.
- 7 Press the **▲** key or the **▼** key to scroll through the monitored parameters until you find the parameter of interest.
- 8 Check the status of the desired parameter or select other parameters to monitor.
When finished, press the **MAIN** key to return to the MAIN menu.

Power Supply 1 STATUS Menus

When the STATUS menu is selected, press the **▼** key or the **▲** key to scroll through the parameters. Some typical STATUS menus are shown below.

STATUS	STATUS	STATUS
Shelf 0 Slot 1	Shelf 0 Slot 1	Shelf 0 Slot 1
Power Supply 1	Power Supply 1	Power Supply 1
Ps1+24V 24.58V	Ps1+5V 5.405V Ps1-5V -5.612V	Ps1Temp 28.52degC
▲ ▼	▲ ▼	▲ ▼

TP163

Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).













To Check Alarms

If the Alarm LED on the front panel is blinking, a minor alarm condition is indicated. If the Alarm LED on the front panel is illuminated, a major alarm condition is indicated.



Alarms fall into one of the following categories.







- Major low
- Minor low
- Minor high
- Major high
- Fault

Complete the following steps to check alarm conditions.

- 1 From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
- 2 Press the  key to address the **Shelf** number. Then press the  key or the  key to scroll to the number of the desired shelf.
- 3 Press the  key. The **Slot** field is highlighted.
- 4 Press the  key or the  key to scroll to the number of the desired slot.
- 5 Press the  key. The ICIM2 displays the MODULE menu.
- 6 Press the  key. Module alarm conditions display.
- 7 Use the  key or the  key to scroll through alarm conditions until the desired alarm is displayed.
- 8 Monitor the alarm condition(s). Take appropriate action. Verify that all settings and thresholds relating to the alarm indication are set correctly to rule out an unintended alarm.
- 9 When finished, press the  key to return to the MAIN menu.

Power Supply 1 ALARMS Menu

After selecting the ALARMS menu function, press the  key or the  key to scroll through the modules in alarm. Some typical ALARMS menus are shown below.

ALARMS	ALARMS	ALARMS
Shelf 0 Slot 1	Shelf 0 Slot 1	Shelf 0 Slot 1
Power Supply 1	Power Supply 1	Power Supply 1
Ps1PwrIn Fault	Ps1+5VDC MajorLow	Ps1-5VDC MajorLow
Ps1+24 MajorLow  	 	 












TP166





Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

To Check Power Supply 1 Manufacturing Data

The Manufacturing Data information can be displayed on the ICIM menu.



Complete the following steps to access the module manufacturing data.

- 1 From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
- 2 Press the  key to address the **Shelf** number. Then press the  key or the  key to scroll to the number of the desired shelf.
- 3 Press the  key. The **Slot** field is highlighted.
- 4 Press the  key or the  key to scroll to the number of the desired slot.
- 5 Press the  key. The MODULE menu for this module will be selected, as shown on the left below. Press the  key to enter the start of the MFG. DATA screens, as shown on the right below.
- 6 The  and  keys allow you to scroll through the manufacturing data.

MODULE	MFG. DATA
Shelf 0 Slot 1	Shelf 0 Slot 1
Power Supply 1	Power Supply 1
Alarms 1	Module Type
Mfg. Data  	5000  

TP546

Power Supply 1 MFG. DATA Menus

When the MFG. DATA menu is selected, the  key or the  key allows you to scroll through the manufacturing parameters specific to this module. Sample MFG. DATA menus are shown below.

MFG. DATA	MFG. DATA	MFG. DATA	MFG. DATA
Shelf 0 Slot 1	Shelf 0 Slot 1	Shelf 0 Slot 1	Shelf 0 Slot 1
Power Supply 1	Power Supply 1	Power Supply 1	Power Supply 1
Module Type 5000	Serial # N/A Date Code N/A	SW Ver N/A	In Service Hours N/A
▲ ▼	▲ ▼	▲ ▼	▲ ▼

TP543


Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

Using ICIM2 with Power Supply 3

Power Supply 3 Menu Structure

From the MAIN or SCROLL menus, you can navigate to the MODULE menu. From the MODULE menu, press the **STAT** or **ALRM** key to display the desired parameter menu.

Note: All parameters may be monitored in the STATUS menu. Because the ICIM2 front panel is read-only for all power supply 3 parameters, no instructions are provided here for navigating the CONFIG menu.



Because the power supplies are double-wide modules, the ICIM2 addresses the power supply installed in slots 1 and 2 as Ps1. Ps3 refers to the power supply installed in slots 3 and 4.

To Check Operating Status

Using the ICIM2, you can check the status of all operating parameters of this module. All status information is displayed on the ICIM2 LCD.

Complete the following steps to monitor operating parameters.

- 1 At the MAIN menu, press the **▼** key to highlight the **Shelf** and **Slot** fields.
- 2 Press the **SEL** key to address the **Shelf** number. Then press the **+** key or the **-** key to scroll to the number of the desired shelf.
- 3 Press the **ENTER** key. The **Slot** field is highlighted.
- 4 Press the **+** key or the **-** key to scroll to the number of the desired slot.
- 5 Press the **ENTER** key. The ICIM2 displays the MODULE menu.

- 6 Press the **STAT** key.
- 7 Press the **▲** key or the **▼** key to scroll through the monitored parameters until you find the parameter of interest.
- 8 Check the status of the desired parameter or select other parameters to monitor.
When finished, press the **MAIN** key to return to the MAIN menu.

Power Supply 3 STATUS Menus

When the STATUS menu is selected, press the **▼** key or the **▲** key to scroll through the parameters. Some typical STATUS menus are shown below.

STATUS	STATUS	STATUS
Shelf 0 Slot 3	Shelf 0 Slot 3	Shelf 0 Slot 3
Power Supply 3	Power Supply 3	Power Supply 3
Ps3-5V -5.612V	Ps3Temp 28.52degC	Ps3+24V 24.58V
▲ ▼	▲ ▼	▲ ▼

TP164

Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).













To Check Alarms

If the Alarm LED on the front panel is blinking, a minor alarm condition is indicated. If the Alarm LED on the front panel is illuminated, a major alarm condition is indicated.



Alarms fall into one of the following categories.







- Major low
- Minor low
- Minor high
- Major high
- Fault

Complete the following steps to check alarm conditions.

- 1 From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
- 2 Press the  key to address the **Shelf** number. Then press the  key or the  key to scroll to the number of the desired shelf.
- 3 Press the  key. The **Slot** field is highlighted.
- 4 Press the  key or the  key to scroll to the number of the desired slot.
- 5 Press the  key. The ICIM2 displays the MODULE menu.
- 6 Press the  key. Module alarm conditions display.
- 7 Use the  key or the  key to scroll through alarm conditions until the desired alarm is displayed.
- 8 Monitor the alarm condition(s). Take appropriate action. Verify that all settings and thresholds relating to the alarm indication are set correctly to rule out an unintended alarm.
- 9 When finished, press the  key to return to the MAIN menu.

Power Supply 3 ALARMS Menu

After selecting the ALARMS menu function, press the  key or the  key to scroll through the modules in alarm. Some typical ALARMS menus are shown below.

ALARMS	ALARMS	ALARMS
Shelf 0 Slot 3	Shelf 0 Slot 3	Shelf 0 Slot 3
Power Supply 3	Power Supply 3	Power Supply 3
Ps3PwrIn Fault	Ps3+5VDC MajorLow	Ps3-5VDC MajorLow
Ps3+24 MajorLow  	 	 












TP167





Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

To Check Power Supply 3 Manufacturing Data

The Manufacturing Data information can be displayed on the ICIM menu.



Complete the following steps to access the module manufacturing data.

- 1 From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
- 2 Press the  key to address the **Shelf** number. Then press the  key or the  key to scroll to the number of the desired shelf.
- 3 Press the  key. The **Slot** field is highlighted.
- 4 Press the  key or the  key to scroll to the number of the desired slot.
- 5 Press the  key. The MODULE menu for this module will be selected, as shown on the left below. Press the  key to enter the start of the MFG. DATA screens, as shown on the right below.
- 6 The  and  keys allow you to scroll through the manufacturing data.

MODULE	MFG. DATA
Shelf 0 Slot 3	Shelf 0 Slot 3
Power Supply 3	Power Supply 3
Alarms 1	Module Type
Mfg. Data  	5000  

TP547

Power Supply 3 MFG. DATA Menus

When the MFG. DATA menu is selected, the  key or the  key allows you to scroll through the manufacturing parameters specific to this module. Sample MFG. DATA menus are shown below.

MFG. DATA	MFG. DATA	MFG. DATA	MFG. DATA
Shelf 0 Slot 3	Shelf 0 Slot 3	Shelf 0 Slot 3	Shelf 0 Slot 3
Power Supply 3	Power Supply 3	Power Supply 3	Power Supply 3
Module Type 5000 ▲ ▼	Serial # N/A Date Code N/A ▲ ▼	SW Ver N/A ▲ ▼	In Service Hours N/A ▲ ▼

TP544

Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

6

Operation using LCI

Introduction

This chapter provides installation and operating instructions for Local Craft Interface (LCI). This information is useful if you are using LCI to configure, operate, or monitor a module.

In This Chapter

- LCI Introduction 124
- System Requirements 125
- Installing LCI 126
- Connecting Your Computer to the Chassis 129
- Starting LCI Software 130
- LCI Module Tree 132
- Accessing the Module Detail Information 133
- Checking the Operating Status 139
- Checking the Module Alarms using LCI 140
- Modifying Module Alarm Limits using LCI 142
- Checking Manufacturing Data using LCI 144

LCI Introduction

Local Craft Interface (LCI) is software that functions as a user interface to the Prisma II Platform.

The LCI software is installed on a Windows laptop or desktop PC. The PC is connected to the chassis via the LCI port.

You can use LCI to configure, operate, and monitor the modules in the chassis to which the PC is connected.

System Requirements

You will need the following computer software and hardware to run LCI.

Computer Requirements

- Pentium II 300 MHz processor or equivalent
- 128 MB RAM
- 10 MB available hard drive space
- CD-ROM Drive
- Windows 95 or later operating system software

Cable Requirements

The required cable is a standard “off the shelf” serial extension cable, DB9 Female to DB9 Male. This cable can be purchased locally or ordered from the factory as part number 180143. The connectors are a serial 9-pin D-shell (EIA 574/232).

Installing LCI

This section describes the procedure for installing your LCI software. The installation steps shown here pertain to LCI release 2.3.


To Install the LCI Software

Complete the following steps to install the LCI software.

- 1 Close all programs that are running on your computer.
- 2 Insert the LCI CD-ROM into your CD-ROM drive.


Results:

- The LCI software installation program starts automatically. If the installation program does not start automatically, open Windows Explorer and double-click the file **setup.exe** on the LCI CD-ROM.
- The Welcome screen appears as shown in the following illustration.




- 3 Click **Next** to continue with the installation process.

Result: The Ready to Install the Program screen appears as shown in the following illustration.




- 4 Click **Install** to begin installation.

Result: After a moment, the **Setup Status** screen appears displaying a progress indicator, as shown in the following illustration.



- 5 When finished, the Installation Wizard Complete screen appears, as shown in the following illustration.



- 6 Click **Finish** to exit the Install wizard.

Result: An LCI shortcut is placed on your Windows desktop, as shown in the following illustration.



The LCI software is now ready to use.

Connecting Your Computer to the Chassis

Before you start LCI, you must first connect your computer to the chassis that contains the module(s) you want to check.


Important:

- LCI only communicates with modules installed in the chassis to which your computer is connected. To check other modules, you must connect your computer to the chassis in which they are installed.
- If LCI does not communicate with a module in the chassis to which your computer is connected, it may be necessary to update the LCI application.

To Connect a Computer to the Chassis

Complete the following steps to connect your computer to the chassis.

- 1 Plug one end of a 9-pin RS-232serial extension cable into your computer.
- 2 Plug the other end of the cable into the LCI port, labeled **Local Craft Interface**.



T10144

Starting LCI Software

When LCI is started, it polls the module(s) located in the chassis to which your computer is attached. For each module it finds, LCI does the following:

- Represents the module in the module tree of the main LCI window
- Makes the polling information available so you can check and configure various parameters

Important: Your computer must be connected to the chassis before you start LCI. For instructions, refer to *Connecting Your Computer to the Chassis* (on page 129).


To Start LCI Software

Complete the following steps to start the LCI software.

- 1 Double-click the LCI icon on your Windows desktop.




Result: The LCI Detect Configuration window appears as shown below.



- 2 In the LCI Detect Configuration window, select the appropriate COM port, chassis ID, and chassis type, and then click **Start**.

Result: LCI polls the modules in the chassis, and when finished, displays a Refresh Complete message.



- 3 Click OK to continue with LCI startup.

Result: The main LCI window appears as shown in the example below.



LCI Module Tree

The LCI main window contains a tree that represents your system in a hierarchical manner.



Module Tree

The module tree shown above represents a computer connected to a chassis that contains no application modules. The following table describes the three tree levels in the hierarchy.

Module Tree Level	Description
Local (System 0)	Computer being used
Chass00 (Chassis)	Chassis to which the computer is connected
Sxxxx (Module name)	Module(s) located within the chassis. Each module is of the format <i>chassis slot location (module name)</i> . Example: In the module tree shown above, S03 (Power Supply / Fan Tray) represents the power supply located in slot 3 of the chassis.

Accessing the Module Detail Information

The Module Details window displays information about module parameters, alarms, and status. You can access this window from the module tree using any of these methods:

- Double-click the chassis and select the module in the graphic that appears.
- Right-click the chassis and select **Open** from the menu that appears.
- Double-click the module.
- Right-click the module and select **Details** from the menu that appears.

Although you can use the method most convenient for you, the procedures throughout this chapter are described using the right-click module technique.

Note: Two items that may appear in the Module Details window are mode-specific. Manual Alarm status only appears in the Controls section when Master mode is selected. Relay status only appears in the Status section when Slave mode is selected.

Module Details Window

Power Supply / Fan Tray

	<u>Parameters</u>							
	Present Value	Present Status	Nominal Value	Minor-Alarm Low-Limit	Minor-Alarm High-Limit	Major-Alarm Low-Limit	Major-Alarm High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

- Summary Status **Alarm**
- Communication Status Normal
- Fans Status **Alarm**
- Input PS1 Status Normal
- Input PS3 Status **Alarm**
- PS1 Summary Status Normal
- PS3 Summary Status **Alarm**

Status


- Power Supply 1 Installed Yes
- Power Supply 1 Temperature 32.4 deg-C
- Power Supply 3 Installed Yes
- Power Supply 3 Temperature 0.1 deg-C
- +24V Voltage 24.5 VDC
- +5V Voltage 5.1 VDC
- 5V Voltage -5.0 VDC
- Fans Running Yes

Properties


- Devtype Revision 1.05
- Name S03
- Graphic**
- Service Name
- Symbol
- Device Location**
- M&C-Scan On-Scan
- Maintenance Mode Normal
- Poll Counter 1782
- Script**
- Address 3
- Port COM1
- Generic Name Power Supply / Fan Tray
- Description Power Supply / Fan Tray
- Software Revision 6.07
- Script Version 9
- Serial Number 1234567
- Time Of Service 0 Hrs
- Day Code J00
- Module Type 5000

To Access the Module Details, Double-Click the Chassis

- 1 Double-click the chassis.



Result: A graphic representation of the chassis appears.



- 2 Double-click the module whose information you want to view or configure.

Result: The Module Details window appears.

Power Supply / Fan Tray

Parameters

	Present Value	Present Status	Nominal Value	Minor-Alarm Low-Limit	Minor-Alarm High-Limit	Major-Alarm Low-Limit	Major-Alarm High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

Summary Status: **Alarm**
 Communication Status: Normal
 Fans Status: **Alarm**
 Input PS1 Status: Normal
 Input PS3 Status: **Alarm**
 PS1 Summary Status: Normal
 PS3 Summary Status: **Alarm**

Status

Power Supply 1 Installed: Yes
 Power Supply 1 Temperature: 32.4 deg-C
 Power Supply 3 Installed: Yes
 Power Supply 3 Temperature: 0.1 deg-C
 +24V Voltage: 24.5 VDC
 +5V Voltage: 5.1 VDC
 -5V Voltage: -5.0 VDC
 Fans Running: Yes

Properties

Devtype Revision: 1.05
 Name: S03
 Graphic:
 Service Name:
 Symbol:
 Device Location:
 M&C Scan: On-Scan
 Maintenance Mode: Normal
 Poll Counter: 1782
 Script:
 Address: 3
 Port: COM1
 Generic Name: Power Supply / Fan Tray
 Description: Power Supply / Fan Tray
 Software Revision: 6.07
 Script Version: 0
 Serial Number: 1234567
 Time Of Service: 0 Hrs
 Day Code: J00
 Module Type: 5000

3 Proceed with viewing or configuring information.

To Access the Module Details, Right-Click the Chassis

1 Right-click the chassis, and then click **Open**.


File View Refresh Help

- Local (System 0)
 - Chas00 (Chassis)
 - S03 (Power Supply / Fan)
 - S06 (Receiver)
 - S08 (Transmitter)
 - S10 (Receiver)

Context Menu:

- Open
- Summary
- Details
- Off-Scan
- On-Scan

Result: A graphic representation of the chassis appears.



- 2 Double-click the module whose information you want to view or configure.

Result: The Module Details window appears.

0 Chas00.S03 p2fantray Power Supply / Fan Tray

Power Supply / Fan Tray

	Present	Present	Nominal	Minor-Alarm	Minor-Alarm	Major-Alarm	Major-Alarm	
	Value	Status	Value	Low-Limit	High-Limit	Low-Limit	High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

Summary Status **Alarm**

Communication Status Normal

Fans Status **Alarm**

Input PS1 Status Normal

Input PS3 Status **Alarm**

PS1 Summary Status Normal

PS3 Summary Status **Alarm**

Status

Power Supply 1 Installed Yes

Power Supply 1 Temperature 32.4 deg-C

Power Supply 3 Installed Yes

Power Supply 3 Temperature 0.1 deg-C

+24V Voltage 24.5 VDC

+5V Voltage 5.1 VDC

-5V Voltage -5.0 VDC

Fans Running Yes

Properties

Devtype Revision 1.05

Name S03

Graphic

Service Name

Symbol

Device Location

M&C-Scan On-Scan

Maintenance Mode Normal

Poll Counter 1782

Script

Address 3

Port COM1

Generic Name Power Supply / Fan Tray

Description Power Supply / Fan Tray

Software Revision 6.07

Script Version 9

Serial Number 1234567

Time Of Service 0 Hrs


Day Code J00

Module Type 5000

- 3 Proceed with viewing or configuring information.

To Access the Module Details, Double-Click the Module

- 1 Double-click the module.



Result: The Module Details window appears.

Chas00.S03 p2fantray Power Supply / Fan Tray

Power Supply / Fan Tray

	Present Value	Present Status	Nominal Value	Minor-Alarm	Minor-Alarm	Major-Alarm	Major-Alarm	deg-C
				Low-Limit	High-Limit	Low-Limit	High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

Summary Status **Alarm**
 Communication Status Normal
 Fans Status **Alarm**
 Input PS1 Status Normal
 Input PS3 Status **Alarm**
 PS1 Summary Status Normal
 PS3 Summary Status **Alarm**

Status

Power Supply 1 Installed Yes
 Power Supply 1 Temperature 32.4 deg-C
 Power Supply 3 Installed Yes
 Power Supply 3 Temperature 0.1 deg-C
 +24V Voltage 24.5 VDC
 +5V Voltage 5.1 VDC
 -5V Voltage -5.0 VDC
 Fans Running Yes


Properties

Devtype Revision 1.05
 Name S03
Graphic
 Service Name
 Symbol
 Device Location
 M&C-Scan On-Scan
 Maintenance Mode Normal
 Poll Counter 1782
 Script
 Address 3
 Port COM1
 Generic Name Power Supply / Fan Tray
 Description Power Supply / Fan Tray
 Software Revision 6.07
 Script Version 9
 Serial Number 1234567
 Time Of Service 0 Hrs
 Day Code J00
 Module Type 5000


- 2 Proceed with viewing or configuring information.

To Access the Module Details, Right-Click the Module

- 1 Right-click the module, and then click **Details**.



Result: The Module Details window appears.




- 2 Proceed with viewing or configuring information.

Checking the Operating Status

To Check the Operating Status using LCI

Using the LCI, you can check the status of all operating parameters of this module.

- 1 In the module tree, right-click the module, and then click **Details**.



Result: The Module Details window appears. The monitored parameters are displayed under **Parameters** and **Status**.

0 Chas00.S03 p2fantray Power Supply / Fan Tray

Power Supply / Fan Tray

	Parameters							
	Present Value	Present Status	Nominal Value	Minor-Alarm Low-Limit	Minor-Alarm High-Limit	Major-Alarm Low-Limit	Major-Alarm High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

Summary Status **Alarm**
 Communication Status Normal
 Fans Status **Alarm**
 Input PS1 Status Normal
 Input PS3 Status **Alarm**
 PS1 Summary Status Normal
 PS3 Summary Status **Alarm**

Status

Power Supply 1 Installed Yes
 Power Supply 1 Temperature 32.4 deg-C
 Power Supply 3 Installed Yes
 Power Supply 3 Temperature 0.1 deg-C
 +24V Voltage 24.5 VDC
 +5V Voltage 5.1 VDC
 -5V Voltage -5.0 VDC
 Fans Running Yes

Properties

Devtype Revision 1.05
 Name S03

Graphic

Service Name
 Symbol

Device Location

M&C-Scan On-Scan
 Maintenance Mode Normal
 Poll Counter 1782
 Script
 Address 3
 Port COM1
 Generic Name Power Supply / Fan Tray
 Description Power Supply / Fan Tray
 Software Revision 6.07
 Script Version 9
 Serial Number 1234567
 Time Of Service 0 Hrs
 Day Code J00
 Module Type 5000

- 2 Check the operating parameters.

Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

Checking the Module Alarms using LCI


Using LCI, you can check the alarm status of various parameters. Alarms that you can check are listed below.

Alarms limits fall into one of the following categories.

- Major low
- Minor low
- Minor high
- Major high

To Check Alarms using LCI

Right-click the module, and then click **Details**.



Result: The Module Details window appears. The alarms are shown under **Parameters and Alarms**.

0 Chas00.S03 p2fantray Power Supply / Fan Tray

Power Supply / Fan Tray

Parameters

	Present Value	Present Status	Nominal Value	Minor-Alarm Low-Limit	Minor-Alarm High-Limit	Major-Alarm Low-Limit	Major-Alarm High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

- Summary Status **Alarm**
- Communication Status Normal
- Fans Status **Alarm**
- Input PS1 Status Normal
- Input PS3 Status **Alarm**
- PS1 Summary Status Normal
- PS3 Summary Status **Alarm**

Status

- Power Supply 1 Installed Yes
- Power Supply 1 Temperature 32.4 deg-C
- Power Supply 3 Installed Yes
- Power Supply 3 Temperature 0.1 deg-C
- +24V Voltage 24.5 VDC
- +5V Voltage 5.1 VDC
- 5V Voltage -5.0 VDC
- Fans Running Yes

Properties

- Devtype Revision 1.05
- Name S03
- Graphic
- Service Name
- Symbol
- Device Location
- M&C Scan On-Scan
- Maintenance Mode Normal
- Poll Counter 1782
- Script
- Address 3
- Port COM1
- Generic Name Power Supply / Fan Tray
- Description Power Supply / Fan Tray
- Software Revision 6.07
- Script Version 9
- Serial Number 1234567
- Time Of Service 0 Hrs
- Day Code J00
- Module Type 5000


Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

Modifying Module Alarm Limits using LCI

To Modify Alarm Limits using LCI

Using LCI, you can modify alarm limits for several parameters. Parameters whose alarm limits you can change are listed below.

- 1 In the module tree, right-click the module, and then click **Details**.



Result: The Module Details window appears. The alarm limits are shown under **Parameters**.

Chas00.S03 p2fantray Power Supply / Fan Tray

Power Supply / Fan Tray

	Present Value	Present Status	Nominal Value	Minor-Alarm		Major-Alarm		
				Low-Limit	High-Limit	Low-Limit	High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.5	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.5	-5.6	-4.5	V

Alarms

Summary Status [Alarm](#)
 Communication Status Normal
 Fans Status [Alarm](#)
 Input PS1 Status Normal
 Input PS3 Status [Alarm](#)
 PS1 Summary Status Normal
 PS3 Summary Status [Alarm](#)

Status


Power Supply 1 Installed Yes
 Power Supply 1 Temperature 32.4 deg-C
 Power Supply 3 Installed Yes
 Power Supply 3 Temperature 0.1 deg-C
 +24V Voltage 24.5 VDC
 +5V Voltage 5.1 VDC
 -5V Voltage -5.0 VDC
 Fans Running Yes

Properties

Devtype Revision 1.05
 Name S03
Graphic
 Service Name
 Symbol
Device Location
 M&C-Scan On-Scan
 Maintenance Mode Normal
 Poll Counter 1782
Script
 Address 3
 Port COM1
 Generic Name Power Supply / Fan Tray
 Description Power Supply / Fan Tray
 Software Revision 6.07
 Script Version 9
 Serial Number 1234567
 Time Of Service 0 Hrs
 Day Code J00
 Module Type 5000

- 2 Double-click the limit you want to change.

Result: The Change Value dialog box appears. This example shows the dialog box for the Power Supply 1 +24V Minor Low Limit parameter.



- 3 In the **Command to** box, type the value to use for the limit.
- 4 Click **Execute**.

Result: The new value appears in the alarm limit column.


Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

Checking Manufacturing Data using LCI

To Check Manufacturing Data using LCI

Using LCI, you can check the manufacturing data of the module.

- 1 In the module tree, right-click the module, and then click **Details**.



Result: The Module Details window appears. The manufacturing data is displayed under **Properties**.

0 Chas00.S03 p2fantray Power Supply / Fan Tray

Power Supply / Fan Tray

	Parameters							deg-C
	Present Value	Present Status	Nominal Value	Minor-Alarm Low-Limit	Minor-Alarm High-Limit	Major-Alarm Low-Limit	Major-Alarm High-Limit	
Chassis Temperature	27.7	Normal	25	-35	60	-40	65	deg-C
+24V Power Supply 1	24.8	Normal	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 1	5.4	Normal	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 1	-5.4	Normal	-5.4	-5.5	-4.6	-5.6	-4.5	V
+24V Power Supply 3	0.1	Low	24.7	18.4	25.9	18.0	26.1	V
+5V Power Supply 3	0.2	Low	5.4	3.7	5.9	3.6	6.1	V
-5V Power Supply 3	0.0	High	-5.4	-5.5	-4.6	-5.6	-4.5	V

Alarms

Summary Status [Alarm](#)
 Communication Status [Normal](#)
 Fans Status [Alarm](#)
 Input PS1 Status [Normal](#)
 Input PS3 Status [Alarm](#)
 PS1 Summary Status [Normal](#)
 PS3 Summary Status [Alarm](#)

Status

Power Supply 1 Installed [Yes](#)
 Power Supply 1 Temperature 32.4 deg-C
 Power Supply 3 Installed [Yes](#)
 Power Supply 3 Temperature 0.1 deg-C
 +24V Voltage 24.5 VDC
 +5V Voltage 5.1 VDC
 -5V Voltage -5.0 VDC
 Fans Running [Yes](#)

Properties

Devtype Revision 1.05
 Name S03

Graphic

Service Name
 Symbol

Device Location

M&C-Scan On-Scan
 Maintenance Mode [Normal](#)
 Poll Counter 1782
 Script
 Address 3
 Port COM1
 Generic Name Power Supply / Fan Tray
 Description Power Supply / Fan Tray
 Software Revision 6.07
 Script Version 9
 Serial Number 1234567
 Time Of Service 0 Hrs
 Day Code J00
 Module Type 5000

- 2 Proceed with viewing the manufacturing data.

Note: For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

7

User Management

Introduction

This chapter explains the procedures for adding and removing ICIM2 or ICIM2-XD users and for changing user access and authorization levels.

In This Chapter

- Introduction..... 146
- Replacing the Default Admin Account..... 149
- Working With User Accounts 153
- User Lockout 160

Introduction

The ICIM2 and ICIM2-XD support up to 16 user accounts. This chapter describes user accounts in detail, and explains how the system administrator (a user with Admin level security access) may set up and edit user accounts through the CLI or Web Interface. Additionally, this chapter includes a table listing access levels and corresponding resources, identifying the activities available to users with specific privileges.

User Accounts

Each user account is set up with a username and password. To initiate an account, the system administrator first chooses the access level and the status. Accounts to be activated immediately are given the status of **enable**, while those whose activation should be delayed are given the status of **disable**. The system administrator may also adjust the (single) inactivity timeout as well as the limit of failed log-in attempts for the ICIM2.

When a user logs onto the ICIM2 or ICIM2-XD via the CLI or Web Interface, the username and password are checked for authentication. A check is also performed to ensure that the user account is enabled. Users with disabled accounts are not permitted access to the ICIM2 or ICIM2-XD.

Additionally, security levels are compared to ensure that the user is authorized to access only the options appropriate to their access level. Another check verifies that the user has not reached the login failure limit as defined by the system administrator and saved in the ICIM2 or ICIM2-XD. A trap is sent if a user reaches the failed login attempts limit, and the user is prevented from making further log-in attempts for a designated lockout time period.

Username

Username, also known as login IDs, are formed from the alphanumeric characters A through Z (uppercase), a through z (lowercase), and the numbers 0 through 9. Special characters are not supported in login IDs. Username must have at least 6 characters, cannot exceed 14 characters, and must contain at least one alphabetic character and one numeric character. The username cannot be changed once it is created. If entered incorrectly, the system administrator must delete the user account and create a new account using the correct username, password, status, and access level.

Passwords

Passwords are formed from the alphanumeric characters A through Z (uppercase), a through z (lowercase), the numbers 0 through 9, and may include other printable keyboard characters. Control characters are not supported. Passwords must have at least 6 characters, cannot exceed 14 characters, and must contain at least one alphabetic character and one numeric character. Additionally, the password may not include or consist solely of the username (login ID). For security reasons, passwords are not echoed when adding, changing, or entering them at login. If you forget your password, contact the system administrator, as only he or she is able to change it. Users with Admin level privileges can change the password for any user.

Security Levels

User account security levels define the privileges available to users at that level. Choices are Read-Only, Read-Write, and Admin. The system administrator must have Admin privileges in order to add, change, or delete user accounts, or to modify system settings for the ICIM2 or ICIM2-XD and the modules in its domain.

Users who do not need to modify module alarm thresholds, controls, or CLLI codes should be assigned Read-Only privileges. Users who need to regulate module information or change CLLI codes need Read-Write privileges.

See *Features Available via Remote User Interface* (on page 335) for details regarding features available through the remote interface and user access levels required to view or edit data elements.

Account Enable or Disable

Each account is assigned a status of enable or disable. If an account is enabled, it may be used right away. If disabled, the account may not be accessed until the system administrator has activated it. The disabled account status is useful for employees who are temporarily unavailable because they have not started work yet or are on vacation.

Each time someone attempts to log onto a disabled account, a trap is sent alerting management to the event. The attempt is also logged in the event log.

Note: If you discover that your account is disabled, see your system administrator.

Login Thresholds

The login threshold defines the number of failed login attempts that must occur before a maximum threshold trap is sent. Admin level users may adjust the login threshold for the ICIM2 or ICIM2-XD. This threshold is the same for all users on a particular ICIM2 or ICIM2-XD. The default is 5 times, and the range is from 0 to 15. Login failure threshold checking may be disabled by setting the threshold to 0. A failed login attempt trap is sent for every failed login attempt.

User Lockout

Beginning with System Release 2.02, User Lockout may be enabled to prevent users who exceed the maximum failed login attempts threshold from logging in for a designated lockout interval (60 minutes by default). Locked-out users may try to log in again after the user lockout period expires or after an administrator removes the lockout. For further details, see *User Lockout* (on page 160).

Inactivity Timeout

The inactivity timeout is the number of minutes that a user account must be idle following login before it is automatically logged out by the ICIM2 or ICIM2-XD. The timeout value is the same number of minutes for all users on a particular ICIM2 or ICIM2-XD. The default is 10 minutes, but this value may be set anywhere from 1 to 60 minutes by a user with Admin privileges. The inactivity timeout cannot be disabled.

Replacing the Default Admin Account

All ICIM2 and ICIM2-XD units ship from the factory with a single default Admin level account. This account is assigned the username `Administrat0r` and the password `AdminPassw0rd`.

For security reasons, it is strongly recommended that the system administrator add a new Admin user level as the first step after starting up the ICIM2 or ICIM2-XD. After this new Admin level user is added, the default Admin user account may be deleted.

Important:

Before deleting the default Admin user account, be sure that you have created a new Admin account and noted its login defaults for future reference. Failure to remember the new username and password may result in being locked out of the ICIM2 or ICIM2-XD permanently. You cannot revert to the default Admin username and password once they are deleted.

To Replace the Default Admin Account

Complete the following steps to replace the default Admin account.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using the default username and password.

The sample dialog below shows the addition of a new user account **newAdmin1** with password **enterpassword1**.

```
CLI> icim
ICIM> user add newAdmin1 admin enable
Please enter the password: enterpassword1
Please reenter the password: enterpassword1
```


Note: Passwords are not echoed to the terminal as they are entered.

- 2 Type **show user**, and then confirm that the new user appears in the resulting list of user names.
- 3 Log out of the ICIM2 or ICIM2-XD.
- 4 Log back onto the ICIM2 or ICIM2-XD using the new Admin account username and password.
- 5 At the ICIM prompt, type **user delete Administrat0r**. The following message appears:


```
You are about to delete user 'Administrat0r' from the authorization table.
```
- 6 To confirm, type **yes**, and then press **Enter**.
- 7 Type **show user**, and then confirm that the user `Administrat0r` no longer appears in the resulting list of user names.

From the Web Interface

- 1 Log onto the ICIM2 or ICIM2-XD using the default username and password.




- 2 Click **User Mgmt** in the menu in the left pane. The User Management table appears as shown below.



TP387

- 3 Click the **New User** button beneath the User Management table. The New User Information screen appears as shown below.



TP397

- 4 Enter the User ID and Password in the fields provided, and then enter the password again in the Confirm Password field.
- 5 Select the appropriate Security Level and Status from the drop-down menus.
- 6 Click the **Save** button to save your settings.
- 7 Log out of the ICIM2 or ICIM2-XD.
- 8 Log back onto the ICIM2 or ICIM2-XD using the new Admin account name and password. For example:

newAdmin1

enterpassword1

- 9 Click **User Mgmt** in the menu in the left pane.
- 10 When the User Management Table appears, move the mouse to the delete button next to the row with the default Admin account username Administrat0r.

User Management

(Max 16 Users)

Number	User ID	Security	Status	Last Login	Failed Logins	Locked		
1	Administrat0r	Admin	Enabled	03/08/07 11:11:32	0	No	Edit	Delete
2	document2	Read-Only	Enabled	<None>	0	No	Edit	Delete
3	icim22	Read-Only	Enabled	<None>	0	No	Edit	Delete
4	newUser5	Read-Only	Enabled	<None>	0	No	Edit	Delete
5	newAdmin1	Admin	Enabled	<None>	0	No	Edit	Delete

[New User](#)

TP388

- 11 Click the **delete** button to remove the default Admin account.

Important:

- Keep track of the Administrator username and password. There is no way to retrieve the default username and password once they are deleted.
- Use the new Administrator account whenever performing system administrator tasks.

Working With User Accounts

The system administrator may perform any of these functions related to user accounts:

- Add new user accounts to give new users access to the ICIM2 or ICIM2-XD via the CLI and Web Interface.
- Change the password, security access level, or status (enabled or disabled) for a user account.
- Unlock user accounts that have become locked due to excessive failed login attempts.
- Delete user accounts that were entered in error or are no longer needed.
- View a list of currently logged in users.

This section describes the steps for each of these procedures.

To Add a New User

When setting up a new account, the system administrator first determines the appropriate user access level for the account. The administrator then determines whether the account will come up in a disabled or enabled state.

Complete the following steps to add a new user.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM mode.
- 3 Add the user at the ICIM prompt. For example:

```
ICIM> user add newUser1 read enable
Please enter the password: userpassword1
Please reenter the password: userpassword1
```

Note: Passwords are not echoed to the terminal as they are entered.

- 4 Type **show user**, and then confirm that the new user appears in the resulting list of usernames.

```
ICIM> show user
LOGIN IDENTIFIER  ACCESS LEVEL  STATUS  LAST LOGIN          FAILED  LOCKED
sysAdmin          ADMIN         Enabled  11/21/06 15:02:47  0      No
icim22            ADMIN         Enabled  11/07/06 10:05:46  0      No
newAdmin1         ADMIN         Enabled  11/21/06 15:06:11  0      No
newUser1          READ          Enabled  00/00/00 00:00:00  0      No
```

From the Web Interface

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.

- 2 Click **User Mgmt** in the menu in the left pane.
- 3 When the User Management table appears, click the **New User** button beneath the table. A New User Information form appears.

New User Information

User ID	<input type="text" value="newUser1"/>
Password	<input type="password"/>
Confirm Password	<input type="password"/>
Security Level	<input type="text" value="Read-Only"/>
Status	<input type="text" value="Enabled"/>

TP398

- 4 Enter the required user account information in the form:
 - username (e.g., newUser1)
 - password (e.g., userpassword1)
 - confirm password (e.g., userpassword1)

Note: Usernames and passwords must contain 6 to 14 characters and include at least 1 alphabetic character and at least 1 number.
- 5 Choose the appropriate access level (Read-Only, Read-Write, or Admin) from the drop-down menu.
- 6 Choose the appropriate account status (enable or disable) from the drop-down menu.
- 7 Click the **Save** button to keep the changes, and then click **OK** on the confirmation dialog to confirm the change.
- 8 Verify that the new account appears on the User Management table with the correct information.

To Change a User Password

Complete the following steps to change a user password.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM mode.
- 3 Add the user at the ICIM prompt. For example:

```
ICIM> user change password newUser1
Please enter the password: changepassword2
Please reenter the password: changepassword2
```

Note: Passwords are not echoed to the terminal as they are entered.

From the Web Interface

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Click **User Mgmt** in the menu in the left pane.
- 3 When the User Management table appears, click the **Edit** button on the row next to the account with the password to be changed.
- 4 When the edit window appears, verify that you are changing the correct account.

User Information (User=newUser1)

Password
 Confirm Password
Cancel Save

Security Level
Cancel Save

Status
Cancel Save

Unlock User Save

TP389

- 5 Type the new password in the password box (e.g., changepassword2).
- 6 Confirm the password in the confirmation box (e.g., changepassword2).
Note: Passwords are not echoed to the terminal as they are entered.
- 7 Click the **Save** button near the Confirm Password field.
- 8 When the OK to Save dialog box appears, choose **Save**.
- 9 Confirm that the user appears on the User Management table.

To Change a User Security Level

Complete the following steps to change a user security level.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM mode.
- 3 Edit the user information at the ICIM prompt. For example:
`ICIM> user change access_rights newUser1 readwrite`
- 4 Type **show user**, and then confirm that the change appears in the Access Level column of the User Management table.

```

ICIM> show user
LOGIN IDENTIFIER  ACCESS LEVEL  STATUS  LAST LOGIN          FAILED  LOCKED
sysAdmin          ADMIN         Enabled  11/21/06 15:02:47  0      No

```

icim22	ADMIN	Enabled	11/07/06 10:05:46	0	No
newAdmin1	ADMIN	Enabled	11/21/06 15:06:11	0	No
newUser1	READWRITE	Enabled	00/00/00 00:00:00	0	No

From the Web Interface

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Click **User Mgmt** in the menu in the left pane. The User Management table appears.
- 3 Click the **Edit** link on the row next to the account with the Security Level to be changed.
- 4 In the edit window, verify that you are changing the correct account.

User Information (User=newUser1)

Password
 Confirm Password
Cancel Save

Security Level
Cancel Save

Status
Cancel Save

Unlock User Save

TP390

- 5 Choose the appropriate Security Level from the drop-down menu.
- 6 Click the **Save** button on the Security Level row.
- 7 When the OK to Save dialog box appears, choose **Save**.
- 8 Confirm that the User Management table reflects the new security level.

To Change User Account Status

Complete the following steps to change (enable or disable) user account status.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM mode.
- 3 Edit the user information at the ICIM prompt. For example:

```
ICIM> user change account_status newUser1 disable
```
- 4 Type **show user**, and then confirm that the change appears in the Status column of the User Management table.

```
ICIM> show user
```

LOGIN IDENTIFIER	ACCESS LEVEL	STATUS	LAST LOGIN	FAILED	LOCKED
sysAdmin	ADMIN	Enabled	11/21/06 15:02:47	0	No
icim22	ADMIN	Enabled	11/07/06 10:05:46	0	No
newAdmin1	ADMIN	Enabled	11/21/06 15:06:11	0	No
newUser1	READ	Disabled	<None>	0	No

From the Web Interface

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Click **User Mgmt** in the menu in the left pane. The User Management table appears.
- 3 Click the **Edit** link on the row next to the account with the status to be changed.
- 4 In the edit window, verify that you are changing the correct account.

User Information (User=newUser1)

Password
 Confirm Password
Cancel Save

Security Level
Cancel Save

Status
Cancel Save

Unlock User
Save

TP391

- 5 Choose the appropriate Status from the drop-down menu.
- 6 Click the **Save** button on the Status row.
- 7 When the OK to Save dialog box appears, choose **Save**.
- 8 Confirm that the User Management table reflects the new status.

To Unlock User Accounts

Users who reach a specified maximum number of failed ICIM2 or ICIM2-XD login attempts may have their user accounts locked. These users will be unable to log in until a predetermined lockout interval expires, or until a system administrator unlocks the account. For complete instructions on working with the User Lockout feature and unlocking user accounts, see *User Lockout* (on page 160).

To Delete a User Account

Complete the following steps to delete a user account.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM mode.
- 3 Add the user at the ICIM prompt. For example:

```
ICIM> user delete newUser1
```

- 4 Type **show user**, and then confirm that the account is no longer listed in the resulting User Management table.

```
ICIM> show user
LOGIN IDENTIFIER  ACCESS LEVEL  STATUS  LAST LOGIN          FAILED  LOCKED
sysAdmin          ADMIN         Enabled  11/21/06 15:02:47  0      No
icim22           ADMIN         Enabled  11/07/06 10:05:46  0      No
newAdmin1        ADMIN         Enabled  11/21/06 15:06:11  0      No
```

From the Web Interface

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Click **User Mgmt** in the menu in the left pane. The User Management table appears.

User Management

(Max 16 Users)

Number	User ID	Security	Status	Last Login	Failed Logins	Locked		
1	Administrat0r	Admin	Enabled	03/08/07 11:11:32	0	No	Edit	Delete
2	document2	Read-Only	Enabled	<None>	0	No	Edit	Delete
3	icim22	Read-Only	Enabled	<None>	0	No	Edit	Delete
4	newUser5	Read-Only	Enabled	<None>	0	No	Edit	Delete
5	newAdmin1	Admin	Enabled	<None>	0	No	Edit	Delete

[New User](#)

TP392

- 3 Click the **Delete** button next to the row with the username for the account to remove.
- 4 In the confirmation box, verify that you are deleting the account that you intend to remove.
- 5 Verify that the account is not listed on the User Management Table.

Note: After an account is deleted, there is no more information concerning it except what has already been logged in the event log file.

To List All Currently Logged In Users

Complete the following steps to list all current ICIM2 or ICIM2-XD users.

From the CLI

- 1 Navigate to the ICIM prompt.
- 2 Type **who**, and then press **Enter** to display a list of current users.

```
ICIM> who
LOGIN IDENTIFIER      IP ADDRESS      TYPE      LOGIN TIME
icim22                172.9.9.12     CLI       11/21/06 15:08:10
newAdmin1            172.8.8.12     WEB       11/21/06 14:18:34
```

From the Web Interface

- 1 Click the **User Mgmt** menu option on the left pane.
- 2 View the Currently Logged In table in the lower section of the page.

Currently Logged In

User ID	Session Type	Source IP	Login Date / Time
document2	WEB	172.18.1.7	11/28/06 16:13:45

TP399

User Lockout

The User Lockout feature imposes a temporary lockout on ICIM2 or ICIM2-XD users who reach the maximum number of failed login attempts. Users who are locked out will not be able to log in to the ICIM2 or ICIM2-XD until the lockout interval expires, even if they try to log in using the correct login information.

By default, User Lockout is enabled with a lockout interval of 60 minutes. Admin users can select any lockout interval from 1 to 60 minutes, or can set the interval to 0 to disable User Lockout. All changes made to the lockout interval are recorded in the event log.

Admin users have commands available for checking the lockout time remaining by user and for unlocking a locked user account before the lockout interval expires. Admin users and users with unknown user names are not subject to lockouts. Lockout data is stored in volatile memory, so if the ICIM2 or ICIM2-XD reboots, this data is lost and all users are unlocked.

This section describes the following User Lockout actions available to Admin users:

- View the current lockout interval
- Specify a new lockout interval
- View locked-out users
- View lockout time remaining by user
- Unlock a locked-out user

Admin users can perform all of these actions through CLI commands, and can view the current lockout interval, specify a new interval, and view locked-out users through the ICIM Web Interface.

To View the Current Lockout Interval

Complete the following steps to view the current status of the User Lockout feature.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM command mode.
- 3 Type **show lockout**, and then press **Enter**. The system displays the current user lockout interval, as shown in the example below.

```
ICIM> show lockout
LOCKOUT
60
SUCCESS!
ICIM>
```

The number following LOCKOUT is the current length of the lockout interval in minutes. An interval of 0 means that user lockout is disabled.

Note: You can use **info lockout** instead of **show lockout**; the two commands have identical functions.

From the Web Interface

- 1 Log on to the ICIM2-XD using an account with Admin privileges.
- 2 Click **System Settings** in the menu in the left pane. The System Settings table appears as shown in the example below.

System Settings

Login Settings

Max Login Attempts	5	attempts	1-15 attempts, 0 disables the limit.
Inactivity Timeout	60	minutes	1-60 minutes
Lockout Interval	60	minutes	1-60 minutes, 0 disables the lockout feature

TP393

- 3 Note the value in the Lockout Interval field. This number indicates the current length of the lockout interval in minutes. A value of 0 means that User Lockout is disabled.

To Specify a New Lockout Interval

Complete the following steps to either disable User Lockout or to enable this feature and specify a new lockout interval.

From the CLI

- 1 Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- 2 Enter ICIM mode.
- 3 Type **set lockout x**, where **x** is a whole number from 0 to 60, and then press **Enter**. The system acknowledges your entry, as shown in the example below.

```
ICIM> set lockout 30
SUCCESS!
ICIM>
```

Note:

- Setting the lockout interval to 0 disables user lockout.
- Never change the User Lockout interval while a user is locked, as this may result in an unexpected actual lockout interval for the user.

From the Web Interface

- 1 Log on to the ICIM2-XD using an account with Admin privileges.
- 2 Click **System Settings** in the menu in the left pane.

- When the System Settings table appears, click in the **Lockout Interval** field and type the desired lockout value in the space provided.

System Settings

Login Settings

Max Login Attempts	5	attempts	1-15 attempts, 0 disables the limit.
Inactivity Timeout	60	minutes	1-60 minutes
Lockout Interval	60	minutes	1-60 minutes, 0 disables the lockout feature

TP394

- Click **Apply** to save your changes, or click **Cancel** to abort.

To View Locked-Out Users

Complete the following steps to view a list of all users and their current lockout status.

From the CLI

- Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- Enter ICIM mode.
- Type **show user**, and then press **Enter**. The system displays a list of all users, as shown in the example below.

```

ICIM> show user
LOGIN IDENTIFIER  ACCESS LEVEL  STATUS  LAST LOGIN          FAILED  LOCKED
Administrat0r    ADMIN         Enabled  03/08/07 11:11:32  0      No
document2        READ          Enabled  <None>         0      Yes
icim22           READ          Enabled  <None>         0      No
newUser5         READ          Enabled  <None>         0      No
    
```

- Check the values in the LOCKED column. Any users with YES in this column, such as document2 in the example above, are currently locked out.

Note: When a user account becomes locked, the Failed count (number of failed login attempts) is returned to zero.

From the Web Interface

- Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.

- Click **User Mgmt** in the menu in the left pane. The User Management table appears as shown in the example below.

User Management

(Max 16 Users)

Number	User ID	Security	Status	Last Login	Failed Logins	Locked		
1	Administrat0r	Admin	Enabled	03/08/07 11:11:32	0	No	Edit	Delete
2	document2	Read-Only	Enabled	<None>	0	Yes	Edit	Delete
3	icim22	Read-Only	Enabled	<None>	0	No	Edit	Delete
4	newUser5	Read-Only	Enabled	<None>	0	No	Edit	Delete

[New User](#)

TP395

- Note the value in the LOCKED column. Any users with YES in this column, such as firstUser2 in the example above, are currently locked out.

To View Lockout Time Remaining by User

Note: This feature is available only to Admin users and is accessible only through CLI.

Complete the following steps to view the lockout time remaining for all currently locked out users.

From the CLI

- Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.
- Enter ICIM mode.
- At the ICIM prompt, type **show lockedusers**, and then press **Enter**. A listing of all currently locked out users and their remaining lockout time appears, as shown in the example below.

```
ICIM> show lockedusers
LOCKED USER      MINUTES UNTIL UNLOCK
firstUser2             12
SUCCESS!
ICIM>
```

Note: If no users are currently locked out, the word (none) will appear in the list.

To Unlock a Locked-Out User

Note: This feature is available only to Admin users and is accessible only through the CLI.

Complete the following steps to unlock a user account that has been locked due to excessive incorrect login attempts.

From the CLI

- Log on to the ICIM2 or ICIM2-XD using an account with Admin privileges.

- 2 Navigate to the ICIM prompt.
- 3 Type **user unlock <username>**, where **<username>** is the name of the user to be unlocked, and then press **Enter**.

```
ICIM> user unlock firstUser2
SUCCESS!
ICIM>
```

The user account is now unlocked, and the user will be able to attempt to log in again.

Alternative Methods

There are two other ways to unlock a user account that has been locked out:

- Cycle power to the ICIM2 or ICIM2-XD off and then on again. Because lockout information is stored in volatile memory, cycling power to the ICIM2 or ICIM2-XD returns all users to default unlocked status.
- In the Web Interface, use the Unlock User feature in the Edit User window under User Management. For details, see **To Change User Account Status** in *Working with User Accounts* (on page 153).

Note: Never change the User Lockout interval while a user is locked, as this may result in an unexpected actual lockout interval for the user.

8

Event Log

The ICIM2 and ICIM2-XD use an event log to record certain events in the Prisma II system. This chapter describes the structure of the event log and identifies actions that it may record. Instructions are provided for viewing the log via the CLI or ICIM Web Interface, and for maintaining the event log via CLI commands.

In This Chapter

- Introduction..... 166
- Viewing the Event Log..... 169
- Clearing the Event Log 171
- Setting Event Log Filter Parameters..... 172
- Event Log-Related Traps 174
- Downloading and Viewing the Event Log Remotely..... 176

Introduction

The ICIM2 and ICIM2-XD maintain a log of significant events in the Prisma II system due to user activity unrelated to the network management system (NMS). The log can be viewed by Admin level users through the CLI or ICIM Web Interface. It can also be downloaded to an FTP server for offline viewing.

Certain types of events can be selected for exclusion from the log. Additionally, changes made through the MIB, usually by the NMS, are not part of the event log.

The event log holds up to 5,000 events. If a new event is logged when the log is already full, the oldest event is removed and the new event is added. To minimize log wrapping, several traps are sent to indicate that the log is nearing capacity, and one trap is sent to indicate that the log is full.

It is up to the NMS user or administrator to empty the log each time it nears capacity. To empty the event log, the NMS typically will first upload the log file from the ICIM2 or ICIM2-XD to an FTP server, and then clear the log file for new events.

Event Log Fields

Each event in the event log contains the following six fields.

Date and Time (Timestamp)

This field records the date and time that the event was logged.

User Name (User ID)

This field records the name of the user whose actions caused the event. Some events, such as inserting or removing a module, will not contain a user name.

User Access Rights (Security Level)

This field records the access rights of the user whose actions caused the event. Possible values of this field will be:

- Admin
- Read-Only
- ReadWrite
- Unknown (e.g., if there is no user name)

Event Category

This field records the category of the event. Possible values of this field will be:

- Security

- Administration
- System
- Hardware
- Provision

Event Action ID

This field records the action ID of the event. Possible values are detailed later.

Event Description

This field contains text describing the event in more detail. For example, if a module is inserted, the description would list the chassis and slot numbers for the insertion.

Event Action IDs

Each event that may appear in the event log is identified by a unique character string called an event action ID. The table below lists the action IDs for these events and identifies their respective event categories.

Note: Action IDs may be displayed differently depending on whether the log is viewed through the CLI or the Web Interface.

Event Action ID	Event Category
LOGIN_SUCCESS	SECURITY
LOGIN_FAILED	SECURITY
LOG_OFF	SECURITY
SESSION_TIMEOUT	SECURITY
LOGIN_THRSHLD_RCHD	SECURITY
IPSEC_ENABLED	SECURITY
IPSEC_DISABLED	SECURITY
IKE_PEER_ADD	SECURITY
IKE_PEER_REMOVE	SECURITY
USER_ACCT_LOCKOUT	SECURITY
CHG_LOGIN_THRESHOLD	ADMINISTRATION
CHG_TRAP_DESTINATION	ADMINISTRATION
CHG_INACTIVITY_TIMER	ADMINISTRATION
CHG_USER	ADMINISTRATION
GET_USER	ADMINISTRATION
CHG_LOG_OPTION	ADMINISTRATION

Event Action ID	Event Category
SET_CLOCK	ADMINISTRATION
CHG_SNTP	ADMINISTRATION
CHG_LOCKOUT_INTERVAL	ADMINISTRATION
LOG_NEAR_FULL	SYSTEM
LOG_FULL	SYSTEM
DOWNLOAD_START	SYSTEM
DOWNLOAD_COMPLETE	SYSTEM
REBOOT	SYSTEM
SYSTEM_ERROR	SYSTEM
WATCHDOG_CPU_OVERLOAD	SYSTEM
WATCHDOG_REBOOT	SYSTEM
EVENTLOG_FORMAT	SYSTEM
SELFTTEST_FAILED	SYSTEM
SNTP_FAILED	SYSTEM
MODULE_INSERT	HARDWARE
MODULE_REMOVE	HARDWARE
CHG_SERVICE_MODE	PROVISION
SET_CLLI	PROVISION
SET_COMMREAD	PROVISION
SET_COMMWRITE	PROVISION
SET_COMMTRAP	PROVISION
SET_GATEWAY	PROVISION
SET_IP	PROVISION
SET_SUBNET	PROVISION
SET_UPDATEID	PROVISION
SET_MODULE_CTRL	PROVISION
SET_ALARM_PARAM	PROVISION
ADD_ROUTE	PROVISION
DELETE_ROUTE	PROVISION

Viewing the Event Log

The event log may be viewed in either of two ways: through the CLI or via the ICIM Web Interface. This section describes both methods.

To View the Event Log through the CLI

Two CLI commands are available for viewing the event log.

- The **icim show eventlog** displays an abbreviated version of the event log. Only the Date and Time, User Name, and Description fields are included, so most log entries will fit on a single line on the terminal screen.
- The **icim show eventlogall** command displays all log fields: Date and Time, User Name, User Access Rights, Event Category, Action ID, and Description. Some fields use abbreviations to maintain a display that is readable on a terminal.

Examples of each command are shown below.

Abbreviated Event Log

To view an abbreviated version of the event log, use the **icim show eventlog** command, as shown in the following example.

```
CLI> icim show eventlog
11/17/06 09:24:17 Administrat0r Set ICIM CLI to ICIM2_CLLI
11/17/06 09:23:33 Administrat0r Log Off
11/17/06 09:22:57 Administrat0r Module inserted (1/12)
11/17/06 09:22:55 Administrat0r Module inserted (1/9)
11/17/06 09:22:32 Administrat0r Login successful
5 log messages displayed

SUCCESS!
CLI>
```

Note: The example above also illustrates that no user name is shown for module insertion events.

Full Event Log

To view a full version of the event log that includes all fields, use the **icim show eventlogall** command, as shown in the following example.

```
CLI> icim show eventlogall
11/17/06 09:24:17 Administrat0r AD PR SET_CLLI Set ICIM CLI to
o ICIM2_CLLI
11/17/06 09:23:33 Administrat0r AD SE LOG_OFF Log Off
11/17/06 09:22:57 Administrat0r HW MODULE_INSERT Module inserted
(1/12)
11/17/06 09:22:55 Administrat0r HW MODULE_INSERT Module inserted
(1/9)
11/17/06 09:22:32 Administrat0r AD SE LOGIN_SUCCESS Login successfu
l
5 log messages displayed

SUCCESS!
CLI>
```

As shown in the example above, the full view of the event log provides more detail, but may be more difficult to read because the log entries typically do not fit on a single line.

To shorten the entries and help improve readability, abbreviated values are used in the User Access Rights and Event Category columns. The User Access Rights column will contain one of the following abbreviated values:

- AD (Admin)
- RW (ReadWrite)
- RO (Read-Only)

Note: If the user name is blank (as in the Module Insert event), the User Access Rights field will also be blank.

Similarly, the Event Category column will contain one of the following values:

- SE (Security)
- AD (Administration)
- SY (System)
- HW (Hardware)
- PR (Provisioning)

To View the Event Log through the Web Interface

After logging in, select **Event Log** from the menu in the left column. The Event Log table appears, resembling the example below.

Event Log

[Clear Event Log](#)

<<Previous [1] Next>>

Page 1 of 1

Timestamp	Action	User ID	Description	Sec Level	Category
11/17/06 09:24:17	Set CLI	Administrat0r	Set ICIM CLI to ICIM2_CLI	Admin	Provision
11/17/06 09:23:33	Log Off	Administrat0r	Log Off	Admin	Security
11/17/06 09:22:57	Module Insert		Module inserted (1/12)	Unknown	Hardware
11/17/06 09:22:55	Module Insert		Module inserted (1/9)	Unknown	Hardware
11/17/06 09:22:32	Login Success	Administrat0r	Login successful	Admin	Security

The log will be displayed one page at a time, with up to 25 logs per page. Use the **Previous** and **Next** links to scroll through any additional pages.

Clearing the Event Log

To prevent event wrapping when the log gets full, the log must be periodically cleared of events. Typically, the log is downloaded to an FTP server before it is cleared from ICIM2 or ICIM2-XD memory.

The event log may be cleared through the CLI or via the Web Interface. This section describes both methods.

To Clear the Event Log through the CLI

To clear the log, use the **icim eventlogclear** command. This will clear the entire log. You will be prompted for confirmation before the log is cleared, as shown in the example below.


```
CLI> icim eventlogclear

You are about to remove 6 entries from the system log.
Are you sure you want to proceed (Yes/No)? yes

SUCCESS!
CLI>
```

To Clear the Event Log through the Web Interface

With the event log displayed in the Web window, click the **Clear Event Log** button. You will be asked to confirm the operation.



Click **OK** to continue.

Setting Event Log Filter Parameters

Associated with the event log are filter parameters that determine whether certain types of events are included in or excluded from the log.

Events are included or excluded according to event category. Each event belongs to one of the following event categories:

- Administration
- Hardware
- Provisioning
- Security
- System

Administration and Security events are always included in the event log. System, Hardware, and Provisioning events may be included in or excluded from the event log by changing filter parameters. Changes to event log filter parameters only affect the logging of future events. Events that are already part of the log file will remain in the log file, regardless of subsequent filter parameter changes.

Event log filter parameters may be viewed and set through the CLI or via the Web Interface. This section describes both methods.

To View Filter Parameters through the CLI

To view the current filter parameter settings, use the **icim show eventlogfilter** command, as shown in the following example.

```
CLI> icim show eventlogfilter
Event Log Settings:
  Provisioning Events: on
  Hardware Events: on
  System Events: on
  (a value of "on" means to log events of that category)
SUCCESS!
CLI>
```

To Set Filter Parameters through the CLI

To change filter parameters through the CLI, use the following command:

```
icim eventlogfilter <category> <setting>
```

The possible values for <category> and <setting> are listed below along with their resulting effects on the filter settings.

<category>	<setting>	Result
hardware	on	Includes hardware events in the event log.
hardware	off	Excludes hardware events from the event log.
provisioning	on	Includes provisioning events in the event log.
provisioning	off	Excludes provisioning events from the event log.
system	on	Includes system events in the event log.
system	off	Excludes system events from the event log.

The example below turns off logging of hardware events, and then shows the filter parameters settings.

```
CLI> icim eventlogfilter hardware off
SUCCESS!
CLI> icim show eventlogfilter
Event Log Settings:
  Provisioning Events: on
  Hardware Events: off
  System Events: on
  (a value of "on" means to log events of that category)
SUCCESS!
CLI>
```

To View Filter Parameters through the Web Interface

To view the current filter parameter settings, log in to the Web Interface and then select the **System Settings** page from the left menu. The second group of items on this page shows the event log settings.

To Set Filter Parameters through the Web Interface

To change the current filter parameter settings, use the check boxes in the Event Log Settings group on the System Settings page.

Event Log Settings

<input checked="" type="checkbox"/> Log Provisioning events
<input checked="" type="checkbox"/> Log Hardware events
<input checked="" type="checkbox"/> Log System events

Check the box beside each event category to be included in the log, and clear the box beside each category to be excluded. When finished, click the **Apply** button to save your changes, or click **Cancel** to abort.

Event Log-Related Traps

To alert the NMS of possible lost event log entries due to wrapping, the ICIM2 sends several traps as the log nears capacity. A trap is sent when the log is 80%, 85%, 90%, 95%, and 100% full. This means that five traps total are sent if the NMS takes no action to clear the log. Once the log reaches 100% full and begins wrapping, no more log-full traps are sent.

The traps are of the TelcoAlarm variety, and contain all the varbinds defined as part of that trap type. All traps except the 100% full trap specify **LogMemHalfFull** as the p2TrapLogLabel varbind, although the p2TrapLogDescr varbind specifies the percentage. The 100% full trap specifies **LogMemoryFull** as the p2TrapLogLabel varbind.

Examples of the 80% full trap and the 100% full trap are provided below.

Example: 80% Full Trap

```
Specific: 9
Message reception date: 9/13/2006
Message reception time: 2:27:25.066 PM
Time stamp: 0 days 00h:11m:20s.13th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.193
  Port: 1035
Manager
  Address: 172.18.9.66
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.193
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 12
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) LogMemHalfFull
  Binding #5: p2icimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.2.15 *** (int32) 2
  Binding #8: p2slotID.2.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.2.15 *** (octets) 1.2.243
  Binding #10: p2moduleCLEIcode.2.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-9-13,1:51:39.42
  Binding #12: p2TrapLogDateTime *** (octets) Wed, 13 Sep 2006 01:51:39 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Log memory is %80 full
```

Example: 100% Full Trap

```
Specific: 9
Message reception date: 9/13/2006
Message reception time: 2:44:27.081 PM
Time stamp: 0 days 00h:28m:22s.13th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.193
  Port: 1039
Manager
  Address: 172.18.9.66
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.193
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 16
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) LogMemoryFull
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.2.15 *** (int32) 2
  Binding #8: p2slotID.2.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.2.15 *** (octets) 1.2.243
  Binding #10: p2moduleCLEIcode.2.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-9-13,2:8:41.45
  Binding #12: p2TrapLogDateTime *** (octets) Wed, 13 Sep 2006 02:08:41 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Log memory is %100 full
```

Downloading and Viewing the Event Log Remotely

The event log can be downloaded from the ICIM2 or ICIM2-XD to an FTP server at any time. It is recommended that the file be downloaded before it reaches capacity to avoid losing the oldest events in the log as new events are added.

Transfer of the event log file is initiated using SNMP via the `prismallFileMgmtGroup` MIB. For additional information, see *Event Log File Management* (on page 195).

To Download the Event Log File

Complete the following steps in SNMP to initiate the event log file download.

- 1 Set `p2icimFileMgmtUsername` to the FTP user name.
- 2 Set `p2icimFileMgmtPassword` to the FTP password.
- 3 Set `p2icimFileMgmtIpAdress` to the IP address of the FTP server.
- 4 Set `p2icimFileMgmtFilePath` to the path of the destination file on the FTP server.
- 5 Set `p2icimFileMgmtFileName` to the destination file name on the FTP server.
- 6 Set `p2icimFileMgmtCmd` to **upload(1)**.
- 7 Set `p2icimFileMgmtAction` to **execute(2)**.

In response to these commands, the ICIM2 or ICIM2-XD will log into the FTP server and transfer the event log file.

The event log file is a text file with space-separated columns, formatted in a manner almost identical to the response to the **icim show eventlogall** command from the CLI. Most recent events appear at the bottom of the file, and there is no file header.

A sample portion of the event log file as downloaded from the ICIM2 or ICIM2-XD to an FTP server is shown below.

```

2006/11/27 16:30: 8 webguil ADMIN SE LOG_OFF Log Off
2006/11/27 16:39:37 console1 ADMIN SE LOG_OFF Log Off
2006/11/27 17:36:45 Administrat0r ADMIN SE LOGIN_SUCCESS Login successful
2006/11/27 17:37:12 Administrat0r ADMIN SE LOG_OFF Log Off
2006/11/28 12:39:16 console1 ADMIN SE LOGIN_SUCCESS Login successful
2006/11/28 12:41:58 webguil ADMIN SE LOGIN_SUCCESS Login successful
2006/11/28 13:21:47 console1 ADMIN SE LOG_OFF Log Off
2006/11/28 13:21:52 webguil ADMIN SE LOG_OFF Log Off
2006/11/28 13:41:50 Administrat0r ADMIN SE LOGIN_SUCCESS Login successful
2006/11/28 13:42: 5 Administrat0r ADMIN SE LOG_OFF Log Off
2006/11/28 15:30: 1 Administrat0r ADMIN SE LOGIN_SUCCESS Login successful
2006/11/28 15:30:19 Administrat0r ADMIN SE LOG_OFF Log Off
2006/11/28 15:31:39 webguil ADMIN SE LOGIN_SUCCESS Login successful
2006/11/28 15:35:25 webguil ADMIN SE LOG_OFF Log Off
2006/11/29 13:39:39 Administrat0r ADMIN SE LOGIN_SUCCESS Login successful
2006/11/29 13:41:51 Administrat0r ADMIN SE LOGIN_SUCCESS Login successful
2006/11/29 13:45:40 Administrat0r ADMIN SE LOG_OFF Log Off
2006/11/29 13:48:53 Administrat0r ADMIN SE LOGIN_SUCCESS Login successful
2006/11/29 13:50: 7 webguil ADMIN SE LOGIN_SUCCESS Login successful
2006/11/29 13:51: 0 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control Mode to 1
2006/11/29 13:51: 1 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control NomPin3 to 18
2006/11/29 13:51: 2 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control NomPin4 to 18
2006/11/29 13:51: 4 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control Delta to 1
2006/11/29 13:51: 5 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control HystAmpl to 1.4
2006/11/29 13:51: 6 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control HystTime to 1
2006/11/29 13:51: 7 Administrat0r ADMIN P SET_MODULE_CTRL Set module (1/9) control Revert to 0
    
```

In this example:

- The date-time format is yyyy/mm/dd hh:mm:ss, and seconds are shown without leading zeros.
- Event categories are abbreviated, with Security shown as SE and Provisioning shown as P.

9

SNMP Management

Introduction

This chapter provides information about using Simple Network Management Protocol (SNMP) commands for remote system monitoring and control. The ICIM2 and ICIM2-XD recognize SNMP v1 and v2c commands, but only sends SNMP v1 traps to ensure backward compatibility.

For details on chassis-related system parameters, see *Module Parameter Descriptions* (on page 347). Parameters for application modules are described in separate user documents for each module. See *Related Publications* (on page 33).

In This Chapter

■ Introduction.....	180
■ ICIM MIB	181
■ Module MIB.....	211
■ Remote Reboot of ICIM2 and Modules	238
■ Prisma II Traps	239
■ Alarm Threshold Modification	277
■ System Behavior.....	279
■ Frequently Asked Questions.....	280

Introduction

Simple network management protocol (SNMP) is an ISO standard communication protocol often used by network and element management systems to monitor network devices for alarms and other significant conditions.

SNMP accesses information about network devices through management information base (MIB) objects. MIBs are hierarchical tree-structured descriptions used to define database elements. SNMP is used to manage individual data elements and the values assigned to MIB objects.

SNMP addresses a single MIB object using a numeric string called an object identifier (OID). The OID defines a branching path through the hierarchy to the location of the object. In addition to the OID, a MIB object is known by its object descriptor, a text string intended to be more meaningful to a human operator. The OID and object descriptor are unique to each MIB object.

Also defined for each MIB object is the access that SNMP can afford to the object data value. For example, if a MIB object has read-write access, SNMP can be used to both get (retrieve) and set (define or change) the value of the object. If an object is read-only, SNMP can be used to get the object value, but not to change it.

Prisma II Enterprise MIBs

The Prisma II Enterprise management information bases (MIBs) allow easy access to ICIM2, trap, and module information via SNMP. There are two proprietary MIBs for management and event notification:

- SCIATL-PRISMAII-ICIM-MIB contains a scalar list of values used to control Prisma II ICIM management functions. Included are two trap tables, one for trap configuration and the other for trap logging.

Current version: 200702222200Z

- SCIATL-PRISMAII-MODULE-MIB contains a series of tables for managing Prisma II application modules.

Current version: 200702062209Z

These MIBs are based on the original ICIM MIBs, PRISMAII-ICIMR13-MIB and PRISMAII-MODULER13-MIB, which are now considered obsolete.

Details of the elements of the ICIM MIB and MODULE MIB are provided in the sections below.

ICIM MIB

MIB objects for the ICIM2 and ICIM2-XD fall into several categories. Information includes the state of the ICIM2 or ICIM2-XD in reference to network settings, FTP, download control, and manufacturing data. Each of the ICIM2 or ICIM2-XD object identifiers appears below with a description and other pertinent information concerning the element.

To View the ICIM MIB

To view the Prisma II ICIM MIB, be sure to compile and load both proprietary MIBs, SCIATL-PRISMAII-ICIM-MIB and SCIATL-PRISMAII-MODULE-MIB, in your MIB browser.

The ICIM2 or ICIM2-XD object identifier (OID) is 1.3.6.1.4.1.1429.1.6.2.2.13.100. This is the dot version of the full path that expands to:

```
iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).scientificatlanta(1429).saTerr(1).saTerrOptical(6).saTerrOpticalPrismaII(2).saPrismaIIrev2(2).saPrismaIIlicim(13).prismaIIlicim(100).
```

ICIM MIB Elements

The ICIM MIB contains the following elements, which are discussed in detail in this section.

ICIM MIB Element	Example Value
p2icimChassisID	6
p2icimSlotID	15
p2icimSMCAAddress	615
p2icimType	5011
p2icimManufactureData	ICIM2
p2icimSerialNumber	AADORSF
p2icimHardwareRevision	BdRev87A
p2icimSoftwareRevision	2.00.08
p2icimSoftwareDate	11032006
p2icimTimeOfService	219
p2icimMACAddr	00:14:FF:FF:FF:61
p2icimIPAddr	172.24.24.24
p2icimSubnetMask	255.255.255.0

ICIM MIB Element	Example Value
p2icimGatewayAddr	172.24.24.254
p2PreviousIP	174.24.24.23
p2icimUpdateChassisIDs	0
p2icimAttnStatus	High (1)
p2icimDomainSize	6
p2icimNextImage	currentActive (1)
p2icimActiveCodeRevision	2.00.08
p2icimInactiveCodeRevision	N/A
p2icimBootCodeRevision	2.00.03
p2icimFtpServerAddr	172.24.13.12
p2icimFtpUsername	Set
p2icimFtpPassword	Set
p2icimDownLdDir	(zero-length)
p2icimDownLdFilename	ICIM2_2_00_08_app.BIN
p2icimDownLdCmd	Cancel (4)
p2icimDownLdState	Idle (1)
p2icimDownLdTarget	100
p2icimDownLdResult	No-result-available (9999)
p2icimDownLdSignature	1146728270
p2icimDownLdSemaphore	1146720732
p2icimDownLdUser	0
p2icimCLLlcode	SCIATL01
p2icimCLElcode	VLLUAA4DAA
p2icimSelfTest	ICIM2 Self-Test Passed
p2icimStatusMsg	6 Nov 03 2006 05:50:03 AM Broadcast reboot command successful
p2icimDownLdProg	0
p2icimClock	2006-12-15 11:38:57
p2icimTimeZone	EDT
p2icimDateTime	Fri, 15 Dec 2006 11:32:57 EST
p2icimNotify	0
p2icimStatusMsgClearKey	2

p2icimChassisID

The number that appears in the chassis ID switch on the front panel of the chassis in which the ICIM2 or ICIM2-XD is installed indicates the value for the chassis ID. Valid chassis ID values are 00 to 99 inclusive. However, the use of 00 as the chassis ID value is not recommended in some circumstances, as the following caution explains.

**CAUTION:**

Setting the chassis ID to 00 is not recommended as it causes the entity MIB to violate RFC-2737 by creating an invalid object identifier. This may affect operation with some management systems that use the entity MIB. In particular, attempts to access the fans (in virtual slot 0) in chassis 00 will fail if made via serial TNCS (or ROSA-EM) or LCI.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.1

p2icimSlotID

The value in this object identifies the slot number in which the ICIM2 or ICIM2-XD is installed, and is always 15.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.2

p2icimSMCAAddress

The value in this object is the chassis number times 100 plus the ICIM2 or ICIM2-XD slot number. Leading zeros may be cropped. Thus, for chassis 20, the p2icimSMCAAddress will be 2015.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.3

p2icimType

The value in this object is used to uniquely identify the ICIM2 or ICIM2-XD model. In other contexts, this may be referred to as the Devtype.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.4

p2icimManufactureData

This object holds a string of up to 30 characters that describes the ICIM2 or ICIM2-XD in words. For the ICIM2, the string is ICIM2.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.5

p2icimSerialNumber

This object holds the serial number assigned to this unit during the manufacturing process.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.6

p2icimHardwareRevision

The value in this object is the hardware revision of this ICIM2 or ICIM2-XD, e.g., BdRev87A.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.7

p2icimSoftwareRevision

This object is no longer used, but kept in place for backward compatibility. Active, inactive, and boot code revisions display through p2icimActiveCodeRevision, p2icimInactiveCodeRevision, and p2icimBootCodeRevision (described below).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.8

p2icimSoftwareDate

The value in this object represents the date that the firmware was built, e.g., 01202007 (Jan. 20, 2007).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.9

p2icimTimeOfService

This object shows the number of hours that this ICIM2 or ICIM2-XD has been in service, which may be any number of hours starting from 0.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.10

p2icimMACAddr

This object holds the physical MAC address assigned to this ICIM2 or ICIM2-XD, in the form 00:11:22:33:44:55.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.12

p2icimIPAddr

This object holds the network IP address assigned to this ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.13

p2icimSubnetMask

This object holds the network subnet mask used to reach this ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.14

p2icimGatewayAddr

This object represents the network gateway address used by this ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.15

p2PreviousIP

This object returns the value 0.0.0.0 until the IP address of the ICIM2 or ICIM2-XD is changed for the first time. After that, it holds the previous IP address.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.16

p2icimUpdateChassisIDs

Setting the value of this object to 1 updates every module in this ICIM2 or ICIM2-XD domain with its chassis ID and slot number. As a result, each module sends all of its information to the ICIM2 or ICIM2-XD. It takes time for the ICIM2 or ICIM2-XD to update the database with the new data. A get on this object always returns the value 0.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.19

p2icimAttnStatus

This object will normally display high (1) unless one of the modules pulls the attention line low (2). In that case, the ICIM2 or ICIM2-XD will service the request from the module, and when complete, will return the attention line to high (1).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.20

p2icimDomainSize

This object shows the number of modules managed by this ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.21

p2icimNextImage

The value in this object indicates which image will be active following the next ICIM2 or ICIM2-XD reboot. Values may be current active image (1) or current inactive image (2).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.22

p2icimActiveCodeRevision

This object displays the active firmware image revision for the ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.23

This object is used to determine the active software version. The ICIM2 and ICIM2-XD can store two flash images, one in the Active area and the other in the Inactive area. The SOUP program is used to download code to the two flash areas and switch between them.

p2icimInactiveCodeRevision

This object displays the inactive firmware image revision for the ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.24

This object is used to determine the inactive software version. The ICIM2 and ICIM2-XD can store two flash images, one in the Active area and the other in the Inactive area. The SOUP program is used to download code to the two flash areas and switch between them.

p2icimBootCodeRevision

This object displays the current boot image revision for the ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.25

p2icimFtpServerAddr**WARNING:**

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

Use this object to set the remote FTP server IP address for the download in the form 172.18.1.11. When the ICIM2 or ICIM2-XD receives a request to start the file transfer process via p2icimDownLdCmd, this string will be accessed for the remote IP address.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.26

p2icimFtpUsername**WARNING:**

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

Use this object to set the remote username for the FTP server. If the object does not contain a value, a get will display “Not set.” For security reasons, if the username is entered and a get operation is requested, “Set” will display rather than the actual entry.

The p2icimFtpUsername may contain up to 31 characters. When the ICIM2 or ICIM2-XD receives a request to start the file transfer process via p2icimDownLdCmd, this string will be accessed for the remote username.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.27

p2icimFtpPassword**WARNING:**

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

Use this object to set the remote password for the FTP server. If the object does not contain a value, a get operation will display “Not set.” For security reasons, if the password is entered and a get operation is requested, “Set” will display rather than the actual entry.

The p2icimFtpPassword may contain up to 31 characters. When the ICIM2 or ICIM2-XD receives a request to start the file transfer process via p2icimDownLdCmd, this string will be accessed for the remote password when the ICIM2 or ICIM2-XD logs into the FTP server.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.28

p2icimDownLdDir**WARNING:**

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

Use this object to set the remote directory path (excluding filename) on the FTP server where the download file exists. The p2icimDownLdDir may contain up to 127 printable characters. When the ICIM2 or ICIM2-XD receives a request to start the file transfer process via p2icimDownLdCmd, this string will be accessed for the remote path (without the filename).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.29

p2icimDownLdFilename**WARNING:**

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

Use this object to set the remote filename of the release file on the FTP server where the download file exists. The p2icimDownLdFilename may contain up to 31 printable characters. When the ICIM2 or ICIM2-XD receives a request to start the file transfer process via p2icimDownLdCmd, this string will be accessed for the remote filename.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.30

p2icimDownLdCmd**WARNING:**

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

This object is used to set commands for execution by the SOUP download utility.

The table below lists all valid commands.

Command	Function
ftp-begin (1)	Ftps the file using the parameters outlined above (p2icimFtpServerAddr, p2icimFtpUsername, p2icimFtpPassword, p2icimDownLdDir, p2icimDownLdFilename) to the target indicated in p2icimDownLdTarget.
download-boot-begin (2)	Downloads the boot image from RAM to flash or from RAM to a module.
download-appl-begin (3)	Downloads an application image from RAM to flash or from RAM to a module.

Command	Function
cancel (4)	Ends the current operation. This is the initialized state of this OID.
download-exit (5)	Exits the download.
version-switch (6)	Changes the pointer for the current inactive image to become the current active image following the next reboot.
soft-reboot (7)	Initiates a firmware reboot.
hard-reboot (8)	Initiates a hardware reboot.
enable-reboot (9)	Allows the next reboot command to take effect on the ICIM2, ICIM2-XD, or module indicated in the p2icimDownLdTarget.
disable-reboot (10)	Disallows the next reboot command to take effect on the ICIM2, ICIM2-XD, or module indicated in the p2icimDownLdTarget.
download-cancel (11)	Cancels the download.
inactive (12)	Used by the ICIM2 or ICIM2-XD firmware exclusively during the download.
invalidate-image (13)	Instructs the ICIM2 or ICIM2-XD to erase its inactive image, which is done to prevent use of an application image that may be incompatible with the boot image.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.31

p2icimDownLdState

This object displays the state machine value to indicate FTP download progress. The values for the download state are set by the download software, and may be one of the following:

Value	Meaning
idle (1)	Indicates the idle state, which is also the initialized state.
ftp-in-progress (2)	Indicates that an image is being transferred to the ICIM2 or ICIM2-XD.
download-in-progress (3)	Indicates that an image is being written to flash or transferred to a module.
version-switch-in-progress (4)	Indicates that the NextImage pointer is being toggled in the ICIM2 or ICIM2-XD or a module from currentActive to currentInactive, or vice versa.
reboot-in-progress (5)	Indicates that an entity (ICIM2, ICIM2-XD, or module) is being rebooted.

Value	Meaning
reboot-enable-in-progress (6)	Indicates that an entity is being flagged for reboot.

Note: If the file being transferred is small, these states may change too quickly to be seen individually.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.32

p2icimDownLdTarget



WARNING:

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

This object identifies the ICIM2 or ICIM2-XD or module chassis and slot to upgrade with the release image, in the form of 0015 for chassis 00, slot 15. This may be the broadcast address of 9999. The target must be set before a file may be downloaded.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.33

p2icimDownLdResult

Perform a get on this object to display the result of the download as one of 47 result codes. The result codes are self-explanatory, e.g., ftp-success(200).

P2icimDownLdResult is only valid when the download state is idle.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.34

p2icimDownLdSignature

This object is used by the element management system when launching the SOUP utility for the download. Performing a get on this object returns a value generated by the ICIM2 or ICIM2-XD clock. The value of the signature is not necessarily positive. See *Remote Firmware Download Feature* (on page 283) for details.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.35

p2icimDownLdSemaphore



WARNING:

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

This object is used together with p2icimDownLdUser exclusively by the SOUP utility to prevent multiple sessions of the SOUP from accessing the ICIM2 or ICIM2-XD simultaneously. Performing a get on this object returns either 0 or a value generated by the ICIM2 or ICIM2-XD clock. The value of the semaphore is not necessarily positive. See *Remote Firmware Download Feature* (on page 283) for details.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.36

p2icimDownLdUser



WARNING:

This object is for use by the SOUP firmware download utility only. It is not intended for use by system operators.

This object is used together with p2icimDownLdSemaphore exclusively by the SOUP utility to prevent multiple sessions of the SOUP from accessing the ICIM2 or ICIM2-XD simultaneously. Performing a get on this object when it is not in use returns the value 0. See *Remote Firmware Download Feature* (on page 283) for details.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.37

p2icimCLLlcode

Use this object to set the Common Language Locator ID (CLLI) code for the ICIM2 or ICIM2-XD. The maximum length of this string is 20 alphanumeric characters.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.38

p2icimCLElcode

Use this object to view the Common Language Equipment ID (CLEI) code that is written to the ICIM2 or ICIM2-XD as part of the manufacturing process. The maximum length of this string is 20 alphanumeric characters. An example of a CLEI code is VLL4AALDAA.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.39

p2icimSelfTest

Use this object to display the results of the basic functional self-test that the ICIM2 or ICIM2-XD performs at boot-up. If the ICIM2 or ICIM2-XD passed the self-test, performing a get on this object returns the message "ICIM Self-Test Passed." If the ICIM2 or ICIM2-XD encountered one or more problems, a get on this object returns the message "ICIM Self-Test failed - Error Code" followed by a decimal representation of the hexadecimal code of the failure(s).

ICIM Test Failed	Hexadecimal Code	Decimal Value
SDRAM	0x01000001	16777217
Boot Flash	0x01000002	16777218
Application Flash	0x01000004	16777220
EEPROM	0x01000008	16777224
Real Time Clock	0x01000010	16777232
Real Time Clock Battery	0x01000020	16777248

If the ICIM2 or ICIM2-XD encounters more than one problem, the error code returned is the *sum* of the individual error codes. For example:

- If the Real Time Clock Battery failed the self-test, the error code would be 16777248 decimal or 1000020 hex.
- If the Real Time Clock Battery and the Real Time Clock both failed the self-test, the error code would be $((16 + 32) + 16777216 =)$ 16777264 decimal or $((10 + 20) + 1000000 =)$ 1000030 hex.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.40

p2icimStatusMsg

Use this object to display the most recent status or error message saved in the ICIM2 or ICIM2-XD. An example of an informational message is:

```
6 Jan 18 2006 01:12:35 PM Broadcast reboot command successful
```

In this message:

- 6 is the level, meaning notice.
- Jan. 18 2006 is the date.
- 01:12:35 PM is the time.
- "Broadcast reboot command successful" is the message text.

The importance level of a message may be one of the following: emergency (1), alert (2), critical (3), error (4), warning (5), notice (6), or general system (7).

Note: To clear p2icimStatusMsg, set p2icimStatusMsgClearKey to 1. Otherwise, the current status message will persist until replaced by a message having an equal or greater urgency level.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.41

p2icimDownLdProg



WARNING:

Accessing this object while the SOUP firmware download utility is running may interfere with the progress of the download.

Perform a get on this object to display the current download progress percentage when a new image is being transferred from RAM to flash or from RAM to a module. The SOUP utility also displays download progress to the user through a colored progress bar.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.42

p2icimClock

Perform a get on this object to return the ICIM2 or ICIM2-XD date and time in the format: 2006-1-18,9:14:8. To change the ICIM2 or ICIM2-XD clock, set this object in the format MM/DD/YY HH:MM:SS, for example: 03/02/07 08:01:01. Note that leading zeros are important.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.43

p2icimTimeZone

To add the time zone to the ICIM2 or ICIM2-XD, set p2icimTimeZone to one of the valid USA time zones using the following abbreviations:

Abbreviation	Time Zone
EST	Eastern Standard Time
EDT	Eastern Daylight Time
CST	Central Standard Time
CDT	Central Daylight Time
MST	Mountain Standard Time
MDT	Mountain Daylight Time
PST	Pacific Standard Time
PDT	Pacific Daylight Time

Abbreviation	Time Zone
AST	Alaska Standard Time
ADT	Alaska Daylight Time
HST	Hawaii-Aleutian Standard Time
HDT	Hawaii-Aleutian Daylight Time

Note: If a time zone is not entered, the default time zone "EST" appears.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.44

p2icimDateTime

This object displays the day of the week, date, time, and time zone in the format "Thu, 04 May 2006 22:43:11 EDT."

Note: If a time zone is not entered in p2icimTimeZone, the default time zone EST (Eastern Standard Time) appears.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.45

p2icimNotify

This object tracks the number of times that an ICIM MIB or Module MIB object is set through the CLI or Web Interface. The value in this object is an integer that starts at 1 when the ICIM2 or ICIM2-XD boots up, and increments each time an ICIM MIB or Module MIB object is set through the CLI or Web Interface.

If p2icimNotify reaches its maximum value of 2,147,483,647 (hexadecimal 7FFFFFFF), any further changes cause the value to return to 1 and increment again from that point. Thus, once incremented, the value of p2icimNotify only returns to 0 if the ICIM2 or ICIM2-XD is reset.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.46

p2icimStatusMsgClearKey

This object lets you control whether status messages are cleared or kept by assigning one of two possible values:

Value	Function
1	Clear status messages
2	Keep status messages

Setting the value of this object to 2 lets the user exit the object gracefully, without error messages or other impact. This setting also allows the status message to persist unless replaced by a message of the same or greater urgency level. A get on this object always returns the value 2.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.100.47

Event Log File Management

The Prisma II File Management Group (prismaIIFileMgmtGroup) is a subset of ICIM MIB objects that allows the user to transfer an event log file from the ICIM2 or ICIM2-XD to a remote computer or workstation. These objects also let users evaluate the progress of the file transfer, as well as to clear the event log, which is recommended following an event log file transfer.

The prismaIIFileMgmtGroup object identifier (OID) is 1.3.6.1.4.1.1429.1.6.2.2.13.101. This is the dot version of the full path that expands to:

iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).scientificatlanta(1429).saTerr(1).saTerrOptical(6).saTerrOpticalPrismaII(2).saPrismaIIrev2(2).saPrismaIIicim(13).prismaIIFileMgmtGroup(101).

Step-by-step procedures for transferring and clearing the event log are provided below following individual prismaIIFileMgmtGroup object descriptions.

p2icimFileMgmtCmd

This object selects the type of activity to perform: uploadLog (1) or clearLog (2). To transfer the event log to a remote PC or workstation, set p2icimFileMgmtCmd to 1. To clear all entries from the event log on the ICIM2 or ICIM2-XD and reformat it to restart logging, set p2icimFileMgmtCmd to 2.

Note: p2icimFileMgmtCmd must be set before p2icimFileMgmtAction is set (see below) in order to perform a successful event log transfer or clear action.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.1

p2icimFileMgmtAction

This object executes the event log transfer or clear action as defined by p2icimFileMgmtCmd. When p2icimFileMgmtAction is set to execute (2), the file transfer begins or the event log is cleared. Other valid values for p2icimFileMgmtAction are idle (1) and abort (3).

Note: For a successful transfer or clear action to occur, p2icimFileMgmtCmd and all other related prismaIIFileMgmtGroup MIB objects must be set before setting p2icimFileMgmtAction to execute (2). To abort an upload, set p2icimFileMgmtAction to abort (3).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.2

p2icimFileMgmtIpAdress

This object holds the destination FTP server IP address, in the format 172.240.250.1, of the remote PC or workstation to which the event log will be transferred. For file transfers, this object must be set before the command is executed.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.3

p2icimFileMgmtUsername

This object holds the FTP username for the file transfer process. The username may be up to 31 characters. Before a username is entered, a get on p2icimFileMgmtUsername returns "Not set." After a username is entered, a get on this object returns "Set." The object does not return the username itself for security reasons. For file transfers, this object must be set before the command is executed.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.4

p2icimFileMgmtPassword

This object holds the FTP password for the file transfer process. The password may be up to 31 characters. Before a password is entered, a get on p2icimFileMgmtPassword returns "Not set." After a password is entered, a get on this object returns "Set." The object does not return the password itself for security reasons. For file transfers, this object must be set before the command is executed.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.5

p2icimFileMgmtFilePath

This object holds the full path (minus the filename) where the event log should be stored on the remote PC or workstation. The path may be up to 127 characters, and may be of zero length. For file transfers, this object must be set before the command is executed. A path of zero length implies the FTP server directory on the remote machine.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.6

p2icimFileMgmtFileName

This object holds the name of the event log file following upload to the remote system. The filename may be up to 31 characters in length, including an optional file extension; for example, event1024.log. For file transfers, this object must be set before the command is executed.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.7

p2icimFileMgmtXferSize

This object holds the size in bytes of the file to be transferred from the ICIM2 or ICIM2-XD. This information is supplied by the underlying file transfer program, and may be used together with p2icimFileMgmtXferBytes to calculate the progress of the file transfer process (see below).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.8

p2icimFileMgmtXferBytes

This object holds the number of bytes of the file that have been transferred so far. This information is supplied by the underlying file transfer program, and may be used together with p2icimFileMgmtXferSize to calculate the progress of the file transfer process (see below).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.9

p2icimFileMgmtResult

This object holds a value representing the progress or result of the file transfer, which is provided by the underlying file transfer program. The possible values for p2icimFileMgmtResult are listed below.

- unknown (1)
- idle (2)
- active (3)
- complete (4)
- failed (5)
- aborting (6)
- aborted (7)

Note: If no files have been transferred, the value displays as idle (2).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.101.10

To Transfer an Event Log File

Complete the following steps to execute an event log file transfer.

- 1 Set the following MIB objects in the file management group:
 - p2icimFileMgmtUsername - file transfer FTP username
 - p2icimFileMgmtPassword - file transfer FTP password
 - p2icimFileMgmtIpAdress - destination IP address
 - p2icimFileMgmtFilePath - destination path omitting file name
 - p2icimFileMgmtFileName - destination file name only
- 2 Set p2icimFileMgmtCmd to upload (1).
- 3 Set p2icimFileMgmtAction to execute (2).

The event log file immediately starts to transfer via FTP (File Transfer Protocol) to the designated remote IP address. This implies that an active FTP server is running on the remote machine.

To Calculate File Transfer Progress

Complete the following steps to calculate progress at any point during the file transfer process.

- 1 Get the current values of p2icimFileMgmtXferSize and p2icimFileMgmtXferBytes.
- 2 Divide the value of p2icimFileMgmtXferBytes by the value of p2icimFileMgmtXferSize.
- 3 Multiply by 100. The result is the percentage of the file size transferred so far.

To Clear the Event Log File

Complete the following steps to clear the event log.

- 1 Set p2icimFileMgmtCmd to clearEventlog (2).
- 2 Set p2icimFileMgmtAction to execute (2).

After clearing the event log, logging will restart with the formatting of a new event log and a single entry in the log noting the clear action.

SNTP Time Synchronization

Synchronized Network Time Protocol (SNTP) enables the ICIM2 or ICIM2-XD to synchronize its real-time clock (RTC) with a Network Time Protocol (NTP) server. SNTP time synchronization is disabled by default, and must be enabled using SNMP or CLI commands.

SNTP time synchronization works in either of two modes: unicast or broadcast. In unicast mode, the ICIM2 or ICIM2-XD requests the time from an NTP server at regular intervals. In broadcast mode, the ICIM2 or ICIM2-XD receives the time from a designated NTP server at regular intervals. This section describes the MIB objects used to select unicast vs. broadcast mode and related SNTP operating parameters.

Important:

- SNTP and network management system (NMS) time synchronization are mutually incompatible. Before enabling the SNTP feature on the ICIM2 or ICIM2-XD, be sure to disable NMS time synchronization, and vice versa.
- The NTP server delivers the time in Coordinated Universal Time (UTC), which the ICIM2 or ICIM2-XD converts to local time. Be sure to set the time zone on the ICIM2 or ICIM2-XD; otherwise, the ICIM2 or ICIM2-XD uses the default Eastern Standard Time (EST) to calculate local time.
- In order for SNTP clock updates to work properly, the time zone must be set correctly before enabling SNTP time synchronization in the ICIM2 or ICIM2-XD.
- Before changing other SNTP settings, the SNTP state must be set to disabled (2). After changing these settings, be sure to reset the SNTP state to enabled (1) to activate the ICIM2 or ICIM2-XD SNTP task with the new parameters.

The SNTP Client group is a subset of ICIM MIB objects that allows the user to configure appropriate SNTP parameters. The SNTP Client group object identifier is 1.3.6.1.4.1.1429.1.6.2.2.13.102. This is the dot version of the full path that expands to:

iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).scientificatlanta(1429).saTerr(1).saTerrOptical(6).saTerrOpticalPrismaII(2).saPrismaIIrev2(2).saPrismaII(13).prismaIISNTPClient(102).

SNTP Configuration Procedure

To request synchronization with the NTP server, you will complete the following steps:

- 1 Be sure that the SNTP state is disabled (2).
- 2 Set p2icimSNTPmode to unicast (1) or broadcast (2) (the default) as appropriate.
- 3 Set p2icimSNTPtimeout to a suitable value from 5 (the default) to 60 seconds.
- 4 Set p2icimSNTPIPaddress to the IP address of the designated NTP server.
- 5 Set p2icimSNTPinterval to a suitable value from 1 (the default) to 168 hours.
- 6 Set the SNTP state to enabled (1) to activate SNTP settings.

The parameters for requesting SNTP time synchronization are further described below. All parameters are stored in non-volatile memory, so they do not need to be reset following ICIM2 or ICIM2-XD reboots.

Note: The same sequence of steps can be performed using CLI commands, as described in the *Prisma II Platform Remote User Interface Guide, System Release 2.03*, part number 4025477.

p2icimSNTPmode

This object selects the mode for SNTP operation: unicast (1) or broadcast (2). The default is broadcast (2). To have the ICIM2 or ICIM2-XD request time from the NTP server, set p2icimSNTPmode to unicast (1). To have the ICIM2 or ICIM2-XD wait to receive time from the NTP server, set p2icimSNTPmode to broadcast (2).

Note: Before changing this setting, be sure that p2icimSNTPstate is set to disabled (2). Then, set p2icimSNTPstate to enabled (1) to activate SNTP settings.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.102.1

p2icimSNTPtimeout

This object specifies the timeout interval for unicast mode. This is the time period that the ICIM2 or ICIM2-XD waits for a response from the NTP server after requesting the time. The timeout interval is expressed in seconds as a whole-number value in the range 5 to 60. The default is 5 seconds.

The timeout interval for broadcast mode is fixed at 20 minutes. This is the time period that the ICIM2 or ICIM2-XD listens for an NTP broadcast after each user-defined interval.

Note: Before changing this setting, be sure that p2icimSNTPstate is set to disabled (2). Then, set p2icimSNTPstate to enabled (1) to activate SNTP settings.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.102.2

p2icimSNTPIPAddress

This object holds the IP address of the designated NTP server. The address must be in the format ###.###.###.###, for example, 123.3.23.12.

Note: Before changing this setting, be sure that p2icimSNTPstate is set to disabled (2). Then, set p2icimSNTPstate to enabled (1) to activate SNTP settings.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.102.3

p2icimSNTPinterval

This object sets the time interval between consecutive synchronization requests in either unicast (requesting time) or broadcast mode (waiting to receive time).

For example, if p2icimSNTPinterval is set to 24 hours:

- The ICIM2 or ICIM2-XD in unicast mode will request the time from the NTP server. When the ICIM2 or ICIM2-XD gets the time and synchronizes its real-time clock, it will wait 24 hours before requesting the time again.

- The ICIM2 or ICIM2-XD in broadcast mode will listen for an NTP broadcast for up to 20 minutes. When it receives the time and synchronizes the real-time clock, it will wait 24 hours before listening for another NTP broadcast.

This polling interval is expressed in hours as a whole-number value in the range 1 to 168 (1 week). The default is 1 hour.

Note: Before changing this setting, be sure that p2icimSNTPstate is set to disabled (2). Then, set p2icimSNTPstate to enabled (1) to activate SNTP settings.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.102.4

p2icimSNTPstate

This object defines the current state of the SNTP client as either enabled (1) or disabled (2). The default is disabled (2). Be sure to disable the SNTP client before changing any other SNTP settings, and to enable the SNTP client when ready to activate SNTP settings.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.102.5

p2icimSNTPlastUpdate

This object holds the time stamp indicating the last time the ICIM2 or ICIM2-XD was synchronized with the NTP server, in the format yyyy-mm-dd, hh:mm:ss.0. For example, 2007-2-6,13:48:16.0.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.102.6

Trap Handling

The Prisma II Trap Handling Group (prismaIItrap) is a subset of ICIM MIB objects that allows users to configure trap receiver properties. These objects also let users review the history of traps generated by the ICIM2 or ICIM2-XD.

The prismaIItrap object identifier (OID) is 1.3.6.1.4.1.1429.1.6.2.2.13.200. This is the dot version of the full path that expands to:

iso(1).org(3).dod(6).internet(1).private(4).enterprise(1).scientificatlanta(1429).saTerr(1).saTerrOptical(6).saTerrOpticalPrismaII(2).saPrismaIIrev2(2).saPrismaII(13).PrismaIItrap(200).

Trap Recv Table

Through setting the objects in the Trap Recv table, you enable traps to be sent to the IP addresses of up to 10 different receivers or targets. The index into the table represents one of 10 rows, designated 0 to 9.

To Receive Traps

Complete the following steps to receive traps.

- 1 Set p2TrapRecvEnable to enabled (2).
- 2 Set the IP address, in the format 172.18.2.24, of the remote entity to receive traps.
- 3 Set p2TrapRecvTelcoAlarm to enabled (2).

Instance	p2TrapRecvIndex(IDX)	p2TrapRecvEnable	p2TrapRecvAddr	p2TrapRecvIP	Command	p2TrapRecvSelfTest	p2TrapRecvTelcoAlarm
0	0	enabled(2)	172.18.50.42	enabled(2)		disabled(1)	enabled(2)
1	1	enabled(2)	172.18.50.3	enabled(2)		disabled(1)	enabled(2)
2	2	enabled(2)	172.18.50.6	enabled(2)		disabled(1)	enabled(2)
3	3	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
4	4	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
5	5	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
6	6	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
7	7	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
8	8	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
9	9	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)

TP490

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Specific OIDs for the Trap Recv Table (1.3.6.1.4.1.1429.1.6.2.2.13.200.8) follow.

p2TrapRecvIndex

This object holds the index into a row of the p2TrapRecvEntry table. It has an integer value from 0 to 9.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.1

p2TrapRecvEnable

The value in this object enables or disables the complete row. If disabled (1), even though there may be a valid remote IP address saved in the row and traps may be enabled (2) in the row, traps will not be sent to this IP address. To enable the row, set p2TrapRecvEnable to enabled (2).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.2

p2TrapRecvAddr

To change this object from its initialized state, enter a valid IP address in the format 172.24.18.2, indicating the PC or workstation to which traps will be sent.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.3

p2TrapRecvIPChange

To receive a trap when the IP address of the ICIM2 or ICIM2-XD is changed, set p2TrapRecvIpChange to enabled (2). Disabled (1) is the default.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.4

p2TrapRecvModuleInsert

To receive a trap when a module is inserted into any chassis managed by this ICIM2 or ICIM2-XD, set p2TrapRecvModuleInsert to enabled (2). Disabled (1) is the default.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.5

p2TrapRecvModuleRemove

To receive a trap when a module is removed from any chassis managed by this ICIM2 or ICIM2-XD, set p2TrapRecvModuleRemove to enabled (2). Disabled (1) is the default.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.6

p2TrapRecvMinorAlarm

Set this object to enable or disable sending traps to the SNMP manager when a minor alarm in a module changes state. The user may choose to receive minor alarm traps never (1), only when cleared (2), only when set (3), or "always," i.e., when set or cleared (4).

This trap is edge triggered, meaning that it is sent if there is a change in a monitored value that causes it to go into or out of a state of minor alarm. If p2TrapRecvEnable is set to disabled (1), traps will not be sent.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.7

p2TrapRecvMajorAlarm

Set this object to enable or disable sending traps to the SNMP manager when a major alarm in a module changes state. The user may choose to receive minor alarm traps never (1), only when cleared (2), only when set (3), or "always," i.e., when set or cleared (4).

This trap is edge triggered, meaning that it is sent if there is a change in a monitored value that causes it to go into or out of a state of major alarm. If p2TrapRecvEnable is set to disabled (1), traps will not be sent.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.8

p2TrapRecvDwnLdComplete

Set this object to enable (2) or disable (1) sending traps following a download to the ICIM2, ICIM2-XD, or module. Disabled (1) is the default.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.9

p2TrapRecvRebootCommand

Set this object to enable (2) or disable (1) sending traps following a reboot command to the ICIM2 and/or module(s). Disabled (1) is the default.

If the reboot command is broadcast to all modules and the ICIM2 or ICIM2-XD, only one broadcast reboot trap will be generated.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.10

p2TrapRecvSelfTest

Set this object to enable (2) or disable (1) sending traps following an ICIM2, ICIM2-XD, or module self-test failure. Disabled (1) is the default.

Specific self-test error code values are enumerated under **p2icimSelfTest** and **p2moduleSelfTest**.

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.11

p2TrapRecvTelcoAlarm

Set this object to enable (2) or disable (1) sending traps following an ICIM2, ICIM2-XD, or module alarm or event. Disabled (1) is the default, but enabled (2) is the normal operating setting to receive traps.

The Enhanced traps generate the most information concerning the condition causing the alarm or event. Bindings for the Enhanced traps are detailed in *Enhanced Trap Binding Information* (on page 253).

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8.1.12

Note: All trap settings are documented for completeness. Information contained in this trap is expanded upon in the Enhanced trap. Where practical, we recommend using the Enhanced trap as it is more useful. Enabling this trap and the Enhanced trap together will cause two traps to be sent for each triggering event. For more information, see *Prisma II Traps* (on page 239).

Trap Logging Auxiliaries

p2TrapLastSequenceNumber

To observe the most current sequence number used by the Enhanced traps, perform a get operation on this object. If no traps have been sent, the p2TrapLastSequenceNumber is 0. Valid sequence numbers are 1 through 2,147,483,647. The sequence number resets to 0 at startup or ICIM2 or ICIM2-XD reboot, or if the p2TrapLogEntry table is cleared with the p2TrapLogClearKey. The first trap sent after the sequence number resets will have the sequence number 1. If incremented past 2,147,483,647, the sequence number wraps to 1 again.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.1

p2TrapLogClearKey

To clear the p2TrapLogEntry table, set p2TrapLogClearKey to clear (1). The next Enhanced trap generated will start with sequence number 1, and be copied to the Trap Log table to start populating it again. To continue to send traps without restarting the sequencing, and continue to save them in the trap log table without first clearing it, set p2TrapLogClearKey to keep (2). This OID will return Keep Logging (2) when a get operation is performed.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.2

Trap Logging Table

The Trap Logging table serves as an aid to tracking by keeping a copy of up to 1,000 traps. When this table becomes full, it makes space for new trap records by deleting the oldest trap records from the table.

To activate trap logging, you configure and enable at least one row in p2TrapRecvTable. If p2TrapRecvTelcoAlarm is also enabled (2), traps are logged automatically. The trap sequence number serves as the index into the Trap Logging table.

A disruption in the network connectivity of the ICIM2 or ICIM2-XD does not mean that a trap is lost. A copy of each Enhanced trap generated is saved in the Trap Logging table, and can be retrieved using the trap sequence number.

Elements of the Trap Logging table line up with trap bindings. For more information regarding the bindings, see *Enhanced Trap Binding Information* (on page 253).

The figure below shows how the Trap Logging table might appear when displayed in a MIB browser.

Instance	p2TrapLogSequenceID	p2TrapLogSeverity	p2TrapLogState	p2TrapLogLabel	p2TrapLogOID	p2TrapLogText	p2TrapLogChassisID	p2TrapLogSlotID	p2TrapLogCLLcode	p2TrapLogCLEIcode	p2TrapLogTime	p2TrapLogDateTime	p2TrapLogValue	p2TrapLogUnit	p2TrapLogDescr
1	1	minor(2)	alarm(1)	InRF	p2almIndex.1.2.3	Module=HDTx, Model=1020	1	2	N/A	N/A	2007-11-27 10:8:42.75	Tue, 27 Nov 2007 10:08:42 EST	-13.2618	dB	InRF exceeded minor threshold
2	2	minor(2)	alarm(1)	InRF	p2almIndex.1.3.3	Module=HDTx, Model=1020	1	3	N/A	N/A	2007-11-27 10:8:44.50	Tue, 27 Nov 2007 10:08:44 EST	-13.8482	dB	InRF exceeded minor threshold
3	3	minor(2)	alarm(1)	InRF	p2almIndex.1.4.3	Module=HDTx, Model=1020	1	4	N/A	N/A	2007-11-27 10:8:45.05	Tue, 27 Nov 2007 10:08:45 EST	-12.9802	dB	InRF exceeded minor threshold
4	4	major(1)	alarm(1)	InRF	p2almIndex.1.5.3	Module=HDTx, Model=1032	1	5	N/A	N/A	2007-11-27 10:8:47.20	Tue, 27 Nov 2007 10:08:47 EST	50	dB	RF input exceeds major threshold
5	5	minor(2)	alarm(1)	InRF	p2almIndex.1.7.3	Module=HDTx, Model=1032	1	7	N/A	N/A	2007-11-27 10:8:49.78	Tue, 27 Nov 2007 10:08:49 EST	50	dB	RF input exceeds minor threshold
6	6	minor(2)	alarm(1)	InRF	p2almIndex.1.8.3	Module=HDTx, Model=1032	1	8	N/A	N/A	2007-11-27 10:8:51.10	Tue, 27 Nov 2007 10:08:51 EST	50	dB	RF input exceeds minor threshold
7	7	minor(2)	alarm(1)	InRF	p2almIndex.1.9.3	Module=HDTx, Model=1032	1	9	N/A	N/A	2007-11-27 10:8:52.41	Tue, 27 Nov 2007 10:08:52 EST	50	dB	RF input exceeds minor threshold
8	8	minor(2)	alarm(1)	InRF	p2almIndex.1.10.3	Module=HDTx, Model=1032	1	10	N/A	N/A	2007-11-27 10:8:53.70	Tue, 27 Nov 2007 10:08:53 EST	50	dB	RF input exceeds minor threshold
9	9	minor(2)	alarm(1)	InRF	p2almIndex.1.11.3	Module=HDTx, Model=1032	1	11	N/A	N/A	2007-11-27 10:8:55.1	Tue, 27 Nov 2007 10:08:55 EST	50	dB	RF input exceeds minor threshold
10	10	minor(2)	alarm(1)	InRF	p2almIndex.1.12.3	Module=HDTx, Model=1032	1	12	N/A	N/A	2007-11-27 10:8:56.33	Tue, 27 Nov 2007 10:08:56 EST	50	dB	RF input exceeds minor threshold
11	11	minor(2)	alarm(1)	InRF	p2almIndex.1.13.3	Module=HDTx, Model=1032	1	13	N/A	N/A	2007-11-27 10:8:57.05	Tue, 27 Nov 2007 10:08:57 EST	50	dB	RF input exceeds minor threshold
12	12	minor(2)	alarm(1)	InRF	p2almIndex.1.14.3	Module=HDTx, Model=1032	1	14	N/A	N/A	2007-11-27 10:8:58.96	Tue, 27 Nov 2007 10:08:58 EST	50	dB	RF input exceeds minor threshold
13	13	minor(2)	alarm(1)	InRF	p2almIndex.1.16.3	Module=HDTx, Model=1032	1	16	N/A	N/A	2007-11-27 10:9:1.56	Tue, 27 Nov 2007 10:09:01 EST	50	dB	RF input exceeds minor threshold
14	14	major(1)	alarm(1)	InPwr	p2almIndex.2.1.1	Module=P2-HD-FDF, Model=2015	2	1	N/A	N/A	2007-11-27 10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	-21.2668	dBm	InPwr exceeded major threshold
15	15	minor(2)	alarm(1)	Alarm	p2almIndex.2.1.4	Module=P2-HD-FDF, Model=2015	2	1	N/A	N/A	2007-11-27 10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	N/A	N/A	Alarm exceeded major threshold
16	16	major(1)	alarm(1)	InPwr	p2almIndex.2.2.1	Module=P2-HD-FDF, Model=2015	2	2	N/A	N/A	2007-11-27 10:9:6.30	Tue, 27 Nov 2007 10:09:06 EST	-21.3549	dBm	InPwr exceeded major threshold
17	17	minor(2)	alarm(1)	InPwr	p2almIndex.2.2.1	Module=P2-HD-FDF, Model=2015	2	2	N/A	N/A	2007-11-27 10:9:6.30	Tue, 27 Nov 2007 10:09:06 EST	-21.3549	dBm	InPwr exceeded major threshold

The table below shows sample entries for each element of the Trap Logging table. The elements themselves are described in this section.

Trap Log Element	Entry 10	Entry 14
p2TrapLogSequence	10	14
p2TrapLogSeverity	minor (2)	major (1)
p2TrapLogState	alarm (1)	alarm (1)
p2TrapLogLabel	InRF	InPwr
p2TrapLogOID	p2almIndex.1.12.3	p2almIndex.2.1.1
p2TrapLogText	Module=HDTx, Model=1032	Module=P2-HD-RXF, Model= 2015
p2TrapLogChassisID	1	2
p2TrapLogSlotID	12	1
p2TrapLogCLLcode	N/A	N/A
p2TrapLogCLEIcode	N/A	N/A
p2TrapLogTime	2007-11-27, 10:8:56.33	2007-11-27, 10:9:4.75
p2TrapLogDateTime	Tue, 27 Nov 2007 10:08:56 EST	Tue, 27 Nov 2007 10:09:04 EST
p2TrapLogValue	-50	-21.2668
p2TrapLogUnit	dB	dBm
p2TrapLogDescr	RF input exceeds minor threshold	InPwr exceeds major threshold

Specific OIDs for the Trap Log Table (1.3.6.1.4.1.1429.1.6.2.2.13.200.20) follow.

p2TrapLogSequence

This object holds a unique number assigned to each trap as it is generated. This serves as an index into the Trap Logging table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.1

p2TrapLogSeverity

This object holds the severity value, which assists in assigning priority to trap generating conditions. Severity may be major (1), minor (2), or warning (3).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.2

p2TrapLogState

This object holds the state value which, together with severity, quickly gives a view into the current condition of the ICIM2, ICIM2-XD, or application module. State may be alarm (1), clear (2), or event (3).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.3

p2TrapLogLabel

This object holds the trap log label. For an alarm or clear trap, the label must be the same as the p2almLabel assigned to the condition which caused the trap; for example, ChasTemp. For events, the value of this object indicates the type of event that occurred and caused the trap to be sent, and may be one of the following:

- DownloadComplete (reserved for future use)
- RebootCommand
- SelfTest
- AuthentictnFailed
- AdminChange
- LogMemHalfFull
- LogMemoryFull
- LoginThreshold
- SNTP (reserved for future use)
- UpdateChassisID

- UserLockout

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.4

p2TrapLogOID

This object holds details regarding the condition that generated the trap. For an alarm or clear trap, this may be the third index into the Module Alarm table. For the download or reboot, this may be the p2icimStatusMessage. However, only the most recent status message is retained by the ICIM2 or ICIM2-XD. If a message from another event overwrites the status message, additional information may no longer be available at the OID specified for the particular trap. If an event is logged, details about the event may be saved in the event log.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.5

p2TrapLogText

This object holds a string that further describes the entity or condition responsible for trap generation. This usually is a concatenation of the module name and model number, although it may include the self-test failure code.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.6

p2TrapLogChassisID

The value in this object identifies the chassis in which the ICIM2, ICIM2-XD, or application module resides at the time of trap generation.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.7

p2TrapLogSlotID

This object holds the slot number in which the ICIM2, ICIM2-XD, or application module resides at the time of trap generation.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.8

p2TrapLogCLLlcode

This object is reserved for future use.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.9

p2TrapLogCLEIcode

This object is reserved for future use.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.10

p2TrapLogTime

This object holds a date and time stamp indicating when the trap was generated.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.11

p2TrapLogDateTime

This object displays the full local time in the format: Tue, 27 Nov 2007 10:08:56 EST. The local time zone must be entered in p2icimTimeZone or the default time zone, EST, will always show.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.12

p2TrapLogValue

This object holds the most recent monitored value associated with the object in alarm or clear state.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.13

p2TrapLogUnit

The value in this object indicates the unit of measure for the value in p2TrapLogValue.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.14

p2TrapLogDescr

This object holds a verbose description of the alarm.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.20.1.15

Module MIB

The module MIB consists of several tables indexed by the chassis and slot numbers of the modules managed by the ICIM2 or ICIM2-XD. A third index into a table may be necessary at times to create a unique instance, as further explained in *Module Alarm Table* (on page 220).

Module MIB Tables

The module MIB includes the following tables:

- p2moduleTable
- p2moduleAlarmTable
- p2moduleCurrentAlarmTable
- p2moduleMonitorTable
- p2moduleControlTable
- p2InsertModuleTable
- p2RemoveModuleTable

The contents of each module MIB table are described below.

Table Name	Table Contents
Module Table	Basic manufacturing features and firmware download data for each module.
Module Alarm Table	Status of each module with regard to alarm thresholds and nominal values. See <i>Module Alarm Table</i> (on page 220) for further information.
Module Current Alarm Table	Records the module elements in major or minor alarm at a given time.
Module Monitor Table	Contains monitored module values.
Module Control Table	Contains module controls that may be adjusted.
Insert Module Table	Chassis and slot number of each module inserted after the ICIM2 or ICIM2-XD initially polls the chassis.
Remove Module Table	Chassis number, slot number, and other information on each module removed from a chassis controlled by this ICIM2 or ICIM2-XD.

p2moduleNumber

This object shows the total number of active modules that have data in the Module table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.1

Module Table

The Module table contains information regarding each of the modules managed by the ICIM2 or ICIM2-XD. It is indexed by the chassis and slot number where the module currently resides.

The p2moduleTable OID is: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.

Rows in the table are accessed via p2moduleEntry.

The p2moduleEntry OID is: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.

The figure below shows how the Module table might appear when displayed in a MIB browser.

Instance	p2chassisID	p2slotID	p2smcAddress	p2moduleType	p2nextImage	p2activeCodeRevision	p2inactiveCodeRevision	p2moduleDownloadable	p2moduleSelfTest	p2FantryPS rpm
1.0	1	0	100	5020	currentActi...	1.01.04	91.01.04	yes(1)	Passed	no(2)
1.1	1	1	101	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
1.15	1	15	115	1032	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
2.0	2	0	200	5020	currentActi...	1.01.04	91.01.04	yes(1)	Passed	no(2)
2.3	2	3	203	2015	currentActi...	1.01.11	91.01.11	yes(1)	Passed	not-applicable(3)
2.12	2	12	212	2015	currentActi...	1.01.11	91.01.11	yes(1)	Passed	not-applicable(3)
3.0	3	0	300	5020	currentActi...	1.01.04	91.01.04	yes(1)	Passed	no(2)
3.2	3	2	302	2014	currentActi...	1.01.09	91.01.09	yes(1)	Passed	not-applicable(3)
3.6	3	6	306	2011	currentActi...	1.01.08	91.01.08	yes(1)	Passed	not-applicable(3)
3.11	3	11	311	2014	currentActi...	1.01.09	91.01.09	yes(1)	Passed	not-applicable(3)
3.16	3	16	316	2011	currentActi...	1.01.08	91.01.08	yes(1)	Passed	not-applicable(3)
98.0	98	0	9800	5020	currentActi...	1.01.04	91.01.04	yes(1)	Passed	no(2)
98.4	98	4	9804	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.5	98	5	9805	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.9	98	9	9809	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.10	98	10	9810	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.11	98	11	9811	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.13	98	13	9813	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.14	98	14	9814	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)
98.15	98	15	9815	1020	not-applica...	N/A	N/A	no(2)	N/A	not-applicable(3)

The table below shows sample entries for each element of the Module table. The elements themselves are described in this section.

Module Table	First Module Entry	Second Module Entry
p2chassisID	1	1
p2slotID	0	1
p2smcAddress	100	101
p2moduleType	5020	1020
p2moduleName	XD-Chassis	HDTx
p2manufactureData		3dBm TxTS 1310 nm
p2dateCode	M07	H07
p2serialNumber	^ABCDEFGF	^MMAAFEFJ
p2coreCodeRevision	CF_CCB3	155
p2scriptRevision	N/A	1

Module Table	First Module Entry	Second Module Entry
p2timeOfService	744	1633
p2numOfMonitoredVars	14	7
p2numOfAnalogControls	0	1
p2numOfDigitalControls	2	5
p2numOfControls	2	6
p2numOfAlarms	12	7
p2NextImage	currentActive (1)	not-applicable (3)
p2activeCodeRevision	1.01.04	N/A
p2inactiveCodeRevision	91.01.04	N/A
p2bootCodeRevision	0.00.03	N/A
p2moduleCLLcode	N/A	N/A
p2moduleCLEIcode	N/A	N/A
p2moduleDownloadable	yes (1)	no (0)
p2moduleSelfTest	Passed	N/A
p2FantrayPSsplit	no (2)	not-applicable (3)

p2chassisID

This object identifies the chassis number in which the module is installed. The value in this object provides one index into the Module table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.1

p2slotID

This object identifies the slot number in which the module is currently installed. The value in this object provides one index into the Module table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.2

p2smcAddress

This object reports the module status monitoring and control (SMC) address, which is the chassis number times 100, plus the slot number of this module. For example, a module in chassis 1 slot 1 would have a p2smcAddress of 101.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.3

p2moduleType

This object holds a number assigned during the manufacturing process to uniquely identify this type of module. This is also referred to as the **devtype** or TNCS type number.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.4

p2moduleName

This object holds the name assigned to modules of this particular type.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.5

p2manufactureData

This object holds a string of manufacturing data, which can be up to 30 characters in length.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.6

p2dateCode

This object holds the date code, which is a string consisting of three characters. A letter specifies the month, and a two-digit number specifies the year this module was manufactured and tested. The following letters are used to specify the month:

Letter	Month
A	January
B	February
C	March
D	April
E	May
F	June
G	July
H	August
J	September
K	October
L	November
M	December

Example: M07 = December 2007

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.7

p2serialNumber

The value in this object designates the module serial number.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.8

p2coreCodeRevision

The value in this object is CF_CCB3 for downloadable CCBs designed to interface with the ICIM2 or ICIM2-XD.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.9

p2scriptRevision

This object is deprecated in the downloadable modules, which do not use scripts. It is retained for compatibility with previous versions of the modules, which still use scripts.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.10

p2timeOfService

This object reports the number of hours this module has been in service. The value is updated every hour for the first 120 hours, and every 12 hours up to 120,000.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.11

p2numOfMonitoredVars

The value in this object represents the total number of monitored variables for this module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.12

p2numOfAnalogControls

The value in this object represents the total number of analog variables for this module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.13

p2numOfDigitalControls

The value in this object represents the total number of digital and state controls for this module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.14

p2numOfControls

The value in this object represents the total number of control variables for this module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.15

p2numOfAlarms

The value in this object represents the total number of alarm variables for this module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.16

p2NextImage

The value in this object represents the firmware image to be active following the module reboot. Options are currentActive (1), currentInactive (2), or not applicable (3).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.17

p2activeCodeRevision

The value in this object represents the version of the firmware active for this module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.18

p2inactiveCodeRevision

This object is reserved for future use.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.19

p2bootCodeRevision

The value in this object represents the current boot image revision for the module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.20

p2moduleCLLlcode

This object is reserved for future use.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.21

p2moduleCLElcode

This object is reserved for future use.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.22

p2moduleDownloadable

The value in this object indicates whether the module supports firmware downloads. The value may be either yes (1) or no (2).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.23

p2moduleSelfTest

This object displays the results of the basic functional self-test that the module performs at boot-up or when inserted into a chassis slot. If the module passed the self-test, performing a get on this object returns the message "Self-Test Passed." If the module encounters one or more problems, the message "Self-Test failed - Error Code" is returned followed by a decimal representation of the hexadecimal code of the failure(s).

Self-Test Error Codes: Prisma II Platform

The following error codes are used for the Prisma II Fan Tray, Pre-Amplifier, Post-Amplifier, and Optical Switch modules.

Modules Test Failed	Hexadecimal Code	Decimal Value
Flash bank 1 CRC	0x2000001	33554433
Flash bank 2 CRC	0x2000002	33554434
ColdFire RAM	0x2000004	33554436

Flash bank 0 CRC	0x2000008	33554440
EEPROM read	0x2000010	33554448
EEPROM write	0x2000020	33554464
EEPROM write-protect	0x2000040	33554496
SPI BUS	0x2000080	33554560
Local Craft Interface port	0x2000100	33554688
ICIM 485 port	0x2000200	33554944
Local Debug port	0x2000400	33555456
CAN BUS	0x2000800	33556480
Analog to Digital	0x2001000	33558528
Digital to Analog	0x2002000	33562624
IO	0x2004000	33570816
Power Supply	0x2008000	33587200

Self-Test Error Codes: Prisma II XD Platform

The following error codes are used for the Prisma II XD client control board, fan assembly, AC-to-DC bulk power supplies, DC-to-DC converters, ICIM2 or ICIM2-XD, and installed application modules.

Modules Test Failed	Hexadecimal Code	Decimal Value
Flash bank 1 CRC	0x2000001	33554433
Flash bank 2 CRC	0x2000002	33554434
ColdFire RAM	0x2000004	33554436
Flash bank 0 CRC	0x2000008	33554440
EEPROM read	0x2000010	33554448
EEPROM write	0x2000020	33554464
EEPROM write-protect	0x2000040	33554496
SPI BUS	0x2000080	33554560
Local Craft Interface port	0x2000100	33554688
ICIM2 485 port	0x2000200	33554944
Local Debug port	0x2000400	33555456
CAN BUS	0x2000800	33556480
Analog to Digital	0x2001000	33558528
Digital to Analog	0x2002000	33562624
IO	0x2004000	33570816

Power Supply	0x2008000	33587200
--------------	-----------	----------

If self-test discovers more than one problem, the error code returned is the *sum* of the individual error codes. For example:

- If the power supply on a pre-amplifier failed, the error code displayed would be 33587200 in decimal (2008000 hex).
- If the power supply and the write to the EEPROM failed on a post-amplifier module self-test, the error code would be $((32768 + 32) + 33554432 =) 33587232$ decimal or $((8000 + 20) + 2000000 =) 2008020$ hex.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.24

p2FantrayPSsplit

Note: This object pertains to the Prisma II Platform chassis only.

The value in this object tells the NMS how to interpret alarms that originate from a fan tray, power supply, or application module. This information is important in establishing the actual origin of fan tray and power supply alarms for troubleshooting purposes.

The fan tray manages alarms for the fan tray as well as for the power supply modules in slot 1 and slot 3. The ICIM2 with Release 1.00 firmware associates fan tray, power supply 1, and power supply 3 alarms with a single logical chassis slot location (slot 3). The NMS must then remap the alarms to physical chassis slot locations in order to indicate the actual origin of the alarm.

In a chassis with an ICIM2 at Release 2.00 or later and a fan tray at Release 1.01 or later firmware, these alarms are reported as originating from their respective physical chassis slot locations. This makes it unnecessary for the NMS to remap fan tray and power supply alarms to chassis slot locations.

However, due to the potential mix of 1.00 and 1.01 fan trays in the field, the NMS must be told when to remap alarms to physical slot locations for a particular chassis. The p2FantrayPSsplit element performs this function. It has three possible values:

Value	Meaning
Yes (1)	This module is a newer fan tray (DevType 5012) or power supply (DevType 5013) with split data. Therefore, the data is only for the particular module (fan tray or power supply) you are viewing. The NMS does not need to perform slot remapping.
No (2)	This module is an older fan tray-power supply combination (DevType 5010) with unsplit data. Therefore, the data needs to be separated into fan tray, power supply 1, and power supply 3. The NMS needs to perform slot remapping.
Not Applicable (3)	This module is neither a power supply nor a fan tray module.

The default value of 3 (not applicable) tells the NMS that the module in alarm is neither the fan tray nor a power supply, making the issue moot. A value of 1 (Yes) means that the alarms are split by module, so alarm remapping is not needed. A value of 2 (No) means that the alarms are not split, so remapping is required.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.2.1.25

Module Alarm Table

Currently, the alarms in the Module Alarm table and the corresponding traps generated by the alarm (or clear) condition are reported as Major or Minor with respect to severity level. See *Alarm Severity Mappings* (on page 225) for details concerning the alarm severity mappings.

The p2moduleAlarmTable OID is: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.

Note:

- Alarm thresholds can only be adjusted for type 1, 2 and 7 alarms. (See the **p2almType** below.) The type of alarm is shown in the p2almType field. The p2almLimitAdjust field will be set to "enabled" if the limits can be adjusted, or "disabled" if they cannot be adjusted.
- The ICIM2 or ICIM2-XD shows the alarm thresholds for all alarm types as read-writable, whether they can be adjusted or not. However, an error will result if the user attempts to change an alarm threshold with non-adjustable limits.

p2module Alarm Table	Entry 1	Entry 2	Entry 3	Entry 4	Entry 5
Instance	6.0.1	6.0.2	6.1.1	6.1.2	6.1.3
index *	1	2	1	2	3
label	FansOk	ChasTemp	Ps1PwrIn	Ps1+24	Ps1+5VDC
Value	1 (fault)	2 (ok)	0 (ok)	2 (ok)	2 (ok)
Type	5	2	5	2	2
Nominal	1	25	1	24.7	5.4
Hysteresis	na	1	na	0.1	0.1
Major Low	na	-40	na	18	3.6
Minor Low	na	-35	na	18.4	3.7
Minor High	na	60	na	25.9	5.9
Major High	na	65	na	26.1	6.1
Limit Adjust	disabled (2)	enabled (1)	disabled (2)	enabled (1)	enabled (1)
Limit Range Lo	na	-32768	na	-3276.8	-3276.8

p2module Alarm Table	Entry 1	Entry 2	Entry 3	Entry 4	Entry 5
Limit Range Hi	na	32767	na	3276.7	3276.7

* The index value for the alarm is actually the third digit of the instance value. The alarm label will always have the same index value for that module. The index value is not a running index for the entire Module Alarm table.

p2almIndex

This object holds one of the indices into the alarm table. Indices include chassis and slot, as well as p2almIndex per alarm type for the module, which form the unique instance into the Module Alarm table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.1

p2almLabel

This object holds a string of eight characters or less that describes an alarm characteristic of a module type.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.2

p2almValue

This object holds the alarm value, which may be a Boolean or Non-Boolean value as appropriate to the alarm type. The table below shows how the meanings of different alarm values vary depending on their class or enumeration (Non-Boolean vs. Boolean).

Class/Enumeration	0	1	2	3	4
Non-Boolean (p2almType 1, 2, 3, 4, 7, 8 - see table under palmType)	Major low	Minor low	OK	Minor high	Major high
Boolean (p2almType 5 or 6)	OK	Fault	na	na	na

Important: Certain alarm values can have very different meanings depending on the type of alarm. For example, for Boolean alarm types (p2almType = 5 or 6), p2almValue = 0 indicates that there is no fault (OK). However, for Non-Boolean alarm types (p2almType = 1, 2, 3, 4, 7, or 8), p2almValue = 0 indicates a major low alarm. See also **p2almType** below for more on alarm types.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.3

p2almType

This object holds the alarm type. The alarm type is a number from 1 to 8 that identifies three key characteristics of the alarm:

- **Class** - whether the alarm value is Boolean or Non-Boolean. This affects the way that the alarm values are interpreted.
- **Impact** - whether the alarm thresholds are fixed by the module or can be changed by the user. A module alarm is controlled by the module. If a monitored value violates an alarm threshold set by a module, the module may shut down. User alarm thresholds may be configured by the user. However, these alarms will not cause modules to shut down.
- **Threshold Implementation** - whether the threshold for the alarm is an absolute value, or is relative to one or more other control parameters.

The table below identifies the class, impact, and threshold implementation for each possible value of p2almType. Alarm types with user-adjustable thresholds are indicated with an asterisk (*) in the table and paragraphs below.

p2almType	Class	Impact	Threshold Implementation
1 *	Non-Boolean	User	Relative
2 *	Non-Boolean	User	Absolute
3	Non-Boolean	Module	Relative
4	Non-Boolean	Module	Absolute
5	Boolean	User	na
6	Boolean	Module	na
7 *	Non-Boolean	User	Absolute
8	Non-Boolean	Module	Absolute

* Only these alarm thresholds may be changed by a user.

More on Alarm Types

A Major alarm for module alarm types 3, 4, and 6 below may shut down the module or an important feature of it, such as the laser, if a major threshold is violated. User alarms of type 1, 2, 5, and 7 will not shut down the module if a Major threshold (low or high) is exceeded.

- 1 The relative user alarm. The alarm thresholds are interpreted as a positive or negative value relative to the nominal value of the alarmed variable. The alarm thresholds can be adjusted by the operator, but this will not shut down the module.
- 2 The absolute user alarm. The alarm thresholds are interpreted as absolute values of the alarmed variable. The alarm thresholds can be adjusted by the operator, but this will not shut down the module.

- 3 The relative module alarm. The interpretation of thresholds is like type 1, but a Major Alarm will set the module in the safe state. The alarm thresholds are not user-adjustable.
- 4 The absolute module alarm. The interpretation of thresholds is like type 2, but a Major Alarm will set the module in the safe state. The alarm thresholds are not user-adjustable.
- 5 User Boolean alarm. The state 0 means no alarm (OK). The nominal set to 1 (see **p2almNominal** below) means that input signal of 1 causes an alarm. If nominal is 0, input value of 0 causes alarm. This alarm does not set the unit to the safe state. The alarm thresholds are not user-adjustable.
- 6 Module Boolean alarm. The state 0 means no alarm (OK). The nominal set to 1 (see **p2almNominal** below) means that input signal of 1 causes an alarm. If nominal is 0, input value of 0 causes alarm. This alarm will set the unit to the safe state. The alarm thresholds are not user-adjustable.
- 7 The user alarm with complete inhibit. Same as type 2 except that inhibiting this alarm will always put it in the no alarm state. It will not set anything to the safe state, set the alarm LED or relay or pull the attention line low. The alarm thresholds can be adjusted by the operator, but this will not shut down the module.
- 8 The Module alarm with complete inhibit. Same as type 7 except that the limits are not user adjustable. Unlike other module alarms it will not set anything to the safe set when an alarm is triggered. The alarm thresholds are not user-adjustable.

Important: The alarm type and alarm value are inseparably linked, in that the value may only be understood with respect to the type of alarm. (See also **p2almValue** above.)

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.4

p2almNominal

This object holds the alarm nominal value. To view the current value for a particular module and element, see the Module Monitor table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.5

p2almHysteresis

This object defines the hysteresis value for the alarm. The hysteresis value determines how far from the alarm threshold a parameter must change before an alarm condition will clear. The purpose of hysteresis is to prevent the rapid setting and clearing of alarms that otherwise would occur when a parameter makes small fluctuations about the alarm threshold value.

For example, assume that the Minor High limit for chassis temperature is set to 45°C, and the hysteresis value for this alarm parameter is 1°C. When the chassis temperature rises above 45°C, the Minor High alarm occurs. In order for the alarm to clear, the temperature must fall below 44°C, which is the alarm threshold value of 45 minus the hysteresis value of 1.

Likewise, if the chassis temperature had a Minor Low alarm threshold of -20°C and a hysteresis value of 1°C, a Minor Low alarm would occur if the temperature fell below -20°C, but would not clear until the temperature rose above -19°C.

See **Note** at the end of this section for additional information.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.8

p2almMajorLowLimit

This object holds the Major Low alarm threshold value. See **Note** at the end of this section for additional information.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.9

p2almMinorLowLimit

This object holds the Minor Low alarm threshold value. See **Note** at the end of this section for additional information.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.10

p2almMinorHighLimit

This object holds the Minor High alarm threshold value. See **Note** at the end of this section for additional information.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.11

p2almMajorHighLimit

This object holds the Major High alarm threshold value. See **Note** at the end of this section for additional information.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.12

p2almLimitAdjust

The value in this object indicates whether an alarm has adjustable threshold values. It will be set to enabled (1) if adjustable, disabled (2) if non-adjustable. See **Note** at the end of this section for additional information.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.13

p2almLimitRangeLo

The value in this object is the lower limit for an adjustable alarm threshold.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.14

p2almLimitRangeHi

The value in this object is the upper limit for an adjustable alarm threshold.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.5.1.15

Note: Alarm thresholds can only be adjusted for type 1, 2 and 7 alarms. The type of alarm is shown in the p2almType field. The p2almLimitAdjust field will be set to "enabled" if the limits can be adjusted, or to "disabled" if they cannot be adjusted.

The ICIM2 or ICIM2-XD treats all modules the same in that the alarm thresholds will be shown as read-writable for all alarm types, whether they can be adjusted or not. An error will result if the user attempts to change an alarm threshold with non-adjustable limits.

Alarm Severity Mappings

All Prisma II and Prisma II XD chassis alarms report to Major or Minor severity levels, as shown in the following tables.

Note: For additional information on alarms, alarm types, and alarm values, see *Module Alarm Table* (on page 220).

Prisma II Chassis - Fan Tray and Power Supplies

Alarm Type	Severity Level
FansOk	Minor
ChasTemp	Major/Minor per threshold settings
Ps1PwrIn	Major
Ps1+24	Major/Minor per threshold settings

Alarm Type	Severity Level
Ps1+5VDC	Major/Minor per threshold settings
Ps1-5VDC	Major/Minor per threshold settings
Ps3PwrIn	Major
Ps3+24	Major/Minor per threshold settings
Ps3+5VDC	Major/Minor per threshold settings
Ps3-5VDC	Major/Minor per threshold settings

Prisma II XD Chassis - Fan Assembly and Power Supplies

Alarm Type	Severity Level
Fan 1_Ok	Major
Fan 2_Ok	Major
Fan 3_Ok	Major
ChasTemp	Major/Minor per threshold settings
ConvAIn	Major
ConvA+24	Major/Minor per threshold settings
ConvA+5	Major/Minor per threshold settings
ConvA-5	Major/Minor per threshold settings
ConvBIn	Major
ConvB+24	Major/Minor per threshold settings
ConvB+5	Major/Minor per threshold settings
ConvB-5	Major/Minor per threshold settings

Current Alarm Table

The Current Alarm table displays the module elements currently in alarm. This table is highly dynamic, and updates with each poll of a module, if needed.

When a module element first goes into alarm, an entry is made in the Current Alarm table and the date and time are recorded. If the alarm changes from Major to Minor or vice versa, the change is acknowledged and the time stamp is adjusted.

If an alarm clears, the entry is removed from the Current Alarm table. If a module is removed from the ICIM2 or ICIM2-XD domain, all of its corresponding alarms are removed from the table.

The indices are chassis, slot, and index, the same as the index into the p2moduleAlarm table associated with this alarmed item.

p2moduleCurrentAlarmTable OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8

p2moduleCurrentAlarmEntry OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8.1

The figure below shows how the Current Alarm table might appear when displayed in a MIB browser.

Instance	p2curAlmIndex(Idx)	p2curAlmSeverity	p2curAlmLabel	p2curAlmDescr	p2curAlmTime
1.2.3	3	minor(2)	InRF	Module=HDTx, Model=1020	Wed, 02 Nov 2005 11:55:39 EST
1.3.3	3	minor(2)	InRF	Module=HDTx, Model=1020	Wed, 02 Nov 2005 11:55:40 EST
1.4.3	3	minor(2)	InRF	Module=HDTx, Model=1020	Wed, 02 Nov 2005 11:55:42 EST
1.5.3	3	major(1)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:43 EST
1.7.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:46 EST
1.8.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:47 EST
1.9.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:48 EST
1.10.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:50 EST
1.11.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:51 EST
1.12.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:52 EST
1.13.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:53 EST
1.14.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:55 EST
1.16.3	3	minor(2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:57 EST
2.1.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:01 EST
2.1.4	4	major(1)	Alarm	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:01 EST
2.2.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:02 EST
2.4.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:05 EST
2.5.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:07 EST
2.6.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:08 EST
2.7.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:10 EST
2.8.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:11 EST
2.9.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:13 EST
2.10.1	1	major(1)	InPwr	Module=P2-HD-RXF, Model=2015	Wed, 02 Nov 2005 11:56:14 EST

TP485

The table below shows sample entries for each element of the Current Alarm table. The elements themselves are described in this section.

Instance	p2curAlm Index *	p2curAlm Severity	p2curAlm Label	p2curAlmDescr	p2curAlmTime
1.2.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:39 EST
1.3.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:40 EST
1.4.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:42 EST
1.5.3	3	major (1)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:43 EST
1.7.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:46 EST
1.8.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:47 EST
1.9.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:48 EST
1.10.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:50 EST
1.11.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:51 EST
1.12.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:52 EST
1.13.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:53 EST

Instance	p2curAlm Index *	p2curAlm Severity	p2curAlm Label	p2curAlmDescr	p2curAlmTime
1.14.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:55:55 EST
1.16.3	3	minor (2)	InRF	Module=HDTx, Model=1032	Wed, 02 Nov 2005 11:56:57 EST
2.1.1	1	minor (2)	InPwr	Module=P2-HD- RXF, Model=2015	Wed, 02 Nov 2005 11:56:01 EST

* The index value for the alarm is actually the third digit of the instance value. The alarm label will always have the same index value for that module. The index value is not a running index for the entire Current Alarm table.

p2curAlmIndex

The value in this object is the index into the p2moduleAlarm table for this object in alarm. It is one of three indices into the Current Alarm table, along with p2chassisID and p2slotID.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8.1.1

p2curAlmSeverity

The value in this object represents the current level of severity for the alarm shows here. The alarm may be Major (1) or Minor (2).

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8.1.2

p2curAlmLabel

The value in this object represents the label assigned to the alarm, which corresponds to the p2almLabel.

Example: Fan1_Ok

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8.1.3

p2curAlmDescr

This object holds the alarm description, which is a concatenation of the module name and the model number in text form. It is exactly the same as p2TrapLogText, sent by the Enhanced traps and logged in the Trap Log table.

Example: Module=HDTx, Model=1032

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8.1.4

p2curAlmTime

This object shows the time that the alarm was first recorded in the Current Alarm table, or the time that the severity level last changed from Major to Minor or vice versa.

Format Example: Wed, 02 Nov 2005 11:56:50 EST

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.8.1.5

Module Monitor Table

The Module Monitor table shows the actual values of module elements. Values may only be updated via a module in response to requests from the ICIM2 or ICIM2-XD.

As with the Module Control table and the Module Alarm table, the Module Monitor table is indexed by the chassis and slot number of a particular module. The third index into the table is represented by the p2monitor Index value.

The OID of p2moduleMonitorTable is: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.

Rows may be accessed via p2moduleMonitorEntry OID:
1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.

The figure below shows how the Current Monitor table might appear when displayed in a MIB browser.

Instance	p2monitorIndex(IDX)	p2monitorLabel	p2monitorValue	p2monitorUnit	p2monitorType	p2monitorStateNames
1.0.1	1	ConvA+24	24.1499	V	F	N/A
1.0.2	2	ConvA+5	5.28269	V	F	N/A
1.0.3	3	ConvA-5	-5.26423	V	F	N/A
1.0.4	4	ConvB+24	24.0095	V	F	N/A
1.0.5	5	ConvB+5	5.27484	V	F	N/A
1.0.6	6	ConvB-5	-5.2905	V	F	N/A
1.0.7	7	PSA_Inst	1	N/A	S	(0) No, (1) Yes
1.0.8	8	PSB_Inst	1	N/A	S	(0) No, (1) Yes
1.0.9	9	ConvAlns	1	N/A	S	(0) No, (1) Yes
1.0.10	10	ConvBlns	1	N/A	S	(0) No, (1) Yes
1.0.11	11	Chas+24V	24.1177	V	F	N/A
1.0.12	12	Chas+5V	5.0277	V	F	N/A
1.0.13	13	Chas-5V	-4.93157	V	F	N/A
1.0.14	14	ChasTemp	26.75	degC	F	N/A
1.1.1	1	OutPwr	2.97	dBm	F	N/A
1.1.2	2	LasBias	72	mA	F	N/A
1.1.3	3	InRF	2.18	dB	F	N/A
1.1.4	4	ModTemp	31.28	degC	F	N/A
1.1.5	5	TecCur	29.4	mA	F	N/A
1.1.6	6	LasTemp	36.2	degC	F	N/A
1.1.7	7	LasRF	1.91	dB	F	N/A
1.2.1	1	OutPwr	3.2	dBm	F	N/A
1.2.2	2	LasBias	45.0147	mA	F	N/A

TP488

The table below shows sample entries for each element of the Current Alarm table. The elements themselves are described in this section.

Instance	Index *	Label	Value	Unit	Type	StateName
1.0.1	1	Conv+24	24.1499	V	F	N/A

Instance	Index *	Label	Value	Unit	Type	StateName
1.0.2	2	ConvA+5	5.28269	V	F	N/A
1.0.3	3	ConvA-5	-5.26423	V	F	N/A
1.0.4	4	ConvB+24	24.0095	V	F	N/A
1.0.5	5	ConvB+5	5.27484	V	F	N/A
1.0.6	6	ConvB-5	-5.2905	N/A	F	N/A
1.0.7	7	PSA_Inst	1	N/A	S	(0) No, (1) Yes
1.0.8	8	PSB_Inst	1	N/A	S	(0) No, (1) Yes
1.0.9	9	ConvAIns	1	N/A	S	(0) No, (1) Yes
1.0.10	10	ConvBIns	1	N/A	S	(0) No, (1) Yes
1.0.11	11	Chas+24V	24.1177	V	F	N/A
1.0.12	12	Chas+5V	5.0277	V	F	N/A
1.0.13	13	Chas-5V	-4.93157	V	F	N/A
1.0.14	14	ChasTemp	26.75	degC	F	N/A
1.1.1	1	OutPwr	2.97	dBm	F	N/A
1.1.2	2	LasBias	72	mA	F	N/A

* The index value for the alarm is actually the third digit of the instance value. The monitor label will always have the same index value for that module. The index value is not a running index for the entire Module Monitor table.

p2monitorIndex

The value in this object is the third index into the Module Monitor table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.1

p2monitorLabel

This object holds a short description, eight characters or less, of the monitored variable found in the string associated with p2monitorLabel.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.2

p2monitorValue

This object holds the monitor value, which is the actual value given by a module for the monitored variable.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.3

p2monitorUnit

This object indicates the units assigned to the value appearing in p2monitorValue. The table below summarizes the common units used by monitored values and controls.

Unit	Meaning
A	amperes
dB	decibels (10log10)
dBm	decibels relative to 1 mW (0.0 dBm is 1.0 mW)
degC	degrees in Centigrade
hrs	hours
Inst	installed
mA	milliamperes
%	percentage
sec	seconds

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.4

p2monitorType

This object indicates the monitor data type, represented with one of the following letters:

Unit	Meaning
F	floating point value
D	digital, integer value
B	Boolean, 0 or 1
L	long, a floating point value converted to 8 ASCII Hex digits
S	state with enumerated list of state names (up to 8 characters each)

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.5

p2monitorStateNames

If the element is a state variable, this object lists all the state names for the element.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.7.1.6

Module Control Table

The Module Control table contains control information for every module in the ICIM2 or ICIM2-XD domain that has control variables.

Like the Alarm table and Monitor table, the Control table has three indices:

- Chassis number
- Slot number
- Individual index, which varies per module by control type

Collectively, these indices make up the instance into the table.

p2ModuleControlTable OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6

p2ModuleControlEntry OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1

The figure below shows how the Module Control table might appear when displayed in a MIB browser.

Insta...	p2cntrlIndex(ID×)	p2cntrlLabel	p2cntrlValue	p2cntrlUnit	p2cntrlType	p2cntrlRangeLo	p2cntrlRangeHi	p2cntrlRangeStep	p2cntrlStateNames
1.0.1	1	AlmMuteA	0	N/A	S	0	1	1	(0) Off, (1) On
1.0.2	2	AlmMuteB	0	N/A	S	0	1	1	(0) Off, (1) On
1.1.1	1	Enable	1	N/A	B	0	1	1	N/A
1.1.2	2	CwMode	0	N/A	B	0	1	1	N/A
1.1.3	3	LoRFInh	0	N/A	B	0	1	1	N/A
1.1.4	4	Master	1	N/A	S	0	1	1	(0) Slave, (1) Master
1.1.5	5	RFDrive	0	dB	F	-1.5	1.5	0.5	N/A
1.1.6	6	AGC	0	N/A	B	0	1	1	N/A
1.2.1	1	Enable	1	N/A	B	0	1	1	N/A
1.2.2	2	CwMode	0	N/A	B	0	1	1	N/A
1.2.3	3	LoRFInh	0	N/A	B	0	1	1	N/A
1.2.4	4	Master	1	N/A	S	0	1	1	(0) Slave, (1) Master
1.2.5	5	RFDrive	0	dB	F	-5	5	0.5	N/A
1.2.6	6	AGC	0	N/A	B	0	1	1	N/A
1.3.1	1	Enable	1	N/A	B	0	1	1	N/A
1.3.2	2	CwMode	0	N/A	B	0	1	1	N/A
1.3.3	3	LoRFInh	0	N/A	B	0	1	1	N/A
1.3.4	4	Master	1	N/A	S	0	1	1	(0) Slave, (1) Master
1.3.5	5	RFDrive	0	dB	F	-5	5	0.5	N/A
1.3.6	6	AGC	0	N/A	B	0	1	1	N/A
1.4.1	1	Enable	1	N/A	B	0	1	1	N/A
1.4.2	2	CwMode	0	N/A	B	0	1	1	N/A
1.4.3	3	LoRFInh	0	N/A	B	0	1	1	N/A
1.4.4	4	Master	1	N/A	S	0	1	1	(0) Slave, (1) Master

TP484

The table below shows sample entries for each element of the Module Control table. The elements themselves are described in this section.

Instance	Index *	Label	Value	Unit	Type	Range Low	Range High	Range Step	StateNames
1.0.1	1	AlmMuteA	0	N/A	S	0	1	1	(0) Off, (1) On
1.0.2	2	AlmMuteB	0	N/A	S	0	1	1	(0) Off, (1) On
1.1.1	1	Enable	1	N/A	B	0	1	1	N/A
1.1.2	2	CwMode	0	N/A	B	0	1	1	N/A
1.1.3	3	LoRFInh	0	N/A	B	0	1	1	N/A
1.1.4	4	Master	1	N/A	S	0	1	1	(0) Slave, (1) Master

Instance	Index *	Label	Value	Unit	Type	Range Low	Range High	Range Step	StateNames
1.1.5	5	RFDrive	0	dB	F	-1.5	1.5	0.5	N/A
1.1.6	6	AGC	0	N/A	B	0	1	1	N/A
1.2.1	1	Enable	1	N/A	B	0	1	1	N/A
1.2.2	2	CwMode	0	N/A	B	0	1	1	N/A

* The index value for the alarm is actually the third digit of the instance value. The alarm label will always have the same index value for that module. The index value is not a running index for the entire Module Control table.

p2cntrlIndex

The value in this object is one index into the Module Control table is the p2cntrlIndex. It is the third index; chassis and slot are the first and second indices to this table.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.1

p2cntrlLabel

This object holds a short description of the control, represented as a string of not more than eight characters. The description varies by module and its controls.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.2

p2cntrlValue

The value in this object may be changed by the user to control an aspect of the module.

Access: read-write

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.3

p2cntrlUnit

This object indicates the units assigned to the values appearing in p2cntrlValue. The table below summarizes the common units used by monitored values and controls.

Unit	Meaning
A	amperes
dB	decibels (10log10)
dBm	decibels relative to 1 mW (0.0 dBm is 1.0 mW)
degC	degrees in Centigrade
hrs	hours

Unit	Meaning
Inst	installed
mA	milliamperes
%	percentage
sec	seconds

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.4

p2cntrlType

The value in this object represents the data type of the control variable:

Unit	Meaning
F	floating point value
D	digital, integer value
B	Boolean, 0 or 1
S	state with enumerated list of state names (up to 8 characters each)

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.5

p2cntrlRangeLo

The value in this object is the lower limit for the control.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.6

p2cntrlRangeHi

The value in this object is the upper limit for the control.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.7

p2cntrlRangeStep

The value in this object is the range step (smallest allowable increment) for the control.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.8

p2cntrlStateNames

If the control is a state variable, this object will list the state names for the control.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.6.1.9

Insert Module Table

If a module is inserted into the chassis following the initial polling of the ICIM2 or ICIM2-XD, the module chassis and slot appear in the Insert Module table. The table is indexed sequentially by occurrence.

p2InsertModuleTable OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.3

p2InsertModuleEntry OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.3.1

p2InsertModuleIndex

The value in this object is the index into the Insert Module table, which is sequential with respect to time.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.3.1.1

p2InsertModuleChassisID

The value in this object represents the number of the chassis in which the module is installed.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.3.1.2

p2InsertModuleSlotID

The value in this object represents the number of the slot in which the module is installed.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.3.1.3

Remove Module Table

If a module is removed from a slot, some data concerning the module appears in the Remove Module table. Information captured in this table allows managers to determine if the removed module was replaced by a module of the same type. This table is indexed sequentially based on occurrence.

As with other tables for the module, the rows in this table may be accessed via the p2RemoveModuleEntry.

p2RemoveModuleTable OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4

p2IRemoveModuleEntry OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1

p2RemoveModuleIndex

The value in this object represents the index into the Remove Module table, which is sequential with respect to time.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1.1

p2RemoveModuleChassisID

The value in this object represents the number of the chassis in which the module had been installed.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1.2

p2RemoveModuleSlotID

The value in this object represents the number of the slot in which the module had been installed.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1.3

p2RemoveModuleName

The value in this object represents the name assigned to this module type during the manufacturing process.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1.4

p2RemoveModuleType

The value in this object represents the number assigned during the manufacturing process to uniquely identify this type of module. This is also referred to as the Devtype or TNCS type number.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1.5

p2RemoveModuleSerialNum

The value in this object designates the serial number of the removed module.

Access: read-only

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.300.4.1.6

Remote Reboot of ICIM2 and Modules

You can boot the ICIM2, ICIM2-XD, and associated application modules remotely using a series of SNMP commands. The modules may be rebooted using a hard reboot (service interrupting) or a soft reboot (non-service interrupting). The ICIM2 or ICIM2-XD always performs a hard reboot (non-service interrupting) in response to either a soft reboot or hard reboot command.

To Reboot the ICIM2 via SNMP

Complete the following steps to reset the ICIM2 or ICIM2-XD via SNMP.

- 1 Set p2icimDownLdTgt to "ccss," where **cc** is the chassis number and **ss** is the slot number.
- 2 Set p2icimDownLdCmd to "9" (reboot enable).
- 3 Set p2icimDownLdCmd to "7" or "8" (7 for soft reboot, 8 for hard reboot).

Note:

- For the ICIM2 or ICIM2-XD, the soft reboot and the hard reboot is the same.
- An ICIM2 or ICIM2-XD reboot clears the module database in the ICIM2 or ICIM2-XD and requires rediscovery of the domain to update the module status. Discovery times may be as long as five minutes, depending on the system size and configuration.

To Reboot a Module via SNMP

Complete the following steps to reset an application module via SNMP.

- 1 Set p2icimDownLdTgt to "ccss," where **cc** is the chassis number and **ss** is the slot number.
- 2 Set p2icimDownLdCmd to "9" (reboot enable).
- 3 Set p2icimDownLdCmd to "7" or "8" (7 for soft reboot, 8 for hard reboot).

Note: A module soft reboot will not interrupt service to the end customer, but a hard reboot may cause a brief disruption of service.

Prisma II Traps

This section describes trap destination configuration and provides details on trap types, conditions causing traps, and trap logging.

About Traps

The Prisma II system can be configured to provide various alarm and warning conditions, called *traps*, to an element management system or system monitor application. Up to eight different traps can be enabled independently to provide information on events occurring in a system:

- IP Change
- Module Insertion
- Module Removal
- Alarm Event
- Download Complete
- Self-Test
- Reboot
- Enhanced Alarm

These traps can be sent to up to ten different IP addresses, or "users." Trap filtering can be configured independently for each user.

Each trap is accompanied by one or more *bindings*, which are parameters representing the physical or logical objects associated with the trap.

The following table briefly describes each of the traps listed above and identifies its associated bindings.

Trap	Description	Binding
IP Change Trap	An informational event indicating when the ICIM2 or ICIM2-XD IP address has been changed.	1. Previous IP address
Module Insertion Trap	An informational event indicating that a module has been inserted into a chassis.	1. Chassis ID 2. Slot ID
Module Removal Trap	An informational event indicating that a module has been removed from a chassis.	1. Chassis ID 2. Slot ID

Trap	Description	Binding
Alarm Event Trap	An informational event indicating that an alarm has changed state on a module.	1. Chassis ID 2. Slot ID 3. Alarm Table Index 4. Alarm Label (Description)
Download Complete Trap	An informational event indicating that new application software has been downloaded to a module.	1. Chassis ID 2. Slot ID
Reboot Command Trap	An informational event indicating that a module has been commanded to reboot (hard or soft).	1. Chassis ID 2. Slot ID
Self-Test Trap	An alarm indicating that a module has failed its power-on self test.	1. Chassis ID 2. Slot ID
Enhanced Alarm Trap	An event indicating that an alarm has changed state or an event has occurred with a module. This trap includes additional bindings to indicate CLLI and CLEI codes for telecommunications equipment.	1. Trap Sequence Number 2. Severity 3. State 4. Description 5. OID 6. Module Name and type 7. Chassis ID 8. Slot ID 9. CLLI code 10. CLEI code 11. TimeStamp 12. Date Time Zone 13. Value 14. Unit 15. Description

Note: All trap types (module insertion, alarm events, etc.) are reported through the Enhanced Alarm trap. By default, only the Enhanced Alarm traps are enabled.

Trap Receiving Configuration

Trap receiving is configured in the p2TrapRecvTable.

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.8

A sample view of this table is provided below.

Object	RX Trap	RX Trap	RX Trap	RX Trap	Example (same as RX Trap #3)					
p2TrapRecvIndex	0	1	2	3	4	5	6	7	8	9
p2TrapRecvEnable	enabled (2)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvAddr	172.24.28.66	172.24.28.94	0.0.0.0	0.0.0.0	0	0	0	0	0	0
p2TrapRecvIPChange	disabled (1)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvModuleInsert	disabled (1)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvModuleRemove	disabled (1)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvMinorAlarm	never (1)	never (1)	never (1)	never (1)	1	1	1	1	1	1
p2TrapRecvMajorAlarm	never (1)	never (1)	never (1)	never (1)	1	1	1	1	1	1
p2TrapRecvDwnLdComplete	disabled (1)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvRebootCommand	disabled (1)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvSelfTest	disabled (1)	disabled (1)	disabled (1)	disabled (1)	1	1	1	1	1	1
p2TrapRecvTelcoAlarm	enabled (2)	enabled (2)	enabled (2)	enabled (2)	2	2	2	2	2	2

As shown in the table, the traps can be filtered for each of the 10 trap receiving addresses. It is important to note that if p2TrapRecvEnable is set to "disabled," no enterprise specific traps will be sent to that IP address even if the individual filters are enabled.

The recommended (and default) trap configuration is to only enable p2TrapRecvTelcoAlarm traps. The other traps are also reported through this trap type. Enabling p2TrapRecvTelcoAlarms along with other trap types will result in duplicate traps for a single alarm event. The trap type filtering remains in place in order to support legacy systems.

To Configure Trap Destination

By setting the objects in the Trap Recv table, you can enable traps to be sent to up to 10 different IP addresses. The index into the table represents one of 10 rows, designated 0 to 9.

Complete the following steps to receive traps.

- 1 Set p2TrapRecvEnable to enabled (2), which allows traps to be sent to the IP address on the same row.
- 2 Set the IP address of the remote entity to receive traps. Use the format 172.18.2.24.
- 3 Set p2TrapRecvTelcoAlarm to enabled (2).

The table below shows how these settings might appear in a MIB browser after enabling IP address 192.0.2.102 to receive Enhanced traps only.

Instance	p2TrapRecvIndex(IDX)	p2TrapRecvEnable	p2TrapRecvAddr	p2TrapRecvIPC	Command	p2TrapRecvSelfTest	p2TrapRecvTelcoAlarm
0	0	enabled(2)	172.18.50.42	enabled(2)		disabled(1)	enabled(2)
1	1	enabled(2)	172.18.50.3	enabled(2)		disabled(1)	enabled(2)
2	2	enabled(2)	172.18.50.6	enabled(2)		disabled(1)	enabled(2)
3	3	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
4	4	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
5	5	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
6	6	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
7	7	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
8	8	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
9	9	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)

TP490

Note: All trap settings are documented for completeness only. Information contained in other proprietary traps is expanded upon in the Enhanced traps. We do not recommend using the older (legacy) traps, as the new Enhanced Trap is more useful. Enabling other traps together with the Enhanced Trap will cause two traps to be sent for each event. For more information, see *Trap Recv Table* (on page 202).

Trap Types

As indicated in the p2TrapRecvTable, there are several types of proprietary traps. All proprietary traps are documented for completeness only. Information contained in other traps is expanded upon in the Enhanced trap. In general, it is best to avoid using older traps as the new Enhanced trap is more useful. Enabling other traps together with the Enhanced trap will cause two traps to be sent for each of these events. For more information, see *Trap Recv Table* (on page 202).

Most traps have two sections: the header and the bindings. The headers are essentially the same from one trap to another. The table shown below describes each data element contained in the trap header. The first field, indicated by the label “Specific:” is important as it identifies which trap has been received.

Trap Header

The table below explains and provides an example of each trap header label.

Label	Example	Description
Specific	8	Type of trap sent (8 = SelfTest).
Message reception date	1/18/2006	Date trap received remotely.
Message reception time	11:31:24.550 AM	Time trap received remotely.
Time stamp	3 days 00h:02m:04s.00th	ICIM2 or ICIM2-XD up time since last reboot.
Message type	Trap (v1)	Trap via SNMP version 1.
Protocol version	SNMPv1	SNMP version 1.

Label	Example	Description
Transport	IP/UDP	Transport protocol used.
Agent		
Address	172.24.28.168	IP address of the ICIM2 or ICIM2-XD.
Port	162	ICIM2 or ICIM2-XD port.
Manager		
Address	172.18.43.3	Remote IP address.
Port	162	Remote port.
Community	prismatrap	SNMP trap community.
SNMPv1 agent address	172.24.28.168	IP address of the ICIM2 or ICIM2-XD.
Enterprise	p2trapEvents	MIB associated with overall trap generation.
Bindings (2)	2	Number of bindings to follow.

The number following the word Specific indicates the type of trap sent. The possible values and meanings of this number are as follows:

Unit	Meaning
2	Insert Module
3	Remove Module
4	Alarm (Major or Minor, Alarm or Clear)
5	IP Change Event
6	Download Complete (reserved for future use)
7	Reboot Command
8	SelfTest Failure
9	Telco Alarm

At least one binding follows the header. The Enhanced traps include 15 bindings carrying information regarding the entity that caused the trap to be sent. For more information on Enhanced traps, see *Enhanced Trap Binding Information* (on page 253).

Other proprietary traps send very basic data, such as the chassis and slot of the ICIM2, ICIM2-XD, or application module.

Trap Binding Example

The table below explains and provides an example of trap bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2chassisID	Chassis where the ICIM2, ICIM2-XD, or application module is installed.
2: SlotID	p2slotID	Slot where the ICIM2, ICIM2-XD, or application module is installed.
3: Self-Test data	p2moduleSelfTest	SelfTest Failed - Error code value.

IP Change Trap (Specific: 5)

This trap is sent when an ICIM2 or ICIM2-XD IP address is changed through the CLI. If p2TrapRecvIPChange is set to enabled (2), a trap containing the previous IP will be sent. The new IP address will take affect on the next ICIM2 or ICIM2-XD reboot.

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 5 appears in the heading to indicate that this is an IP Change trap. The table below describes the binding.

Binding	MIB Name (Examples)	Explanation
1: PreviousIP	p2PreviousIP	The IP address previously given to the ICIM2 or ICIM2-XD before a new IP address was assigned. The new IP address takes effect upon the next ICIM2 or ICIM2-XD reboot.

IP Change Trap Example

```
Specific: 5
Message reception date: 1/31/2006
Message reception time: 1:19:58.793 PM
Time stamp: 3 days 00h:25m:57s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.168
  Port: 1051
Manager
  Address: 172.18.4.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.168
Enterprise: p2trapEvents
Bindings (1)
  Binding #1: p2PreviousIP.0 (ipaddr) 172.24.28.168
```

Module Insert Trap (Specific: 2)

This trap is sent as soon as the ICIM2 or ICIM2-XD discovers that a module has been inserted. If p2TrapRecvModuleInsert is enabled (2), a trap containing the chassis and slot of the new module is sent. A number appears in the heading indicating that this is a module insert trap.

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 2 appears in the heading to indicate that this is an InsertRemove trap. The table below describes the bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2InsertModuleChassisID	Chassis where the module is installed.
2: SlotID	p2InsertModuleSlotID	Slot where the module is installed.

Module Insert Trap Example

```
Specific: 2
Message reception date: 1/31/2006
Message reception time: 1:24:47.626 PM
Time stamp: 3 days 00h:30m:46s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.168
  Port: 1055
Manager
  Address: 172.18.4.28
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.168
Enterprise: p2trapEvents
Bindings (2)
  Binding #1: p2InsertModuleChassisID.1 (int32) 2
  Binding #2: p2InsertModuleSlotID.1 (int32) 13
```

Module Remove Trap (Specific: 3)

This trap is sent when the ICIM2 or ICIM2-XD discovers that a module has been removed from the chassis. If p2TrapReceiveModuleRemove is enabled (2), a trap with the chassis and slot where the removed module had been installed will be sent.

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 3 appears in the heading to indicate that this is a ModuleRemove trap. The table below describes the bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2RemoveModuleChassisID	Chassis where the module was formerly installed.
2: SlotID	p2RemoveModuleSlotID	Slot where the module was formerly installed.

Module Remove Trap Example

```

Specific: 3
Message reception date: 1/31/2006
Message reception time: 1:27:35.778 PM
Time stamp: 3 days 00h:33m:35s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.168
  Port: 1060
Manager
  Address: 172.18.4.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.168
Enterprise: p2trapEvents
Bindings (2)
  Binding #1: p2RemoveModuleChassisID.1 (int32) 2
  Binding #2: p2RemoveModuleSlotID.1 (int32) 11

```

Alarm Traps (Specific: 4)

Alarm traps are edge triggered, meaning that whenever an alarm changes state, a trap is sent. An alarm changes state when a monitored value exceeds a limit set by an alarm threshold, or when a monitored Boolean parameter value changes from OK to Fault. Both of these events will generate alarms.

Alarms may trigger Major or Minor alarm traps, depending on the type of alarm limit that was exceeded. A Major alarm trap is sent when the monitored value exceeds the Major High or a Major Low alarm threshold. A Minor alarm trap is sent when the monitored value exceeds the Minor High or Minor Low alarm threshold.

Major and Minor alarm traps affect the ICIM2 or ICIM2-XD polling cycle in different ways, as follows:

- If an alarm is Minor, the module in alarm sends a trap to the ICIM2 or ICIM2-XD after the next polling interval. Minor alarm handling is integral to the polling process, and does not disrupt the normal polling cycle.
- If an alarm is Major, the module in alarm brings the ICIM2 or ICIM2-XD Attention line low to request immediate service. In response, the ICIM2 or ICIM2-XD first identifies the module requesting attention, and then polls the module to obtain the alarm information. After handling the Major alarm, the ICIM2 or ICIM2-XD resets the polling process, so that it resumes at the beginning of the cycle, rather than at the point in the cycle at which it was interrupted.

To configure alarm traps in the p2TrapRecvTable, select values for p2TrapRecvMajorAlarm or p2TrapRecvMinorAlarm. If traps are to be sent when monitored values exceed their Major Low or Major High threshold values, configure p2TrapRecvMajorAlarm. If traps are to be sent when monitored values exceed their Minor Low or Minor High threshold values, set values in p2TrapRecvMinorAlarm.

Note: A monitor value stated in a trap binding is a snapshot in time, and so may not indicate a value consistent with an alarm condition. If in doubt, verify the actual monitor value using the appropriate equipment interfaces.

The user may configure alarm trap behavior by selecting one of four options:

- Never (1), meaning that traps of this type should never be sent
- Clear (2), meaning that traps should be sent only when alarms are cleared
- Set (3), meaning that traps should be sent only when alarms are set
- Always (4), meaning that traps should be sent when alarms are set or cleared

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 4 appears in the heading to indicate an Alarm trap. (Specific: 4 as a value indicates a major alarm or clear, or a minor alarm or clear condition.) The table below describes the bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2chassisID	Chassis where the module is installed.
2: SlotID	p2slotID	Slot where the module is installed.
3: Index	p2almIndex	The index into the alarm table where more information may be found.
4: Label	p2almLabel	Label for the element that is in the state of alarm, e.g., ConvA+24.

Alarm Trap Example

```

Specific: 4
Message reception date: 1/31/2006
Message reception time: 1:31:58.829 PM
Time stamp: 3 days 00h:37m:58s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.168
  Port: 1074
Manager
  Address: 172.18.4.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.168
Enterprise: p2trapEvents
Bindings (4)
  Binding #1: p2chassisID.2.3 (int32) 2
  Binding #2: p2slotID.2.3 (int32) 3
  Binding #3: p2almIndex.2.3.4 (int32) 4
  Binding #4: p2almLabel.2.3.4 (octets) Psl+24

```

Download Complete Trap (Specific: 6)

When a download to the ICIM2, ICIM2-XD, or application module completes, a trap is sent. To enable this trap type, set p2TrapRecvDwnLdComplete to enabled (2).

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 6 appears in the heading to indicate a RebootCommand trap. The table below describes the bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2chassisID	Chassis where the ICIM2, ICIM2-XD, or application module is installed.
2: SlotID	p2slotID	Slot where the ICIM2, ICIM2-XD, or application module is installed.

Download Complete Trap Example

```

Specific: 6
Message reception date: 1/31/2006
Message reception time: 1:45:19.299 PM
Time stamp: 3 days 00h:51m:21s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.168
  Port: 1141
Manager
  Address: 172.18.4.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.168
Enterprise: p2trapEvents
Bindings (2)
  Binding #1: p2chassisID.2 (int32) 2
  Binding #2: p2slotID.2 (int32) 3

```

Reboot Command Trap (Specific: 7)

When the ICIM2, ICIM2-XD, or application module receives the command to reboot, a trap is generated. If this reboot command is generated via the SOUP application, a broadcast reboot is sent out. In this case, only one trap may be generated for the ICIM2 or ICIM2-XD and all modules under its management. To configure the reboot command trap to be sent, set p2TrapRecvRebootCommand to enabled (2).

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 7 appears in the heading to indicate a RebootCommand trap. The table below describes the bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2chassisID	Chassis where the ICIM2, ICIM2-XD, or application module is installed.
2: SlotID	p2slotID	Slot where the ICIM2, ICIM2-XD, or application module is installed.

The example below shows the bindings for a broadcast RebootCommand trap. Chassis 99 and slot 99 indicate that the reboot command was broadcast to all modules.

Reboot Command Trap Example

```

Specific: 7
  Message reception date: 1/31/2006
  Message reception time: 1:47:14.920 PM
  Time stamp: 3 days 00h:53m:16s.00th
  Message type: Trap (v1)
  Protocol version: SNMPv1
  Transport: IP/UDP
  Agent
    Address: 172.24.28.168
    Port: 1145
  Manager
    Address: 172.18.4.23
    Port: 162
  Community: prismatrap
  SNMPv1 agent address: 172.24.28.168
  Enterprise: p2trapEvents
  Bindings (2)
    Binding #1: p2chassisID.99 (int32) 99
    Binding #2: p2slotID.99 (int32) 99

```

Self-Test Trap (Specific: 8)

This trap is sent if the ICIM2, ICIM2-XD, or application module fails the self-test. The trap contains an error code, which is module specific. See the sections on p2icimSelfTest in *ICIM MIB* (on page 181) and p2moduleSelfTest in *Module MIB* (on page 211) for further discussion of the error codes. To receive the SelfTest traps, set p2TrapRecvSelfTest to enabled (2).

Note: Documentation on this trap is included for completeness. All information in this trap is contained in and expanded upon in the Enhanced trap. We recommend using the Enhanced trap instead of this trap, as the Enhanced trap is more useful. Enabling this trap together with the Enhanced trap will cause two traps to be sent for each triggering event.

Specific: 8 appears in the heading to indicate a SelfTest trap. The table below describes the bindings.

Binding	MIB Name (Examples)	Explanation
1: ChassisID	p2chassisID	Chassis where ICIM2, ICIM2-XD, or application module is installed.
2: SlotID	p2slotID	Slot where the ICIM2, ICIM2-XD, or application module is installed.
3: Self-Test data	p2moduleSelfTest	SelfTest Failed - Error Code value.

Self-Test Trap Example

```

Specific: 8
  Message reception date: 1/31/2006
  Message reception time: 2:22:20.190 PM
  Time stamp: 3 days 00h:00m:20s.00th
  Message type: Trap (v1)
  Protocol version: SNMPv1
  Transport: IP/UDP
  Agent
    Address: 172.24.28.168
    Port: 1025
  Manager
    Address: 172.18.4.23
    Port: 162
  Community: prismatrap
  SNMPv1 agent address: 172.24.28.168
  Enterprise: p2trapEvents
  Bindings (3)
    Binding #1: p2chassisID.2 (int32) 2
    Binding #2: p2slotID.2 (int32) 15
    Binding #3: p2moduleSelfTest.2.15 (octets) SelfTest Failed - Error Code 32.

```

Enhanced Traps (Specific: 9)

The Enhanced traps summarize information for all trap types, with additional data, exclusive of all other traps. Also, if an alarm exists upon startup or module insertion, Enhanced traps will be sent. To configure the Enhanced traps, set p2TrapRecvTelcoAlarm to enabled (2).

Specific: 9 appears in the heading to indicate an Enhanced trap. The table below describes the bindings.

Example of Bindings

Trap Binding	MIB Name (Examples)	Explanation
1 Sequence	p2TrapLogSequence	Tracking number from 1 to 2,147,483,647.
2 Severity	p2TrapLogSeverity	Trap severity level - major (1), minor (2), warning (3).
3 State	p2TrapLogState	State - alarm (1), clear (2), event (3).
4 Label	p2TrapLogLabel or p2almLabel.1.3.4	Event Name or Alarm Label.
5 OID	p2almIndex.1.3 or p2icimStatusMsg	More data regarding the alarm or event is found at this OID.
6 Text	p2TrapLogText	Module name and model number of ICIM2 or ICIM2-XD.
7 ChassisID	p2icimChassisID	Chassis where the ICIM2, ICIM2-XD, or application module is installed.
8 SlotID	p2icimSlotID	Slot where the ICIM2, ICIM2-XD, or application module is installed.
9 CLLIcode	p2icimCLLIcode	Reserved for future use.
10 CLEIcode	p2icimCLEIcode	Reserved for future use.

Trap Binding	MIB Name (Examples)	Explanation
11 Time	p2TrapLogTime	Time trap generated in the format: YYYY-MM-DD, HH:MM:SS.ss
12 DateTime	p2TrapLogDateTime	Date and time generated in the format: DOW, DD MM YYYY HH:MM:SS ZZZ
13 Value	p2TrapLogValue	Monitored value of the object in alarm.
14 Units	p2TrapLogUnit	Monitored units of the value in alarm.
15 Description	p2TrapLogDesc	Verbose description of the alarm or event.

Example

```

Binding #1: p2TrapLogSequence *** (int32) 6
Binding #2: p2TrapLogSeverity *** (int32) major(1)
Binding #3: p2TrapLogState *** (int32) alarm(1)
Binding #4: p2almLabel.0.11.2 *** (octets) OutPwrA
Binding #5: p2almIndex.0.11 *** (int32) 2
Binding #6: p2TrapLogText *** (octets)
  Module=1550nm Post-Amp FTTP,Model=3031
Binding #7: p2chassisID.0.11 *** (int32) 0
Binding #8: p2slotID.0.11 *** (int32) 11
Binding #9: p2moduleCLLIcode.0.11 *** (octets)SCIATL01
Binding #10: p2moduleCLEIcode.0.11 *** (octets) PostAmpCLEI
Binding #11: p2TrapLogTime *** (octets) 2006-8-22,15:45:38.11
Binding #12: p2TrapLogDateTime *** (octets) Tue, 22 Aug 2006 15:45:38 EST
Binding #13: p2TrapLogValue *** (octets) -50
Binding #14: p2TrapLogUnit *** (octets) dBm
Binding #15: p2TrapLogDescr *** (octets)
  Optical output power of bank A exceeds major threshold (1550nm)

```

Trap Generation

Proprietary traps are generated as described above for edge triggered alarms or clear alarms (meaning a change in state of an alarm), as well as for any of the following events:

- Changing the IP address of an ICIM2 or ICIM2-XD
- Inserting or removing a module
- Successful completion of a download
- Reboot of ICIM2, ICIM2-XD, or application module
- Failure of an ICIM2, ICIM2-XD, or application module self-test

Additionally, the Enhanced traps are generated if an alarm condition exists in one of the modules upon startup or module insertion.

Trap Logging

When an Enhanced trap is sent, a copy is also kept in the Trap Logging table. Each trap has a unique sequence number which may be used as the index into the Trap Logging table. All bindings captured in the Enhanced traps are also logged, and may be accessed in the event of network failures between the SNMP manager and the ICIM2 or ICIM2-XD. The log retains up to 1,000 most recent Enhanced traps.

The figure below shows how the Trap Logging table might appear when displayed in a MIB browser.

Instance	p2TrapLogSequenceID	p2TrapLogSeverity	p2TrapLogState	p2TrapLogLabel	p2TrapLogOID	p2TrapLogText	p2TrapLogChannelID	p2TrapLogSlotID	p2TrapLogCLIcode	p2TrapLogCLEIcode	p2TrapLogTime	p2TrapLogDate	p2TrapLogTime	p2TrapLogDate	p2TrapLogTime	p2TrapLogDate	p2TrapLogTime	p2TrapLogDate	p2TrapLogTime	p2TrapLogDate	p2TrapLogTime	p2TrapLogDate	
1	1	minor(2)	alarm(1)	IrRF	p2almindex.1.2.3	ModuleHD Tx, Model=1020	1	2	N/A	N/A	2007-11-27 10:9:42.75	Tue, 27 Nov 2007 10:08:42 EST	-13.2618	dB	IrRF exceeded minor threshold								
2	2	minor(2)	alarm(1)	IrRF	p2almindex.1.3.3	ModuleHD Tx, Model=1020	1	3	N/A	N/A	2007-11-27 10:9:44.50	Tue, 27 Nov 2007 10:08:44 EST	-13.8482	dB	IrRF exceeded minor threshold								
3	3	minor(2)	alarm(1)	IrRF	p2almindex.1.4.3	ModuleHD Tx, Model=1020	1	4	N/A	N/A	2007-11-27 10:9:45.05	Tue, 27 Nov 2007 10:08:45 EST	-12.9802	dB	IrRF exceeded minor threshold								
4	4	major(1)	alarm(1)	IrRF	p2almindex.1.5.3	ModuleHD Tx, Model=1032	1	5	N/A	N/A	2007-11-27 10:9:47.20	Tue, 27 Nov 2007 10:08:47 EST	-50	dB	RF input exceeds major threshold								
5	5	minor(2)	alarm(1)	IrRF	p2almindex.1.7.3	ModuleHD Tx, Model=1032	1	7	N/A	N/A	2007-11-27 10:9:49.78	Tue, 27 Nov 2007 10:08:49 EST	-50	dB	RF input exceeds minor threshold								
6	6	minor(2)	alarm(1)	IrRF	p2almindex.1.8.3	ModuleHD Tx, Model=1032	1	8	N/A	N/A	2007-11-27 10:9:51.10	Tue, 27 Nov 2007 10:08:51 EST	-50	dB	RF input exceeds minor threshold								
7	7	minor(2)	alarm(1)	IrRF	p2almindex.1.9.3	ModuleHD Tx, Model=1032	1	9	N/A	N/A	2007-11-27 10:9:52.41	Tue, 27 Nov 2007 10:08:52 EST	-50	dB	RF input exceeds minor threshold								
8	8	minor(2)	alarm(1)	IrRF	p2almindex.1.10.3	ModuleHD Tx, Model=1032	1	10	N/A	N/A	2007-11-27 10:9:53.70	Tue, 27 Nov 2007 10:08:53 EST	-50	dB	RF input exceeds minor threshold								
9	9	minor(2)	alarm(1)	IrRF	p2almindex.1.11.3	ModuleHD Tx, Model=1032	1	11	N/A	N/A	2007-11-27 10:9:55.1	Tue, 27 Nov 2007 10:08:55 EST	-50	dB	RF input exceeds minor threshold								
10	10	minor(2)	alarm(1)	IrRF	p2almindex.1.12.3	ModuleHD Tx, Model=1032	1	12	N/A	N/A	2007-11-27 10:9:56.33	Tue, 27 Nov 2007 10:08:56 EST	-50	dB	RF input exceeds minor threshold								
11	11	minor(2)	alarm(1)	IrRF	p2almindex.1.13.3	ModuleHD Tx, Model=1032	1	13	N/A	N/A	2007-11-27 10:9:57.65	Tue, 27 Nov 2007 10:08:57 EST	-50	dB	RF input exceeds minor threshold								
12	12	minor(2)	alarm(1)	IrRF	p2almindex.1.14.3	ModuleHD Tx, Model=1032	1	14	N/A	N/A	2007-11-27 10:9:59.96	Tue, 27 Nov 2007 10:08:59 EST	-50	dB	RF input exceeds minor threshold								
13	13	minor(2)	alarm(1)	IrRF	p2almindex.1.16.3	ModuleHD Tx, Model=1032	1	16	N/A	N/A	2007-11-27 10:9:1.56	Tue, 27 Nov 2007 10:09:01 EST	-50	dB	RF input exceeds minor threshold								
14	14	major(1)	alarm(1)	IrPwr	p2almindex.2.1.1	ModuleFP2HD-FDF, Model=2015	2	1	N/A	N/A	2007-11-27 10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	-21.2658	dBm	IrPwr exceeded major threshold								
15	15	major(1)	alarm(1)	IrPwr	p2almindex.2.1.4	ModuleFP2HD-FDF, Model=2015	2	1	N/A	N/A	2007-11-27 10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	-21.2658	dBm	IrPwr exceeded major threshold								
16	16	major(1)	alarm(1)	IrPwr	p2almindex.2.2.1	ModuleFP2HD-FDF, Model=2015	2	2	N/A	N/A	2007-11-27 10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	-21.2658	dBm	IrPwr exceeded major threshold								
17	17	major(1)	alarm(1)	IrPwr	p2almindex.2.2.1	ModuleFP2HD-FDF, Model=2015	2	2	N/A	N/A	2007-11-27 10:9:6.30	Tue, 27 Nov 2007 10:09:06 EST	-21.3543	dBm	IrPwr exceeded major threshold								

Note: At least one row in p2TrapRecvTable must be configured and enabled and p2TrapRecvTelcoAlarm enabled (2) for logging of traps to occur automatically. For details, see *To Configure Trap Destination* (on page 241).

Enhanced Trap Binding Information

The Enhanced trap type was originally added to support the Telco requirement to include a trap sequence number (p2TrapLogSequence) binding. In addition, the Enhanced trap type includes other bindings to convey complete alarm information.

Important: The default and recommended configuration is to enable only the Enhanced trap type. Enabling Enhanced alarm traps and other trap types at the same time may result in duplicate traps being sent to the element management system. These other trap types remain to allow backward compatibility with previously deployed systems.

The table below provides a descriptive listing of the Enhanced trap bindings.

Trap Binding	Description
1 p2TrapLogSequence	A unique number assigned to each trap as it is generated. Serves as an index into the Trap Logging table.
2 p2TrapLogSeverity	The number assigned as a guide to prioritizing trap generating conditions. Severity may be major (1), minor (2), or warning (3).
3 p2TrapLogState	State, along with severity, quickly gives a view into the current state of an entity. State may be alarm (1), clear (2), or event (3).

Trap Binding	Description
4 p2almLabel p2TrapLogLabel	For an alarm or clear trap, the label is the same as the p2almLabel assigned to the condition that caused the trap, e.g. ChasTemp. For events, the type of event that sent the trap is identified as DownloadComplete, RebootCommand, SelfTest, AuthentictnFailed, AdminChange, LogMenuHalfFull, LogMenuFull, LoginThreshold, SNTP, UpdateChassisIDs, or UserLockout.
5 p2almIndex p2InsertModuleEntry p2icimStatusMsg p2RemoveModuleEntry p2ModuleSelfTest p2icimSelfTest p2icimIPAddr	More information regarding the trap may be found at the OID specified in this element. For an alarm or clear trap, this may be the third index into the Module Alarm table. For the download, reboot, or self-test event, this may be the p2icimStatusMessage. However, only the most recent status message is retained by the ICIM2 or ICIM2-XD. If a message generated by another even overwrites the status message, additional information may no longer be available at the OID specified for the particular trap. If an event is logged, event details may be saved in the event log.
6 p2TrapLogText	Display string which further describes the entity or condition responsible for trap generation. This usually is a concatenation of the module name and module number, although it may include the self-test failure code.
7 p2icimChassisID p2chassis	Chassis in which the ICIM2, ICIM2-XD, or application module resides at the time of trap generation.
8 p2icimSlotID p2slotID	Slot number in which the ICIM2, ICIM2-XD, or application module resides at the time of trap generation.
9 p2icimCLLcode	Reserved for future use.
10 p2icimCLEIcode	Reserved for future use.
11 p2TrapLogTime	Date and time stamp indicating when the trap was generated.
12 p2TrapLogDateTime	Full local time displayed in the format: DOW, DD MMM YYYY HH:MM:SS ZZZ Note: The local time zone must be entered in p2icimTimeZone or the default time zone, EST, will show.
13 p2TrapLogValue	Monitored value of the object in alarm.
14 p2TrapLogUnit	Monitored units of the value in alarm.
15 p2TrapLogDescr	Verbose description of the alarm or event.

Trap Sequence Numbering

To observe the most current sequence number used by the Enhanced traps, perform a get operation on this OID. If no traps have been sent, the p2TrapLastSequenceNumber is 0. Valid sequence numbers are 1 through 2,147,483,647. The sequence number resets to 1 with the first trap sent after the ICIM2 or ICIM2-XD boots up, or the p2TrapLogEntry table is cleared with the p2TrapLogClearKey, or with the trap following sequence number 2,147,483,647.

OID: 1.3.6.1.4.1.1429.1.6.2.2.13.200.1

Enhanced Trap Binding Categories

Each trap has a heading and bindings. Generally, Enhanced trap bindings fall into the categories below. However, examples of specific traps follow this general explanation.

Enhanced Trap Header Example

Labels	Example	Explanation
Specific	9	Type of trap sent (9 = Enhanced).
Message reception date	1/18/2006	Date trap was received remotely.
Message reception time	11:31:24.550 AM	Time trap was received remotely.
Time stamp	3 days 00h:02m:04s.00th	ICIM2 or ICIM2-XD up time since last reboot.
Message type	Trap (v1)	Trap via SNMP version 1.
Protocol version	SNMPv1	SNMP version 1.
Transport	IP/UDP	Transport protocol used.
Agent		
Address	172.1.1.2	IP address of the ICIM2 or ICIM2-XD.
Port	1037	ICIM2 or ICIM2-XD port.
Manager		
Address	172.2.2.3	Remote IP address.
Port	162	Remote port.
Community	prismatrap	SNMP trap community.
SNMPv1 agent address	172.1.1.2	IP address of the ICIM2 or ICIM2-XD.
Enterprise	p2trapEvents	MIB associated with overall trap generation.
Bindings (15)	15	Number of bindings to follow.

In the heading of a trap, the type of trap is indicated after the first word Specific. Values following the Specific stand for:

- 2 Insert Module
- 3 Remove Module
- 4 Alarm (Major or Minor, Alarm or Clear)
- 5 Ip Change Event
- 6 Download Complete (reserved for future use)
- 7 Reboot Command
- 8 SelfTest Failure
- 9 Enhanced Alarm

Important: The default and recommended configuration is to enable only the Enhanced trap type. Enabling Enhanced alarm traps and other trap types at the same time may result in duplicate traps being sent to the element management system. These other trap types remain to allow backward compatibility with previously deployed systems.

Enhanced Trap Bindings Example

Trap Binding	MIB Name (Examples)	Explanation
1 Sequence	p2TrapLogSequence	Tracking number from 1 to 2,147,483,647.
2 Severity	p2TrapLogSeverity	Trap severity level - major (1), minor (2), warning (3).
3 State	p2TrapLogState	State - alarm (1), clear (2), event (3).
4 Label	p2TrapLogLabel or p2almLabel.1.3.4	Event Name or Alarm Label.
5 OID	p2almIndex.1.3 or p2icimStatusMsg	More data regarding the alarm or event is found at this OID.
6 Text	p2TrapLogText	Module name and model number of ICIM2 or ICIM2-XD.
7 ChassisID	p2icimChassisID	Chassis where the ICIM2, ICIM2-XD, or application module is installed.
8 SlotID	p2icimSlotID	Slot where the ICIM2, ICIM2-XD, or application module is installed.
9 CLLIcode	p2icimCLLIcode	Reserved for future use.
10 CLEIcode	p2icimCLEIcode	Reserved for future use.

Trap Binding	MIB Name (Examples)	Explanation
11 Time	p2TrapLogTime	Time trap generated in the format: YYYY-MM-DD,HH:MM:SS.ss
12 DateTime	p2TrapLogDateTime	Date and Time generated in the format: DOW, DD MMM YYYY HH:MM:SS ZZZ
13 Value	p2TrapLogValue	Value of the element in alarm.
14 Units	p2TrapLogUnit	Units in which the value is described.
15 Description	p2TrapLogDescr	Verbose description of the alarm or event.

Enhanced Trap Alarms

The current system release supports Enhanced trap alarms that alert the element management system to the following alarm types:

- Alarm Major
- Alarm Major Clear
- Alarm Minor
- Alarm Minor Clear

This section provides examples of each of these alarm types.

Alarm Major

```

Specific: 9
Message reception date: 12/17/2007
Message reception time: 5:36:49 PM
Time stamp: 4 days 02h:04m:34s.68th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 192.168.1.149
  Port: 1182
Manager
  Address: 192.168.1.7
  Port: 162
Community: prismatrap
SNMPv1 agent address: 192.168.1.149
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 81
  Binding #2: p2TrapLogSeverity *** (int32) major(1)
  Binding #3: p2TrapLogState *** (int32) alarm(1)
  Binding #4: p2almLabel.99.0.2 *** (octets) Fan2_Ok
  Binding #5: p2almIndex.99.0 *** (int32) 2
  Binding #6: p2TrapLogText *** (octets) Module=XD-Chassis, Model=5020
  Binding #7: p2chassisID.99.0 *** (int32) 99
  Binding #8: p2slotID.99.0 *** (int32) 0
  Binding #9: p2moduleCLLIcode.99.0 *** (octets) Grayson
  Binding #10: p2moduleCLEIcode.99.0 *** (octets) N/A
  Binding #11: p2TrapLogTime *** (octets) 2007-12-17,17:36:55.80
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 17 Dec 2007 17:36:55 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Fan2_Ok exceeded major threshold

```

Alarm Major Clear

```

Specific: 9
Message reception date: 12/17/2007
Message reception time: 5:37:46 PM
Time stamp: 4 days 02h:05m:31s.68th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 192.168.1.149
  Port: 1184
Manager
  Address: 192.168.1.7
  Port: 162
Community: prismatrap
SNMPv1 agent address: 192.168.1.149
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 82
  Binding #2: p2TrapLogSeverity *** (int32) major(1)
  Binding #3: p2TrapLogState *** (int32) clear(2)
  Binding #4: p2almLabel.99.0.2 *** (octets) Fan2_Ok
  Binding #5: p2almIndex.99.0 *** (int32) 2
  Binding #6: p2TrapLogText *** (octets) Module=XD-Chassis, Model=5020
  Binding #7: p2chassisID.99.0 *** (int32) 99
  Binding #8: p2slotID.99.0 *** (int32) 0
  Binding #9: p2moduleCLLIcode.99.0 *** (octets) Grayson
  Binding #10: p2moduleCLEIcode.99.0 *** (octets) N/A
  Binding #11: p2TrapLogTime *** (octets) 2007-12-17,17:37:52.80
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 17 Dec 2007 17.37.52 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Fan2_Ok within major threshold

```


Alarm Minor

Specific: 9

```

Message reception date: 12/17/2007
Message reception time: 5:34:38 PM
Time stamp: 4 days 02h:02m:23s.50th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 192.168.1.149
  Port: 1178
Manager
  Address: 192.168.1.7
  Port: 162
Community: prismatrap
SNMPv1 agent address: 192.168.1.149
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 79
  Binding #2: p2TrapLogSeverity *** (int32) minor(2)
  Binding #3: p2TrapLogState *** (int32) alarm(1)
  Binding #4: p2almLabel.99.0.4 *** (octets) ChasTemp
  Binding #5: p2almIndex.99.0 *** (int32) 4
  Binding #6: p2TrapLogText *** (octets) Module=XD-Chassis, Model=5020
  Binding #7: p2chassisID.99.0 *** (int32) 99
  Binding #8: p2slotID.99.0 *** (int32) 0
  Binding #9: p2moduleCLLIcode.0.0 *** (octets) Grayson
  Binding #10: p2moduleCLEIcode.0.0 *** (octets) N/A
  Binding #11: p2TrapLogTime *** (octets) 2007-12-17,17:34:44.62
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 17 Dec 2007 17:34:44 EST
  Binding #13: p2TrapLogValue *** (octets) 28.75
  Binding #14: p2TrapLogUnit *** (octets) degC
  Binding #15: p2TrapLogDescr *** (octets) ChasTemp exceeded minor threshold

```

Alarm Minor Clear

Specific: 9

```

Message reception date: 12/17/2007
Message reception time: 5:35:46 PM
Time stamp: 4 days 02h:03m:31s.50th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 192.168.1.149
  Port: 1180
Manager
  Address: 192.168.1.7
  Port: 162
Community: prismatrap
SNMPv1 agent address: 192.168.1.149
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 80
  Binding #2: p2TrapLogSeverity *** (int32) minor(2)
  Binding #3: p2TrapLogState *** (int32) clear(2)
  Binding #4: p2almLabel.99.0.4 *** (octets) ChasTemp
  Binding #5: p2almIndex.99.0 *** (int32) 4
  Binding #6: p2TrapLogText *** (octets) Module=XD-Chassis, Model=5020
  Binding #7: p2chassisID.99.0 *** (int32) 99
  Binding #8: p2slotID.99.0 *** (int32) 0
  Binding #9: p2moduleCLLIcode.99.0 *** (octets) Grayson
  Binding #10: p2moduleCLEIcode.99.0 *** (octets) N/A
  Binding #11: p2TrapLogTime *** (octets) 2007-12-17,17:35:52.62
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 17 Dec 2007 17:35:52 EST
  Binding #13: p2TrapLogValue *** (octets) 25.75
  Binding #14: p2TrapLogUnit *** (octets) degC
  Binding #15: p2TrapLogDescr *** (octets) ChasTemp within minor threshold

```

Enhanced Trap Events

The current system release supports Enhanced traps that alert management to certain events related to user login, changes to system settings, event log memory usage, SNMP failures, and user lockout activity.

All event traps display binding 2 (severity) as warning (3) and binding 3 (state) as event (3).

Binding 4 (label) may be an alarm label, or may include any of the following event types:

- Admin Change
- Authentication Failed
- Download Complete (reserved for future use)
- IP Change
- Login Threshold
- Log (Event Log)
- Module Insert
- Module Remove
- Reboot
- SelfTest
- SNMP (reserved for future use)
- Update Chassis IDs
- User Lockout

For example:

```
Binding #2: p2TrapLogSeverity *** (int32) warning(3)
Binding #3: p2TrapLogState *** (int32) event(3)
Binding #4: p2TrapLogLabel *** (octets) AdminChange
```

This section describes the events that cause each of these traps to be sent and gives examples of each trap where appropriate.

AdminChange

An AdminChange trap is sent when an Admin user performs one of the following actions.

- Add a user
- Change a password
- Change access level

- Enable or disable the status of a user
- Delete a user
- Fail to add a user because the list of users is full (16)
- Change the inactivity timeout
- Change the login thresholds
- Change the User Lockout interval setting

Admin Change Example - Add New User

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:46:53.476 PM
Time stamp: 2 days 22h:12m:43s.91th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1055
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 22
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AdminChange
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLlcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:46:35.19
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:46:35 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Add user ReadWrite3

```

Admin Change Example - Change ICIM2 or ICIM2-XD Setting (Inactivity Timer)

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:25:26.078 PM
Time stamp: 2 days 21h:51m:16s.53th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1054
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 21
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AdminChange
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLlcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:25:7.77
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:25:07 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Change inactivity timer setting
    to: 10 minutes

```

Admin Change Example - Change ICIM2 or ICIM2-XD Setting (Login Threshold)

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:19:04.310 PM
Time stamp: 2 days 21h:44m:54s.78th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1049
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 16
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AdminChange
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLlcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:18:46.0
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:18:46 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Change login threshold setting
    to: 5 minutes

```

Admin Change Example - Change User Password

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:48:37.618 PM
Time stamp: 2 days 22h:14m:28s.06th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1056
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 23
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AdminChange
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLlcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:48:19.34
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:48:19 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Changed user password for
    ReadWrite3

```

Admin Change Example - Delete User

```
Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:50:06.243 PM
Time stamp: 2 days 22h:15m:56s.68th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1057
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 24
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AdminChange
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:49:47.97
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:49:47 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Delete user ReadWrite3
```

AuthentictnFailed

An AuthentictnFailed trap is sent when a user login (authentication) fails due to one of the following causes:

- The user ID is disabled.
- The password is not correct.
- The user ID is not correct or is not found.
- There are too many users logged into the ICIM2 or ICIM2-XD at the current time.
- The list of valid users could not be retrieved from the EEPROM.

Authentication Failed - Password incorrect

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:15:21.261 PM
Time stamp: 2 days 21h:41m:11s.73th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1048
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 15
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AuthentictnFailed
  Binding #5: p2icimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:15:2.94
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:15:02 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Password failed: Administrat0r

```

Authentication Failed - User ID Disabled

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 4:31:48.399 PM
Time stamp: 0 days 00h:06m:26s.51th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.151
  Port: 1047
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.151
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 24
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) AuthentictnFailed
  Binding #5: p2icimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.3.15 *** (int32) 3
  Binding #8: p2slotID.3.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.3.15 *** (octets) icimCLLIcode7
  Binding #10: p2moduleCLEIcode.3.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,16:33:14.89
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 16:33:14 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Try to login to a disabled account:
    bogusUser2

```

Download Complete

This trap is reserved for future use.

IP Change

An IPChange trap is sent as notification that the IP address of the ICIM2 or ICIM2-XD has been changed.

IP Change Example - ICIM2 or ICIM2-XD IP Change

```
Specific: 9
Message reception date: 8/25/2006
Message reception time: 10:03:30.896 AM
Time stamp: 0 days 00h:15m:19s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1030
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 7
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) IPchange
  Binding #5: p2icimIPAddr *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM IP address changed --
    172.24.28.151.
  Binding #7: p2icimChassisID *** (int32) 0
  Binding #8: p2icimSlotID *** (int32) 15
  Binding #9: p2icimCLLIcode *** (octets) SCIATL01
  Binding #10: p2icimCLEIcode *** (octets) VLLUAA4DAA
  Binding #11: p2TrapLogTime *** (octets) 2006-8-25,10:5:8.42
  Binding #12: p2TrapLogDateTime *** (octets) Fri, 25 Aug 2006 10:05:08 EDT
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) ICIM IP Address has been changed
```

LoginThreshold

The LoginThreshold trap is sent when a user reaches the number of failed login attempts via the CLI or Web Interface as allowed by the login threshold.

Login Threshold Example - Too Many Failed Login Attempts

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 1:19:29.216 PM
Time stamp: 2 days 21h:45m:19s.70th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.25.175
  Port: 1052
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.25.175
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 19
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) LoginThreshold
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.1.15 *** (int32) 1
  Binding #8: p2slotID.1.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.1.15 *** (octets) Engineering Lab
  Binding #10: p2moduleCLEIcode.1.15 *** (octets) ICIMCLEI75
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,13:19:10.91
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 13:19:10 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Maximum failed session login
  attempts reached

```

Log Memory Traps

The event log traps LogMemHalfFull or LogMemoryFull are sent when the event log is nearing capacity. Traps are sent at each of the following intervals.

- 80% full
- 85% full
- 90% full
- 95% full
- 100% full

When all 5,000 entries in the event log table are filled, the LogMemoryFull trap is sent. New entries then replace the oldest entries as the information wraps. No additional LogMemoryFull traps are sent.

LogMemHalfFull Example

```

Specific: 9
Message reception date: 9/13/2006
Message reception time: 2:27:25.066 PM
Time stamp: 0 days 00h:11m:20s.13th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.193
  Port: 1035
Manager
  Address: 172.18.9.66
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.193
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 12
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) LogMemHalfFull
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2ChassisID.2.15 *** (int32) 2
  Binding #8: p2SlotID.2.15 *** (int32) 15
  Binding #9: p2ModuleCLLlCode.2.15 *** (octets) 1.2.243
  Binding #10: p2ModuleCLEIcode.2.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-9-13,1:51:39.42
  Binding #12: p2TrapLogDateTime *** (octets) Wed, 13 Sep 2006 01:51:39 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Log memory is %80 full

```

LogMemoryFull Example

```

Specific: 9
Message reception date: 9/13/2006
Message reception time: 2:44:27.081 PM
Time stamp: 0 days 00h:28m:22s.13th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.193
  Port: 1039
Manager
  Address: 172.18.9.66
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.193
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 16
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) LogMemoryFull
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2ChassisID.2.15 *** (int32) 2
  Binding #8: p2SlotID.2.15 *** (int32) 15
  Binding #9: p2ModuleCLLlCode.2.15 *** (octets) 1.2.243
  Binding #10: p2ModuleCLEIcode.2.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-9-13,2:8:41.45
  Binding #12: p2TrapLogDateTime *** (octets) Wed, 13 Sep 2006 02:08:41 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Log memory is %100 full

```

LogWriteError

An Event trap is sent when an attempt to write to the event log fails. This serves as a backup to alert the management system to a problem writing to the event log.

LogWriteError Example

```
Specific: 9
Message reception date: 9/13/2006
Message reception time: 2:44:27.081 PM
Time stamp: 0 days 00h:28m:22s.13th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.193
  Port: 1039
Manager
  Address: 172.18.9.66
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.193
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 16
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) LogWriteError
  Binding #5: p2IcimStatusMsg.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.2.15 *** (int32) 2
  Binding #8: p2slotID.2.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.2.15 *** (octets) 1.2.243
  Binding #10: p2moduleCLEIcode.2.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-9-13,2:8:41.45
  Binding #12: p2TrapLogDateTime *** (octets) Wed, 13 Sep 2006 02:08:41 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) Log error, can't log message:
    Password failed: UserName14
```

Module Insert

A ModuleInsert trap is sent when an application module is inserted into a chassis in the ICIM2 or ICIM2-XD domain.

Module Insert Example

```
Specific: 9
Message reception date: 8/22/2006
Message reception time: 4:54:36.478 PM
Time stamp: 0 days 01h:09m:16s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1034
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 11
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) ModuleInsert
  Binding #5: p2InsertModuleEntry *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) Not available
  Binding #7: p2chassisID.0.11 *** (int32) 0
  Binding #8: p2slotID.0.11 *** (int32) 11
  Binding #9: p2moduleCLLlcode.0.11 *** (octets) SCIATL01
  Binding #10: p2moduleCLEIcode.0.11 *** (octets) CLEIcode
  Binding #11: p2TrapLogTime *** (octets) 2006-8-22,16:54:36.45
  Binding #12: p2TrapLogDateTime *** (octets) Tue, 22 Aug 2006 16:54:36 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) A module has been inserted into a
    chassis
```

ModuleRemove

A ModuleRemove trap is sent when an application module is removed from a chassis in the ICIM2 or ICIM2-XD domain.

Module Remove Example

```

Specific: 9
Message reception date: 8/22/2006
Message reception time: 4:34:08.853 PM
Time stamp: 0 days 00h:48m:48s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1033
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 10
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) ModuleRemove
  Binding #5: p2RemoveModuleEntry *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) Not available
  Binding #7: p2chassisID.0.11 *** (int32) 0
  Binding #8: p2slotID.0.11 *** (int32) 11
  Binding #9: p2moduleCLLlcode.0.11 *** (octets) SCIATL01
  Binding #10: p2moduleCLEIcode.0.11 *** (octets) CLEIcode
  Binding #11: p2TrapLogTime *** (octets) 2006-8-22,16:34:8.84
  Binding #12: p2TrapLogDateTime *** (octets) Tue, 22 Aug 2006 16:34:08 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) A module has been removed from a
    chassis

```

Reboot

The Reboot trap is sent when an ICIM2, ICIM2-XD, or application module has been commanded to reboot, either individually or as a result of a broadcast reboot command.

Reboot Example - Broadcast Reboot Command

```

Specific: 9
Message reception date: 8/28/2006
Message reception time: 2:20:20.014 PM
Time stamp: 0 days 00h:03m:34s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1032
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 9
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) RebootCommand
  Binding #5: p2IcimStatusMsg *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) Broadcast
  Binding #7: p2chassisID.99.99 *** (int32) 99
  Binding #8: p2slotID.99.99 *** (int32) 99
  Binding #9: p2moduleCLLlcode.99.99 *** (octets) N/A
  Binding #10: p2moduleCLEIcode.99.99 *** (octets) N/A
  Binding #11: p2TrapLogTime *** (octets) 2006-8-28,14:20:20.43
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 28 Aug 2006 14:20:20 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) An ICIM/module has been commanded
    to reboot (CH 99 SL 99 indicates a broadcast reboot)

```

Reboot Example - Reboot ICIM2 or ICIM2-XD Command

```

Specific: 9
Message reception date: 8/22/2006
Message reception time: 3:44:20.455 PM
Time stamp: 0 days 00h:10m:17s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1034
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 11
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) RebootCommand
  Binding #5: p2IcimStatusMsg *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) Broadcast
  Binding #7: p2chassisID.99.99 *** (int32) 99
  Binding #8: p2slotID.99.99 *** (int32) 99
  Binding #9: p2moduleCLLlcode.99.99 *** (octets) SCIATL01
  Binding #10: p2moduleCLEIcode.99.99 *** (octets) CLEIcode
  Binding #11: p2TrapLogTime *** (octets) 2006-8-22,15:44:21.0
  Binding #12: p2TrapLogDateTime *** (octets) Tue, 22 Aug 2006 15:44:21 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) An ICIM/module has been commanded
    to reboot (CH 99 SL 99 indicates a broadcast reboot)

```

SelfTest

A SelfTest trap is sent when either the ICIM2, ICIM2-XD, or application module fails its power-on self test.

SelfTest Example - ICIM2 or ICIM2-XD Failure

```
Specific: 9
Message reception date: 8/25/2006
Message reception time: 9:43:26.623 AM
Time stamp: 0 days 00h:00m:57s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1024
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 1
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) SelfTest
  Binding #5: p2icimSelfTest *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) SelfTest Failed - Error Code 16777232
  Binding #7: p2icimChassisID *** (int32) 0
  Binding #8: p2icimSlotID *** (int32) 15
  Binding #9: p2icimCLLIcode *** (octets) SCIATL01
  Binding #10: p2icimCLEIcode *** (octets) VLLUAA4DAA
  Binding #11: p2TrapLogTime *** (octets) 2006-8-25,9:45:1.76
  Binding #12: p2TrapLogDateTime *** (octets) Fri, 25 Aug 2006 09:45:01 EDT
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) An ICIM/module has failed its
power-on self test
```

SelfTest Example - Module Failure

```
Specific: 9
Message reception date: 8/25/2006
Message reception time: 9:49:50.657 AM
Time stamp: 0 days 00h:01m:39s.00th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.2.5.168
  Port: 1024
Manager
  Address: 172.24.3.151
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.2.5.168
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 1
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) SelfTest
  Binding #5: p2moduleSelfTest.0.0 *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) SelfTest Failed - Error Code 33558528
  Binding #7: p2chassisID.0.0 *** (int32) 0
  Binding #8: p2slotID.0.0 *** (int32) 0
  Binding #9: p2moduleCLLIcode.0.0 *** (octets) SCIATL01
  Binding #10: p2moduleCLEIcode.0.0 *** (octets)CLEIcode
  Binding #11: p2TrapLogTime *** (octets) 2006-8-25,9:51:28.17
  Binding #12: p2TrapLogDateTime *** (octets) Fri, 25 Aug 2006 09:51:28 EDT
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) An ICIM/module has failed its
    power-on self test
```

SNTP

This trap is reserved for future use.

UpdateChassisID

The UpdateChassisID trap is sent to indicate that the ICIM2 or ICIM2-XD is rediscovering the domain as a result of one of the following actions.

- The p2icimUpdateChassisID is set to 1 via SNMP.
- The CLI command `set updateid 1` is issued from the ICIM> command prompt.

UpdateChassisID Example

```

Specific: 9
Message reception date: 10/30/2006
Message reception time: 12:39:26.263 PM
Time stamp: 0 days 00h:04m:32s.51th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 172.24.28.151
  Port: 1037
Manager
  Address: 172.18.10.23
  Port: 162
Community: prismatrap
SNMPv1 agent address: 172.24.28.151
Enterprise: p2trapEvents
Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 14
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) UpdateChassisIDs
  Binding #5: p2IcimUpdateChassisIDs *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.4.15 *** (int32) 4
  Binding #8: p2slotID.4.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.4.15 *** (octets) icimCLLIcode7
  Binding #10: p2moduleCLEIcode.4.15 *** (octets) (zero-length)
  Binding #11: p2TrapLogTime *** (octets) 2006-10-30,12:40:9.94
  Binding #12: p2TrapLogDateTime *** (octets) Mon, 30 Oct 2006 12:40:09 EST
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) A user requested update for all
    chassis IDs has occurred

```

UserLockout

The UserLockout trap is sent whenever a user is locked out as a result of reaching the failed login attempts threshold. The UserLockout event may result in the following message:

- User <user_name> has reached maximum failed login attempts and been locked out.

UserLockout Example

```
Specific: 9
Message reception date: 3/15/2007
Message reception time: 2:15:02.352 PM
Time stamp: 0 days 00h:21m:11s.61th
Message type: Trap (v1)
Protocol version: SNMPv1
Transport: IP/UDP
Agent
  Address: 190.2.0.110
  Port: 1056
Manager
  Address: 190.2.0.108
  Port: 162
Community: prismatrap
SNMPv1 agent address: 190.2.0.114
Enterprise: p2trapEvents
  Bindings (15)
  Binding #1: p2TrapLogSequence *** (int32) 32
  Binding #2: p2TrapLogSeverity *** (int32) warning(3)
  Binding #3: p2TrapLogState *** (int32) event(3)
  Binding #4: p2TrapLogLabel *** (octets) UserLockout
  Binding #5: p2icimStatusMsg *** (int32) 0
  Binding #6: p2TrapLogText *** (octets) ICIM2
  Binding #7: p2chassisID.3.15 *** (int32) 3
  Binding #8: p2slotID.3.15 *** (int32) 15
  Binding #9: p2moduleCLLIcode.3.15 *** (octets) ICIMCLLI
  Binding #10: p2moduleCLEIcode.3.15 *** (octets) VLLUAA4DAA
  Binding #11: p2TrapLogTime *** (octets) 2007-3-15,14:15:1.84
  Binding #12: p2TrapLogDateTime *** (octets) Thu, 15 Mar 2007 14:15:01 EDT
  Binding #13: p2TrapLogValue *** (octets) N/A
  Binding #14: p2TrapLogUnit *** (octets) N/A
  Binding #15: p2TrapLogDescr *** (octets) User ferret3 has reached maximum
    failed login attempts and been locked out.
```

Alarm Threshold Modification

The meaning of an alarm value depends on the type of alarm. For example, a p2almValue of 0 (zero) indicates OK for a Boolean alarm type (p2almType = 5 or 6), but signals a Major Low alarm for a Non-Boolean alarm type (p2almType = 1, 2, 3, 4, 7 or 8). For more information, see *Module Alarm Table* (on page 220).

The following example illustrates how an alarm threshold may be set, and the subsequent behavior that results from violating the alarm threshold. This behavior includes a module going into an alarm state and a trap being sent.

- 1 First, observe that the actual value of the +24 V rail voltage from DC-to-DC converter B is 24.0095 V, as found in the p2moduleMonitorTable shown below.

Instance	p2monitorIndex(IDX)	p2monitorLabel	p2monitorValue	p2monitorUnit	p2monitorType	p2monitorStateNames
1.0.1	1	ConvA+24	24.1499	V	F	N/A
1.0.2	2	ConvA+5	5.28269	V	F	N/A
1.0.3	3	ConvA-5	-5.26423	V	F	N/A
1.0.4	4	ConvB+24	24.0095	V	F	N/A
1.0.5	5	ConvB+5	5.27484	V	F	N/A
1.0.6	6	ConvB-5	-5.2905	V	F	N/A
1.0.7	7	PSA Inst	1	N/A	S	[0] No, [1] Yes
1.0.8	8	PSB Inst	1	N/A	S	[0] No, [1] Yes
1.0.9	9	ConvAlns	1	N/A	S	[0] No, [1] Yes
1.0.10	10	ConvBlns	1	N/A	S	[0] No, [1] Yes
1.0.11	11	Chas+24V	24.1177	V	F	N/A
1.0.12	12	Chas+5V	5.0277	V	F	N/A

TP479

- 2 Next, moving to the Module Alarm table, we change the minor low limit from 18.4 to 24.9, as shown below.

Instance	p2almIndex(IDX)	p2almLabel	p2almValue	p2almType	p2almNominal	p2almHysteresis	p2almMajorLowLimit	p2almMinorLowLimit	p2almMinorHighLimit
1.0.1	1	Fan 1 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.2	2	Fan 2 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.3	3	Fan 3 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.4	4	ChasTemp	2 (ok)	2	25	1	-40	-35	60
1.0.5	5	ConvAln	0 (ok)	5	1	N/A	N/A	N/A	N/A
1.0.6	6	ConvA+24	2 (ok)	2	24.7	0.1	18	18.4	25.9
1.0.7	7	ConvA+5	2 (ok)	2	5.4	0.1	3.6	3.7	5.9
1.0.8	8	ConvA-5	2 (ok)	2	-5.4	0.1	-5.6	-5.5	-4.6
1.0.9	9	ConvBln	0 (ok)	5	1	N/A	N/A	N/A	N/A
1.0.10	10	ConvB+24	2 (ok)	2	24.7	0.1	18	24.9	25.9
1.0.11	11	ConvB+5	2 (ok)	2	5.4	0.1	3.6	3.7	5.9
1.0.12	12	ConvB-5	2 (ok)	2	-5.4	0.1	-5.6	-5.5	-4.6
1.1.1	1	LasTemp	2 (ok)	3	40	1	-15	-5	5
1.1.2	2	LasBias	2 (ok)	3	75	3	-20	-10	10
1.1.3	3	InRF	2 (ok)	1	0	0.5	-1000	-5	5
1.1.4	4	TxEnable	0 (ok)	6	0	N/A	N/A	N/A	N/A
1.1.5	5	OutPwr	2 (ok)	1	2.9	0.1	-1	-0.5	0.5
1.1.6	6	CwMode	0 (ok)	5	1	N/A	N/A	N/A	N/A

TP480

- Because the actual value (24.0095) of the +24 V rail converter B is less than the Minor Low limit of 24.9, an Enhanced trap for a Minor alarm is sent. A copy of the trap is kept in the Trap Logging table, as shown below.

Instance	p2TrapLogSequenceID(X)	p2TrapLogSeverity	p2TrapLogState	p2TrapLogLabel	p2TrapLogOID	p2TrapLogText
93	93	minor(2)	alarm(1)	ConvB+24	p2almIndex.1.0.10	Module=XD-Chassis, Model=5020
92	92	major(1)	clear(2)		p2almIndex.2.3.4	Module=P2-HD-RXF, Model=2015
91	91	major(1)	alarm(1)	Alarm	p2almIndex.2.3.4	Module=P2-HD-RXF, Model=2015
90	90	major(1)	clear(2)	Alarm	p2almIndex.2.3.4	Module=P2-HD-RXF, Model=2015
89	89	major(1)	alarm(1)	Alarm	p2almIndex.2.3.4	Module=P2-HD-RXF, Model=2015
88	88	major(1)	clear(2)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
87	87	major(1)	alarm(1)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
86	86	major(1)	clear(2)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
85	85	major(1)	alarm(1)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
84	84	major(1)	clear(2)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
83	83	major(1)	alarm(1)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
82	82	major(1)	clear(2)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
81	81	major(1)	alarm(1)	CwMode	p2almIndex.1.1.6	Module=HDTx, Model=1020
80	80	warning(3)	event(3)	UpdateChassisIDs	p2cimUpdateChassisIDs.0	ICIM2

TP481

- Now, we change the minor low limit back to 18.4 in the Module Alarm table, as shown below.

Instance	p2almIndex(IDX)	p2almLabel	p2almValue	p2almType	p2almNominal	p2almHysteresis	p2almMajorLowLimit	p2almMinorLowLimit	p2almMinorHighLimit
1.0.1	1	Fan 1 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.2	2	Fan 2 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.3	3	Fan 3 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.4	4	ChasTemp	2 (ok)	2	25	1	-40	-35	60
1.0.5	5	ConvAln	0 (ok)	5	1	N/A	N/A	N/A	N/A
1.0.6	6	ConvA+24	2 (ok)	2	24.7	0.1	18	18.4	25.9
1.0.7	7	ConvA+5	2 (ok)	2	5.4	0.1	3.6	3.7	5.9
1.0.8	8	ConvA-5	2 (ok)	2	-5.4	0.1	-5.6	-5.5	-4.6
1.0.9	9	ConvBln	0 (ok)	5	1	N/A	N/A	N/A	N/A
1.0.10	10	ConvB+24	1 (minor lo...)	2	24.7	0.1	18	18.4	25.9
1.0.11	11	ConvB+5	2 (ok)	2	5.4	0.1	3.6	3.7	5.9
1.0.12	12	ConvB-5	2 (ok)	2	-5.4	0.1	-5.6	-5.5	-4.6
1.1.1	1	LasTemp	2 (ok)	3	40	1	-15	-5	5
1.1.2	2	LasBias	2 (ok)	3	75	3	-20	-10	10
1.1.3	3	InRF	2 (ok)	1	0	0.5	-1000	-5	5
1.1.4	4	TxEEnable	0 (ok)	6	0	N/A	N/A	N/A	N/A
1.1.5	5	OutPwr	2 (ok)	1	2.9	0.1	-1	-0.5	0.5
1.1.6	6	CwMode	0 (ok)	5	1	N/A	N/A	N/A	N/A

TP482

When we do this, an Enhanced trap for a Minor clear is generated, and a copy of the trap is kept in the Trap Logging table.

- Finally, returning to the Module Alarm table, we note that the alarm value has changed from 1 (Minor Low) to 2 (OK).

Instance	p2almIndex(IDX)	p2almLabel	p2almValue	p2almType	p2almNominal	p2almHysteresis	p2almMajorLowLimit	p2almMinorLowLimit	p2almMinorHighLimit
1.0.1	1	Fan 1 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.2	2	Fan 2 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.3	3	Fan 3 Ok	0 (ok)	6	1	N/A	N/A	N/A	N/A
1.0.4	4	ChasTemp	2 (ok)	2	25	1	-40	-35	60
1.0.5	5	ConvAln	0 (ok)	5	1	N/A	N/A	N/A	N/A
1.0.6	6	ConvA+24	2 (ok)	2	24.7	0.1	18	18.4	25.9
1.0.7	7	ConvA+5	2 (ok)	2	5.4	0.1	3.6	3.7	5.9
1.0.8	8	ConvA-5	2 (ok)	2	-5.4	0.1	-5.6	-5.5	-4.6
1.0.9	9	ConvBln	0 (ok)	5	1	N/A	N/A	N/A	N/A
1.0.10	10	ConvB+24	2 (ok)	2	24.7	0.1	18	18.4	25.9
1.0.11	11	ConvB+5	2 (ok)	2	5.4	0.1	3.6	3.7	5.9
1.0.12	12	ConvB-5	2 (ok)	2	-5.4	0.1	-5.6	-5.5	-4.6
1.1.1	1	LasTemp	2 (ok)	3	40	1	-15	-5	5
1.1.2	2	LasBias	2 (ok)	3	75	3	-20	-10	10
1.1.3	3	InRF	2 (ok)	1	0	0.5	-1000	-5	5
1.1.4	4	TxEEnable	0 (ok)	6	0	N/A	N/A	N/A	N/A
1.1.5	5	OutPwr	2 (ok)	1	2.9	0.1	-1	-0.5	0.5
1.1.6	6	CwMode	0 (ok)	5	1	N/A	N/A	N/A	N/A

TP483

System Behavior

ICIM2 as Proxy for Module Information

The user gains access to information about modules in the ICIM2 or ICIM2-XD domain through the ICIM2 or ICIM2-XD via SNMP and the MIBs. A virtual database in the ICIM2 or ICIM2-XD keeps track of data supplied by each module. The ICIM2 or ICIM2-XD periodically refreshes this database to ensure that the information it provides is up-to-date.

In this way, all module information obtained via SNMP is proxied through the ICIM2 or ICIM2-XD. Because the modules never interface directly with SNMP, this proxy behavior differs from that of SNMP Proxy Agents, and the two methods should not be confused with each other.

Delay in the Discovery Process

Depending on when an event occurs in relation to the ICIM2 or ICIM2-XD polling cycle, a user may notice delays in the discovery process.

Such delays may be experienced when inserting or removing a module. For example, if the ICIM2 or ICIM2-XD has just polled a module in chassis 02 slot 06, and the module is removed, it may be several seconds before the ICIM2 or ICIM2-XD realizes that chassis 02 slot 06 is empty. Once the empty slot is detected, and if trap destination is configured, a trap indicating module removal will be sent.

Depending on the number of modules managed by an ICIM2 or ICIM2-XD and the timing of the polling cycle, it may be possible to remove and re-insert a module from chassis 02 slot 06, for example, without the ICIM2 or ICIM2-XD even detecting that it was missing.

Module Removal and Enhanced Traps

If a module is removed, an Enhanced trap is sent. No other traps indicating alarms or clearings are sent for that module. Once again, because of the delay in the discovery process, it may be possible to remove and reinsert a module without traps being sent.

Frequently Asked Questions

How do I configure trap destination?

Trap destination is set up via an entry into the p2TrapRecvTable. Select an index (choices are 0 through 9) that is not currently used for trap destination.

Note: Some element management systems access and populate the first two entries (0 and 1), making them unavailable for user configuration.

- 1 Set p2TrapRecvEnable to enabled (2).
- 2 Set p2TrapRecvAddr to the IP address of the remote entity, in the format 172.0.0.1.
- 3 Set p2TrapRecvTelcoAlarm to enabled (2).

Instance	p2TrapRecvIndex(IDX)	p2TrapRecvEnable	p2TrapRecvAddr	p2TrapRecvIPC	Command	p2TrapRecvSelfTest	p2TrapRecvTelcoAlarm
0	0	enabled(2)	172.18.50.42	enabled(2)		disabled(1)	enabled(2)
1	1	enabled(2)	172.18.50.3	enabled(2)		disabled(1)	enabled(2)
2	2	enabled(2)	172.18.50.6	enabled(2)		disabled(1)	enabled(2)
3	3	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
4	4	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
5	5	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
6	6	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
7	7	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
8	8	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)
9	9	disabled(1)	0.0.0.0	disabled(1)		disabled(1)	enabled(2)

TP490

Note: Enable the row, or traps will not be sent.

For additional information, see *To Configure Trap Destination* (on page 241), *Trap Types* (on page 242), and *Trap Recv Table* (on page 202).

Why do the same alarm values represent different conditions?

For example, why does an alarm value of zero sometimes mean "OK," and other times indicate a state of alarm? The answer is that the alarm value and the alarm type are inseparably linked, with the meaning of the alarm value inherently connected with the type of alarm.

For example:

- A zero in p2almValue indicates that all is fine for a Boolean (p2almType 5 or 6).
- A zero in p2almValue indicates a major low alarm for a Non-Boolean (p2almType 1, 2, 3, 4, 7 or 8).

For additional information, see the sections on alarms in *Module Alarm Table* (on page 220).

How do Enhanced Traps differ from other trap types?

The Enhanced traps contain additional information in the bindings that is not included in the original proprietary traps.

All proprietary traps are represented with the Enhanced traps. If Enhanced traps are enabled and if the row in the p2TrapRecvTable is enabled, all traps will be sent to the IP address set in that particular row.

All trap settings are documented for completeness only. Information contained in other proprietary traps is expanded upon in the Enhanced traps. Use of the older traps is not recommended, as the new Enhanced trap is more useful. Enabling other traps together with the Enhanced trap will cause two traps to be sent for each event. For more information, see *Prisma II Traps* (on page 239), *Trap Types* (on page 242), and *Enhanced Trap Binding Information* (on page 253).

When do traps associated with module insertion, removal, and alarms occur?

If modules are in a state of alarm, traps are generated at module insertion, module startup, chassis startup, or ICIM2 or ICIM2-XD startup. If p2TrapRecvTable is not configured with IP addresses, rows enabled, and Enhanced traps enabled, no traps are sent for alarms detected at startup.

If a module is inserted after a steady-state condition is reached, a trap is generated when the ICIM2 or ICIM2-XD recognizes the insertion event. This fact is recorded in p2InsertModuleTable. Also, if the module is in a state of alarm, this will be indicated with startup traps. For additional information, see *System Behavior* (on page 279).

Upon removal of a module, and once the ICIM2 or ICIM2-XD detects the change, a trap is generated. Module removal is detected by continued lack of response to internal ICIM2 or ICIM2-XD polling of the module, so it may take several polling cycles to discover that the module was removed. However, no traps will be sent to clear the alarms.

After a module is removed, the ICIM2 or ICIM2-XD keeps no further information on the module except what appears in p2RemoveModuleTable.

After the modules are discovered by the ICIM2 or ICIM2-XD and initial alarms are acknowledged by traps, subsequent alarm traps are edge-triggered. Thus, alarm traps are generated upon module startup, and if there is a change in the state of an alarm following initial discovery.

Tip: Enable the row, set the IP address, and enable Enhanced traps, or startup alarm traps will not be sent or logged.

Where can I find trap definitions?

Because trap bindings are defined in the code, we have added comments describing Enhanced traps in the SCIATL-PRISMAII-ICIM-MIB. The current document also describes the behavior of all proprietary traps and the bindings associated with each trap.

What is the Trap Logging Table?

If trap destination is configured and enabled for Enhanced traps, the Trap Logging table maintains a listing of Enhanced traps sent. Each entry in the table contains all of the bindings of the original trap. The table serves as a backup in the event of network connectivity failure.

The Trap Logging table holds up to 1,000 entries. When the table gets full, each new entry causes the oldest one to age out of the listing, leaving the most recent 1,000 entries.

The figure below illustrates the Trap Logging table with several entries.

Instance	p2TrapLogSequenceID	p2TrapLogSeverity	p2TrapLogState	p2TrapLogLabel	p2TrapLogOID	p2TrapLogText	p2TrapLogChannelID	p2TrapLogSlotID	p2TrapLogCLLcode	p2TrapLogCLEcode	p2T
1	1	minor(2)	alarm(1)	InRF	p2almindex.1.2.3	ModuleHD Tx, Model=1020	1	2	N/A	N/A	200
2	2	minor(2)	alarm(1)	InRF	p2almindex.1.3.3	ModuleHD Tx, Model=1020	1	3	N/A	N/A	200
3	3	minor(2)	alarm(1)	InRF	p2almindex.1.4.3	ModuleHD Tx, Model=1020	1	4	N/A	N/A	200
4	4	major(1)	alarm(1)	InRF	p2almindex.1.5.3	ModuleHD Tx, Model=1032	1	5	N/A	N/A	200
5	5	minor(2)	alarm(1)	InRF	p2almindex.1.7.3	ModuleHD Tx, Model=1032	1	7	N/A	N/A	200
6	6	minor(2)	alarm(1)	InRF	p2almindex.1.8.3	ModuleHD Tx, Model=1032	1	8	N/A	N/A	200
7	7	minor(2)	alarm(1)	InRF	p2almindex.1.9.3	ModuleHD Tx, Model=1032	1	9	N/A	N/A	200
8	8	minor(2)	alarm(1)	InRF	p2almindex.1.10.3	ModuleHD Tx, Model=1032	1	10	N/A	N/A	200
9	9	minor(2)	alarm(1)	InRF	p2almindex.1.11.3	ModuleHD Tx, Model=1032	1	11	N/A	N/A	200
10	10	minor(2)	alarm(1)	InRF	p2almindex.1.12.3	ModuleHD Tx, Model=1032	1	12	N/A	N/A	200
11	11	minor(2)	alarm(1)	InRF	p2almindex.1.13.3	ModuleHD Tx, Model=1032	1	13	N/A	N/A	200
12	12	minor(2)	alarm(1)	InRF	p2almindex.1.14.3	ModuleHD Tx, Model=1032	1	14	N/A	N/A	200
13	13	minor(2)	alarm(1)	InRF	p2almindex.1.16.3	ModuleHD Tx, Model=1032	1	16	N/A	N/A	200
14	14	major(1)	alarm(1)	InPwr	p2almindex.2.1.1	ModuleP2HD-PDF, Model=2015	2	1	N/A	N/A	200
15	15	major(1)	alarm(1)	Alarm	p2almindex.2.1.4	ModuleP2HD-PDF, Model=2015	2	1	N/A	N/A	200
16	16	major(1)	alarm(1)	InPwr	p2almindex.2.2.1	ModuleP2HD-PDF, Model=2015	2	2	N/A	N/A	200
17	17	major(1)	alarm(1)	Alarm	p2almindex.2.2.1	ModuleP2HD-PDF, Model=2015	2	2	N/A	N/A	200

Trap	p2TrapLogChannelID	p2TrapLogSlotID	p2TrapLogCLLcode	p2TrapLogCLEcode	p2TrapLogTime	p2TrapLogDateTime	p2TrapLogValue	p2TrapLog	p2TrapLogDesc
HD Tx, Model=1020	1	2	N/A	N/A	2007-11-27:10:8:42.75	Tue, 27 Nov 2007 10:08:42 EST	-13.2618	dB	InRF exceeded minor threshold
HD Tx, Model=1020	1	3	N/A	N/A	2007-11-27:10:8:44.50	Tue, 27 Nov 2007 10:08:44 EST	-13.8482	dB	InRF exceeded minor threshold
HD Tx, Model=1020	1	4	N/A	N/A	2007-11-27:10:8:45.05	Tue, 27 Nov 2007 10:08:45 EST	-12.9002	dB	InRF exceeded minor threshold
HD Tx, Model=1032	1	5	N/A	N/A	2007-11-27:10:8:47.20	Tue, 27 Nov 2007 10:08:47 EST	50	dB	RF input exceeds major threshold
HD Tx, Model=1032	1	7	N/A	N/A	2007-11-27:10:8:49.78	Tue, 27 Nov 2007 10:08:49 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	8	N/A	N/A	2007-11-27:10:8:51.10	Tue, 27 Nov 2007 10:08:51 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	9	N/A	N/A	2007-11-27:10:8:52.41	Tue, 27 Nov 2007 10:08:52 EST	50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	10	N/A	N/A	2007-11-27:10:8:53.70	Tue, 27 Nov 2007 10:08:53 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	11	N/A	N/A	2007-11-27:10:8:55.1	Tue, 27 Nov 2007 10:08:55 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	12	N/A	N/A	2007-11-27:10:8:56.33	Tue, 27 Nov 2007 10:08:56 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	13	N/A	N/A	2007-11-27:10:8:57.65	Tue, 27 Nov 2007 10:08:57 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	14	N/A	N/A	2007-11-27:10:8:58.96	Tue, 27 Nov 2007 10:08:58 EST	-50	dB	RF input exceeds minor threshold
HD Tx, Model=1032	1	16	N/A	N/A	2007-11-27:10:8:1.56	Tue, 27 Nov 2007 10:09:01 EST	50	dB	RF input exceeds minor threshold
P2HD-PDF, Model=2015	2	1	N/A	N/A	2007-11-27:10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	-21.2668	dBm	InPwr exceeded major threshold
P2HD-PDF, Model=2015	2	1	N/A	N/A	2007-11-27:10:9:4.75	Tue, 27 Nov 2007 10:09:04 EST	N/A	N/A	Alarm exceeded major threshold
P2HD-PDF, Model=2015	2	2	N/A	N/A	2007-11-27:10:9:6.30	Tue, 27 Nov 2007 10:09:06 EST	-21.3549	dBm	InPwr exceeded major threshold

For additional information, see *Prisma II Traps* (on page 239), *Trap Logging Table* (on page 206), and *Enhanced Trap Binding Information* (on page 253).

10

Remote Firmware Download Feature

Introduction

The Prisma II Software Upgrade Program (SOUP) is a user-friendly utility that allows users to perform firmware upgrades on Prisma II modules. The SOUP utility simplifies the firmware upgrade process by providing a graphical user interface (GUI) that is easy to use and requires little training.

When connected to a chassis, the SOUP utility shows the user the current versions of firmware on all modules and allows the user to download and activate other versions from system release files. The SOUP works together with the ICIM2 or ICIM2-XD to send the binary image files and appropriate commands to the modules to upgrade their firmware. As the modules are being upgraded, the SOUP displays relevant progress information to the user.

In This Chapter

- Installing the SOUP 284
- Concepts..... 285
- Usage 287
- Firmware Updates 296

Installing the SOUP

To Install SOUP on Windows

Complete the following steps to install the Prisma II SOUP on Windows.

- 1 Download the Prisma II SOUP installation file to your Windows desktop.
- 2 Double-click the Prisma II SOUP installation icon to start the installation.
- 3 Follow the instructions of the installation wizard.
- 4 After the installation is complete, you will have an icon on the desktop to launch the SOUPLauncher application. There will also be a program group called Prisma II SOUP on your Start button menu.

To Uninstall the SOUP on Windows

Complete the following steps to remove the Prisma II SOUP from your computer.

- 1 Open the **Control Panel** from the Windows Start menu.
- 2 From the Control Panel, open the **Add or Remove Programs** application.
- 3 Find and choose the **Prisma II SOUP** entry in the list of installed programs. If the entry is not present, the program is not installed on the computer or was not installed properly.
- 4 Click the **Change/Remove** button.
- 5 Follow the instructions of the uninstall wizard.

Concepts


The Chassis and the ICIM2

The ICIM2 or ICIM2-XD acts as the communication interface to all modules in the chassis system. All communication with the chassis system from the SOUP program or the FTP server is managed by the ICIM2 or ICIM2-XD. The physical IP network connection for the chassis system is made through the Ethernet connector on the ICIM2 or ICIM2-XD front panel.

Release Files

The Prisma II SOUP works with system release files. A Prisma II system release contains binary image files for the modules that can be installed in the chassis.

System release files are held in a repository accessible through FTP. The Prisma II SOUP can access this repository to display information about available system releases and let the user choose among them. When the user selects a system release, the ICIM2 or ICIM2-XD retrieves the binary image files and upgrades the installed modules.



Note: Although shown separately above for clarity, the Prisma II SOUP and the FTP Server Release Repository may be resident on the same computer.

The format of a release file is explained in *Firmware Updates* (on page 296).

Active and Inactive Flash

The application modules have two flash memory areas, active and inactive. Each area can hold a copy of the module firmware. Module code always loads from active flash at boot-up. Inactive flash is used only for module firmware upgrades.

When upgrading firmware, the new version is downloaded to inactive flash. The module is then commanded to make the inactive flash active (and vice versa) and reboot, causing the new module code to load from the now active flash.

Concurrency

The upgrade process for a chassis depends on the number of modules in the chassis, the firmware versions that the modules are currently running, and the firmware versions that are currently being stored in the inactive flash area of each module.

The SOUP reads the current state of the modules in the chassis to determine what tasks are necessary to perform the upgrade, and then executes these tasks. For the upgrade process to work correctly, the state of the modules in the chassis must be fully known and not changed by another instance of the program running on a different system. This means that only one instance of the SOUP can be allowed to make any changes in a chassis at a time.

To enforce this, the SOUP attempts to grab a semaphore when it first connects to an ICIM2 or ICIM2-XD in a chassis. A semaphore is a control token that can only be grabbed by one instance of the SOUP at a time, and must be released before another instance can grab it. The attempt fails if the semaphore is already taken by another instance of the program running on another system and already connected to this ICIM2 or ICIM2-XD.

If the SOUP detects that the semaphore is taken, it does not attempt to make any changes to the modules in the chassis. Instead, it displays a message giving the user the option of proceeding in Browse Only mode. In Browse Only mode, the user is able to look at module information, but cannot download new firmware versions or change active or inactive flash areas.

Integration with an NMS (Optional)

The SOUP is designed to integrate into a network management system (NMS) that will handle permission security, access to the SOUP and its features, and actual launching of the SOUP utility.

When invoked, the SOUP requires a number of command line parameters to identify the ICIM2 or ICIM2-XD to be managed, the FTP server address, and the SNMP settings. Among these parameters is a security key that the NMS must retrieve from the ICIM2 or ICIM2-XD and pass to the SOUP.

If this parameter is not correct, or if the program is launched from the command line without it, the SOUP will only allow the user to run in Browse Only mode. In this mode, you can view information from the ICIM2 or ICIM2-XD and modules, but you cannot make changes.

Specifics on launching the SOUP utility vary from one NMS to another. Consult your system administrator for details on running the SOUP from your NMS.

Usage


When launched, the SOUP utility first tries to connect to the ICIM2 or ICIM2-XD and retrieve information about the modules it manages. After retrieving the module information, the SOUP connects to the FTP server holding the system release files and retrieves the firmware versions available for each module. Information about new and existing module firmware is then displayed in the SOUP application main screen.

Launching Standalone (Windows Only)

A Windows program called SOUPLauncher also lets Admin users launch the Prisma II SOUP manually as a standalone application.


Complete the following steps to launch SOUP as a standalone application.

- 1 Open the Windows Start menu, open the Prisma II SOUP program group, and click the SOUPLauncher program item. The Prisma II SOUP Login window appears as shown in the following illustration.



- 2 In the ICIM IP: field, type the IP address of the ICIM2 or ICIM2-XD to receive the download.
- 3 Type your Admin username and password in the fields provided.
Note: You must be an Admin user to log into the Prisma II SOUP.

- 4 Click **OK**. The Prisma II SOUP FTP Configuration window appears as shown in the following illustration.




Note: This window is bypassed after the first use of SOUPLauncher as long as the initial FTP server configuration remains valid.

- 5 In the FTP Host field, type the IP address of the FTP server to be used for the download.
- 6 In the FTP User and FTP Password fields, type the name and password of a user with permission to access files on the FTP server.
- 7 If the release files are in a folder rather than at the login root directory, type the name of the folder in the FTP Dir field.
If the release files are located at the login root directory, leave this field blank.
- 8 Click **OK** to launch the SOUP application.

After the Prisma II SOUP is running, you can change the FTP configuration if needed by accessing the FTP Server option from the Settings menu. See *FTP Settings* (on page 292) for details.

SOUP Main Screen

This screen serves as the control center for the SOUP utility. Most SOUP operations will be driven from here.



The table below describes the information displayed in this screen.

Item	Description
ICIM IP Address	The address of the ICIM2 or ICIM2-XD currently connected. This is determined at utility startup and cannot be changed.
CLLI Code	The value of the p2icimCLLICode SNMP element in the ICIM2 or ICIM2-XD.
Release File	The system release version and date of the current release file. Release files are listed in a drop-down box that the user can choose from to select the desired release.
Modules	<p>This table lists the modules and ICIM2 or ICIM2-XD present in the connected chassis. The table displays one row per module, with each row displaying details about the module.</p> <p>Each row in the table also displays:</p> <ul style="list-style-type: none"> ■ The firmware version contained in the release file for each module according to module type. ■ The Suggested Action, a value determined by the program as explained below.

Suggested Action

The SOUP utility determines a Suggested Action for each module by comparing the firmware version available in the system release file with the firmware version in the module Active and Inactive flash areas. The possible values for the Suggested Action are listed below.

Value	Description
None	No action needed; this module already holds the correct version of the firmware.
DnLoad + Activate	The module is not running the version of the firmware in the release file and that version is not available in the inactive flash. To upgrade the module, the program will need to first download the firmware to the inactive flash in the module, and then activate the firmware.
Activate	The module is not running the version of the firmware in the release file, but it is holding that version in its inactive flash. To upgrade the module, the program just needs to make the inactive flash active.
N/A	There is no information about this module in the system release file.

Screen Functions

The user can then initiate any of the following functions from the main screen.

Function	Description
Details (ICIM)	This function displays a dialog box containing additional details from the ICIM2 or ICIM2-XD to which the program is connected.
Details (Release File)	This function displays a dialog box containing additional details from the release file currently chosen.
Download	The download function looks at the selected modules in the Modules table and determines which ones need to have a new firmware binary image downloaded to their inactive flash. It then presents a dialog to the user with this list before starting the download process.
Activate	The activate function looks at the selected modules in the Modules table and checks that all the modules have a version that matches the release version in either their active or inactive flash. If this is not the case, the program displays an error and does not allow the user to proceed. If it is the case, the program creates a list of the modules whose flash areas will be switched, and then presents the list to the user before starting to send commands to the modules.
DnLoad + Activate	The download and activate function combines the two previous functions into a single step. When called, the program determines which modules need a new binary image download and which need to have their flash areas switched. The program then presents a combined list of modules to the user before proceeding.

Function	Description
Select	This function is a shortcut to select or clear a number of modules in one step. When the button is pressed, a menu is shown that allows the user to select or clear all modules, or to select all modules of a particular type.
Refresh	This function retrieves module information from the ICIM2 or ICIM2-XD and refreshes the Modules table.
Color Coding	Module rows are displayed in different colors to indicate the active, inactive, and current revisions.

Firmware Upgrade Process


The procedure for upgrading the firmware in the ICIM2, ICIM2-XD, or application module has two main steps:

- Download the new firmware image to the module.
- Make the downloaded firmware image active.

These functions are available through the interface through the two buttons “Download” and “Activate.” They can also be combined into a single action using the “DnLoad + Activate” button.

When any of these functions is selected, the program first determines the tasks required by comparing the active and inactive firmware versions in the module flash areas to the version in the system release file. The list of tasks is then shown to the user in a dialog box, and the program waits for the user to respond.

For example, the task list displayed after the “DnLoad + Activate” button is pressed might appear as shown below.



This dialog shows the tasks necessary to upgrade the ICIM2 or ICIM2-XD to a new firmware version. These tasks are described individually below.

- 1 Transfer the file to the ICIM2 or ICIM2-XD memory. File transfer is done using FTP. The SOUP utility sends the FTP server information to the ICIM2 or ICIM2-XD and then commands it to download the file. The SOUP then polls the ICIM2 or ICIM2-XD until the file transfer is finished or an error occurs.
- 2 Transfer the file from the ICIM2 or ICIM2-XD memory to the inactive flash area of the target module. The SOUP will send the necessary commands to the ICIM2 or ICIM2-XD to start this transfer and then poll the ICIM2 or ICIM2-XD until the transfer is finished or an error occurs. Even when the module being upgraded is the ICIM2 or ICIM2-XD, the binary image still has to be downloaded from the ICIM2 or ICIM2-XD RAM to the inactive flash.
- 3 Switch the active flash pointer on the module and then tell the module to reboot. A module always has a pointer to the flash memory area that it will use to load its firmware on boot-up. After downloading the new image to the inactive flash area, the SOUP will first send a command to the module to switch the flash pointer. Then, it will send a command to reboot the module so that the new firmware is loaded. The reboot command used is a soft reboot, meaning that the module will not go through its full reboot process to minimize service interruption. The ICIM2 or ICIM2-XD performs a hard reboot.
- 4 If one of the modules is the ICIM2 or ICIM2-XD, as it is in this case, the SOUP loses contact with the chassis while rebooting. If the SOUP detects that one of the modules is the ICIM2 or ICIM2-XD, it waits after sending the reboot command until it regains its connection to the ICIM2 or ICIM2-XD.

FTP Settings

To upgrade firmware for Prisma II application modules, an FTP server is needed to transfer system release files and firmware binary images. When the Prisma II SOUP utility is launched from a network management system (NMS), information about the FTP server must be passed to it in the command line. When launched as a standalone application using SOUPLauncher, this information is requested from the user.

Specifically, the SOUP needs the FTP server address, the user and password to log into the server, and an optional subdirectory path for the location of the system release files. If the SOUP is running in Administrator level, you can look at and change these settings by first clicking on **Settings** in the main menu bar, and then choosing **FTP Server**.

A dialog box displaying the FTP server information opens, allowing you to change and test the settings.

The table below describes the fields in the FTP Settings dialog box.


Item	Description
FTP Server Address	The address of the FTP server. This can be an IP address or a name that can be resolved by the computer running the SOUP.
Directory on FTP Server	The path to the system release files within the FTP server; for example, /dload/Prisma2 .
User	The user name to log into the FTP server.
Password	The password to log into the FTP server.

SNMP Settings

SNMP Settings are passed to the SOUP utility by an NMS as command line parameters. If launched using SOUPLauncher, this information is retrieved from the ICIM2 or ICIM2-XD after a successful login.

To connect to the ICIM2 through SNMP, the SOUP utility needs the SNMP Read and Write community strings. If the SOUP is running in Administrator mode, you can browse and change the SNMP settings by first clicking on **Settings** in the main menu bar, and then choosing **SNMP Settings**.

The SNMP Settings dialog appears as shown in the following illustration.



In addition to the Read and Write community strings, the Administrator can change:

- The timeout value (in milliseconds) to use when communicating with the ICIM2 or ICIM2-XD.
- The number of retries for SNMP messages.

These two settings are saved locally by the SOUP utility.

FTP Server

The SOUP utility and the ICIM2 work together with an FTP server to perform firmware upgrades. The FTP server makes the binary image files available to the ICIM2 and acts as a repository for system release files. The only requirement for the FTP server is that it be accessible through TCP/IP by both the SOUP and the ICIM2.

Consult your system administrator for details on how to configure an FTP server for this application.

Firmware Updates

New system release files are distributed when a firmware update becomes available. System release files package the firmware binary images for the different modules and provide version information for those images. These files are produced and distributed by the manufacturer, and are not intended to be created or modified by end users in any manner.



CAUTION:

Do not try to perform a firmware update that would result in downgrading ICIM2 or ICIM2-XD firmware below system release 2.02.09. Earlier system releases may incorrectly identify the ICIM2 or ICIM2-XD slot number and fail to connect with the ICIM2 or ICIM2-XD when completing the download.

The following is a sample system release file. The information contained in the XML file is listed in the table below.

Item	Description
PrismaIIRelease	The root element in the file identifies this to be a Prisma II system release file.
ReleaseDate	The official release date.
Name	A descriptive name for the system release, typically a system version number.

Item	Description
Module	<p data-bbox="574 268 1393 365">One or more module elements containing information about the versions contained in this system release file for a particular module type.</p> <ul style="list-style-type: none"> <li data-bbox="574 390 1127 415">■ TypeNo - The target module type number. <li data-bbox="574 438 1256 464">■ Version - The version of the firmware for the module. <li data-bbox="574 487 1393 541">■ Filename - The file name of the binary image holding the module firmware. <li data-bbox="574 564 1373 661">■ Boot - An element containing information about the boot image necessary to run this version of the firmware. (ICIM2 or ICIM2-XD only) <ul style="list-style-type: none"> <li data-bbox="623 678 1135 703">- Version - The version of the boot image. <li data-bbox="623 720 1268 745">- Filename - The file name that holds the boot image. <li data-bbox="574 768 1354 928">■ Depends - An optional element containing information about dependencies of this version of the firmware to other modules and their version. These elements are used to make sure that when an upgrade is performed, any dependencies across modules are enforced. <ul style="list-style-type: none"> <li data-bbox="623 945 1325 970">- TypeNo - The type number of the module depended on. <li data-bbox="623 987 1300 1041">- Version - The version of the firmware necessary in the module on which it depends. <li data-bbox="623 1058 1365 1186">- VersionEq - A comparison operator to use when looking at the version in the module. This can either be Equal for strict equality, or EqualOrGreater to accept a matching or newer version.

Structure	Values
PrismaIIRelease	
ReleaseDate	06/15/2005
Name	V2.00
Module	
TypeNo	3020
Version	2.01.01
Filename	M3020V2.00.01.bin
Boot	
Version	1.00.01
Filename	M3020BootV1.00.01.bin
Module	
TypeNo	1805
Version	2.01.00
Filename	M1805V2.00.01.bin
Depends	
TypeNo	5000
Version	2.00.00
VersionEq	Equal / EqualOrGreater
Boot	
Version	1.00.01
Filename	M1805BootV1.00.01.bin

For Help, press F1

11

Maintenance and Troubleshooting

Introduction

This chapter provides information to assist you in maintaining and troubleshooting the platform.

Qualified Personnel

Only appropriately qualified and skilled personnel should attempt to maintain or troubleshoot chassis faults.



WARNING:

Allow only qualified and skilled personnel to install, operate, maintain, and service these products. Otherwise, personal injury or equipment damage may occur.

In This Chapter

■ Maintenance	301
■ Troubleshooting	302
■ FansOk Alarm	304
■ ChasTemp Alarm.....	305
■ Ps1PwrIn Alarm.....	307
■ Ps1+24 Alarm	308
■ Ps1+5VDC Alarm.....	309
■ Ps1-5VDC Alarm.....	310
■ Ps3PwrIn Alarm.....	311
■ Ps3+24 Alarm	312
■ Ps3+5VDC Alarm.....	313
■ Ps3-5VDC Alarm.....	314
■ Cleaning Optical Connectors	315
■ Connecting Optical Cables	319

Maintenance

The following maintenance is recommended to ensure optimal performance.

Frequency	Maintenance Required
Yearly	<ul style="list-style-type: none"> ■ Check all parameters and test points. ■ Record data. ■ Make adjustments as needed. ■ Make sure all cables are mated properly. ■ Inspect cables for stress and chafing. ■ Make sure all retaining screws are tight. ■ Replace chassis air filter. Depending on office environment cleanliness/filtration, the chassis air filter may require more frequent servicing.
When needed	Carefully clean the module with a soft cloth that is dampened with mild detergent.

Maintenance Record

It may be helpful to establish a maintenance record or log for this equipment. You may want to record laser power level, laser temperature readings, laser bias current, or power supply voltages, as well as the filter change dates.

Large variations in any of the parameters above should be investigated prior to failure.

Troubleshooting

This section provides general information on servicing and troubleshooting this equipment. The troubleshooting information describes the most common alarms and gives typical symptoms, causes, and items to check before contacting Customer Service.

Chassis Troubleshooting

The main function of the chassis is to distribute power and establish communication links for the application modules installed in the chassis. Most troubleshooting involves the modules installed in the chassis, but in some instances, you will need to troubleshoot the chassis itself.

The table below describes the most common problems and gives typical symptoms, possible causes, and items to check before contacting Customer Service.



WARNING:

Avoid electric shock and damage to this product! Do not open the enclosure of this product. There are no user-serviceable parts inside. Refer servicing to qualified service personnel.

Symptom	Possible Causes	Solutions
ON indicator is not illuminated	Power supply connection loose	Check that all power supply connections are secure.
	Loss of system power	Check that power is present at receptacle.
	Power failure; backup in use	Check other displays and indicators for power indication.
	Module indicator burned out	Contact Customer Service for an indicator replacement.
ALARM indicator is on or flashing	Application module in alarm	Consult network management system (NMS) for module alarms (see module documentation for details).
	Chassis failed power-up self-test	Check that all power supply connections are secure. Check Power On and Alarm LED indicators on power supplies.

ICIM indicator is off	ICIM2 not installed or not fully seated	Confirm that chassis is part of an ICIM2 daisy chain (no need for separate ICIM2). If not, check that the ICIM2 is fully seated in back of chassis.
-----------------------	---	--

Alarm Troubleshooting

The Prisma II Platform generates certain alarms that are specific to the chassis, its fan assembly, and its power supply components.

Parameter	Function
FansOk	Fan tray operating status
ChasTemp	Fan tray internal temperature
Ps1PwrIn	Power supply slot 1 input power
Ps1+24	Power supply slot 1 +24 VDC output voltage
Ps1+5VDC	Power supply slot 1 +5 VDC output voltage
Ps1-5VDC	Power supply slot 1 -5 VDC output voltage
Ps3PwrIn	Power supply slot 3 input power
Ps3+24	Power supply slot 3 +24 VDC output voltage
Ps3+5VDC	Power supply slot 3 +5 VDC output voltage
Ps3-5VDC	Power supply slot 3 -5 VDC output voltage

Troubleshooting information for each of these alarms is provided in the following sections of this chapter.

Other alarms may occur as a result of fault conditions in specific application modules. For information on troubleshooting alarms for specific application modules, see the appropriate module documentation.

Additional Assistance

If you need additional assistance, telephone one of our Technical Service Centers or your local sales subsidiary. The chapter *Customer Support Information* (on page 321) contains a list of telephone numbers.

FansOk Alarm

This alarm indicates fan status, and triggers in the event of a fault in fan operation.

FansOk Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
FansOk	fan status	na	na	na	na	na	OK or Fault

Suggested Actions

- 1 Check for PsOk or other alarms that could indicate a general chassis power loss.
- 2 If *no* fans are running, confirm that the fan tray is properly mounted in the chassis. If so, *momentarily* remove the fan tray by loosening the two screws, one on either side of the front panel, and then reseal the fan tray. If necessary, correct the installation and check again for proper operation.



WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

- 3 If FansOk is in fault condition but the fans sound like they are running, *momentarily* remove the fan tray by loosening the two screws, one on either side of the front panel.



WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

Quickly remove the fan tray and visually confirm that all fans are spinning. A fault will occur if even one fan is not working. If any of the fans is not working or if the alarm persists, replace the fan tray.

Important: Do not operate any chassis without a fan tray installed. For correct operation, proper chassis cooling must be maintained over the specified temperature range.

- 4 If these steps do not clear the alarm, contact Customer Service for assistance.

ChasTemp Alarm

This alarm indicates a problem with fan tray temperature. It triggers when the fan tray temperature is outside the threshold levels.

ChasTemp Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
ChasTemp	fan tray temperature	-40°C	-35°C	60°C	65°C	1°C	-40°C to 65°C

The factory default range for ChasTemp is -40°C to 65°C. While these values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Verify that the conditioned ambient airflow is within chassis temperature alarm threshold set-points. If not, rectify the condition.
- 2 Look for and remove any air flow obstructions at the chassis air intake and exhaust areas. *Momentary* fan tray removal may be needed for this inspection.



WARNING:

Normal operation and maintenance should be performed with two power supplies installed and operating. Removal and rapid reinsertion of a fan tray into an active Prisma II Chassis can result in temporary service interruption if only a single power supply is active. Inrush current protection circuitry requires a delay of two (2) or more seconds before reinsertion.

- 3 Check the condition of the air filter in the floor of the chassis. Replace the fan filters at least annually, or more often if office conditions require it.
- 4 If needed, replace the chassis air filter as follows:
 - a Locate the air filter in the floor of the chassis behind the fiber bracket (if installed).
 - b Locate the two pivot clips holding the front of the filter in place. Turn the two clips approximately 90 degrees. The filter will drop down. Carefully pull the filter down and away from the chassis. Avoid dislodging dust from the filter that could be pulled into the chassis.
 - c With the filter removed, install a clean filter and note the air movement direction (arrow) of the filter. Install the filter with the arrow pointing up.
 - d Note that two pins secure the rear of the filter. Install the filter above these pins, and then push upward.

Ps1PwrIn Alarm

This alarm indicates the status of the line input voltage to the power supply installed in slot 1 of the chassis. It triggers in the event that the power supply input voltage is not in the voltage range recommended by the manufacturer.

Ps1PwrIn Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps1PwrIn	Slot 1 input power	na	na	na	na	na	OK or Fault

Suggested Actions

- 1 Check the chassis power cord and confirm that the power supply in slot 1 is fully seated.
- 2 If the line voltage is feeding only the alarming power supply, check the line for both proper voltage *and* polarity. If the line voltage and polarity are acceptable, replace the power supply module.
- 3 If the line voltage is feeding more than one chassis with no indication of Ps1PwrIn alarm on any other power supply, replace the alarming power supply module.
- 4 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps1+24 Alarm

This alarm indicates the status of the +24 V DC output voltage from the power supply installed in slot 1 of the chassis. It triggers when this output voltage is outside the threshold levels.

Ps1+24 Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps1+24	Slot 1 +24 voltage	18.0 V DC	18.4 V DC	25.9 V DC	26.1 V DC	0.1 V DC	23.8 to 25.6 V DC

While the threshold values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Confirm that the power supply in slot 1 is fully seated.
- 2 Confirm that the alarm is caused by the voltage exceeding or falling below *factory-set* threshold values. If so, replace the power supply module.
- 3 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps1+5VDC Alarm

This alarm indicates the status of the +5 V DC output voltage from the power supply installed in slot 1 of the chassis. It triggers when this output voltage is outside the threshold levels.

Ps1+5VDC Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps1+5VDC	Slot 1 +5 voltage	3.6 V DC	3.7 V DC	5.9 V DC	6.1 V DC	0.1 V DC	4.9 to 5.3 V DC

While the threshold values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Confirm that the power supply in slot 1 is fully seated.
- 2 Confirm that the alarm is caused by the voltage exceeding or falling below *factory-set* threshold values. If so, replace the power supply module.
- 3 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps1-5VDC Alarm

This alarm indicates the status of the -5 V DC output voltage from the power supply installed in slot 1 of the chassis. It triggers when this output voltage is outside the threshold levels.

PS1-5VDC Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps1-5VDC	Slot 1 -5 voltage	-5.6 V DC	-5.5 V DC	-4.6 V DC	-4.5 V DC	0.1 V DC	-5.3 to -4.9 V DC

While the threshold values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Confirm that the power supply in slot 1 is fully seated.
- 2 Confirm that the alarm is caused by the voltage exceeding or falling below *factory-set* threshold values. If so, replace the power supply module.
- 3 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps3PwrIn Alarm

This alarm indicates the status of the input power to the power supply installed in slot 3 of the chassis. It triggers in the event that the power supply input voltage is not in the range recommended by the manufacturer.

Ps3PwrIn Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps3PwrIn	Slot 3 input power	na	na	na	na	na	OK or Fault

Suggested Actions

- 1 Check the chassis power cord and confirm that the power supply in slot 3 is fully seated.
- 2 If the line voltage is feeding only the alarming power supply, check the line for both proper voltage *and* polarity. If the line voltage and polarity are acceptable, replace the power supply module.
- 3 If the line voltage is feeding more than one chassis with no indication of Ps3PwrIn alarm on any other power supply, replace the alarming power supply module.
- 4 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps3+24 Alarm

This alarm indicates the status of the +24 V DC output voltage from the power supply installed in slot 3 of the chassis. It triggers when this output voltage is outside the threshold levels.

Ps3+24 Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps3+24	Slot 3 +24 voltage	18.0 V DC	18.4 V DC	25.9 V DC	26.1 V DC	0.1 V DC	23.8 to 25.6 V DC

While the threshold values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Confirm that the power supply in slot 3 is fully seated.
- 2 Confirm that the alarm is caused by the voltage exceeding or falling below *factory-set* threshold values. If so, replace the power supply module.
- 3 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps3+5VDC Alarm

This alarm indicates the status of the +5 V DC output voltage from the power supply installed in slot 3 of the chassis. It triggers when this output voltage is outside the threshold levels.

Ps3+5VDC Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps3+5VDC	Slot 3 +5 voltage	3.6 V DC	3.7 V DC	5.9 V DC	6.1 V DC	0.1 V DC	4.9 to 5.3 V DC

While the threshold values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Confirm that the power supply in slot 3 is fully seated.
- 2 Confirm that the alarm is caused by the voltage exceeding or falling below *factory-set* threshold values. If so, replace the power supply module.
- 3 If these steps do not clear the alarm, contact Customer Service for assistance.

Ps3-5VDC Alarm

This alarm indicates the status of the -5 V DC output voltage from the power supply installed in slot 3 of the chassis. It triggers when this output voltage is outside the threshold levels.

PS3-5VDC Alarm Parameters

Alarm	Function	Major Low Threshold	Minor Low Threshold	Minor High Threshold	Major High Threshold	Hysteresis	Typical Range/ Nom. Value
Ps3-5VDC	Slot 3 -5 voltage	-5.6 V DC	-5.5 V DC	-4.6 V DC	-4.5 V DC	0.1 V DC	-5.3 to -4.9 V DC

While the threshold values can be user-adjustable, they must be left at the default values. Failure to do so may result in improper operation or alarming, or may lead to equipment damage.

Suggested Actions

- 1 Confirm that the power supply in slot 3 is fully seated.
- 2 Confirm that the alarm is caused by the voltage exceeding or falling below *factory-set* threshold values. If so, replace the power supply module.
- 3 If these steps do not clear the alarm, contact Customer Service for assistance.

Cleaning Optical Connectors

Note: The proper procedure for cleaning optical connectors depends on the connector type. The following describes general instructions for cleaning optical connectors. Many companies have established procedures for cleaning conductors which should be followed. If your company has established procedures, the following instructions should be considered along with your procedures.

Cleaning fiber-optic connectors can help prevent interconnect problems and aid system performance. When optical connectors are disconnected or reconnected, the fiber surface can become dirty or scratched. If not addressed, this dirt or damage may lead to interconnect problems and reduced system performance.

Fiber-optic connectors should be inspected prior to mating and cleaned as needed to remove all dust and contaminants without leaving any residue. Connectors should be visually inspected after cleaning to confirm that they are clean and undamaged.

Recommended Equipment

The following equipment is recommended to clean the ends of fiber-optic connectors.

- CLETOP or OPTIPOP ferrule cleaner (CLETOP Type A for SC, Type B for LC)
- Compressed air (also called “canned air”)
- Lint-free wipes moistened with optical-grade (99%) isopropyl alcohol
- Bulkhead swabs for LC or SC type connectors (choose appropriate type)
- Optical connector scope

Tips for Optimal Fiber-Optic Connector Performance

Follow these guidelines to ensure optimal connector performance.

- Do not connect or disconnect optical connectors while optical power is present.
- Always use compressed air before cleaning the fiber-optic connectors.
- Always use end caps on connectors when they are not in use.
- Always use compressed air to clean the end caps.
- If you have any degraded signal problems, clean the fiber-optic connector.
- Advance a clean portion of the ferrule cleaner reel for each cleaning.
- Turn off optical power before making or breaking optical connections in order to avoid microscopic damage to fiber mating surfaces.

To Clean Optical Connectors

Note: The proper procedure for cleaning optical connectors depends on the connector type. The following describes general instructions for cleaning optical connectors. Many companies have established procedures for cleaning conductors which should be followed. If your company has established procedures, the following instructions should be considered along with your procedures.



WARNING:

- **Avoid personal injury! Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.**
 - **Avoid personal injury! The laser light source on this equipment emits invisible laser radiation. Avoid direct exposure to the laser light source.**
 - **Avoid personal injury! Viewing the laser output with optical instruments (such as eye loupes, magnifiers, or microscopes) may pose an eye hazard.**
- Connect or disconnect fiber *only* when equipment is OFF or in Service mode.
 - Do not apply power to this equipment if the fiber is unmated or unterminated.
 - Do not look into an unmated fiber or at any mirror-like surface that could reflect light that is emitted from an unterminated fiber.
 - Do not view an activated fiber with optical instruments such as eye loupes, magnifiers, or microscopes.
 - Use safety-approved optical fiber cable to maintain compliance with applicable laser safety requirements.

Fiber Optic Connector Cleaning Instructions

Connector cleanliness is crucially important for optimum results in fiber-optic communications links. Even the smallest amount of foreign material can make it impossible to obtain the expected insertion and return losses. This can reduce the range of the equipment, shorten its expected service life, and possibly prevent the link from initializing at all.

New equipment is supplied with clean optical connectors and bulkheads. All optical connectors (bulkheads and jumpers) should be inspected using an appropriate optical scope prior to connector mating. If endface contamination is observed, the connector should be cleaned and then re-inspected to verify cleaning.

Connectors and Bulkheads

Most fiber-optic connectors are of the physical contact (PC) type. PC type connectors are designed to touch their mating connectors, thereby preventing air gaps which cause reflections. For optimum performance, *all* dirt must be removed.

Bulkheads can also become dirty enough to affect performance, either from airborne dust or from contamination introduced by connectors.

**WARNING:**

Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.

Important: Read the above warning before performing cleaning procedures.

Cleaning Connectors

Important:

- All external jumper connectors must be cleaned before inserting them into the optical module.
- Before you begin, remove optical power from the module or ensure that optical power has been removed.

Complete the following steps to clean fiber-optic connectors that will be connected to the optical module.

- 1 Inspect the connector through an optical connector scope. If the connector is damaged, e.g., scratched, burned, etc., replace the jumper.
- 2 If the connector is dirty but otherwise undamaged, clean the connector as follows:
 - a Make several swipes across the face of the connector with the appropriate ferrule cleaner. This will remove dust and some films.
 - b Listen for a slight "squeak" typically generated during this process, indicating a clean connector.
 - c Inspect the connector again through the scope to confirm that it is clean.
- 3 If a second inspection indicates that further cleaning is needed:
 - a Use 99% isopropyl alcohol and a lint-free wipe to clean the connector.
 - b Use the appropriate ferrule cleaner again to remove any film left over from the alcohol.
 - c Inspect the connector again through the scope and confirm that it is clean.
- 4 If necessary, repeat steps 3a-3c until the connector is clean.

Cleaning Bulkheads

Important:

- Do not detach the bulkhead from the module front panel for cleaning under any circumstances. There is little or no slack in the fiber attached to the bulkhead, and any attempt to remove the bulkhead will risk damage to the fiber.
- It is generally more difficult to clean bulkhead connectors and verify their condition due to the inaccessibility of the fiber end face. For this reason, you should *only* attempt to clean a bulkhead connector when a dirty connector is indicated.

Complete the following steps to clean the bulkhead.



WARNING:

- **Avoid personal injury! Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.**
- **Avoid personal injury! The laser light source on this equipment emits invisible laser radiation. Avoid direct exposure to the laser light source.**
- **Avoid personal injury! Viewing the laser output with optical instruments (such as eye loupes, magnifiers, or microscopes) may pose an eye hazard.**

- 1 Insert a dry bulkhead swab into the bulkhead and rotate the swab several times.
- 2 Remove the swab and discard.

Important: Swabs may be used only once.

- 3 Check the bulkhead optical surface with a fiber connector scope to confirm that it is clean. If further cleaning is needed:
 - a Moisten a new bulkhead swab using a lint-free wipe moistened with optical-grade (99%) isopropyl alcohol.
 - b With the connector removed, fully insert the bulkhead swab into the bulkhead and rotate the swab several times.
 - c Remove the swab and discard. Swabs may be used only once.
 - d Repeat steps 1 and 2 with a new dry bulkhead swab to remove any excess alcohol or residue.
 - e Check with a fiber connector scope again to confirm that there is no dirt or alcohol residue on the optical surface.
 - f If any alcohol residue remains, repeat steps 3d-3f.
- 4 Mate all connectors to bulkheads and proceed to **Verifying Equipment Operation** below.
- 5 It is also recommended that all connectors be visually inspected after cleaning to verify the connector is clean and undamaged.

Verifying Equipment Operation

Perform circuit turn-up. If the equipment does not come up, i.e., fails verification or indicates a reflection problem, clean the connectors and bulkheads again.

For Further Assistance

If you have any questions or concerns about cleaning fiber-optic connectors, contact Customer Service using the contact information provided in *Customer Support Information* (on page 321).

Connecting Optical Cables

Important: It is recommended that all connections be made with the optical power off. This will reduce the risk of damage to fiber-optic connectors.

Note: Observe laser safety precautions. Refer to *Laser Safety* (on page xxv) for further information.

To Connect Optical Cables



CAUTION:

High power density exists on fiber when optical power is present. To avoid microscopic damage to fiber mating surfaces, turn off optical power or reduce power below 15 dBm before making or breaking optical connections.

Complete the following steps for each optical cable connection to be made and on every module to be installed.

- 1 Clean the end of the fiber to be connected as described in *Cleaning Optical Connectors* (on page 315).
- 2 Connect the optical cable to the module connector.
- 3 Route the cable to the appropriate destination.
- 4 Clean the remaining cable end, and then connect the cable to the mating module connector.

Note: Remember to observe minimum bend radius and other accepted handling practices when working with fiber-optic cables.

- 5 After cable installation is complete, return the module control settings to their original states.

12

Customer Support Information

If You Have Questions

If you have technical questions, call Cisco Services for assistance. Follow the menu options to speak with a service engineer.

Access your company's extranet site to view or order additional technical publications. For accessing instructions, contact the representative who handles your account. Check your extranet site often as the information is updated frequently.

A

Prisma II Permitted CLI Commands

Introduction

The following tables summarize the available CLI commands for the Prisma II Platform. Each table lists the commands available for one of the four major CLI prompts: CLI, */* MODULE, TERMINAL, and ICIM.

Entries shown in parenthesis () are module-specific and must be typed in full. Hints are given to display available entries for those cases. All other entries may be abbreviated to the shortest unambiguous form, as explained in the CLI online help screens.

Note: Some commands are limited to Admin level users only.

For further information and assistance when working with CLI, type **help** at the appropriate CLI prompt, and then press **Enter** to display the corresponding help screens.

In This Appendix

■ From CLI	324
■ From ICIM	325
■ From */* MODULE	331
■ From TERMINAL	334

From CLI

ALARM	
CLEAR	
DATE	
EXIT	
HELP	ALARM
	CLEAR
	COMMANDS
	DATE
	EDIT
	EXIT
	ICIM
	LOGOUT
	MANUAL
	MODULE
	TERMINAL
	WHO
	WHOAMI
ICIM	
LOGOUT	
MANUAL	
MODULE	
TERMINAL	
WHO	
WHOAMI	
'?'	

From ICIM

ALARM		
EVENTLOGCLEAR		
EVENTLOGFILTER	HARDWARE	ON/OFF
	PROVISIONING	ON/OFF
	SYSTEM	ON/OFF
EXIT		
FILE	IP	(IP_ADDRESS)
	NAME	(FILENAME)
	PASSWORD	(PASSWORD)
	PATH	(PATH)
	USER	(USERNAME)
HELP		
IKE *	ADD	(IP_ADDRESS)
	DELETE	(IP_ADDRESS)
INFO	ACTIVEREV	
	ATTNSTATUS	
	BOOTREV	
	CHASSIS	
	CLEI *	
	CLLI *	
	COMMREAD	
	COMMTRAP	
	COMMWRITE	
	DEVTYPE	
	DOWNLDCMD	
	DOWNLDDIR	
	DOWNLDFILE	
	DOWNLDRESULT	
	DOWNLDSEM	
	DOWNLDSIG	
	DOWNLDSTATE	

Appendix A
Prisma II Permitted CLI Commands

	DOWNLDTGT	
	DOWNLDUSER	
	FTPSERVER	
	FTPUSER	
	GATEWAY	
	HWREV	
	INACTIVEREV	
	IP	
	IPSEC *	
	LOCKOUT	
	MAC	
	MANDATA	
	NEXTIMAGE	
	PREVIOUSIP	
	SELFTEST	
	SERIAL	
	SIZE	
	SLOT	
	SMC	
	STATUSMSG	
	SUBNET	
	SWDATE	
	SWREV	
	THRESHOLD	
	TIMEOUT	
	TOS	
	TZONE	
	UPDATEID	
IPROUTE	ADD	(DESTINATION)
		(GATEWAY)
	DELETE	(DESTINATION)
		(GATEWAY)
IPSEC *	DISABLE	

	ENABLE	
LOGOUT		
MANUAL		
REBOOT		
SET	CLLI *	(CLLI)
	CLOCK	(DATE_TIME)
	COMMREAD	(READ_STRING)
	COMMTRAP	(TRAP_STRING)
	COMMWRITE	(WRITE_STRING)
	GATEWAY	(GATEWAY)
	IP	(IP_ADDRESS)
	LOCKOUT	(INTERVAL)
	STATUSMSG-CLEARKEY	(1)
	SUBNET	(SUBNET_MASK)
	THRESHOLD	(THRESHOLD)
	TIMEOUT	(TIMEOUT)
	TZONE	(TIMEZONE)
	UPDATEID	(1)
SHOW	ACTIVEREV	
	ATTNSTATUS	
	BOOTREV	
	CHASSIS	
	CLEI *	
	CLLI *	
	CLOCK	
	COMMREAD	
	COMMTRAP	
	COMMWRITE	
	DEVTYPE	
	DOMAIN	
	DOWNLDCMD	
	DOWNLDDIR	
	DOWNLDFILE	

Appendix A
Prisma II Permitted CLI Commands

	DOWNLDRESULT	
	DOWNLDSEM	
	DOWNLDSIG	
	DOWNLDSTATE	
	DOWNLDTGT	
	DOWNLDUSER	
	EVENTLOG	
	EVENTLOGALL	
	EVENTLOGFILTER	
	FILE	
	FTPSERVER	
	FTPUSER	
	GATEWAY	
	HWREV	
	IKE *	
	INACTIVEREV	
	IP	
	IPROUTE	
	IPSEC *	
	LOCKOUT	
	LOCKEDUSERS	
	MAC	
	MANDATA	
	NEXTIMAGE	
	PREVIOUSIP	
	PROVISIONING	
	SELFTEST	
	SERIAL	
	SIZE	
	SLOT	
	SMC	
	SNTP *	
	STATUSMSG	

	SUBNET	
	SWDATE	
	SWREV	
	THRESHOLD	
	TIMEOUT	
	TOS	
	TRAPS	
	TZONE	
	UPDATEID	
	USER	
SNTP *	INTERVAL	
	IP	
	MODE	
	STATE	
	TIMEOUT	
TRAPS	DISABLE	(INDEX)
		(IP_ADDRESS)
	ENABLE	(INDEX)
		(IP_ADDRESS)

USER	ADD	(USER_ID)	ADMIN	DISABLE
				ENABLE
			READ	DISABLE
				ENABLE
			READWRITE	DISABLE
				ENABLE
	CHANGE	ACCESS_RIGHTS	(USER_ID)	ADMIN
				READ
				READWRITE
		ACCOUNT_STATUS	(USER_ID)	DISABLE
				ENABLE
		PASSWORD	(USER_ID)	(PASSWORD)
	DELETE	(USER_ID)		
	UNLOCK	(USER_ID)		

Appendix A
Prisma II Permitted CLI Commands

'?'				
-----	--	--	--	--

* Reserved for future use.

From */* MODULE

ALARM	DOMAIN		
	MODULE		
CHASSIS	(digits)		
	*		
	[range]		
EXIT			
HELP			
INFO	ALARM	(ALARMNAME)	HYSTERESIS
		use show alarms *	INDEX
			LABEL
			LIMITADJUST
			MAJORHIGH
			MAJORLOW
			MINORHIGH
			MINORLOW
			NOMINAL
			RANGEHI
			RANGELO
			TYPE
			VALUE
	CONTROL	(CONTROLNAME)	INDEX
		use show control *	LABEL
			RANGEHI
			RANGELO
			RANGESTEP
			STATENAMES
			TYPE
			UNITS
			VALUE
	MODULE	ACTIVEREV	
		BOOTREV	
		CLEI ¹	

Appendix A
Prisma II Permitted CLI Commands

		CLLI ¹	
		CODEREV	
		DATECODE	
		DEVTYPE	
		DOWNLOADABLE	
		INACTIVEREV	
		MANDATA	
		MODTYPE	
		NAME	
		NEXTIMAGE	
		NUMANALOGCONTROLS	
		NUMCONTROLS	
		NUMDIGITALCONTROLS	
		NUMMONITS	
		NUMOFALARMS	
		SCRIPTREV	
		SELFTEST	
		SERIAL	
		TOS	
	MONITOR	(MONITORNAME)	INDEX
		use show mon *	LABEL
			STATENAMES
			TYPE
			UNITS
			VALUE
LOGOUT			
MANUAL			
MODID	digits		
	*		
	[range]		
RESET			
SET	ALARMPARAM	(ALARMNAME)	HYSTERESIS
			MAJORHIGH

			MAJORLOW
			MINORHIGH
			MINORLOW
	CONTROL	(CONTROLNAME)	(VALUE)
	MODULE	CLLI ¹	(CLLI)
SHOW	ALARMPARAM	(ALARMNAME)	HYSTERESIS
		use show alarms *	MAJORHIGH
			MAJORLOW
			MINORHIGH
			MINORLOW
	ALARMSTATE	(ALARMNAME)	
	CONTROL	(CONTROLNAME)	
	MODULE		
	MONITOR	(MONITORNAME)	
SLOT	digits		
	*		
	[range]		
'?'			

¹ Reserved for future use.

From TERMINAL

ALARM	
COLSEP	(string)
EXIT	
HEADERS	(digits)
HELP	
LOGOUT	
MANUAL	
PAGING	(digits)
PATTERN	REGEX
	WILDCARD
SHOW	
'?'	

B

Features Available via Remote User Interface

Introduction

This appendix lists the features of the remote user interface and identifies the availability (CLI, Web Interface, or both) and required user access level (Read-Only, Read-Write, or Admin) for each feature.

In This Appendix

■ Overview	336
■ ICIM Data.....	337
■ Module Data.....	340
■ Current Alarms	341
■ Module Alarms	342
■ Module Controls	343
■ Module Monitors	344
■ System Information	345
■ User Management.....	346

Overview

The tables below list the features available via either the CLI or the Web Interface. Symbols appearing in the cells of these tables have the meanings described below.

- In the CLI or Web column:
 - An asterisk (*) indicates that the corresponding interface (CLI or Web) supports this feature.
 - A dash (-) indicates that the corresponding interface (CLI or Web) does not support this feature.
- In the Read-Only User, Read-Write User, or Admin User security column:
 - A dash (-) indicates that this feature is not available to the corresponding access level.
 - The letter R indicates that the corresponding access level has Read-Only access to this feature.
 - The letter RW indicates that the corresponding access level has Read-Write access to this feature.

Note: The hierarchy of access goes from Read-Only to Read-Write to Admin. So, if a Read-Only user has the privilege to view a particular data element, a Read-Write user would be able to view the same data element. Similarly, if a Read-Write user is able to view or edit a data element, an Admin level user would be able to do the same.

ICIM Data

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
IP address	* ¹	*	R	R	RW
Active rev	*	*	R	R	R
Attnstatus	*	-	R	R	R
Boot rev	*	-	R	R	R
Chassis	*	*	R	R	R
CLEI ²	*	*	R	R	R
CLLI ²	*	*	R	RW	RW
Clock	* ¹	*	R	R	RW
Commread	*	-	-	-	RW
Commwrite	*	-	-	-	RW
Commtrap	*	-	-	-	RW
DevType	*	-	R	R	R
Domain	*	*	R	R	R
Downldcmd	*	-	R	R	R
Downlddir	*	-	R	R	R
Downldfile	*	-	R	R	R
Downldresult	*	-	R	R	R
Downldsem	*	-	R	R	R
Downldsig	*	-	R	R	R
Downldstate	*	*	R	R	R
Downldtgt	*	-	R	R	R
Downlduser	*	-	R	R	R
Eventlog	*	-	-	-	R
Eventlogall	*	*	-	-	R
File	*	-	-	R	RW
Ftpserver	*	-	R	R	R
Ftpuser	*	-	-	-	R
Gateway	* ¹	*	R	R	RW

Appendix B
Features Available via Remote User Interface

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Hwrev	*	*	R	R	R
Inactiverrev	*	*	R	R	R
IKE ²	*	-	-	-	RW
IProute	*	-	R	R	RW
IPSec ²	*	-	R	R	RW
LockedUsers	*	*	-	-	R
LockoutInterval	*	*	R	R	RW
MAC	*	*	R	R	R
Mandata	*	*	R	R	R
Nextimage	*	-	R	R	R
Previousip	*	-	R	R	R
Provisioning	*	-	R	R	R
Reboot	*	-	-	-	W
Selftest	*	*	R	R	R
Serial	*	*	R	R	R
Size	*	*	R	R	R
Slot	*	*	R	R	R
Smc	*	*	R	R	R
SNTPInterval ²	*	-	-	-	RW
SNTPIPAddress ²	*	-	-	-	RW
SNTPLastUpdate ²	*	-	-	-	R
SNTPMode ²	*	-	-	-	RW
SNTPState ²	*	-	-	-	RW
SNTPTimeout ²	*	-	-	-	RW
Statusmsg	*	-	R	R	R
Statusmsgclearkey	*	-	-	-	W
Subnet	* ¹	*	R	R	RW
Swdate	*	-	R	R	R
Swrev	*	-	R	R	R
sysDescr	-	*	R	R	R

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
sysLocation	-	*	R	R	R
sysUptime	-	*	R	R	R
Threshold	* ³	*	R	R	RW
Timeout	* ³	*	R	R	RW
TOS	*	*	R	R	R
Traps	* ³	*	R	R	RW
Timezone	* ¹	*	R	R	RW
Updateid	*	-	R	R	RW
User	*	*	-	-	RW

¹ May be modified through the CLI but not through the Web Interface.

² Reserved for future use.

³ May be read through the CLI but not through the Web Interface.

Module Data

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Active rev	*	*	R	R	R
Boot rev	*	-	R	R	R
Chassis	*	*	R	R	R
CLEI ¹	*	*	R	R	R
CLLI ¹	*	*	R	RW	RW
Device Type	*	*	R	R	R
Downloadable	*	*	R	R	R
Inactive Rev	*	*	R	R	R
Module Name	*	*	R	R	R
Module Type	*	*	R	R	R
Reset	*	-	-	-	W
Selftest	*	*	R	R	R
Serial	*	*	R	R	R
Slot	*	*	R	R	R
Time of Service	*	*	R	R	R

¹ Reserved for future use.

Current Alarms

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Current Alarms	*	*	R	R	R

Module Alarms

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Hysteresis	*	*	R	RW	RW
Label	*	*	R	R	R
MajorHigh	*	*	R	RW	RW
MajorLow	*	*	R	RW	RW
MinorHigh	*	*	R	RW	RW
MinorLow	*	*	R	RW	RW
RangeHigh	*	*	R	R	R
RangeLow	*	*	R	R	R
Type	*	*	R	R	R
Value	*	*	R	R	R

Module Controls

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
High	*	*	R	R	R
Label	*	*	R	R	R
Low	*	*	R	R	R
Step	*	*	R	R	R
Units	*	*	R	R	R
Value	*	*	R	RW	RW

Module Monitors

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Label	*	*	R	R	R
Units	*	*	R	R	R
Value	*	*	R	R	R

System Information

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Event Log Filter	* ⁴	*	R	R	RW
Event Log Clear	*	*	-	-	R/Clear
Max Login Attempts	* ⁴	*	R	R	RW
Inactivity Timeout	* ⁴	*	R	R	RW
Lockout Interval	*	*	R	R	RW
Trap Receive Table	* ⁴	*	R	R	RW

⁴ May be read through the CLI but not through the Web Interface.

User Management

Feature	CLI	Web	Read-Only User Privilege	Read-Write User Privilege	Admin User Privilege
Add user	*	*	-	-	RW
Change user	*	*	-	-	RW
Current users	*	*	-	-	R
Delete user	*	*	-	-	RW
Unlock user	*	- ¹	-	-	RW

¹ A user account may be unlocked through the Web Interface by enabling the account.

C

Module Parameter Descriptions

Introduction

This appendix provides control, alarm, monitor, and manufacturing data parameters for this equipment. The examples shown in the tables are for guidance only.



CAUTION:

The warranty may be voided and the equipment damaged if you operate the equipment above the specified temperature limits (0 to 50°C). Specification temperature limits are measured in the air stream at the fan inlet and may be higher than room ambient temperature.

In This Appendix

- Prisma II Chassis Parameters 348

Prisma II Chassis Parameters

Prisma II Chassis Configurable Parameters

Parameter Name (LCI)	ICIM2 Abbreviation	Description	Value	Default
na	na	na	na	na

Prisma II Chassis Alarm Data Parameters

Parameter Name (LCI)	ICIM2 Abbrev.	Nominal Value	Major Low Limit	Minor Low Limit	Minor High Limit	Major High Limit	Hys-teresis	Operating Range
Fan Status	FansOk	na	na	na	na	na	na	OK or Fault
Chassis Temperature	ChasTemp	25°C	-40°C	-35°C	60°C	65°C	1°C	-40°C to 65°C
Input PS1 Status	Ps1PwrIn	na	na	na	na	na	na	OK or Fault
+24V Power Supply 1	Ps1+24	24.7 VDC	18.0 VDC	18.4 VDC	25.9 VDC	26.1 VDC	0.1 VDC	23.8 to 25.6 VDC
+5V Power Supply 1	Ps1+5VDC	5.4 VDC	3.6 VDC	3.7 VDC	5.9 VDC	6.1 VDC	0.1 VDC	4.9 to 5.3 VDC
-5V Power Supply 1	Ps1-5VDC	-5.4 VDC	-5.6 VDC	-5.5 VDC	-4.6 VDC	-4.5 VDC	0.1 VDC	-5.3 to -4.9 VDC
Input PS3 Status	Ps3PwrIn	na	na	na	na	na	na	OK or Fault
+24V Power Supply 3	Ps3+24	24.7 VDC	18.0 VDC	18.4 VDC	25.9 VDC	26.1 VDC	0.1 VDC	23.8 to 25.6 VDC
+5V Power Supply 3	Ps3+5VDC	5.4 VDC	3.6 VDC	3.7 VDC	5.9 VDC	6.1 VDC	0.1 VDC	4.9 to 5.3 VDC
-5V Power Supply 3	Ps3-5VDC	-5.4 VDC	-5.6 VDC	-5.5 VDC	-4.6 VDC	-4.5 VDC	0.1 VDC	-5.3 to -4.9 VDC

Prisma II Chassis Operating Status Parameters

Parameter Name (LCI)	ICIM2 Abbreviation	Function	Initial Value	Typical Value (Op.)
Power Supply 1 Installed	Ps1Inst	1 if slot 1 PS installed, 0 if not	1 (Inst)	1 (Inst)

Parameter Name (LCI)	ICIM2 Abbreviation	Function	Initial Value	Typical Value (Op.)
+24V Power Supply 1	Ps1+24V	measured +24 V DC of slot 1	24.97V	24.97V
+5V Power Supply 1	Ps1+5V	measured +5 V DC of slot 1	5.38V	5.38V
-5V Power Supply 1	Ps1-5V	measured -5 V DC of slot 1	-5.42V	-5.42V
Power Supply 1 Temperature	Ps1Temp	internal slot 1 PS temperature	32.7°C	32.7°C
Power Supply 3 Installed	Ps3Inst	1 if slot 3 PS installed, 0 if not	1 (Inst)	1 (Inst)
+24V Power Supply 3	Ps3+24V	measured +24 V DC of slot 3	25.03V	25.03V
+5V Power Supply 3	Ps3+5V	measured +5 V DC of slot 3	5.38V	5.38V
-5V Power Supply 3	Ps3-5V	measured -5 V DC of slot 3	-5.43V	-5.43V
Power Supply 3 Temperature	Ps3Temp	internal slot 3 PS temperature	28.7°C	28.7°C
+24V Voltage	Chas+24V	chassis +24 V rail	24.14V	24.14V
+5V Voltage	Chas+5V	chassis +5 V rail	5.08V	5.08V
-5V Voltage	Chas-5V	chassis -5 V rail	-5.05V	-5.05V
Chassis Temperature	ChasTemp	fan tray internal temperature	36.0°C	36.0°C
Fans Running	FansOn	1 if fans are running, 0 if shut off	1 (ON)	1 (ON)

Note: All monitored values may vary from module to module. The values shown above are examples only.

Prisma II Chassis Manufacturing Data Parameters

Fan Tray

Parameter Name (LCI)	ICIM2 Abbreviation	Typical Values
Generic Name	na	Fan Tray
Description	na	Fan Tray
Software Revision	Sw Ver	CCB612

Appendix C
Module Parameter Descriptions

Parameter Name (LCI)	ICIM2 Abbreviation	Typical Values
Script Version	na	9
Serial Number	Serial #	AALR1RL
Time of Service	In Service Hours	26 Hrs
Day Code	Date Code	J04
Module Type	na	5000
na	Spec Data (MANDATA)	(blank)

Power Supply

Parameter Name (LCI)	ICIM Abbreviation	Typical Values
Generic Name	na	Power Supply
Description	na	Power Supply
Software Revision	Sw Ver	na
Script Version	na	na
Serial Number	Serial #	na
Time of Service	In Service Hours	na
Day Code	Date Code	na
Module Type	na	5000
na	Spec Data (MANDATA)	(blank)

Note: Some of these values may vary from module to module. The values shown above are examples only.

Glossary

ac, AC

alternating current. An electric current that reverses its direction at regularly recurring intervals.

AGC

automatic gain control. A process or means by which gain is automatically adjusted in a specified manner as a function of input level or other specified parameters.

binding

A parameter representing the physical or logical objects associated with a trap.

CAT5

category 5 Ethernet cable.

CDE

common desktop environment.

CLEI

common language equipment identifier. CLEI code is globally unique ten-character intelligent code, assigned by Telcordia, that identifies communications equipment in a concise, uniform feature-oriented language, which describes product type, features, source document and associated drawings and vintages.

CLI

command line interface. A command reference software that allows the user to interact with the operating system by entering commands and optional arguments.

CLLI

common language location identification. A CLLI code is typically an 11-character alphanumeric descriptor used to identify network elements and their locations.

CSV

comma-separated values. A data file format supported by many spreadsheet programs, in

Glossary

which fields are separated by commas. Also referred to as comma delimited.

DB-37

37-pin D-sub connector.

dc, DC

direct current. An electric current flowing in one direction only and substantially constant in value.

EIA

Electronic Industries Association. A United States association that provides standards for use between manufacturers and purchasers of electronic products.

EMC

electromagnetic compatibility. A measure of equipment tolerance to external electromagnetic fields.

EMT

externally-modulated transmitter.

ESD

electrostatic discharge. Discharge of stored static electricity that can damage electronic equipment and impair electrical circuitry, resulting in complete or intermittent failures.

FTTP

fiber-to-the-premises. Fiber optic service to the subscriber's premises.

GUI

graphical user interface. A program interface that takes advantage of a computer graphics capabilities to make the program visually easier to use.

I/O

input/output.

ICIM

intelligent communications interface module.

IP

Internet protocol. A standard that was originally developed by the United States Department

of Defense to support the internetworking of dissimilar computers across a network. IP is perhaps the most important of the protocols on which the Internet is based. It is the standard that describes software that keeps track of the internetwork addresses for different nodes, routes, and outgoing/incoming messages on a network. Some examples of IP applications include email, chat, and Web browsers.

ISO

International Organization for Standardization. An international body that defines global standards for electronic and other industries.

LCD

liquid crystal display. A display medium made of liquid crystal. Liquid crystal's reflectance changes when an electric field is applied. Commonly used in monitors, televisions, cell phones, digital watches, etc.

LED

light-emitting diode. An electronic device that lights up when electricity passes through it.

MIB

management information base. SNMP collects management information from devices on the network and records the information in a management information base. The MIB information includes device features, data throughput statistics, traffic overloads, and errors.

nm

nanometer. One billionth of a meter.

NMS

network management system. A software system designed specifically to monitor a network and to facilitate troubleshooting.

OID

object identifier.

OMI

optical modulation index.

PLL

phase lock loop. An electronic servo system controlling an oscillator to maintain a constant phase angle relative to a reference signal.

Glossary

polling

In a transmission network system, the active sampling of the status of network devices by a control and monitoring program.

RF

radio frequency. The frequency in the portion of the electromagnetic spectrum that is above the audio frequencies and below the infrared frequencies, used in radio transmission systems.

RMA

return material authorization. A form used to return products.

RT

remote terminal. Remote equipment of a supervisory system.

RTC

real time clock.

RX

receive or receiver.

SBS

stimulated Brillouin scattering. The easiest fiber nonlinearity to trigger. When a powerful lightwave travels through a fiber, it interacts with acoustical vibration modes in the glass. This causes a scattering mechanism to be formed that reflects much of the light back to the source.

semaphore

In programming, a control token (variable or abstract data type) used to restrict access to a resource. The Cisco SOUP program uses a semaphore to prevent multiple instances of the SOUP from running and trying to change Prisma II EMS chassis parameters at the same time.

SMC

status monitoring and control. The process by which the operation, configuration, and performance of individual elements in a network or system are monitored and controlled from a central location.

SNMP

simple network management protocol. A protocol that governs network management and the monitoring of network devices and their functions.

SOUP

software upgrade program. A utility used to update firmware in Prisma II EMS application modules.

TEC

thermoelectric cooler. A device used to dissipate heat in electronic assemblies.

Telco

telephone company.

TNCS

Transmission Network Control System. A Cisco application that allows status monitoring and control of all transmission equipment located in headends and hubs plus optical nodes, power supplies, and amplifiers in the outside plant. TNCS provides access to and information on the entire network in an easy to understand, topology driven, graphical user display.

trap

An unsolicited message sent by a network device to notify a network or element management system of an alarm or other condition that requires administrative attention.

TX

transmit or transmitter.

Index

A

About Traps • 239
ac, AC • 351
Accessing the Module Detail Information • 133
Active and Inactive Flash • 285
Additional Assistance • 303
AGC • 351
ALARM IN and OUT Connections • 62
Alarm Severity Mappings • 225
Alarm Threshold Modification • 277
Alarm Troubleshooting • 303
ALARMS IN Connector • 63
ALARMS OUT Connector • 63

B

Back Panel Connectors • 48
Back Plane Bus Connectors • 40
Before You Begin • 50
binding • 351

C

Cable Requirements • 125
CAT5 • 351
CDE • 351
Chassis Back Plane Bus • 39
Chassis Configuration • 36
Chassis Dimensions • 55
Chassis Fan Filter • 65
Chassis Front Panel Features • 38
Chassis Troubleshooting • 302
Chassis Wiring and Fusing • 6, 51
Chassis-to-Chassis ICIM2 Activation • 60
Chassis-to-Chassis ICIM2 Connections • 3
ChasTemp Alarm • 305
ChasTemp Alarm Parameters • 305
Checking Manufacturing Data using LCI • 144
Checking the Module Alarms using LCI • 140
Checking the Operating Status • 139
Cleaning Optical Connectors • 77, 315
Clearing the Event Log • 171
CLEI • 351

CLI • 351
CLI Parameters • 87
CLLI • 351
Computer Requirements • 125
Concepts • 285
Concurrency • 286
Configuring for Remote Network Access • 104
Connecting Optical Cables • 81, 319
Connecting RF Cables • 82
Connecting the ICIM2 to Additional Chassis • 58
Connecting Your Computer to the Chassis • 129
Connector Interface Panel • 56
Connector Interface Panel Illustration • 56
CSV • 351
Current Alarm Table • 226
Current Alarms • 341
Customer Support Information • 321

D

DB-37 • 352
DC Power Inlet Illustration • 8
dc, DC • 352
Delay in the Discovery Process • 279
Downloading and Viewing the Event Log Remotely • 176

E

EIA • 352
Electrical Input Voltages • 43
Electrical Power Connections • 6, 67
EMC • 352
EMT • 352
Enhanced Trap Alarms • 257
Enhanced Trap Binding Information • 253
Enhanced Trap Events • 260
Equipment Configuration • 83
ESD • 352
Event Action IDs • 167
Event Log • 165
Event Log Fields • 166
Event Log File Management • 195

Event Log-Related Traps • 174
 External Alarms Connections • 62

F

Fan Tray • 64
 Fan Tray ALARMS Menus • 109
 Fan Tray Configuration • 41
 Fan Tray Front Panel Features • 42
 Fan Tray Illustration (Top View) • 42
 Fan Tray Installation • 41
 Fan Tray Menu Structure • 107
 Fan Tray MFG. DATA Menus • 111
 Fan Tray STATUS Menus • 108
 FansOk Alarm • 304
 FansOk Alarm Parameters • 304
 Firmware Updates • 296
 Firmware Upgrade Process • 291
 Frequently Asked Questions • 280
 From */* MODULE • 331
 From CLI • 324
 From ICIM • 325
 From TERMINAL • 334
 Front-Access Chassis • 38
 FTP Server • 295
 FTP Settings • 292
 FFTP • 352

G

GUI • 352

H

Hardware Installation • 49
 How do Enhanced Traps differ from other trap types? • 281
 How do I configure trap destination? • 280
 HyperTerminal Session Setup • 84

I

I/O • 352
 ICIM • 352
 ICIM Data • 337
 ICIM IN and ICIM OUT Cables • 5, 60
 ICIM IN and ICIM OUT Connectors • 3, 60
 ICIM MIB • 181
 ICIM2 • 35
 ICIM2 as Proxy for Module Information • 279
 ICIM2 Block Diagram • 46
 ICIM2 Front Panel Features • 47, 99
 ICIM2 Illustration (Front Panel) • 47, 99
 ICIM2 Keypad • 100

ICIM2 LCD • 100
 ICIM2 Menu • 103
 ICIM2 Operation • 97
 Insert Module Table • 235
 Installing LCI • 126
 Installing the ICIM2 • 72
 Installing the Module in the Chassis • 74
 Installing the Power Supplies • 67
 Installing the SOUP • 284
 Integration with an NMS (Optional) • 286
 Introduction • 31, 146, 166, 180
 IP • 352
 ISO • 353

L

Launching Standalone (Windows Only) • 287
 LCD • 353
 LCI Introduction • 124
 LCI Module Tree • 132
 LED • 353
 Login • 87
 Login Settings • 93

M

MAIN Menu • 102
 Maintenance • 301
 Maintenance and Troubleshooting • 299
 Maintenance Record • 301
 Master-Slave Illustration • 63
 Master-Slave Operation • 62
 MIB • 353
 Modifying Module Alarm Limits using LCI • 142
 Module Alarm Table • 220
 Module Alarms • 342
 Module Back Panel • 48
 Module Control Table • 232
 Module Controls • 343
 Module Data • 340
 Module Details Window • 133
 Module MIB • 211
 Module Monitor Table • 229
 Module Monitors • 344
 Module Removal and Enhanced Traps • 279
 Module Table • 212
 Module Tree • 132
 Mounting the Chassis in a Rack • 54

N

nm • 353

NMS • 353

O

OID • 353

OMI • 353

Operating Environment • 51

Operating the ICIM2 • 99

Operation using LCI • 123

Overview • 336

P

Platform Configuration • 98

PLL • 353

polling • 354

Power and Communications Connector • 48

Power Inlets • 43

Power Supply 1 ALARMS Menus • 114

Power Supply 1 Menu Structure • 112

Power Supply 1 MFG. DATA Menus • 116

Power Supply 1 STATUS Menus • 113

Power Supply 3 ALARMS Menus • 119

Power Supply 3 Menu Structure • 117

Power Supply 3 MFG. DATA Menus • 121

Power Supply 3 STATUS Menus • 118

Power Supply Block Diagram • 44

Power Supply Cooling Fans • 70

Power Supply Front Panel Features • 45

Power Supply Front Panel Illustrations • 44

Prisma II Application Modules • 35

Prisma II Chassis • 36

Prisma II Chassis Alarm Data Parameters • 348

Prisma II Chassis Configurable Parameters • 348

Prisma II Chassis Manufacturing Data

Parameters • 349

Prisma II Chassis Operating Status Parameters • 348

Prisma II Chassis Parameters • 348

Prisma II Enterprise MIBs • 180

Prisma II Fan Tray • 35, 41

Prisma II ICIM2 • 46

Prisma II MAIN Menu and ICIM Menu Structure • 102

Prisma II Platform Components • 34

Prisma II Platform Description • 34

Prisma II Power Supplies • 35, 40

Prisma II Power Supply • 43

Prisma II Traps • 239

Ps1+24 Alarm • 308

Ps1+24 Alarm Parameters • 308

Ps1+5VDC Alarm • 309

Ps1+5VDC Alarm Parameters • 309

Ps1-5VDC Alarm • 310

PS1-5VDC Alarm Parameters • 310

Ps1PwrIn Alarm • 307

Ps1PwrIn Alarm Parameters • 307

Ps3+24 Alarm • 312

Ps3+24 Alarm Parameters • 312

Ps3+5VDC Alarm • 313

Ps3+5VDC Alarm Parameters • 313

Ps3-5VDC Alarm • 314

PS3-5VDC Alarm Parameters • 314

Ps3PwrIn Alarm • 311

Ps3PwrIn Alarm Parameters • 311

Q

Quick Start Guide • 1

R

Rack Location Requirements • 53

Recommended Equipment • 77, 315

Related Publications • 33

Release Files • 285

Remote Firmware Download Feature • 283

Remote Reboot of ICIM2 and Modules • 238

Remove Module Table • 235

Replacing the Default Admin Account • 149

Required Equipment and Tools • 50

RF • 354

RMA • 354

RT • 354

RTC • 354

RX • 354

S

SBS • 354

semaphore • 354

Setting Event Log Filter Parameters • 172

Site Requirements • 51

SMC • 354

SNMP • 354

SNMP Management • 179

SNMP Parameters • 92

SNMP Settings • 293

SNTP Time Synchronization • 198

SOUP • 355

SOUP Main Screen • 289

Space Requirements • 67

Starting LCI Software • 130

Step 1

Install the Chassis in a Rack • 2

Step 10
 Perform Chassis-to-Chassis ICIM2
 Activation (Optional) • 23

Step 11
 Make Changes to Traps and Enterprise MIBs
 • 24

Step 12
 Make Physical Connections to Modules • 26

Step 13
 Verify System Release and Module Firmware
 Versions • 27

Step 14
 Install and Use the Firmware Update (SOUP)
 Utility (Optional) • 28

Step 2
 Make Chassis-to-Chassis ICIM2 Connections
 • 3

Step 3
 Make Electrical Power Connections • 6

Step 4
 Install the ICIM2 • 12

Step 5
 Set Network Parameters from the Command
 Line Interface (CLI) • 13

Step 6
 Connect the ICIM2 to the Network • 17

Step 7
 Install Modules in the Chassis • 18

Step 8
 Set Additional Parameters via CLI (Optional)
 • 20

Step 9
 Set and Verify SNMP Community Strings •
 21

Suggested Actions • 304, 305, 307, 308, 309,
 310, 311, 312, 313, 314

System Behavior • 279

System Information • 345

System Requirements • 125

T

TEC • 355

Telco • 355

Telnet Session • 90

The Chassis and the ICIM2 • 285

Tips for Optimal Fiber-Optic Connector
 Performance • 77, 315

TNCS • 355

To Access the Module Details, Double-Click the
 Chassis • 134

To Access the Module Details, Double-Click the
 Module • 137

To Access the Module Details, Right-Click the
 Chassis • 135

To Access the Module Details, Right-Click the
 Module • 138

To Adjust the ICIM2 LCD Contrast • 101

To Change the Chassis ID Number • 4, 59

To Check Alarms • 108, 113, 118

To Check Alarms using LCI • 140

To Check Fan Tray Manufacturing Data • 109

To Check Manufacturing Data using LCI • 144

To Check Operating Status • 107, 112, 117

To Check Power Supply 1 Manufacturing Data •
 115

To Check Power Supply 3 Manufacturing Data •
 120

To Check the Operating Status using LCI • 139

To Clean Optical Connectors • 78, 316

To Configure the ICIM2 for SNMP • 104

To Configure Trap Destination • 241

To Connect a Computer to the Chassis • 129

To Connect Optical Cables • 81, 319

To Connect RF Cables • 82

To Install SOUP on Windows • 284

To Install the AC Power Cord • 10, 68

To Install the Chassis in a Rack • 2, 54

To Install the DC Power Cord • 9, 69

To Install the ICIM2 • 12, 72

To Install the LCI Software • 126

To Install the Module • 18, 74

To Install the Power Supply in the Chassis • 10,
 69

To Log In • 93

To Log Out • 94

To Make ICIM IN and ICIM OUT Cable
 Connections • 3, 58

To Modify Alarm Limits using LCI • 142

To Monitor the Power Supply • 71

To Remove Chassis Fan Filter • 65

To Remove the Fan Tray • 64

To Restart the ICIM2 • 106

To Set Additional Users for ICIM2 or ICIM2-
 XD Access • 20, 88

To Set and Verify SNMP Community Strings •
 89

To Set the Clock • 88

- To Set Up a HyperTerminal Serial Port Session • 84
- To Set Up a Telnet CLI Session • 17, 90
- To Start LCI Software • 130
- To Uninstall the SOUP on Windows • 284
- trap • 355
- Trap Handling • 201
- Trap Logging Auxiliaries • 206
- Trap Logging Table • 206
- Trap Receiving Configuration • 240
- Trap Recv Table • 202
- Trap Types • 242
- Troubleshooting • 302
- TX • 355
- Typical Chassis Block Diagram • 37

U

- Unpacking and Inspecting the Chassis • 50
- Unused Slots • 53
- Usage • 287
- User Lockout • 160
- User Management • 145, 346
- Using ICIM2 with Power Supply 1 • 112
- Using ICIM2 with Power Supply 3 • 117
- Using ICIM2 with the Fan Tray • 107
- Using the ICIM Web Interface • 93

V

- Viewing the Event Log • 169

W

- Warning Labels • xxvii
- What is the Trap Logging Table? • 282
- When do traps associated with module insertion, removal, and alarms occur? • 281
- Where can I find trap definitions? • 282
- Why do the same alarm values represent different conditions? • 280
- Working With User Accounts • 153



Cisco Systems, Inc.
5030 Sugarloaf Parkway, Box 465447
Lawrenceville, GA 30042

678 277-1120
800 722-2009
www.cisco.com

This document includes various trademarks of Cisco Systems, Inc. Please see the Notices section of this document for a list of the Cisco Systems, Inc. trademarks used in this document.

Product and service availability are subject to change without notice.

© 2008, 2012 Cisco and/or its affiliates.

All rights reserved.

October 2012 Printed in USA

Part Number 78-4025478-01 Rev B