



Cloud Native BNG Control Plane Command Reference Guide, Release 2023.04

First Published: 2023-10-31

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2023 Cisco Systems, Inc. All rights reserved.



CONTENTS

PREFACE

About this Guide	ix
Conventions Used	ix

CHAPTER 1

cnBNG CP Commands	1
clear subscriber	4
endpoint ep	6
endpoint ep interface	7
endpoint ep interface sla	7
endpoint ep interface vip	8
endpoint ep vip	8
helm	9
helm charts	9
helm repository	9
ipam address-pool	10
ipam address-pool ipv4 address-range	11
ipam address-pool ipv4 split-size	11
ipam address-pool ipv4 threshold	12
ipam address-pool ipv6 address-ranges address-range	12
ipam address-pool ipv6 address-ranges split-size	13
ipam address-pool ipv6 address-ranges threshold	13
ipam address-pool ipv6 prefix-ranges prefix-range	14
ipam address-pool ipv6 prefix-ranges split-size	14
ipam address-pool ipv6 prefix-ranges threshold	15
ipam address-pool static	15
ipam source	15
ipam threshold	16

k8 bng	16
k8 label pod-group-config	17
kubernetes	18
kubernetes nodes	19
logging level	20
logging logger	21
logging logger level	21
logging transaction	23
profile aaa	23
profile aaa accounting	24
profile aaa authentication	24
profile aaa authorization	25
profile aaa authorization type subscriber	25
profile aaa authorization username	25
profile attribute-format	26
profile coa	26
profile coa client	27
profile dhcp	27
profile dhcp ipv4	27
profile dhcp ipv4 class	28
profile dhcp ipv4 class matches	28
profile dhcp ipv4 class matches match	28
profile dhcp ipv4 class server	29
profile dhcp ipv4 class server lease	30
profile dhcp ipv4 class server netbios-node-type	31
profile dhcp ipv4 class server option-codes	31
profile dhcp ipv4 class server option-codes option-code	32
profile dhcp ipv4 server	33
profile dhcp ipv4 server lease	34
profile dhcp ipv4 server netbios-node-type	34
profile dhcp ipv4 server option-codes	35
profile dhcp ipv4 server option-codes option-code	36
profile dhcp ipv6	37
profile dhcp ipv6 class	37

profile dhcp ipv6 class server	37
profile dhcp ipv6 class server lease	38
profile dhcp ipv6 server	39
profile dhcp ipv6 server lease	40
profile feature-template	41
profile feature-template ipv4	41
profile feature-template ipv4 verify-unicast-source	42
profile feature-template ipv6	42
profile feature-template ipv6 verify-unicast-source	43
profile feature-template ppp	43
profile feature-template ppp chap	44
profile feature-template ppp ipcp	44
profile feature-template ppp ipcp dns	45
profile feature-template ppp ipcp renegotiation	45
profile feature-template ppp ipcp wins	45
profile feature-template ppp ipv6cp renegotiation	46
profile feature-template ppp keepalive	46
profile feature-template ppp lcp delay	47
profile feature-template ppp lcp renegotiation	47
profile feature-template ppp pap	48
profile feature-template ppp timeout	48
profile feature-template ppp timeout absolute	48
profile feature-template qos	49
profile feature-template service-accounting	49
profile feature-template session-accounting	50
profile pppoe	51
profile pppoe max-payload	54
profile pppoe session-limit circuit-id	55
profile pppoe session-limit mac	55
profile pppoe session-limit max	55
profile pppoe session-limit outer-vlan	56
profile radius	56
profile radius accounting	57
profile radius accounting attribute called-station-id	59

profile radius accounting attribute calling-station-id 60

profile radius accounting attribute nas-identifier-format 60

profile radius accounting attribute nas-port-id 60

profile radius accounting detect-dead-server 61

profile radius attribute called-station-id 61

profile radius attribute called-station-id format 62

profile radius attribute calling-station-id 62

profile radius attribute calling-station-id format 63

profile radius attribute nas-identifier-format 63

profile radius attribute nas-identifier-format format 64

profile radius attribute nas-ip 64

profile radius attribute nas-port-id 65

profile radius attribute nas-port-id format 65

profile radius detect-dead-server 66

profile radius server 66

profile radius server-group 67

profile radius server-group server 67

profile server-group 68

profile subscriber 68

profile subscriber aaa 69

profile subscriber class 70

profile subscriber class aaa 71

profile subscriber class matches 71

profile subscriber class matches match 71

profile subscriber event 72

profile subscriber event aaa 73

profile subscriber event class 74

profile subscriber event class aaa 74

profile subscriber event class matches 75

profile subscriber event class matches match 75

show sessions 76

show sessions affinity 76

show sessions commit-pending 77

show diagnostics 77

show diagnostics info	77
show endpoint all	77
show endpoint info	77
show ipam dp	78
show ipam pool	78
show peers	78
show peers all	78
show resources	79
show resources info	79
show rpc	79
show rpc all	79
show running-status	79
show running-status info	80
show subscriber	80
show subscriber	81
show subscriber filter	82
show subscriber redundancy	85
show subscriber redundancy-sync	85
show subscriber session	86
show subscriber synchronize	86
subscriber featurette dhcp-lease-reservation enable	87
subscriber-redundancy group	87
subscriber redundancy session-synchronize add	88
subscriber redundancy session-synchronize delete	89
subscriber reset-token	90
subscriber route-synchronize	90
subscriber session-synchronize	90
subscriber session-synchronize-cp	91
subscriber token	91
user-plane	92
user-plane flowctrl-group	92
user-plane peer-address	93
user-plane port-id	93

CHAPTER 2	Input Pattern Types	95
	arg-type	95
	crypt-hash	96
	date-and-time	97
	domain-name	97
	dotted-quad	98
	hex-list	98
	hex-string	99
	ipv4-address	99
	ipv4-address-and-prefix-length	99
	ipv4-address-no-zone	99
	ipv4-prefix	99
	ipv6-address	100
	ipv6-address-and-prefix-length	100
	ipv6-address-no-zone	101
	ipv6-prefix	101
	mac-address	102
	object-identifier	102
	object-identifier-128	102
	octet-list	103
	phys-address	103
	sha-256-digest-string	103
	sha-512-digest-string	104
	size	104
	uuid	105
	yang-identifier	105



About this Guide



Note The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. While any existing biased terms are being substituted, exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

This guide provides details about the CLI commands available for the Cloud Native Broadband Network Gateway (cnBNG) Control Plane (CP).

- [Conventions Used, on page ix](#)

Conventions Used

The following tables describe the conventions used throughout this documentation.

Notice Type	Description
Information Note	Provides information about important features or instructions.
Caution	Alerts you of potential damage to a program, device, or system.
Warning	Alerts you of potential personal injury or fatality. May also alert you of potential electrical hazards.

Typeface Conventions	Description
Text represented as a screen display	This typeface represents displays that appear on your terminal screen, for example: <code>Login:</code>
Text represented as commands	This typeface represents commands that you enter, for example: <code>show ip access-list</code> This document always gives the full form of a command in lowercase letters. Commands are not case sensitive.

Typeface Conventions	Description
Text represented as a command <i>variable</i>	This typeface represents a variable that is part of a command, for example: show card <i>slot_number</i> <i>slot_number</i> is a variable representing the desired chassis slot number.
Text represented as menu or sub-menu names	This typeface represents menus and sub-menus that you access within a software application, for example: Click the File menu, then click New



CHAPTER 1

cnBNG CP Commands

This guide describes the CLI commands that are used to configure a control plane in cnBNG.

Some keywords and commands are common across multiple commands and configuration modes respectively. Use the information in the Command Modes section only as a reference to navigate to the command in the applicable configuration modes.

- [clear subscriber, on page 4](#)
- [endpoint ep, on page 6](#)
- [endpoint ep interface, on page 7](#)
- [endpoint ep interface sla, on page 7](#)
- [endpoint ep interface vip, on page 8](#)
- [endpoint ep vip, on page 8](#)
- [helm, on page 9](#)
- [helm charts, on page 9](#)
- [helm repository, on page 9](#)
- [ipam address-pool, on page 10](#)
- [ipam address-pool ipv4 address-range, on page 11](#)
- [ipam address-pool ipv4 split-size, on page 11](#)
- [ipam address-pool ipv4 threshold, on page 12](#)
- [ipam address-pool ipv6 address-ranges address-range, on page 12](#)
- [ipam address-pool ipv6 address-ranges split-size, on page 13](#)
- [ipam address-pool ipv6 address-ranges threshold, on page 13](#)
- [ipam address-pool ipv6 prefix-ranges prefix-range, on page 14](#)
- [ipam address-pool ipv6 prefix-ranges split-size, on page 14](#)
- [ipam address-pool ipv6 prefix-ranges threshold, on page 15](#)
- [ipam address-pool static, on page 15](#)
- [ipam source, on page 15](#)
- [ipam threshold, on page 16](#)
- [k8 bng, on page 16](#)
- [k8 label pod-group-config, on page 17](#)
- [kubernetes, on page 18](#)
- [kubernetes nodes, on page 19](#)
- [logging level, on page 20](#)
- [logging logger, on page 21](#)
- [logging logger level, on page 21](#)

- logging transaction, on page 23
- profile aaa, on page 23
- profile aaa accounting, on page 24
- profile aaa authentication, on page 24
- profile aaa authorization, on page 25
- profile aaa authorization type subscriber, on page 25
- profile aaa authorization username, on page 25
- profile attribute-format, on page 26
- profile coa, on page 26
- profile coa client, on page 27
- profile dhcp, on page 27
- profile dhcp ipv4, on page 27
- profile dhcp ipv4 class, on page 28
- profile dhcp ipv4 class matches, on page 28
- profile dhcp ipv4 class matches match, on page 28
- profile dhcp ipv4 class server, on page 29
- profile dhcp ipv4 class server lease, on page 30
- profile dhcp ipv4 class server netbios-node-type, on page 31
- profile dhcp ipv4 class server option-codes, on page 31
- profile dhcp ipv4 class server option-codes option-code, on page 32
- profile dhcp ipv4 server, on page 33
- profile dhcp ipv4 server lease, on page 34
- profile dhcp ipv4 server netbios-node-type, on page 34
- profile dhcp ipv4 server option-codes, on page 35
- profile dhcp ipv4 server option-codes option-code, on page 36
- profile dhcp ipv6, on page 37
- profile dhcp ipv6 class, on page 37
- profile dhcp ipv6 class server, on page 37
- profile dhcp ipv6 class server lease, on page 38
- profile dhcp ipv6 server, on page 39
- profile dhcp ipv6 server lease, on page 40
- profile feature-template, on page 41
- profile feature-template ipv4, on page 41
- profile feature-template ipv4 verify-unicast-source, on page 42
- profile feature-template ipv6, on page 42
- profile feature-template ipv6 verify-unicast-source, on page 43
- profile feature-template ppp, on page 43
- profile feature-template ppp chap, on page 44
- profile feature-template ppp ipcp, on page 44
- profile feature-template ppp ipcp dns, on page 45
- profile feature-template ppp ipcp renegotiation, on page 45
- profile feature-template ppp ipcp wins, on page 45
- profile feature-template ppp ipv6cp renegotiation, on page 46
- profile feature-template ppp keepalive, on page 46
- profile feature-template ppp lcp delay, on page 47
- profile feature-template ppp lcp renegotiation, on page 47

- [profile feature-template ppp pap](#), on page 48
- [profile feature-template ppp timeout](#), on page 48
- [profile feature-template ppp timeout absolute](#), on page 48
- [profile feature-template qos](#), on page 49
- [profile feature-template service-accounting](#), on page 49
- [profile feature-template session-accounting](#), on page 50
- [profile pppoe](#), on page 51
- [profile pppoe max-payload](#), on page 54
- [profile pppoe session-limit circuit-id](#), on page 55
- [profile pppoe session-limit mac](#), on page 55
- [profile pppoe session-limit max](#), on page 55
- [profile pppoe session-limit outer-vlan](#), on page 56
- [profile radius](#), on page 56
- [profile radius accounting](#), on page 57
- [profile radius accounting attribute called-station-id](#), on page 59
- [profile radius accounting attribute calling-station-id](#), on page 60
- [profile radius accounting attribute nas-identifier-format](#), on page 60
- [profile radius accounting attribute nas-port-id](#), on page 60
- [profile radius accounting detect-dead-server](#), on page 61
- [profile radius attribute called-station-id](#), on page 61
- [profile radius attribute called-station-id format](#), on page 62
- [profile radius attribute calling-station-id](#), on page 62
- [profile radius attribute calling-station-id format](#), on page 63
- [profile radius attribute nas-identifier-format](#), on page 63
- [profile radius attribute nas-identifier-format format](#), on page 64
- [profile radius attribute nas-ip](#), on page 64
- [profile radius attribute nas-port-id](#), on page 65
- [profile radius attribute nas-port-id format](#), on page 65
- [profile radius detect-dead-server](#), on page 66
- [profile radius server](#), on page 66
- [profile radius server-group](#), on page 67
- [profile radius server-group server](#), on page 67
- [profile server-group](#), on page 68
- [profile subscriber](#), on page 68
- [profile subscriber aaa](#), on page 69
- [profile subscriber class](#), on page 70
- [profile subscriber class aaa](#), on page 71
- [profile subscriber class matches](#), on page 71
- [profile subscriber class matches match](#), on page 71
- [profile subscriber event](#), on page 72
- [profile subscriber event aaa](#), on page 73
- [profile subscriber event class](#), on page 74
- [profile subscriber event class aaa](#), on page 74
- [profile subscriber event class matches](#), on page 75
- [profile subscriber event class matches match](#), on page 75
- [show sessions](#), on page 76

- [show sessions affinity](#), on page 76
- [show sessions commit-pending](#), on page 77
- [show diagnostics](#), on page 77
- [show diagnostics info](#), on page 77
- [show endpoint all](#), on page 77
- [show endpoint info](#), on page 77
- [show ipam dp](#), on page 78
- [show ipam pool](#), on page 78
- [show peers](#), on page 78
- [show peers all](#), on page 78
- [show resources](#), on page 79
- [show resources info](#), on page 79
- [show rpc](#), on page 79
- [show rpc all](#), on page 79
- [show running-status](#), on page 79
- [show running-status info](#), on page 80
- [show subscriber](#), on page 80
- [show subscriber](#), on page 81
- [show subscriber filter](#), on page 82
- [show subscriber redundancy](#), on page 85
- [show subscriber redundancy-sync](#), on page 85
- [show subscriber session](#), on page 86
- [show subscriber synchronize](#), on page 86
- [subscriber featurette dhcp-lease-reservation enable](#), on page 87
- [subscriber-redundancy group](#), on page 87
- [subscriber redundancy session-synchronize add](#), on page 88
- [subscriber redundancy session-synchronize delete](#), on page 89
- [subscriber reset-token](#), on page 90
- [subscriber route-synchronize](#), on page 90
- [subscriber session-synchronize](#), on page 90
- [subscriber session-synchronize-cp](#), on page 91
- [subscriber token](#), on page 91
- [user-plane](#), on page 92
- [user-plane flowctrl-group](#), on page 92
- [user-plane peer-address](#), on page 93
- [user-plane port-id](#), on page 93

clear subscriber

Clears BNG subscriber data.

Command Modes

Exec

Syntax Description

```
clear subscriber [ force ] type { [ ipv4-pool ipv4_pool_name ] [ ipv4-range
ipv4_address_range ] [ ipv6-addr-pool ipv6_address_pool_name ] [ ipv6-addr-range
ipv6_address_range ] [ ipv6-pfx-pool ipv6_prefix_pool_name ] [ ipv6-pfx-range
```

```
ipv6_prefix_range ] [ mac mac_address ] [ port-id upf_port_id ] [ sublabel  
subscriber_label ] [ upf upf_name ] }
```

force

Specify to force session deletion, even if UP is down.

ipv4-pool *ipv4_pool_name*

Specify the IPv4 address pool name.

Must be a string.

ipv4-range *ipv4_address_range*

Specify the IPv4 address range in the format "*poolName/start-ip*".

Must be a string.

ipv6-addr-pool *ipv6_address_pool_name*

Specify the IPv6 address pool name.

Must be a string.

ipv6-addr-range *ipv6_address_range*

Specify the IPv6 address range in the format "*poolName/start-ip*".

Must be a string.

ipv6-pfx-pool *ipv6_prefix_pool_name*

Specify the IPv6 prefix pool name.

Must be a string.

ipv6-pfx-range *ipv6_prefix_range*

Specify the IPv6 prefix range in the format "*poolName/start-pfx*".

Must be a string.

mac *mac_address*

Specify the MAC address in the format "*aabb.cccd.eeff*".

Must be a string.

port-id *upf_port_id*

Specify the user plane function port ID in the format "*upf/port-id*".

Must be a string.

sublabel *subscriber_label*

Specify the subscriber label.

Must be a string.

upf *upf_name*

Specify the user plane function name.

Must be a string.

type

Specify the type.

Must be one of the following:

- **dhcp**
- **pppoe**
- **sessmgr**

Usage Guidelines Use this command to clear BNG subscriber data.

endpoint ep

Configures endpoint parameters.

Command Modes Exec > Global Configuration

Syntax Description **endpoint** *endpoint_type* { **replicas** *replicas_per_node* | **nodes** *node_replicas_for_resiliency* | **loopbackEth** *loopbackEth* | **loopbackPort** *loopbackPort* }

eptype *endpoint_type*

Specify the endpoint type.

loopbackEth *loopbackEth*

Specify the endpoint local interface name or host IP.

Must be a string.

loopbackPort *loopbackPort*

Specify the endpoint local port.

Must be an integer.

nodes *node_replicas_for_resiliency*

Specify the number of node replicas for resiliency.

Must be an integer.

Default Value: 1.

replicas *replicas_per_node*

Specify the number of replicas per node.

Must be an integer.

Default Value: 1.

Usage Guidelines Use this command to configure endpoint parameters.

endpoint ep interface

Configures the interface type.

Command Modes Exec > Global Configuration

Syntax Description `endpoint ep interface interface_type`

loopbackEth *loopback_eth*

Specify the loopback Eth.

Must be a string.

loopbackPort *loopback_port*

Specify the loopback port.

Must be an integer.

interface_type

Specify the interface type.

Usage Guidelines Use this command to configure the interface type.

endpoint ep interface sla

Configures SLA parameters.

Command Modes Exec > Global Configuration

Syntax Description `endpoint ep interface sla { response response_time | procedure procedure_time }`

procedure *procedure_time*

Specify the procedure time in milliseconds.

Must be an integer in the range of 1000-120000.

response *response_time*

Specify the response time in milliseconds.

Must be an integer in the range of 1000-180000.

Usage Guidelines Use this command to configure SLA parameters.

endpoint ep interface vip

Configures VIP IP parameters.

Command Modes Exec > Global Configuration

Syntax Description `endpoint ep interface vip { vip-ip vip_ip | vip-port vip_port | offline }`

offline

Specify to mark the vip-ip as offline.

vip-ip *vip_ip*

Specify the host IP address.

Must be a string.

vip-port *vip_port*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP IP parameters.

endpoint ep vip

Configures VIP parameters.

Command Modes Exec > Global Configuration > Endpoint Configuration

Syntax Description `vip-ip vip_ip_address [[vip-port port_number] [offline]]`

offline

Specify the VIP-IP as offline.

vip-ip *vip_ip_address*

Specify the VIP IP address.

Must be a string.

vip-port *port_number*

Specify the port number.

Must be an integer.

Usage Guidelines Use this command to configure VIP parameters.

helm

Configures Helm configuration parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **helm default-repository** *default_repository_name*

default-repository *default_repository_name*

Specify the name of the default Helm repository.

Usage Guidelines Use this command to configure Helm configuration parameters.

helm charts

Displays Helm release details.

Command Modes Exec > Global Configuration (config)

Syntax Description **charts**

Usage Guidelines Use this command to view Helm release details.

helm repository

Configures Helm repository parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description **helm repository** *helm_repo_name* [[**access-token** *access_token*] [**url** *helm_repo_url*] [**username** *helm_repo_username*] [**password** *helm_repo_password*]]

access-token *helm_repo_access_token*

Specify the access token for the Helm repository.

Must be a string.

password *helm_repo_password*

Specify the password for the Helm repository.

Must be an aes-cfb-128-encrypted string.

url *helm_repo_url*

Specify the URL for the Helm repository.

Must be a string.

username *helm_repo_username*

Specify the username for the Helm repository.

Must be a string.

helm_repo_name

Specify the name of the Helm repository.

Must be a string.

Usage Guidelines Use this command to configure the Helm repository parameters.

ipam address-pool

Configures IPAM address pools.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam)

Syntax Description **address-pool** *pool_name* [**static** | **offline** | **vrf-name** *vrf_name*]

address-quarantine-timer *address_quarantine_timer_interval*

Specify the address quarantine timer interval in seconds.

Must be an integer in the range of 4-60.

Default Value: 4.

default-gateway *ip_address*

Specify the default gateway IP address for static pool.

Must be an IPv4 address.

offline

Specify the pool as an offline pool.

prefix-length *prefix_length*

Specify the prefix length.

Must be an integer in the range of 1-64.

Default Value: 64.

vrf-name *vrf_name*

Specify the VRF name.

Must be a string.

pool_name

Specify the address pool's name.

Must be a string.

Usage Guidelines Use this command to configure IPAM address pools.

ipam address-pool ipv4 address-range

Configures IPv4 address ranges.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Address Pool Configuration

Syntax Description **address-range** *start_ipv4_address end_ipv4_address* [**offline**]

default-gateway *ip_address*

Specify the default gateway IP address for static pool.

Must be an IPv4 address.

offline

Specify the IPv4 address range as offline.

end_ipv4_address

Specify the end address of the IPv4 address range.

Must be an IPv4 address.

start_ipv4_address

Specify the start address of the IPv4 address range.

Must be an IPv4 address.

Usage Guidelines Use this command to configure IPv4 address ranges.

ipam address-pool ipv4 split-size

Configures chunk split size.

Command Modes	Exec > Global Configuration > IPAM Configuration
Syntax Description	<p>split-size [per-cache <i>number_of_addresses</i>] [per-dp <i>number_of_addresses</i>]</p> <p>no-split</p> <p>Specify not to split the address range into smaller chunks.</p> <p>per-cache <i>number_of_addresses</i></p> <p>Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2. Must be an integer in the range of 2-262144.</p> <p>per-dp <i>number_of_addresses</i></p> <p>Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2. Must be an integer in the range of 2-262144.</p>
Usage Guidelines	Use this command to configure chunk split sizes.

ipam address-pool ipv4 threshold

Configures pool thresholds.

Command Modes	Exec > Global Configuration > IPAM Configuration
Syntax Description	<p>threshold upper-threshold <i>upper_threshold</i></p> <p>upper-threshold <i>upper_threshold</i></p> <p>Specify the upper threshold value in percentage. Must be an integer in the range of 1-100.</p>
Usage Guidelines	Use this command to configure pool thresholds.

ipam address-pool ipv6 address-ranges address-range

Configures IPv6 address ranges.

Command Modes	Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Address Pool Configuration > Address Ranges Configuration
Syntax Description	<p>address-range <i>start_ipv6_address end_ipv6_address</i> [offline]</p> <p>default-gateway <i>ip_address</i></p> <p>Specify the default gateway IP address for static pool. Must be an IPv4 address.</p>

offline

Specify the IPv6 address range as offline.

end_ipv6_address

Specify the end address of the IPv6 address range.

Must be an IPv6 address.

start_ipv6_address

Specify the start address of the IPv6 address range.

Must be an IPv6 address.

Usage Guidelines

Use this command to configure IPv6 address ranges.

ipam address-pool ipv6 address-ranges split-size

Configures chunk split size.

Command Modes

Exec > Global Configuration > IPAM Configuration

Syntax Description

split-size [**per-cache** *number_of_addresses*] [**per-dp** *number_of_addresses*]

no-split

Specify not to split the address range into smaller chunks.

per-cache number_of_addresses

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp number_of_addresses

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines

Use this command to configure chunk split sizes.

ipam address-pool ipv6 address-ranges threshold

Configures pool thresholds.

Command Modes

Exec > Global Configuration > IPAM Configuration

Syntax Description

threshold upper-threshold *upper_threshold*

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines Use this command to configure pool thresholds.

ipam address-pool ipv6 prefix-ranges prefix-range

Configures IPv6 prefix ranges.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Address Pool Configuration > Prefix Ranges Configuration

Syntax Description **prefix-range** *prefix_value* **length** *prefix_length* [**offline**]

length *prefix_length*

Specify the prefix length.

Must be an integer in the range of 1-63.

offline

Specify the IPv6 prefix range as offline.

prefix-range *prefix_value*

Specify the IPv6 prefix range.

Must be an IPv6 address.

Usage Guidelines Use this command to configure IPv6 prefix ranges.

ipam address-pool ipv6 prefix-ranges split-size

Configures chunk split size.

Command Modes Exec > Global Configuration > IPAM Configuration

Syntax Description **split-size** [**per-cache** *number_of_addresses*] [**per-dp** *number_of_addresses*]

no-split

Specify not to split the address range into smaller chunks.

per-cache *number_of_addresses*

Specify the number of addresses per chunk for IPAM cache allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

per-dp number_of_addresses

Specify the number of addresses per chunk for data-plane allocation. Specify in power of 2.

Must be an integer in the range of 2-262144.

Usage Guidelines

Use this command to configure chunk split sizes.

ipam address-pool ipv6 prefix-ranges threshold

Configures pool thresholds.

Command Modes

Exec > Global Configuration > IPAM Configuration

Syntax Description

threshold upper-threshold *upper_threshold*

upper-threshold *upper_threshold*

Specify the upper threshold value in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines

Use this command to configure pool thresholds.

ipam address-pool static

Configures static pool parameters.

Command Modes

Exec > Global Configuration (config) > IPAM Configuration (config-ipam) > Address Pool Configuration

Syntax Description

static { enable | user-plane *user_plane* }

enable

Specify to set pool as static.

user-plane *user_plane*

Specify to associate user plane for this static pool.

Must be a string.

Usage Guidelines

Use this command to configure static pool parameters.

ipam source

Configures pool-datastore source selection.

Command Modes

Exec > Global Configuration (config)

Syntax Description `ipam source local`

local

Specify to use local address pool datastore.

Usage Guidelines Use this command to configure pool-datastore source selection. Enters the IPAM Configuration mode";

ipam threshold

Configures global thresholds.

Command Modes Exec > Global Configuration (config) > IPAM Configuration (config-ipam)

Syntax Description `threshold [[ipv4-addr ipv4_address_threshold] | [ipv6-addr ipv6_address_threshold] | [ipv6-prefix ipv6_prefix_threshold]]`

ipv4-addr ipv4_address_threshold

Specify the IPv4 address threshold in percentage.

Must be an integer in the range of 1-100.

ipv6-addr ipv6_address_threshold

Specify the IPv6 address threshold in percentage.

Must be an integer in the range of 1-100.

ipv6-prefix ipv6_prefix_threshold

Specify the IPv6 prefix threshold in percentage.

Must be an integer in the range of 1-100.

Usage Guidelines Use this command to configure global thresholds.

k8 bng

Configures k8 BNG parameters.

Command Modes Exec > Global Configuration

Syntax Description `bng etcd-endpoint etcd_endpoint datastore-endpoint datastore_endpoint coverage-build { false | true }`

etcd-endpoint etcd_endpoint

Specify the Etcd endpoint configuration. For example, *hostname:port*

Default Value: "etcd:2379".

datastore-endpoint *datastore_endpoint*

Specify the Datastore endpoint configuration. For example, *hostname:port*

etcd-endpoint *etcd_endpoint*

Specify the Etcd endpoint configuration. For example, *hostname:port*

Default Value: "datastore-ep-session:8882".

coverage-build { false | true }

Specify to enable or disable coverage build.

Must be one of the following:

- false
- true

Default Value: false.

datastore-endpoint *datastore_endpoint*

Specify the Datastore endpoint configuration. For example, *hostname:port*

etcd-endpoint *etcd_endpoint*

Specify the Etcd endpoint configuration. For example, *hostname:port*

Usage Guidelines

Use this command to configure k8 BNG parameters.

k8 label pod-group-config

Configures K8 node affinity label pod group configuration.

Command Modes

Exec > Global Configuration

Syntax Description

k8 label pod-group-config pod-group *pod_group* **key** *label_key* **value** *label_value*

key *label_key*

Specify the key for the label.

Must be a string.

pod-group *pod_group*

Specify the pod group for the VMs.

Must be one of the following:

- cdl-layer
- oam-layer

- **protocol-layer**
- **service-layer**

value *label_value*

Specify the value for the label.

Must be a string.

Usage Guidelines

Use this command to configure K8 node affinity label pod group configuration.

kubernetes

Configures Kubernetes parameters.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
k8s name k8s_cluster_name [ [ image-pull-secrets image_pull_secrets ] [
ingress-host-name ingress_host_name ] [ namespace k8s_namespace ] [ nf-name nf_name
] [ registry image_registry ] [ single-node { false | true } ] [
use-volume-claims { false | true } ] ]
```

image-pull-secrets *image_pull_secrets*

Specify the image pull secrets stored within K8s.

Must be a string.

ingress-host-name *ingress_host_name*

Specify the generic ingress host name.

Must be a string.

name *k8s_cluster_name*

Specify the K8s cluster name.

Must be a string.

namespace *k8s_namespace*

Specify the K8s namespace for the network function.

Must be a string.

nf-name *nf_name*

Specify the NF deployed in this k8s namespace.

Must be a string.

registry image_registry

This keyword is deprecated.

Must be a string.

single-node { false | true }

Specify to enable or disable single node deployment.

Must be one of the following:

- **false**
- **true**

Default Value: false.

use-volume-claims { false | true }

Specify to enable or disable using volume claims when deploying.

Must be one of the following:

- **false**
- **true**

Default Value: false.

Usage Guidelines

Use this command to configure Kubernetes parameters.

kubernetes nodes

Configures list of k8s nodes.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
k8s nodes k8s_node_name [ [ node-type node_type ] [ worker-type worker_type ] ]
```

node-type node_type

Specify the K8s node type.

Must be a string.

worker-type worker_type

Specify the k8s worker type.

Must be a string.

k8s_node_name

Specify the K8s node name.

Must be a string.

Usage Guidelines Use this command to configure the list of k8s nodes.

logging level

Configures the logging level.

Command Modes Exec > Global Configuration

Syntax Description `level log_level`

application *application_log_level*

Specify the application logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

monitor-subscriber *monitor_subscriber_log_level*

Specify the monitor subscriber logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

tracing *tracing_log_level*

Specify the tracing logging level.

Must be one of the following:

- **debug**
- **error**

- info
- off
- trace
- warn

transaction *transaction_log_level*

Specify the transaction logging level.

Must be one of the following:

- debug
- error
- info
- off
- trace
- warn

Usage Guidelines Use this command to configure the logging level.

logging logger

Configures the log name.

Command Modes Exec > Global Configuration

Syntax Description **logger** *log_name*

log_name

Specify the log name in "module.component.interface" format.

Must be a string.

Usage Guidelines Use this command to configure the log name.

logging logger level

Configures the logging level.

Command Modes Exec > Global Configuration

Syntax Description **logger level** *log_type_options*

application *application_log_level*

Specify the application logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

monitor-subscriber *monitor_subscriber_log_level*

Specify the monitor subscriber logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

tracing *tracing_log_level*

Specify the tracing logging level.

Must be one of the following:

- **debug**
- **error**
- **info**
- **off**
- **trace**
- **warn**

transaction *transaction_log_level*

Specify the transaction logging level.

Must be one of the following:

- **debug**

- **error**
- **info**
- **off**
- **trace**
- **warn**

Usage Guidelines Use this command to configure the logging level.

logging transaction

Configures the transaction logging parameters.

Command Modes Exec > Global Configuration

Syntax Description **transaction** *transaction_log_parameters*

duplicate

Specify to enable duplicate in transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

message

Specify to enable messages in transaction logging.

Must be one of the following:

- **disable**
- **enable**

Default Value: disable.

Usage Guidelines Use this command to configure the transaction logging parameters.

profile aaa

Configures AAA profiles.

Command Modes Exec > Global Configuration (config)

Syntax Description `profile aaa aaa_profile_name`

aaa_profile_name

Specify the AAA profile name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\"')]*).

Usage Guidelines Use this command to configure AAA profiles. Enters the AAA Profile Configuration mode.

profile aaa accounting

Configures accounting configuration parameters.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-*aaa_profile_name*)

Syntax Description `accounting method-order method_list_order`

method-order method_list_order

Specify the method list order.

Must be one of the following:

- **radius**

Usage Guidelines Use this command to configure accounting parameters.

You can configure a maximum of three elements with this command.

profile aaa authentication

Configures authentication parameters.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-*aaa_profile_name*)

Syntax Description `authentication [method-order method_list_order]`

method-order method_list_order

Specify the method list order.

Must be one of the following:

- **radius**

Usage Guidelines Use this command to configure authentication parameters.

You can configure a maximum of three elements with this command.

profile aaa authorization

Configures authorization parameters.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name)

Syntax Description **authorization** [**password** *default_password*]

password *default_password*

Specify the default password.

Must be a string.

Usage Guidelines Use this command to configure authorization parameters. Enters the Authorization Configuration mode.

profile aaa authorization type subscriber

Configures authorization type subscriber.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name) > Authorization Configuration (config-authorization)

Syntax Description **type subscriber method-order** *method_list_order*

method-order *method_list_order*

Specify the method list order.

Must be one of the following:

- radius

Usage Guidelines Use this command to configure authorization type subscriber.

You can configure a maximum of three elements with this command.

profile aaa authorization username

Configures the default user name.

Command Modes Exec > Global Configuration (config) > AAA Profile Configuration (config-aaa-aaa_profile_name) > Authorization Configuration (config-authorization)

Syntax Description **username** { **format** *attribute_format* | **identifier** *identifier_type* | **value** *user_name* }

format *attribute_format*

Specify the attribute format.

identifier *identifier_type*

Specify the identifier type.

value *user_name*

Specify the user name.

Must be a string.

Usage Guidelines Use this command to configure the default user name.

profile attribute-format

Configures AAA attribute templates.

Command Modes Exec > Global Configuration (config)

Syntax Description **profile attribute-format** *profile_name* [**format-order** *attributes_list*]

format-order *attributes_list*

Specify the ordered list of attributes.

profile_name

Specify the profile name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

Must be a string.

Usage Guidelines Use this command to configure AAA attribute templates. Enters the Attribute Format Profile Configuration mode.

You can configure a maximum of 32 elements with this command.

profile coa

Configures RADIUS Dynamic-author/COA parameters.

Command Modes Exec > Global Configuration

Syntax Description **profile coa server-key** *server_shared_secret_key*

server-key *server_shared_secret_key*

Specify the COA server shared secret key.

Must be an aes-cfb-128-encrypted string.

Usage Guidelines Use this command to configure RADIUS Dynamic-author/COA parameters.

profile coa client

Configures RADIUS COA client parameters.

Command Modes Exec > Global Configuration

Syntax Description **client ip** *client_ip_address* **server-key** *client_shared_secret_key*

ip *client_ip_address*

Specify the client IP address.

Must be an IP address.

server-key *client_shared_secret_key*

Specify the client shared secret key.

Must be an aes-cfb-128-encrypted string.

Usage Guidelines Use this command to configure RADIUS COA client parameters.

profile dhcp

Configures DHCP profiles.

Command Modes Exec > Global Configuration (config)

Syntax Description **dhcp** *dhcp_profile_name*

dhcp_profile_name

Specify the DHCP profile name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\"']*).

Usage Guidelines Use this command to configure DHCP profiles. Enters the DHCP Profile Configuration mode.

profile dhcp ipv4

Configures DHCP IPv4 parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-*dhcp_profile_name*)

Syntax Description **ipv4** [**mode** *dhcp_mode*]

mode *dhcp_mode*

Specify the DHCP server or proxy mode.

Default Value: server.

Usage Guidelines Use this command to configure DHCP IPv4 parameters. Enters the DHCP IPv4 Configuration mode.

profile dhcp ipv4 class

Configures DHCP IPv4 class configuration parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-*dhcp_profile_name*) > DHCP IPv4 Configuration (config-ipv4)

Syntax Description **class** *dhcp_class_name*

dhcp_class_name

Specify the DHCP class name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\"']*).

Usage Guidelines Use this command to configure DHCP IPv4 class configuration parameters. Enters the DHCP Class Configuration mode.

profile dhcp ipv4 class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-*dhcp_profile_name*) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-*dhcp_class_name*)

Syntax Description **matches** [**match-type** { **all** | **any** }]

match-type *match_type*

Specify the match type.

Usage Guidelines Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile dhcp ipv4 class matches match

Configures match key and value.

Command Modes Exec > Global Configuration (config) > DHCP Configuration (config-dhcp-*dhcp_profile_name*) > DHCP Class Configuration (config-class-*dhcp_class_name*) > Matches Configuration (config-matches)

Syntax Description **match** *match_key* { **ascii** *ascii_string* | **hex** *hex_string* }

match_key

Specify the match key.

ascii ascii_string

Specify the ASCII strings.

Must be a string.

hex hex_string

Specify the hexadecimal strings.

Must be a string in the pattern `([0-9a-fA-F]{2}([0-9a-fA-F]{2})*)?`.

match_key

Specify the match key.

You can configure a maximum of "8" elements with this command.

Usage Guidelines

Use this command to configure match key and value.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv4 class server

Configures DHCP server mode.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name)

Syntax Description

server [**boot-filename** *boot_file_name* | **dns-servers** *ip_address* | **domain-name** *domain_name* | **netbios-name-server** *ip_address* | **next-server** *ip_address* | **ntp-servers** *ntp_servers* | **pool-name** *pool_name*]

boot-filename boot_file_name

Specify the boot file name.

Must be a string in the pattern `([a-zA-Z1-9_][^\s,\\t,\\;])*`.

dns-servers ip_address

Specify the DNS server IP addresses.

Must be an IPv4 address.

domain-name domain_name

Specify the domain name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,']*)).

netbios-name-server *ip_address*

Specify the NetBIOS name server IP addresses.

Must be an IPv4 address.

next-server *ip_address*

Specify the TFTP server IP address to be used by the client.

Must be an IPv4 address.

ntp-servers *ntp_servers*

Specify the NTP servers.

Must be an IPv4 address.

pool-name *pool_name*

Specify the pool name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,']*)).

Usage Guidelines

Use this command to configure the DHCP server mode. Enters the DHCP Server Configuration mode.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv4 class server lease

Configures DHCP Server Lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description

lease { [**days** *days*] [**hours** *hours*] [**minutes** *minutes*] }

days *days*

Specify the number of days.

Must be an integer in the range of 0-365.

hours *hours*

Specify the hours.

Must be an integer in the range of 0-23.

minutes *minutes*

Specify the minutes.

Must be an integer in the range of 0-59.

Usage Guidelines

Use this command to configure the DHCP Server Lease parameters.

profile dhcp ipv4 class server netbios-node-type

Configures NetBIOS node type.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description

netbios-node-type { **broadcast-node** | **hexadecimal** *hex_number* | **hybrid-node** | **mixed-node** | **peer-to-peer-node** }

broadcast-node

Specify broadcast node.

hexadecimal *hex_number*

Specify the hexadecimal number.

Must be a string in the pattern ([0-9a-fA-F]{2}(:[0-9a-fA-F]{2})*)?.

hybrid-node

Specify hybrid node.

mixed-node

Specify mixed node.

peer-to-peer-node

Specify peer-to-peer node.

Usage Guidelines

Use this command to configure the NetBIOS node type.

profile dhcp ipv4 class server option-codes

Configures the OptionCode table.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server)
Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)
Syntax Description	option-codes
Usage Guidelines	Use this command to configure the OptionCode table. Enters the Option Codes Configuration mode.

profile dhcp ipv4 class server option-codes option-code

Configures a DHCP option code.

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)
----------------------	---

Command Modes	Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)
----------------------	---

Syntax Description	option-code <i>dhcp_option_code</i> [ascii-string <i>ascii_string</i> force-insert { false true } hex-string <i>hex_string</i> ip-address <i>ip_address</i>]
---------------------------	---

ascii-string *ascii_string*

Specify the ASCII string.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,']*)).

force-insert { **false** | **true** }

Specify whether to force insert this option.

Must be one of the following:

- **false**
- **true**

hex-string *hex_string*

Specify the hexadecimal string.

Must be a string in the pattern ([0-9a-fA-F]{2}([0-9a-fA-F]{2})*)?.

ip-address *ip_address*

Specify the server's IP addresses.

Must be an IPv4 address.

option-code *dhcp_option_code*

Specify the DHCP option code.

Must be an integer in the range of 0-255.

Usage Guidelines

Use this command to configure a DHCP option code. Enters the Option Code Configuration mode.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv4 server

Configures DHCP server mode.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name)

Syntax Description

```
server [ boot-filename boot_file_name | dns-servers ip_address | domain-name domain_name | netbios-name-server ip_address | next-server ip_address | ntp-servers ntp_servers | pool-name pool_name ]
```

boot-filename *boot_file_name*

Specify the boot file name.

Must be a string in the pattern ([a-zA-Z1-9_]^[^\s,\\t,\\',']*).

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be an IPv4 address.

domain-name *domain_name*

Specify the domain name.

Must be a string in the pattern ([a-zA-Z1-9_]^[^\s,\\t,\\',']*).

netbios-name-server *ip_address*

Specify the NetBIOS name server IP addresses.

Must be an IPv4 address.

next-server *ip_address*

Specify the TFTP server IP address to be used by the client.

Must be an IPv4 address.

ntp-servers *ntp_servers*

Specify the NTP servers.

Must be an IPv4 address.

pool-name *pool_name*

Specify the pool name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\"']*).

Usage Guidelines

Use this command to configure the DHCP server mode. Enters the DHCP Server Configuration mode.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv4 server lease

Configures DHCP Server Lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description

lease { [**days** *days*] [**hours** *hours*] [**minutes** *minutes*] }

days *days*

Specify the number of days.

Must be an integer in the range of 0-365.

hours *hours*

Specify the hours.

Must be an integer in the range of 0-23.

minutes *minutes*

Specify the minutes.

Must be an integer in the range of 0-59.

Usage Guidelines

Use this command to configure the DHCP Server Lease parameters.

profile dhcp ipv4 server netbios-node-type

Configures NetBIOS node type.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description **netbios-node-type** { **broadcast-node** | **hexadecimal** *hex_number* | **hybrid-node** | **mixed-node** | **peer-to-peer-node** }

broadcast-node

Specify broadcast node.

hexadecimal *hex_number*

Specify the hexadecimal number.

Must be a string in the pattern ([0-9a-fA-F]{2}(:[0-9a-fA-F]{2})*)?.

hybrid-node

Specify hybrid node.

mixed-node

Specify mixed node.

peer-to-peer-node

Specify peer-to-peer node.

Usage Guidelines Use this command to configure the NetBIOS node type.

profile dhcp ipv4 server option-codes

Configures the OptionCode table.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description **option-codes**

Usage Guidelines Use this command to configure the OptionCode table. Enters the Option Codes Configuration mode.

profile dhcp ipv4 server option-codes option-code

Configures a DHCP option code.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv4 Configuration (config-ipv4) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server) > Option Codes Configuration (config-option-codes)

Syntax Description

option-code *dhcp_option_code* [**ascii-string** *ascii_string* | **force-insert** { **false** | **true** } | **hex-string** *hex_string* | **ip-address** *ip_address*]

ascii-string *ascii_string*

Specify the ASCII string.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\'"]*)

force-insert { **false** | **true** }

Specify whether to force insert this option.

Must be one of the following:

- **false**
- **true**

hex-string *hex_string*

Specify the hexadecimal string.

Must be a string in the pattern ([0-9a-fA-F]{2}([0-9a-fA-F]{2})*)?

ip-address *ip_address*

Specify the server's IP addresses.

Must be an IPv4 address.

option-code *dhcp_option_code*

Specify the DHCP option code.

Must be an integer in the range of 0-255.

Usage Guidelines

Use this command to configure a DHCP option code. Enters the Option Code Configuration mode.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv6

Configures DHCP IPv6 parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name)

Syntax Description `ipv6 [mode dhcp_mode]`

mode dhcp_mode

Specify the DHCP mode server or proxy.

Default Value: server.

Usage Guidelines Use this command to configure DHCP IPv6 parameters. Enters the DHCP IPv6 Configuration mode.

profile dhcp ipv6 class

Configures DHCP IPv6 class configuration parameters.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6)

Syntax Description `class dhcp_class_name`

dhcp_class_name

Specify the DHCP class name.

Must be a string in the pattern (`[a-zA-Z1-9][^\s,\t,']*`).

Usage Guidelines Use this command to configure DHCP IPv6 class configuration parameters.

profile dhcp ipv6 class server

Configures DHCP server mode.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6) > DHCP Class Configuration (config-class-dhcp_class_name)

Syntax Description `server { aftr-name aftr_name | dns-servers ip_address | domain-name domain_name | iana-pool-name iana_pool_name | iapd-pool-name iapd_pool_name | preference server_preference | rapid-commit }`

aftr-name *aftr_name*

Specify the Address Family Transition Router (AFTR) name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be an IPv6 address.

domain-name *domain_name*

Specify the domain name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

iana-pool-name *iana_pool_name*

Specify the IANA pool name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

iapd-pool-name *iapd_pool_name*

Specify the IAPD pool name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

preference *server_preference*

Specify the DHCP server preference.

Must be an integer in the range of 1-255.

rapid-commit

Specify to allow rapid commit.

Usage Guidelines

Use this command to configure the DHCP server mode.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv6 class server lease

Configures the lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6) > DHCP Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description `lease { [days days] [hours hours] [minutes minutes] }`

days *days*

Specify the number of days.

Must be an integer in the range of 0-365.

hours *hours*

Specify the hours.

Must be an integer in the range of 0-23.

minutes *minutes*

Specify the minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure lease parameters.

profile dhcp ipv6 server

Configures DHCP server mode.

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-*dhcp_profile_name*) > DHCP IPv6 Configuration (config-ipv6)

Command Modes Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-*dhcp_profile_name*) > DHCP IPv6 Configuration (config-ipv6) > DHCP Class Configuration (config-class-*dhcp_class_name*)

Syntax Description `server { aftr-name aftr_name | dns-servers ip_address | domain-name domain_name | iana-pool-name iana_pool_name | iapd-pool-name iapd_pool_name | preference server_preference | rapid-commit }`

aftr-name *aftr_name*

Specify the Address Family Transition Router (AFTR) name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,'])*).

dns-servers *ip_address*

Specify the DNS server IP addresses.

Must be an IPv6 address.

domain-name *domain_name*

Specify the domain name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,'])*).

iana-pool-name *iana_pool_name*

Specify the IANA pool name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

iapd-pool-name *iapd_pool_name*

Specify the IAPD pool name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,'])*).

preference *server_preference*

Specify the DHCP server preference.

Must be an integer in the range of 1-255.

rapid-commit

Specify to allow rapid commit.

Usage Guidelines

Use this command to configure the DHCP server mode.

You can configure a maximum of "8" elements with this command.

profile dhcp ipv6 server lease

Configures the lease parameters.

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6) > DHCP Server Configuration Mode (config-server)

Command Modes

Exec > Global Configuration (config) > DHCP Profile Configuration (config-dhcp-dhcp_profile_name) > DHCP IPv6 Configuration (config-ipv6) > DHCP Class Configuration (config-class-dhcp_class_name) > DHCP Server Configuration Mode (config-server)

Syntax Description

lease { [**days** *days*] [**hours** *hours*] [**minutes** *minutes*] }

days *days*

Specify the number of days.

Must be an integer in the range of 0-365.

hours *hours*

Specify the hours.

Must be an integer in the range of 0-23.

minutes *minutes*

Specify the minutes.

Must be an integer in the range of 1-59.

Usage Guidelines Use this command to configure lease parameters.

profile feature-template

Configures feature templates.

Command Modes Exec > Global Configuration (config)

Syntax Description **feature-template** *feature_template_name* [[**vrf-name** *vrf_name*] [**httpr-policy** *httpr_policy_name*]]

httpr-policy *httpr_policy_name*

Specify the PBR HTTPR policy name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,"']*).

vrf-name *vrf_name*

Specify the VRF name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,"']*).

feature_template_name

Specify the feature template name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,"']*).

Usage Guidelines Use this command to configure feature templates. Enters the Feature Template Configuration mode.

profile feature-template ipv4

Configures IPv4 features.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*)

Syntax Description **ipv4** [[**mtu** *maximum_transmission_unit*] [**ingress-acl** *ingress_ipv4_acl_name*] [**egress-acl** *egress_ipv4_acl_name*] [**disable-unreachables**]]

disable-unreachables

Specify to disable sending ICMP Unreachable messages.

egress-acl *egress_ipv4_acl_name*

Specify the egress IPV4 ACL name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,"']*).

ingress-acl *ingress_ipv4_acl_name*

Specify the ingress IPV4 ACL name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\'"]*)).

mtu *maximum_transmission_unit*

Specify the Maximum Transmission Unit in bytes.

Must be an integer in the range of 68-65535.

Usage Guidelines

Use this command to configure IPv4 features. Enters the IPv4 Configuration mode.

profile feature-template ipv4 verify-unicast-source

Enables per-packet validation for unicast.

Command Modes

Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > IPv4 Configuration (config-ipv4)

Syntax Description

verify-unicast-source reachable-via-rx

reachable-via-rx

Specify the source is reachable via interface on which packet was received.

Usage Guidelines

Use this command to enable per-packet validation for unicast.

profile feature-template ipv6

Configures IPv6 features.

Command Modes

Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*)

Syntax Description

ipv6 [[mtu *maximum_transmission_unit*] [ingress-acl *ingress_ipv6_acl_name*] [egress-acl *egress_ipv6_acl_name*]]

disable-unreachables

Specify to disable sending ICMP Unreachable messages.

egress-acl *egress_ipv6_acl_name*

Specify the egress IPV6 ACL name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\'"]*)).

ingress-acl *ingress_ipv6_acl_name*

Specify the ingress IPV6 ACL name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\";']*)).

mtu *maximum_transmission_unit*

Specify the Maximum Transmission Unit in bytes.

Must be an integer in the range of 1280-65535.

Usage Guidelines Use this command to configure IPv6 features. Enters the IPv6 Configuration mode.

profile feature-template ipv6 verify-unicast-source

Configures per packet validation for unicast.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > IPv6 Configuration (config-ipv6)

Syntax Description **verify-unicast-source reachable-via-rx**

reachable-via-rx

Specify source is reachable via interface on which packet was received.

Usage Guidelines Use this command to configure per packet validation for unicast.

profile feature-template ppp

Configures PPP feature.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*)

Syntax Description **ppp [[authentication *authentication_method*] [max-bad-auth *max_auth_failures*] [max-configure *max_configure*] [max-failure *max_conf_naks*]]**

authentication *authentication_method*

Specify the authentication method.

Must be one of the following:

- chap
- pap

max-bad-auth *max_auth_failures*

Specify the maximum authentication failures to allow.

Must be an integer in the range of 0-10.

max-configure *max_configure*

Specify the maximum conf-reqs to send without response.

Must be an integer in the range of 1-10.

max-failure *max_conf_naks*

Specify the maximum conf-naks to receive.

Must be an integer in the range of 1-5.

Usage Guidelines

Use this command to configure the PPP feature. Enters the PPP Configuration mode.

You can configure a maximum of "2" elements with this command.

profile feature-template ppp chap

Configures Challenge Handshake Authentication Protocol (CHAP) parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description

chap hostname *chap_host_name* [**password** *chap_password*]

hostname *chap_host_name*

Specify the CHAP host name.

hostname *chap_host_name*

Specify the CHAP host name.

password *chap_password*

Specify the CHAP password.

Must be an aes-cfb-128-encrypted string.

Usage Guidelines

Use this command to configure CHAP parameters.

profile feature-template ppp ipcp

Configures PPP IPCP negotiation parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description

ipcp peer-address-pool *peer_address_pool_name*

peer-address-pool *peer_address_pool_name*

Specify the peer-address pool name.

Usage Guidelines

Use this command to configure PPP IPCP negotiation parameters.

profile feature-template ppp ipcp dns

Configures DNS address to be used for peer.

Command Modes

Exec > Global Configuration (config) > Feature Template Profile Configuration
(config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description

ipcp dns primary-address *primary_address* **secondary-address** *secondary_address*

primary-address *primary_address*

Specify the primary address. The first address is considered as Primary and second address as Secondary.
Must be an IPv4 address.

secondary-address *secondary_address*

Specify the secondary address.

Must be an IPv4 address.

Usage Guidelines

Use this command to configure DNS address to be used for peer.

profile feature-template ppp ipcp renegotiation

Configures renegotiation parameters.

Command Modes

Exec > Global Configuration (config) > Feature Template Profile Configuration
(config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description

ipcp renegotiation ignore

ignore

Specify to ignore attempts by the peer to renegotiate LCP.

Usage Guidelines

Use this command to configure renegotiation parameters.

profile feature-template ppp ipcp wins

Configures WINS address to be used for peer.

Command Modes	Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template- <i>feature_template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>ipcp wins primary-address <i>primary_ip_address</i> secondary-address <i>secondary_ip_address</i></p> <p>primary-address <i>primary_ip_address</i> Specify the primary address. Must be an IPv4 address.</p> <p>secondary-address <i>secondary_ip_address</i> Specify the secondary address. Must be an IPv4 address.</p>
Usage Guidelines	Use this command to configure WINS address to be used for peer.

profile feature-template ppp ipv6cp renegotiation

Configures IPv6CP renegotiation parameters.

Command Modes	Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template- <i>feature_template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>ipv6cp renegotiation ignore</p> <p>ignore Specify to ignore attempts by the peer to renegotiate LCP.</p>
Usage Guidelines	Use this command to configure IPv6CP renegotiation parameters.

profile feature-template ppp keepalive

Configures PPP Keepalive parameters.

Command Modes	Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template- <i>feature_template_name</i>) > PPP Configuration (config-ppp)
Syntax Description	<p>keepalive { disable interval <i>keepalive_interval</i> retry <i>keepalive_retries</i> }</p> <p>disable Specify to disable PPP keepalive.</p> <p>interval <i>keepalive_interval</i> Specify the keepalive interval in minutes.</p>

Must be an integer in the range of 10-120.

retry *keepalive_retries*

Specify the number of keepalive retries.

Must be an integer in the range of 1-255.

Usage Guidelines Use this command to configure PPP Keepalive parameters.

profile feature-template ppp lcp delay

Configures the time to delay before starting active LCP negotiations.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description `lcp delay seconds delay_value milliseconds delay_value`

milliseconds *delay_value*

Specify the delay value in milliseconds.

Must be an integer in the range of 0-70000000.

seconds *delay_value*

Specify the delay value in seconds.

Must be an integer in the range of 0-255.

Usage Guidelines Use this command to configure the time to delay before starting active LCP negotiations.

profile feature-template ppp lcp renegotiation

Configures LCP renegotiation feature.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description `lcp renegotiation ignore`

ignore

Specify to ignore attempts by the peer to renegotiate LCP.

Usage Guidelines Use this command to configure LCP renegotiation feature.

profile feature-template ppp pap

Configures PAP parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description **pap accept-null-password**

accept-null-password

Specify to accept null-password option.

Usage Guidelines Use this command to configure PAP parameters.

profile feature-template ppp timeout

Configures PPP timeout parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description **timeout { [authentication total_auth_complete_time] [retry max_response_time] }**

Command Modes Exec > Global Configuration (config) > Endpoint N4 Protocol Configuration (config-endpoint-n4-protocol)

Syntax Description **retransmission timeout total_auth_complete_time [retry max_response_time]**

authentication total_auth_complete_time

Specify the total time to allow for authentication to complete.

Must be an integer in the range of 3-30.

retry max_response_time

Specify the maximum time to wait for a response to a Conf-Req in seconds.

Must be an integer in the range of 1-10.

Usage Guidelines Use this command to configure PPP timeout parameters.

profile feature-template ppp timeout absolute

Configures the absolute timeout period for a PPP session.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*) > PPP Configuration (config-ppp)

Syntax Description **timeout absolute minutes** *timeout_minutes* **seconds** *timeout_seconds*

minutes *timeout_minutes*

Specify the timeout period in minutes.

Must be an integer in the range of 0-70000000.

Usage Guidelines Use this command to configure the absolute timeout period for a PPP session.

profile feature-template qos

Configures QoS input policy parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*)

Syntax Description **qos** [**in-policy** *in_policy_name* | **out-policy** *out_policy_name* | **merge-level** *merge_level*]

in-policy *in_policy_name*

Specify the QoS input policy name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\";'])*).

merge-level *merge_level*

Specify the merge level. 0 = merge disabled, 0 = merge enabled + level.

Must be an integer.

out-policy *out_policy_name*

Specify the QoS output policy name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\";'])*).

Usage Guidelines Use this command to configure QoS input policy parameters.

profile feature-template service-accounting

Configures service accounting parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*)

Syntax Description `service-accounting [[enable] [aaa-profile aaa_profile_name] [periodic-interval interim_interval]]`

aaa-profile *aaa_profile_name*

Specify the AAA profile to use for service accounting.

enable

Specify to enable service accounting.

periodic-interval *interim_interval*

Specify the interim interval in seconds.

Must be an integer in the range of 60-4320000.

Usage Guidelines Use this command to configure service accounting parameters.

profile feature-template session-accounting

Configures session accounting parameters.

Command Modes Exec > Global Configuration (config) > Feature Template Profile Configuration (config-feature-template-*feature_template_name*)

Syntax Description `session-accounting enable { aaa-profile aaa_profile_name | periodic-interval interim_interval | dual-stack-delay dual_stack_delay_wait }`

aaa-profile *aaa_profile_name*

Specify the AAA profile to use for session accounting.

dual-stack-delay *dual_stack_delay_wait*

Specify the dual stack set delay wait in seconds.

Must be an integer in the range of 1-30.

enable

Specify to enable session accounting.

periodic-interval *interim_interval*

Specify the interim interval in seconds.

Must be an integer in the range of 60-4320000.

Usage Guidelines Use this command to configure session accounting parameters.

profile pppoe

Configures PPPOE Subscriber profiles.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
profile pppoe pppoe_profile_name [ [ ac-cookie ac_cookie ] [ ac-name ac_name ] [ ctrl-pkt-priority priority ] [ service-name pppoe_service_names ] [ service-selection-disable { false | true } ] [ timeout-completion session_completion_timeout ] ]
```

ctrl-pkt-priority *priority*

Specify the CoS bits to use in PADx packets.

Must be an integer in the range of 0-7.

Default Value: 0.

mtu *pppoe_mtu*

Specify the PPPOE MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

service-name *pppoe_service_names*

Specify the supported PPPoE service names. You can simultaneously configure multiple service names.

service-selection-disable { **false** | **true** }

Specify to disable or enable the advertising of extra service names in PADO packets.

Must be one of the following:

- **false**
- **true**

Default Value: false.

pppoe_profile_name

Specify the PPPOE profile name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\";'])*).

ac-name *ac_name*

Specify the the AC-Name to use in PADO packets.

ctrl-pkt-priority *priority*

Specify the CoS bits to use in PADx packets.

Must be an integer in the range of 0-7.

Default Value: 0.

mtu *pppoe_mtu*

Specify the PPPOE MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

service-name *pppoe_service_names*

Specify the supported PPPoE service names. You can simultaneously configure multiple service names.

service-selection-disable { *false* | *true* }

Specify to disable or enable the advertising of extra service names in PADO packets.

Must be one of the following:

- **false**
- **true**

Default Value: false.

pppoe_profile_name

Specify the PPPOE profile name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,']*)

ac-cookie *ac_cookie*

Specify the AC-Cookie to use in PADO packets.

ac-name *ac_name*

Specify the the AC-Name to use in PADO packets.

ctrl-pkt-priority *priority*

Specify the CoS bits to use in PADx packets.

Must be an integer in the range of 0-7.

Default Value: 0.

mtu *pppoe_mtu*

Specify the PPPOE MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

service-name *pppoe_service_names*

Specify the supported PPPoE service names. You can simultaneously configure multiple service names.

service-selection-disable { false | true }

Specify to disable or enable the advertising of extra service names in PADO packets.

Must be one of the following:

- **false**
- **true**

Default Value: false.

pppoe_profile_name

Specify the PPPOE profile name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\\t,\\']*)

ac-cookie *ac_cookie*

Specify the AC-Cookie to use in PADO packets.

ac-name *ac_name*

Specify the the AC-Name to use in PADO packets.

ctrl-pkt-priority *priority*

Specify the CoS bits to use in PADx packets.

Must be an integer in the range of 0-7.

Default Value: 0.

mtu *pppoe_mtu*

Specify the PPPOE MTU for LCP negotiation.

Must be an integer in the range of 500-2000.

Default Value: 1492.

service-name *pppoe_service_names*

Specify the supported PPPoE service names. You can simultaneously configure multiple service names.

service-selection-disable { false | true }

Specify to disable or enable the advertising of extra service names in PADO packets.

Must be one of the following:

- **false**
- **true**

Default Value: false.

timeout-completion *session_completion_timeout*

Specify the maximum wait time for session to be completed.

Must be an integer in the range of 3-600.

Default Value: 180.

pppoe_profile_name

Specify the PPPOE profile name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,']*)

Usage Guidelines

Use this command to configure PPPOE Subscriber profiles. Enters the PPPOE Profile Configuration mode.

profile pppoe max-payload

Configures a range for the ppp-max payload tag value.

Command Modes

Exec > Global Configuration (config) > PPPOE Profile Configuration (config-pppoe-*pppoe_profile_name*)

Syntax Description

```
max-payload { deny | minimum minimum_payload_value | maximum maximum_payload_value
}
```

deny

Specify to deny the PPP-max payload value.

maximum *maximum_payload_value*

Specify the maximum payload value.

Must be an integer in the range of 1-40000.

Default Value: "1500".

minimum *minimum_payload_value*

Specify the minimum value for the payload.

Must be an integer in the range of 1-40000.

Default Value: "1492".

Usage Guidelines

Use this command to configure a range for the ppp-max payload tag value.

profile pppoe session-limit circuit-id

Configures the maximum number of sessions allowed per Circuit-ID.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration (config-pppoe-*pppoe_profile_name*)

Syntax Description **session-limit circuit-id** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value *attribute_value*

Specify the attribute value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per Circuit-ID.

profile pppoe session-limit mac

Configures the maximum number of sessions allowed per peer MAC address.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration (config-pppoe-*pppoe_profile_name*)

Syntax Description **session-limit mac** *value* [**threshold** *threshold_count*]

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value *attribute_value*

Specify the attribute value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per peer MAC address.

profile pppoe session-limit max

Configures the maximum number of sessions allowed under the PPPoE profile.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration (config-pppoe-*pppoe_profile_name*)

Syntax Description `session-limit max value [threshold threshold_count]`

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value *attribute_value*

Specify the attribute value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed under the PPPoE profile.

profile pppoe session-limit outer-vlan

Configures the maximum number of sessions allowed per outer-vlan, per access interface.

Command Modes Exec > Global Configuration (config) > PPPOE Profile Configuration (config-pppoe-*pppoe_profile_name*)

Syntax Description `session-limit outer-vlan value [threshold threshold_count]`

threshold *threshold_count*

Specify the threshold count.

Must be an integer in the range of 1-65535.

value *attribute_value*

Specify the attribute value.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure the maximum number of sessions allowed per outer-vlan, per access interface.

profile radius

Configures RADIUS client profile parameters.

Command Modes Exec > Global Configuration (config)

Syntax Description `profile radius [algorithm radius_server_selection_algorithm | deadtime dead_time | max-retry max_retry | timeout retransmit_timeout_duration]`

algorithm *radius_server_selection_algorithm*

Specify the algorithm for selecting RADIUS server.

Must be one of the following:

- **first-server**: Highest priority first.
- **round-robin**: Round-robin.

deadtime *dead_time*

Specify the time to elapse, in minutes, between RADIUS server marked unreachable and when connection can be re-attempted.

Must be an integer in the range of 0-65535.

max-retry *max_retry*

Specify the maximum number of times the system must attempt retry with the RADIUS server.

Must be an integer in the range of 0-65535.

timeout *retransmit_timeout_duration*

Specify the time duration to wait for response from the RADIUS server before retransmitting.

Must be an integer in the range of 1-65535.

Usage Guidelines

Use this command to configure RADIUS client parameters. Enters the RADIUS Client Profile Configuration mode.

profile radius accounting

Configures RADIUS accounting parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Syntax Description

```

profile radius accounting
  algorithm { first-server | round-robin }
  attribute { nas-identifier value | nas-ip { ipv4_address | user-plane-ip
} |
  nas-port { nas_port } | { format-e format_e
      { nas-port-type nas_port_type } }
  deadtime value
  detect-dead-server response-timeout value
  max-retry value
  timeout value
  commit

```

algorithm { first-server | round-robin }

Specify the algorithm for selecting RADIUS server.

Must be one of the following:

- **first-server**: Highest priority first.
- **round-robin**: Round-robin.

attribute { nas-identifier *value* | nas-ip { *ipv4_address* | user-plane-ip } | nas-port { format-e *format_e_value* | nas-port-type *nas_port_type* } }

Configures the RADIUS identification parameters.

- **nas-identifier *value***: Specifies the attribute name by which the system will be identified in Accounting-Request messages. *value* must be an alphanumeric string.
- **nas-ip *ipv4_address***: Specifies the NAS IPv4 address. *ipv4_address* must be an IPv4 address in dotted decimal notation.
- **nas-ip user-plane-ip**: Enables the `user-plane-ip-address` AVPair to use the configured User-Plane IP address in Accounting-Request messages.
- **nas-port { *nas_port* } | { format-e *format_e* { nas-port-type *nas_port_type* } }**: Specifies the nas-port attributes.
 - *nas_port* configures the NAS port value. The NAS port value ranges from 1 to 4294967295.



Note If none of the NAS port configurations are present, the existing default nas-port logic is applied. That is, setting a fixed-number per radius-pod.

- **format-e *format_e_value***: Specifies the custom attribute formation support for nas-port. The nas-port is a 32 bit integer format. The configuration takes a 32 length of characters, each presenting a particular attribute mapping. The *format_e_value* pattern is: 01FSAPRiLUVQ]*):
 - 0 – Set bit to 0
 - 1 – Set bit to 1
 - F - PHY_SHELF
 - S – PHY_SLOT
 - A – PHY_ADAPTER
 - P - PHY_PORT
 - R - PHY_CHASSIS
 - i - PHY_SUBSLOT
 - L - PHY_CHANNEL
 - V - OUTER_VLAN_ID
 - Q - INNER_VLAN_ID
 - U - PPPOE_SESSION_ID
- **nas-port-type *nas_port_type***: Specifies the NAS port type. The supported values range from 0 to 44.

**Note**

- The nas-port-type configuration is not in scope of the Control Plane. It is derived from the interface-type.
- The supported NAS port types are 36 , 37, 43, and 44.
- The NAS port type value takes precedence over the common NAS port format-e.

deadtime *dead_time*

Sets the time to elapse, in minutes, between RADIUS server marked unreachable and when connection can be re-attempted.

Must be an integer in the range of 0-65535. Default: 10 minutes.

detect-dead-server response-timeout *value*

Sets the timeout value that marks a server as "dead" when a packet is not received for the specified number of seconds.

value must be an integer from 1 through 65535. Default: 10 seconds.

max-retry *max_retry*

Sets the maximum number of times the system must attempt retry with the RADIUS server.

Must be an integer in the range of 0-65535. Default: 2

timeout *retransmit_timeout_duration*

Sets the time duration to wait for response from the RADIUS server before retransmitting.

Must be an integer in the range of 1-65535. Default: 2 seconds.

Usage Guidelines

Use this command to configure RADIUS accounting parameters. Enters the RADIUS Accounting Configuration mode.

profile radius accounting attribute called-station-id

Configures the AAA called-station-id attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description

attribute called-station-id *value*

value

Specify the value of the AAA called-station-id attribute.

Must be a string.

Usage Guidelines Use this command to configure the AAA called-station-id attribute.

profile radius accounting attribute calling-station-id

Configures the AAA calling-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description `attribute calling-station-id value`

value

Specify the value of the AAA calling-station-id attribute.

Must be a string.

Usage Guidelines Use this command to configure the AAA calling-station-id attribute.

profile radius accounting attribute nas-identifier-format

Configures the AAA nas-identifier-format attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description `attribute nas-identifier-format value`

Usage Guidelines Use this command to configure the AAA nas-identifier-format attribute.

profile radius accounting attribute nas-port-id

Configures the AAA nas-port-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute nas-port-id** *value*

value

Specify value of the AAA nas-port-id attribute.

Must be a string.

Usage Guidelines Use this command to configure the AAA nas-port-id attribute.

profile radius accounting detect-dead-server

Configures parameters to detect a dead RADIUS server.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **detect-dead-server response-timeout** *response_timeout_duration*

response-timeout response_timeout_duration

Specify the time duration, in seconds, for a response from the RADIUS server to mark it as unreachable.

Must be an integer in the range of 1-65535.

Usage Guidelines Use this command to configure parameters to detect a dead RADIUS server.

profile radius attribute called-station-id

Configures the AAA called-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute called-station-id** *value*

format-name format_name

Specify the attribute format name.

Must be a string.

value

Specify the value of the AAA called-station-id attribute.

Must be a string.

Usage Guidelines Use this command to configure the AAA called-station-id attribute.

profile radius attribute called-station-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute** *attribute_name* **format** **nas-port-type** *nas_port_type* **format-name** *format_name*

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

format-name *format_name*

Specify the attribute format name.

Must be a string.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute calling-station-id

Configures the AAA calling-station-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute** **calling-station-id** *value*

format-name *format_name*

Specify the attribute format name.

Must be a string.

value

Specify the value of the AAA calling-station-id attribute.

Must be a string.

Usage Guidelines

Use this command to configure the AAA calling-station-id attribute.

profile radius attribute calling-station-id format

Configures node parameters.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description

attribute *attribute_name* **format** **nas-port-type** *nas_port_type* **format-name** *format_name*

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

format-name *format_name*

Specify the attribute format name.

Must be a string.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute nas-identifier-format

Configures the AAA nas-identifier-format attribute.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description

attribute **nas-identifier-format** *value*

format-name *format_name*

Specify the attribute format name.

Must be a string.

Usage Guidelines Use this command to configure the AAA nas-identifier-format attribute.

profile radius attribute nas-identifier-format format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute** *attribute_name* **format nas-port-type** *nas_port_type* **format-name** *format_name*

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

format-name *format_name*

Specify the attribute format name.

Must be a string.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

Usage Guidelines Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius attribute nas-ip

Configures the NAS IPv4 or User-Plane IP address.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Attribute Configuration (config-attribute)

Syntax Description **attribute nas-ip** { *ipv4_address* | **user-plane-ip** }

nas-ip *ipv4_address*

Specifies the AAA NAS IPv4 address.

nas-ip user-plane-ip

Enables the `user-plane-ip-address` AVPair to use the configured User-Plane IP address in Access-Request or Accounting-Request messages.

Usage Guidelines Use this command to configure the AAA NAS-IP attribute.

profile radius attribute nas-port-id

Configures the AAA nas-port-id attribute.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute nas-port-id** *value*

format-name *format_name*

Specify the attribute format name.

Must be a string.

value

Specify value of the AAA nas-port-id attribute.

Must be a string.

Usage Guidelines Use this command to configure the AAA nas-port-id attribute.

profile radius attribute nas-port-id format

Configures node parameters.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description **attribute** *attribute_name* **format nas-port-type** *nas_port_type* **format-name** *format_name*

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

format-name *format_name*

Specify the attribute format name.

Must be a string.

nas-port-type *nas_port_type*

Specify the Nas-Port-Type value to apply format name on.

Must be an integer.

Usage Guidelines

Use this command to configure node parameters for nas-port-id, calling-station-id, called-station-id, nas-identifier-format.

profile radius detect-dead-server

Configures parameters to detect a dead RADIUS server.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Accounting Configuration (config-accounting)

Syntax Description

detect-dead-server **response-timeout** *response_timeout_duration*

response-timeout *response_timeout_duration*

Specify the time duration, in seconds, for a response from the RADIUS server to mark it as unreachable.

Must be an integer in the range of 1-65535.

Usage Guidelines

Use this command to configure parameters to detect a dead RADIUS server.

profile radius server

Configures RADIUS external server configuration.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Syntax Description

server *radius_server_ip_address* *radius_server_port_number* [**priority** *radius_server_priority* | **secret** *radius_server_secret* | **type** *server_type*]

priority *radius_server_priority*

Specify the priority of the RADIUS server.

Must be an integer in the range of 1-100.

secret radius_server_secret

Specify the secret of the RADIUS server.

Must be an aes-cfb-128-encrypted string.

type server_type

Specify the server type.

Must be one of the following:

- **acct**
- **auth**

Default Value: auth.

radius_server_ip_address

Specify the IP address of the RADIUS server.

Must be an IP address.

radius_server_port_number

Specify the port number of the RADIUS server.

Must be an integer in the range of 1-65535.

Usage Guidelines

Use this command to configure RADIUS external server configuration.

profile radius server-group

Configures association of RADIUS servers to groups.

Command Modes

Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius)

Syntax Description

server-group *server_group_name*

server_group_name

Specify the server group name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,'])*).

Usage Guidelines

Use this command to configure association of RADIUS servers to groups. Enters the Server Group Configuration mode.

profile radius server-group server

Configures RADIUS server information.

Command Modes Exec > Global Configuration (config) > RADIUS Profile Configuration (config-radius) > RADIUS Server Group Configuration (config-server-group-*server_group_name*)

Syntax Description **server** *radius_server_type* **ip** *radius_server_ip_address* **port** *radius_port_number*

ip *radius_server_ip_address*

Specify IP address of the RADIUS server.

port *radius_port_number*

Specify the port number of the RADIUS server.

radius_server_type

Specify the server type.

Must be one of the following:

- **acct**: Server used for accounting requests.
- **auth**: Server is used for authentication/authorization requests.

Usage Guidelines Use this command to configure RADIUS server information.

profile server-group

Configures AAA custom server groups.

Command Modes Exec > Global Configuration (config)

Syntax Description **server-group** *server_group_name* **radius-group** *radius_server_group_name*

radius-group *radius_server_group_name*

Specify the RADIUS server group name.

aaa_server_group_name

Specify the AAA server group name.

Must be a string in the pattern ([a-zA-Z1-9][^\s\\t\\\";']*)

Usage Guidelines Use this command to configure AAA custom server groups.

profile subscriber

Configures subscriber profiles.

Command Modes Exec > Global Configuration (config)

Syntax Description

```
profile subscriber subscriber_profile_name [ [ activate-feature-templates
template_names ] [ apply-all-class ] [ dhcp-profile dhcp_profile_name ] [
pppoe-profile pppoe_profile_name ] [ session-type session_type ] ]
```

activate-feature-templates *template_names*

Specify the list of feature templates to activate.

apply-all-class

Specify to apply all classes if enabled.

dhcp-profile *dhcp_profile_name*

Specify the DHCP-FSOL profile name.

pppoe-profile *pppoe_profile_name*

Specify the PPPOE-FSOL profile name.

session-type *session_type*

Specify the allowed session type.

Must be one of the following:

- **ipv4**
- **ipv4v6**
- **ipv6**

Default Value: ipv4v6.

subscriber_profile_name

Specify the subscriber profile name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\"']*).

Usage Guidelines

Use this command to configure subscriber profiles. Enters the Subscriber Profile Configuration mode.

You can configure a maximum of "8" elements with this command.

profile subscriber aaa

Configures AAA operations.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-*subscriber_profile_name*)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-*subscriber_profile_name*) > Class Configuration (config-class-*class_name*)

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber- <i>subscriber_profile_name</i>) > Event Configuration (config-event- <i>event_name</i>)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber- <i>subscriber_profile_name</i>) > Event Configuration (config-event- <i>event_name</i>) > Class Configuration (config-class- <i>class_name</i>)
Syntax Description	<p>aaa <i>aaa_option</i> <i>aaa_profile_name</i></p> <p>aaa_option</p> <p>Specify the AAA option.</p> <p>Must be one of the following:</p> <ul style="list-style-type: none"> • authenticate • authorize <p>aaa_profile_name</p> <p>Specify the AAA profile name.</p>
Usage Guidelines	Use this command to configure AAA operations.

profile subscriber class

Configures subscriber classification parameters.

Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber- <i>subscriber_profile_name</i>)
Command Modes	Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber- <i>subscriber_profile_name</i>) > Event Configuration (config-event- <i>event_name</i>)
Syntax Description	<p>class <i>class_name</i> [activate-feature-templates <i>feature_template_names</i>]</p> <p>activate-feature-templates <i>feature_template_names</i></p> <p>Specify the list of feature template names to activate.</p> <p>class_name</p> <p>Specify the class name.</p> <p>Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,']*)</p>
Usage Guidelines	<p>Use this command to configure subscriber classification parameters. Enters the Subscriber Class Configuration mode.</p> <p>You can configure a maximum of "8" elements with this command.</p>

profile subscriber class aaa

Configures AAA operations.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Subscriber Class Configuration (config-class-class_name)

Syntax Description **aaa** *aaa_option* *profile_name*

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

profile_name

Specify the AAA profile name.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description **matches** [**match-type** { **all** | **any** }]

match-type match_type

Specify the match type.

Usage Guidelines Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile subscriber class matches match

Configures match key and value.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Class Configuration (config-class-*class_name*) > Matches Configuration (config-matches)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*) > Class Configuration (config-class-*class_name*) > Matches Configuration (config-matches)

Syntax Description **match** *match_key* { *match_protocol* | **ascii** *ascii_string* | **regex** *regex_string* }

match_key

Specify the match key.

ascii ascii_string

Specify the ASCII string.

Must be a string.

regex regex_string

Specify the regular expression string.

Must be a string.

match_key

Specify the match key.

match_protocol

Specify the match protocol.

Must be one of the following:

- **dhcp**
- **ppp**

You can configure a maximum of "2" elements with this command.

You can configure a maximum of "8" elements with this command.

Usage Guidelines Use this command to configure match key and value.

You can configure a maximum of "8" elements with this command.

profile subscriber event

Configures subscriber events.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Event Configuration (config-event-*event_name*)

Syntax Description

```
event event_name [ activate-feature-templates template_names | apply-all-class
| deactivate-feature-templates template_names ]
```

event *event_name*

Specify the event name.

activate-feature-templates *template_names*

Specify the list of feature templates to activate.

apply-all-class

Specify to apply all classes if enabled.

deactivate-feature-templates *template_names*

Specify the list of feature templates to deactivate.

event *event_name*

Specify the event name.

You can configure a maximum of "8" elements with this command.

Usage Guidelines

Use this command to configure subscriber events.

You can configure a maximum of "8" elements with this command.

profile subscriber event aaa

Configures AAA operations.

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-subscriber_profile_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name)

Command Modes

Exec > Global Configuration (config) > Subscriber Profile Configuration
(config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class
Configuration (config-class-class_name)

Syntax Description

```
aaa aaa_option aaa_profile_name
```

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

aaa_profile_name

Specify the AAA profile name.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber event class

Configures subscriber classification.

Command Modes Exec > Global Configuration

Syntax Description **class** { **class-name** *class_name* | **deactivate-feature-templates** *template_names* | **activate-feature-templates** *template_names* }

activate-feature-templates *template_names*

Specify the list of feature template names to activate.

class-name *class_name*

Specify the class name.

Must be a string in the pattern ([a-zA-Z1-9][^\s,\t,\'"]*)

deactivate-feature-templates *template_names*

Specify the list of feature template names to deactivate.

You can configure a maximum of "8" elements with this command.

Usage Guidelines Use this command to configure subscriber classification.

You can configure a maximum of "8" elements with this command.

profile subscriber event class aaa

Configures AAA operations.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-*subscriber_profile_name*) > Subscriber Class Configuration (config-class-*class_name*)

Syntax Description **aaa** *aaa_option* *profile_name*

aaa_option

Specify the AAA option.

Must be one of the following:

- **authenticate**
- **authorize**

profile_name

Specify the AAA profile name.

Usage Guidelines Use this command to configure AAA operations.

profile subscriber event class matches

Configures the list of match values.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name)

Syntax Description **matches** [**match-type** { **all** | **any** }]

match-type *match_type*

Specify the match type.

Usage Guidelines Use this command to configure the list of match values. Enters the Matches Configuration mode.

profile subscriber event class matches match

Configures match key and value.

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Command Modes Exec > Global Configuration (config) > Subscriber Profile Configuration (config-subscriber-subscriber_profile_name) > Event Configuration (config-event-event_name) > Class Configuration (config-class-class_name) > Matches Configuration (config-matches)

Syntax Description **match** *match_key* { *match_protocol* | **ascii** *ascii_string* | **regex** *regex_string* }

match_key

Specify the match key.

ascii *ascii_string*

Specify the ASCII string.

Must be a string.

regex *regex_string*

Specify the regular expression string.

Must be a string.

match_key

Specify the match key.

match_protocol

Specify the match protocol.

Must be one of the following:

- dhcp
- ppp

Usage Guidelines

Use this command to configure match key and value.

You can configure a maximum of "8" elements with this command.

show sessions

Displays pending session commits in the database.

Command Modes

Exec

Syntax Description

show sessions

Usage Guidelines

Use this command to view pending session commits in the database.

show sessions affinity

Displays instance-wise affinity count.

Command Modes

Exec

Syntax Description

show sessions affinity

Usage Guidelines

Use this command to view the instance-wise affinity count.

show sessions commit-pending

Displays all pending session commits.

Command Modes Exec

Syntax Description `show sessions commit-pending`

Usage Guidelines Use this command to view all pending session commits.

show diagnostics

Displays diagnostics information.

Command Modes Exec

Syntax Description `show diagnostics`

Usage Guidelines Use this command to view diagnostics information.

show diagnostics info

Displays diagnostics information.

Command Modes Exec

Syntax Description `show diagnostics info`

Usage Guidelines Use this command to view diagnostics information.

show endpoint all

Displays endpoint status.

Command Modes Exec

Syntax Description `show endpoint all`

Usage Guidelines Use this command to view endpoint status for all endpoints.

show endpoint info

Displays endpoint information.

show ipam dp

Command Modes	Exec
Syntax Description	<code>show endpoint info</code>
Usage Guidelines	Use this command to view endpoint information.

show ipam dp

Displays IPAM data-plane allocations.

Command Modes	Exec
Syntax Description	<code>show ipam dp</code>
Usage Guidelines	Use this command to view IPAM data-plane allocations.

show ipam pool

Displays pool allocation information.

Command Modes	Exec
Syntax Description	<code>show ipam pool</code>
Usage Guidelines	Use this command to view pool allocation information.

show peers

Displays peer information.

Command Modes	Exec
Syntax Description	<code>show peers</code>
Usage Guidelines	Use this command to view peer information.

show peers all

Displays information for all peers.

Command Modes	Exec
Syntax Description	<code>show peers all</code>
Usage Guidelines	Use this command to view information for all peers.

show resources

Displays resources information.

Command Modes Exec

Syntax Description `show resources`

Usage Guidelines Use this command to view resources information.

show resources info

Displays resources information.

Command Modes Exec

Syntax Description `show resources info`

Usage Guidelines Use this command to view resources information.

show rpc

Displays RPC information.

Command Modes Exec

Syntax Description `show rpc`

Usage Guidelines Use this command view RPC information.

show rpc all

Displays information for all RPCs.

Command Modes Exec

Syntax Description `show rpc all`

Usage Guidelines Use this command to view information for all RPCs.

show running-status

Displays system running status information.

Command Modes Exec

Syntax Description `show running-status`

Usage Guidelines Use this command to view system running status information.

show running-status info

Displays system running status information.

Command Modes Exec

Syntax Description `show running-status info`

Usage Guidelines Use this command to view system running status information.

show subscriber

Displays BNG subscriber data.

Command Modes Exec

Syntax Description `show subscriber type [count | detail | sublabel subscriber_label]`

acct-sess-id *accounting_session_id*

Specify the accounting session ID.

Must be a string.

count

Specify to display the number of sessions.

debug

Specify debug information.

detail

Specify to display detailed information.

sublabel *subscriber_label*

Specify the subscriber label.

Must be a string.

sync *sync_info*

Specify synchronization information.

Must be one of the following:

- **synchronize**

upf *upf_info*

Specify UPF information.

Must be a string.

upmgr

Specify SMUP information.

type

Specify the type.

Must be one of the following:

- **charging**
- **dhcp**
- **pppoe**
- **session**

Usage Guidelines Use this command to view BNG subscriber data.

show subscriber

Displays subscriber information.

Command Modes Exec

Syntax Description `show subscriber { all | supi supi_id }`

all

Specify all SUPI.

supi *supi_id*

Specify the SUPI.

Must be a string.

Usage Guidelines Use this command to view summary and detailed subscriber information for all subscribers or specific subscribers based on SUPI.

show subscriber filter

Configures additional filters.

Command Modes

Exec

Syntax Description

```
show subscriber type filter [ afi address_family | iana-state-bound
iana_bound_state | iapd-state-bound iapd_bound_state | ipv4-addr ipv4_address |
ipv4-pool ipv4_pool_name | ipv4-range ipv4_address_range | ipv4-state-bound
ipv4_bound_state | ipv6-addr ipv6_address | ipv6-addr-pool ipv6_address_pool_name |
ipv6-addr-range ipv6_address_range | ipv6-pfx ipv6_prefix | ipv6-pfx-pool
ipv6_prefix_pool | ipv6-pfx-range ipv6_prefix_range | mac mac_address | port-id
upf_port_id | state session_state | up-subs-id up_subscriber_id | upf upf_name |
upmgr sm_up_info | username session_user_name | vrf vrf_name ]
```

afi *address_family*

Specify the address family.

Must be one of the following:

- **dual**
- **ipv4**
- **ipv6**
- **pending**

iana-state-bound *iana_bound_state*

Specify the IANA bound state.

Must be one of the following:

- **iana-state-bound**

iapd-state-bound *iapd_bound_state*

Specify the IAPD bound state.

Must be one of the following:

- **iapd-state-bound**

ipv4-addr *ipv4_address*

Specify the IPv4 address in the format "*pool-name/ipv4-addr*".

Must be a string.

ipv4-pool *ipv4_pool_name*

Specify the IPv4 pool name.

Must be a string.

ipv4-range *ipv4_address_range*

Specify the IPv4 address range in the format "*poolName/start-ip*".

Must be a string.

ipv4-state-bound *ipv4_bound_state*

Specify the IPv4 bound state.

Must be one of the following:

- **ipv4-state-bound**

ipv6-addr-pool *ipv6_address_pool_name*

Specify the IPv6 address pool name.

Must be a string.

ipv6-addr-range *ipv6_address_range*

Specify the IPv6 address range in the format "*poolName/start-ip*".

Must be a string.

ipv6-addr *ipv6_address*

Specify the IPv6 address in the format "*pool-name/ipv6-addr*".

Must be a string.

ipv6-pfx-pool *ipv6_prefix_pool*

Specify the IPv6 prefix pool name.

Must be a string.

ipv6-pfx-range *ipv6_prefix_range*

Specify the IPv6 prefix range in the format "*poolName/start-pfx*".

Must be a string.

ipv6-pfx *ipv6_prefix*

Specify the IPv6 prefix in the format "*pool-name/ipv6-pfx*".

Must be a string.

mac *mac_address*

Specify the MAC address in the format "*aabb.ccdd.eeff*".

Must be a string.

port-id *upf_port_id*

Specify the user plane function port ID in the format "*upf/portid*".

Must be a string.

smstate *sm_session_state*

Specify the state of the SM session.

Must be one of the following:

- **created**
- **deleted**
- **established**

smupstate *smup_session_state*

Specify the state of the SMUP session.

Must be one of the following:

- **smUpSessionCreated**
- **smUpSessionDeleted**
- **smUpSessionWait4SmCreate**

state *session_state*

Specify the session state.

Must be one of the following:

- **complete**
- **incomplete**

up-subscriber-id *up_subscriber_id*

Specify the UP subscriber ID.

Must be a string.

upf *upf_name*

Specify the user plane function name.

Must be a string.

upmgr *upmgr*

Specify the UPMgr.

Must be one of the following:

- **upmgr**

username *session_user_name*

Specify the user name of the session.

Must be a string.

Usage Guidelines

Use this command to configure additional filters.

show subscriber redundancy

Displays the key values of SRG groups

Command Modes

Exec

Syntax Description

show subscriber redundancy [**count** | **debug** | **detail** | **gr-instance** *gr_instance_id* | **srg-peer-id** *srg_peer_id* | **upf** *upf_name*]

count

Specify the count of SRG groups

debug

Specify debug information

detail

Specify to display detailed information.

gr-instance *gr_instance_id*

Specify the geo redundancy instance identity.

srg-peer-id *srg_peer_id*

Specify the identity of peer user plane for the group.

upf *upf_name*

Specify the name of user plane function.

Usage Guidelines

Use this command to view the key values of SRG groups.

show subscriber redundancy-sync

Displays the subscriber reconciliation details.

Command Modes

Exec

Syntax Description

show subscriber redundancy-sync [**gr-instance** *gr_instance_id* | **srg-peer-id** *srg_peer_id* | **upf** *upf_name*]

gr-instance *gr_instance_id*

Specify the geo redundancy instance identity.

srg-peer-id *srg_peer_id*

Specify the identity of peer user plane for the SRG.

upf *upf_name*

Specify the name of user plane function.

Usage Guidelines Use this command to view the subscriber reconciliation details.

show subscriber session

Displays the session manager CDL record keys per session.

Command Modes Exec

Syntax Description `show subscriber session [detail | filter { smupstate { upf_name/smUpSessionCreated } }]`

detail

Display the session details from SM CDL record.

filter { smupstate { upf_name/smUpSessionCreated } }

Display whether the session is created in the respective UPF for the SRG sessions.

Usage Guidelines Use this command to view the session manager CDL record keys per session.

show subscriber synchronize

Synchronize information.

Command Modes Exec

Syntax Description `show subscriber synchronize [srg-peer-id peer_id | upf upf_info]`

Syntax Description `show subscriber synchronize-cp upf upf_info`

synchronise-cp

Specify to synchronise CP information.

Must be one of the following:

- **synchronize-cp**

synchronize

Specify to synchronise UP information.

Must be one of the following:

- **synchronize**

srg-peer-id *peer_id*

Specify the identity of peer user plane for the group.

upf *upf_info*

Specify UPF information.

Must be a string of 1-64 characters.

Usage Guidelines

Use this command to synchronise information.

subscriber featurette dhcp-lease-reservation enable

Enables/disables DHCP IP Lease Reservation.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
[ no ] subscriber featurette dhcp-lease-reservation enable
```

subscriber featurette dhcp-lease-reservation enable

Enables DHCP IP Lease Reservation

no subscriber featurette dhcp-lease-reservation enable

Disables DHCP IP Lease Reservation

Usage Guidelines

Use this command to enable or disable DHCP IP Lease Reservation.

subscriber-redundancy group

Configures subscriber geographical redundancy group.

Command Modes

Exec > Global Configuration > Userplane Configuration (config-user-plane-userplane_name)

Syntax Description

```
subscriber-redundancy group group_name { disable | domain-identifier
domain-name | peer-identifier peer-id | port-id-map port-name port-id name
port-id | [ preferred-role-active ] [ revertive-timer sec ] }
```

subscriber-redundancy group *group_name*

Specifies the name of the subscriber redundancy group that is unique to a user plane.

disable

Disables an SRG group without deleting the entire configuration of the group. The behaviour is same as removing an SRG group.

domain-identifier *domain_name*

Specifies the domain name to identify all groups common between two userplanes.

peer-identifier *peer_id*

Identifies the peer user-plane for the group. This identifier must be unique across all groups in the control plane. The same peer-identifier must be configured in the peer user-plane.

port-id-map port-name *port_name port_id*

Specifies the mapping of access interfaces between user planes. At least one port-id-map must be configured.

preferred-role-active

This is an optional configuration.

Sets the preferred role active for user plane. If preferred-role-active is not configured, none of the UPs under the SRG group will be active. Default value: false.

revertive-timer *sec*

This is an optional configuration.

Specifies the revertive timer in seconds. revertive_timer_value must be an integer in the range of 60 to 3600. This command is available only when **preferred-role-active** is configured.

Usage Guidelines

Use this command to configure the subscriber redundancy group (SRG) configuration.

subscriber redundancy session-synchronize add

Synchronizes the sessions with the standby UP.

Command Modes

Exec

Syntax Description

```
subscriber-redundancy session-synchronize add { domain [ domain_ID ] |
duration timeout_value | peer-id [ peer_id ] | target-upf upf_id | tps value |
upf [ upf_id ] }
```

domain [*domain_id*]

Specifies the list of SRG domains.

duration *timeout_value*

Specifies the maximum timeout value in minutes.

peer-id [*peer_id*]

Specifies the list of SRG peer identities.

target-upf *upf_id*

Specifies the identity of target UP.

tps *value*

Specifies the maximum number of allowed transactions per second (TPS).

upf [*upf_id*]

Specifies the list of UPs.

subscriber redundancy session-synchronize delete

Deletes SRG sessions.

Command Modes

Exec

Syntax Description

```
subscriber-redundancy session-synchronize delete { domain [ domain_ID ] |  
  duration timeout_value | peer-id [ peer_id ] | target-upf upf_id | tps value  
  | upf [ upf_id ] }
```

domain [*domain_id*]

Specifies the list of SRG domains.

duration *timeout_value*

Specifies the maximum timeout value in minutes.

peer-id [*peer_id*]

Specifies the list of SRG peer identities.

target-upf *upf_id*

Specifies the identity of target UP.

tps *value*

Specifies the maximum number of allowed transactions per second (TPS).

upf [*upf_id*]

Specifies the list of UPs.

subscriber reset-token

Configure to reset the in-use token for the specified protocol.

Command Modes

Exec

Syntax Description

```
subscriber reset-token { dhcp | pppoe }
```

```
subscriber reset-token { dhcp | pppoe }
```

Reset the in-use token to zero for DHCP or PPPoE.

Usage Guidelines

Use this command to reset the in-use token to zero.

subscriber route-synchronize

Synchronizes routes to UPF.

Command Modes

Exec

Syntax Description

```
subscriber route-synchronize upf user_plane_name
```

```
upf user_plane_name
```

Specify the user plane name.

Must be a string.

Usage Guidelines

Use this command to synchronize routes to UPF.

subscriber session-synchronize

Synchronizes sessions to UPF.

Command Modes

Exec

Syntax Description

```
subscriber session-synchronize upf user_plane_name [ abort | timeout sla_timeout ]
```

```
abort
```

Specify to abort synchronization.

```
timeout sla_timeout
```

Specify the SLA timeout duration in seconds.

Must be an integer in the range of 10-1800.

upf *user_plane_name*

Specify the user plane name.

Must be a string.

Usage Guidelines

Use this command to synchronize sessions to UPE.

subscriber session-synchronize-cp

Synchronizes sessions on CP.

Command Modes

Exec

Syntax Description

```
subscriber session-synchronize-cp upf user_plane_name [ abort | timeout
timeout_value | tps tps ]
```

abort

Specify to abort synchronization.

timeout *timeout_value*

Specify the timeout duration in minutes.

Must be an integer in the range of 2-100.

tps *tps*

Specify the TPS.

Must be an integer in the range of 40-4000.

upf *user_plane_name*

Specify name of the user plane function.

Must be a string of 1-64 characters.

Usage Guidelines

Use this command to synchronize sessions on CP.

subscriber token

Configures FSOL token mechanism.

Command Modes

Exec > Global Configuration (config)

Syntax Description

```
subscriber token { dhcp | pppoe } token_count
```

```
subscriber token { dhcp | pppoe } token_count
```

Set the maximum token available for FSOL pod.

token_count is cumulative across instances. For example, if there are 4 DHCP pods and DHCP token is set as 2000, then 500 tokens will be assigned for each pod

- **dhcp**: Set the DHCP pod token count.
- **pppoe**: Set the PPPoE pod token count.

Usage Guidelines Use this command to configure FSOL token mechanism.

user-plane

Configures the userplane configuration.

Command Modes Exec > Global Configuration (config)

Syntax Description **user-plane** *userplane_name* [**offline** | **subscriber-profile** *subscriber_profile*]

offline

Specify as offline.

subscriber-profile *subscriber_profile_name*

Specify the Subscriber Profile to associate at current level.

userplane_name

Specify the userplane name.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\t,\"']*).

Usage Guidelines Use this command to configure the userplane configuration. Enters the Userplane Configuration mode.

user-plane flowctrl-group

Configures the associated flow control group in user plane.

Command Modes Exec > Global Configuration > Userplane Configuration (config-user-plane-*userplane_name*)

Syntax Description **flowctrl-group** *group_name*

flowctrl-group *group_name*

Specify the flow control group to be associated.

Usage Guidelines Use this command to associate the flow control group in user plane.

user-plane peer-address

Configures the userplane IP address.

Command Modes Exec > Global Configuration (config) > User Plane Configuration (config-user-plane-*userplane_name*)

Syntax Description **peer-address ipv4** *ipv4_address*

ipv4 *ipv4_address*

Specify the IPv4 address.

Must be an IPv4 address.

Usage Guidelines Use this command to configure the userplane IP address.

user-plane port-id

Configures Port Identifier parameters.

Command Modes Exec > Global Configuration (config) > User Plane Configuration (config-user-plane-*userplane_name*)

Syntax Description **port-id** *port_number* [**subscriber-profile** *subscriber_profile_name*]

subscriber-profile *subscriber_profile_name*

Specify the Subscriber Profile to associate to the Port Identifier level.

port_number

Specify the port identifier.

Must be a string in the pattern ([a-zA-Z1-9_][^\s,\\t,\\,')*).

Usage Guidelines Use this command to configure Port Identifier parameters.

user-plane port-id



CHAPTER 2

Input Pattern Types

- `arg-type`, on page 95
- `crypt-hash`, on page 96
- `date-and-time`, on page 97
- `domain-name`, on page 97
- `dotted-quad`, on page 98
- `hex-list`, on page 98
- `hex-string`, on page 99
- `ipv4-address`, on page 99
- `ipv4-address-and-prefix-length`, on page 99
- `ipv4-address-no-zone`, on page 99
- `ipv4-prefix`, on page 99
- `ipv6-address`, on page 100
- `ipv6-address-and-prefix-length`, on page 100
- `ipv6-address-no-zone`, on page 101
- `ipv6-prefix`, on page 101
- `mac-address`, on page 102
- `object-identifier`, on page 102
- `object-identifier-128`, on page 102
- `octet-list`, on page 103
- `phys-address`, on page 103
- `sha-256-digest-string`, on page 103
- `sha-512-digest-string`, on page 104
- `size`, on page 104
- `uuid`, on page 105
- `yang-identifier`, on page 105

arg-type

Pattern:

```
'[^\*]*.*|..+>'; // must not be single '*'
```

Pattern:

```
'\*'
```

This statement can be used to hide a node from some, or all, northbound interfaces. All nodes with the same value are considered a hide group and are treated the same with regards to being visible or not in a northbound interface.

A node with an hidden property is not shown in the northbound user interfaces (CLI and Web UI) unless an 'unhide' operation is performed in the user interface.

The hidden value 'full' indicates that the node must be hidden from all northbound interfaces, including programmatical interfaces such as NETCONF. The value '*' is not valid. A hide group can be unhidden only if this is explicitly allowed in the confd.conf(5) daemon configuration.

Multiple hide groups can be specified by giving this statement multiple times. The node is shown if any of the specified hide groups is given in the 'unhide' operation. If a mandatory node is hidden, a hook callback function (or similar) might be needed in order to set the element

crypt-hash

Pattern:

```
'$0$.*'
'|$1$[a-zA-Z0-9./]{1,8}$[a-zA-Z0-9./]{22}'
'|$5$(rounds=\d+)$?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{43}'
'|$6$(rounds=\d+)$?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{86}'
```

The **crypt-hash** type is used to store passwords using a hash function. The algorithms for applying the hash function and encoding the result are implemented in various UNIX systems as the function crypt(3).

A value of this type matches one of the forms:

- `0<clear text password>`
- `$<id>$<salt>$<password hash>`
- `$<id>$<parameter>$<salt>$<password hash>`

The '\$0\$' prefix signals that the value is clear text. When such a value is received by the server, a hash value is calculated, and the string '\$<id>\$<salt>\$' or '\$<id>\$<parameter>\$<salt>\$' is prepended to the result. This value is stored in the configuration data store.

If a value starting with '\$<id>\$', where <id> is not '0', is received, the server knows that the value already represents a hashed value, and stores it as is in the data store.

When a server needs to verify a password given by a user, it finds the stored password hash string for that user, extracts the salt, and calculates the hash with the salt and given password as input. If the calculated hash value is the same as the stored value, the password given by the client is accepted.

This type defines the following hash functions:

Id	Hash Function	Feature
1	MD5	crypt-hash-md5
5	SHA-256	crypt-hash-sha-256
6	SHA-512	crypt-hash-sha-512

The server indicates support for the different hash functions by advertising the corresponding feature.

Reference:

- IEEE Std 1003.1-2008 - crypt() function
- RFC 1321: The MD5 Message-Digest Algorithm
- FIPS.180-3.2008: Secure Hash Standard

date-and-time

Pattern:

```
'\d{4}-\d{2}-\d{2}T\d{2}:\d{2}:\d{2}(\.\d+)?'
'(Z|[\+\-]\d{2}:\d{2})'
```

The date-and-time type is a profile of the ISO 8601 standard for representation of dates and times using the Gregorian calendar. The profile is defined by the date-time production in Section 5.6 of RFC 3339. The date-and-time type is compatible with the dateTime XML schema type with the following notable exceptions:

1. The date-and-time type does not allow negative years.
2. The date-and-time time-offset -00:00 indicates an unknown time zone (see RFC 3339) while -00:00 and +00:00 and Z all represent the same time zone in dateTime.
3. The canonical format (see below) of data-and-time values differs from the canonical format used by the dateTime XML schema type, which requires all times to be in UTC using the time-offset 'Z'.

This type is not equivalent to the DateAndTime textual convention of the SMIV2 since RFC 3339 uses a different separator between full-date and full-time and provides higher resolution of time-secfrac. The canonical format for date-and-time values with a known time zone uses a numeric time zone offset that is calculated using the device's configured known offset to UTC time.

A change of the device's offset to UTC time will cause date-and-time values to change accordingly. Such changes might happen periodically in case a server follows automatically daylight saving time (DST) time zone offset changes. The canonical format for date-and-time values with an unknown time zone (usually referring to the notion of local time) uses the time-offset -00:00.

Reference:

- RFC 3339: Date and Time on the Internet: Timestamps
- RFC 2579: Textual Conventions for SMIV2
- XSD-TYPES: XML Schema Part 2: Datatypes Second Edition

domain-name

Pattern:

```
'((([a-zA-Z0-9_]([a-zA-Z0-9\-\_]){0,61})?[a-zA-Z0-9]\.)*'
'([a-zA-Z0-9_]([a-zA-Z0-9\-\_]){0,61})?[a-zA-Z0-9]\.?)'
'|\.'
```

The domain-name type represents a DNS domain name. The name must fully qualified whenever possible. Internet domain names are only loosely specified. Section 3.5 of RFC 1034 recommends a syntax (modified in Section 2.1 of RFC 1123). The Pattern above is intended to allow for current practice in domain name use, and some possible future expansion. It is designed to hold various types of domain names, including names used for A or AAAA records (host names) and other records, such as SRV records.

The Internet host names have a stricter syntax (described in RFC 952) than the DNS recommendations in RFCs 1034 and 1123, and that systems that want to store host names in schema nodes using the domain-name type are recommended to adhere to this stricter standard to ensure interoperability.

The encoding of DNS names in the DNS protocol is limited to 255 characters. Since the encoding consists of labels prefixed by a length bytes and there is a trailing NULL byte, only 253 characters can appear in the textual dotted notation.

The description clause of schema nodes using the domain-name type must describe when and how these names are resolved to IP addresses. The resolution of a domain-name value may require to query multiple DNS records. For example, A for IPv4 and AAAA for IPv6. The order of the resolution process and which DNS record takes precedence can either be defined explicitly or may depend on the configuration of the resolver.

Domain-name values use the US-ASCII encoding. Their canonical format uses lowercase US-ASCII characters. Internationalized domain names MUST be A-labels as per RFC 5890.

Reference:

- RFC 952: DoD Internet Host Table Specification
- RFC 1034: Domain Names - Concepts and Facilities
- RFC 1123: Requirements for Internet Hosts -- Application and Support
- RFC 2782: A DNS RR for specifying the location of services (DNS SRV)
- RFC 5890: Internationalized Domain Names in Applications (IDNA): Definitions and Document Framework

dotted-quad

Pattern:

```
'(( [0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5] ) \. ) {3} '
' ( [0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5] ) '
```

An unsigned 32-bit number expressed in the dotted-quad notation, that is, four octets written as decimal numbers and separated with the '.' (full stop) character.

hex-list

Pattern:

```
' ( ( [0-9a-fA-F] ) {2} ( : ( [0-9a-fA-F] ) {2} ) * ) ? '
```

DEPRECATED: Use yang:hex-string instead. There are no plans to remove tailf:hex-list. A list of colon-separated hexa-decimal octets, for example '4F:4C:41:71'.

The statement tailf:value-length can be used to restrict the number of octets. Using the 'length' restriction limits the number of characters in the lexical representation

hex-string

Pattern:

```
' ([0-9a-fA-F]{2} (: [0-9a-fA-F]{2}) *) ?'
```

A hexadecimal string with octets represented as hex digits separated by colons. The canonical representation uses lowercase characters.

ipv4-address

Pattern:

```
' (([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) \. ) {3} '  
' ([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) '  
' (% [\p{N} \p{L} ]+ ) ?'
```

The ipv4-address type represents an IPv4 address in dotted-quad notation. The IPv4 address may include a zone index, separated by a % sign. The zone index is used to disambiguate identical address values. For link-local addresses, the zone index will typically be the interface index number or the name of an interface. If the zone index is not present, the default zone of the device will be used. The canonical format for the zone index is the numerical format.

ipv4-address-and-prefix-length

Pattern:

```
' (([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) \. ) {3} '  
' ([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) '  
' / ( ([0-9] ) | ( [1-2] [0-9] ) | ( 3 [0-2] ) )'
```

The ipv4-address-and-prefix-length type represents a combination of an IPv4 address and a prefix length. The prefix length is given by the number following the slash character and must be less than or equal to 32.

ipv4-address-no-zone

Pattern:

```
' [0-9\. ] *'
```

An IPv4 address is without a zone index and derived from ipv4-address that is used in situations where the zone is known from the context and hence no zone index is needed.

ipv4-prefix

Pattern:

```
' (([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) \. ) {3} '  
' ([0-9] | [1-9] [0-9] | 1 [0-9] [0-9] | 2 [0-4] [0-9] | 25 [0-5]) '  
' / ( ([0-9] ) | ( [1-2] [0-9] ) | ( 3 [0-2] ) )'
```

The ipv4-prefix type represents an IPv4 address prefix. The prefix length is given by the number following the slash character and must be less than or equal to 32.

A prefix length value of 'n' corresponds to an IP address mask that has n contiguous 1-bits from the most significant bit (MSB) and all other bits set to 0.

The canonical format of an IPv4 prefix has all bits of the IPv4 address set to zero that are not part of the IPv4 prefix.

ipv6-address

Pattern:

```
'((:| [0-9a-fA-F]{0,4}) : ) ([0-9a-fA-F]{0,4} : ) {0,5}'
'((( [0-9a-fA-F]{0,4} : ) ? ( : | [0-9a-fA-F]{0,4} )) |)'
'((( (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) \. ) {3} |'
' (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] )))'
' (% [\p{N} \p{L} ]+ ) ?'
```

Pattern:

```
'(([^: ]+ : ) {6} ( ([^: ]+ : [^: ]+ ) | ( . * \. . * ) ) ) |'
'((( [^: ]+ : ) * [^: ]+ ) ? : ( ([^: ]+ : ) * [^: ]+ ) ? )'
' (% .+ ) ?'
```

The ipv6-address type represents an IPv6 address in full, mixed, shortened, and shortened-mixed notation. The IPv6 address may include a zone index, separated by a % sign.

The zone index is used to disambiguate identical address values. For link-local addresses, the zone index will typically be the interface index number or the name of an interface. If the zone index is not present, the default zone of the device will be used.

The canonical format of IPv6 addresses uses the textual representation defined in Section 4 of RFC 5952. The canonical format for the zone index is the numerical format as described in Section 11.2 of RFC 4007.

Reference:

- RFC 4291: IP Version 6 Addressing Architecture
- RFC 4007: IPv6 Scoped Address Architecture
- RFC 5952: A Recommendation for IPv6 Address Text Representation

ipv6-address-and-prefix-length

Pattern:

```
'((:| [0-9a-fA-F]{0,4}) : ) ([0-9a-fA-F]{0,4} : ) {0,5}'
'((( [0-9a-fA-F]{0,4} : ) ? ( : | [0-9a-fA-F]{0,4} )) |)'
'((( (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) \. ) {3} |'
' (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] )))'
' ( / ( ([0-9] ) | ([0-9] {2} ) | (1 [0-1] [0-9] ) | (12 [0-8] )))'
```

Pattern:

```
'(([^: ]+ : ) {6} ( ([^: ]+ : [^: ]+ ) | ( . * \. . * ) ) ) |'
```

```
' ((([^\:]+\:)*[^\:]+)?\: (([^\:]+\:)*[^\:]+)? )'  
' (/.\+ )'
```

The `ipv6-address-and-prefix-length` type represents a combination of an IPv6 address and a prefix length. The prefix length is given by the number following the slash character and must be less than or equal to 128.

ipv6-address-no-zone

Pattern:

```
' [0-9a-fA-F:\.]* '
```

An IPv6 address without a zone index. This type, derived from `ipv6-address`, may be used in situations where the zone is known from the context and hence no zone index is needed.

Reference:

- RFC 4291: IP Version 6 Addressing Architecture
- RFC 4007: IPv6 Scoped Address Architecture
- RFC 5952: A Recommendation for IPv6 Address Text Representation

ipv6-prefix

Pattern:

```
' ((:| [0-9a-fA-F] {0,4}) : ) ( [0-9a-fA-F] {0,4} : ) {0,5} '  
' ((( [0-9a-fA-F] {0,4} : ) ? ( : | [0-9a-fA-F] {0,4} ) ) | '  
' (( (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) \. ) {3} ' Pattern:  
' (25 [0-5] | 2 [0-4] [0-9] | [01] ? [0-9] ? [0-9] ) ) ) '  
' ( / ( ( [0-9] ) | ( [0-9] {2} ) | ( 1 [0-1] [0-9] ) | ( 12 [0-8] ) ) ) ) ' ;
```

Pattern:

```
' (([^\:]+\:){6} ([^\:]+\: [^\:]+\: | (.*\.\. *))) | '  
' ((([^\:]+\:)*[^\:]+)?\: (([^\:]+\:)*[^\:]+)? )'  
' (/.\+ )'
```

The `ipv6-prefix` type represents an IPv6 address prefix. The prefix length is given by the number following the slash character and must be less than or equal to 128.

A prefix length value of `n` corresponds to an IP address mask that has `n` contiguous 1-bits from the most significant bit (MSB) and all other bits set to 0.

The IPv6 address should have all bits that do not belong to the prefix set to zero. The canonical format of an IPv6 prefix has all bits of the IPv6 address set to zero that are not part of the IPv6 prefix. Furthermore, the IPv6 address is represented as defined in Section 4 of RFC 5952

Reference:

- RFC 5952: A Recommendation for IPv6 Address Text Representation

mac-address

Pattern:

```
' [0-9a-fA-F] {2} ( : [0-9a-fA-F] {2} ) {5} '
```

The mac-address type represents an IEEE 802 MAC address. The canonical representation uses lowercase characters. In the value set and its semantics, this type is equivalent to the MacAddress textual convention of the SMIV2.

Reference:

- IEEE 802: IEEE Standard for Local and Metropolitan Area Networks: Overview and Architecture
- RFC 2579: Textual Conventions for SMIV2

object-identifier

Pattern:

```
' ( ([0-1] (\ . [1-3]? [0-9])) | (2 \ . (0 | ([1-9] \d*))) ) '
' (\ . (0 | ([1-9] \d*))) * '
```

The object-identifier type represents administratively assigned names in a registration-hierarchical-name tree. The values of this type are denoted as a sequence of numerical non-negative sub-identifier values. Each sub-identifier value MUST NOT exceed $2^{32}-1$ (4294967295). The Sub-identifiers are separated by single dots and without any intermediate whitespace.

The ASN.1 standard restricts the value space of the first sub-identifier to 0, 1, or 2. Furthermore, the value space of the second sub-identifier is restricted to the range 0 to 39 if the first sub-identifier is 0 or 1. Finally, the ASN.1 standard requires that an object identifier has always at least two sub-identifiers. The pattern captures these restrictions.

Although the number of sub-identifiers is not limited, module designers should realize that there may be implementations that stick with the SMIV2 limit of 128 sub-identifiers.

This type is a superset of the SMIV2 OBJECT IDENTIFIER type since it is not restricted to 128 sub-identifiers. Hence, this type SHOULD NOT be used to represent the SMIV2 OBJECT IDENTIFIER type; the object-identifier-128 type SHOULD be used instead.

Reference:

- ISO9834-1: Information technology - Open Systems
- Interconnection - Procedures for the operation of OSI
- Registration Authorities: General procedures and top arcs of the ASN.1 Object Identifier tree

object-identifier-128

Pattern:

```
' \d* (\ . \d* ) {1,127} '
```


This type represents object-identifiers restricted to 128 sub-identifiers. In the value set and its semantics, this type is equivalent to the OBJECT IDENTIFIER type of the SMIV2.

Reference:

- RFC 2578: Structure of Management Information Version 2 (SMIV2)

octet-list

Pattern:

```
'(\d*(.\d*)*)?'
```

A list of dot-separated octets, for example '192.168.255.1.0'. The statement tailf:value-length can be used to restrict the number of octets. Using the 'length' restriction limits the number of characters in the lexical representation.

phys-address

Pattern:

```
'([0-9a-fA-F]{2}(:[0-9a-fA-F]{2})*)?'
```

Represents media- or physical-level addresses represented as a sequence octets, each octet represented by two hexadecimal numbers. Octets are separated by colons. The canonical representation uses lowercase characters. In the value set and its semantics, this type is equivalent to the PhysAddress textual convention of the SMIV2.

Reference:

- RFC 2579: Textual Conventions for SMIV2

sha-256-digest-string

Pattern:

```
'$0$.*'
'|$5$(rounds=\d+)?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{43}'
```

The sha-256-digest-string type automatically computes a SHA-256 digest for a value adhering to this type. A value of this type matches one of the forms:

- \$0\$<clear text password>
- \$5\$<salt>\$<password hash>
- \$5\$rounds=<number>\$<salt>\$<password hash>

The '\$0\$' prefix signals that this is plain text. When a plain text value is received by the server, a SHA-256 digest is calculated, and the string '\$5\$<salt>\$' is prepended to the

result, where <salt> is a random 16 character salt used to generate the digest. This value is stored in the configuration data store. The algorithm can be tuned through the /confdConfig/cryptHash/rounds parameter, which if set to a number other than the default will cause '\$5\$rounds=<number>\$<salt>\$' to be prepended instead of only '\$5\$<salt>\$'.

If a value starting with '\$5\$' is received, the server knows that the value already represents a SHA-256 digest, and stores it as is in the data store.

If a default value is specified, it must have a '\$5\$' prefix.

The digest algorithm used is the same as the SHA-256 crypt function used for encrypting passwords for various UNIX systems.

Reference:

- IEEE Std 1003.1-2008 - crypt() function FIPS.180-3.2008: Secure Hash Standard

sha-512-digest-string

Pattern:

```
'$0$.*'
'|$6$(rounds=\d+$)?[a-zA-Z0-9./]{1,16}$[a-zA-Z0-9./]{86}'
```

The sha-512-digest-string type automatically computes a SHA-512 digest for a value adhering to this type. A value of this type matches one of the forms

- \$0\$<clear text password>
- \$6\$<salt>\$<password hash>
- \$6\$rounds=<number>\$<salt>\$<password hash>

The '\$0\$' prefix signals that this is plain text. When a plain text value is received by the server, a SHA-512 digest is calculated, and the string '\$6\$<salt>\$' is prepended to the

result, where <salt> is a random 16 character salt used to generate the digest. This value is stored in the configuration data store. The algorithm can be tuned through the

/confdConfig/cryptHash/rounds parameter, which if set to a number other than the default will cause '\$6\$rounds=<number>\$<salt>\$' to be prepended instead of only '\$6\$<salt>\$'.

If a value starting with '\$6\$' is received, the server knows that the value already represents a SHA-512 digest, and stores it as is in the data store.

If a default value is specified, it must have a '\$6\$' prefix. The digest algorithm used is the same as the SHA-512 crypt function used for encrypting passwords for various UNIX systems.

Reference:

- IEEE Std 1003.1-2008 - crypt() function FIPS.180-3.2008: Secure Hash Standard

size

Pattern:

```
'S(\d+G)?(\d+M)?(\d+K)?(\d+B)?'
```

A value that represents a number of bytes. An example could be S1G8M7K956B; meaning 1GB + 8MB + 7KB + 956B = 1082138556 bytes.

The value must start with an S. Any byte magnifier can be left out, for example, S1K1B equals 1025 bytes. The order is significant though, that is S1B56G is not a valid byte size.

In ConfD, a 'size' value is represented as an uint64.

uuid

Pattern:

```
'[0-9a-fA-F]{8}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-'[  
'[0-9a-fA-F]{4}-[0-9a-fA-F]{12}'
```

A Universally Unique IDentifier in the string representation defined in RFC 4122. The canonical representation uses lowercase characters. The following is an example of a UUID in string representation: f81d4fae-7dec-11d0-a765-00a0c91e6bf6.

Reference:

- RFC 4122: A Universally Unique Identifier (UUID) URN Namespace

yang-identifier

Pattern:

```
'[a-zA-Z_][a-zA-Z0-9\-\_\.]*'
```

Pattern:

```
'\.\.\. | [^xX] .* | [^mM] .* | \.\. [^1L] .*'
```

A YANG identifier string as defined by the 'identifier' rule in Section 12 of RFC 6020. An identifier must start with an alphabetic character or an underscore followed by an arbitrary sequence of alphabetic or numeric characters, underscores, hyphens, or dots. A YANG identifier MUST NOT start with any possible combination of the lowercase or uppercase character sequence 'xml'.

Reference:

- RFC 6020: YANG - A Data Modeling Language for the Network Configuration Protocol (NETCONF)

