



Send document comments to nexus1k-docfeedback@cisco.com.



Cisco Nexus 1000V Command Reference, Release 4.0(4)SV1(1)

June 21, 2011

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-19423-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco Nexus 1000V Command Reference, Release 4.0(4)SV1(1)
©2009-2011 Cisco Systems, Inc. All rights reserved.



Preface

This preface describes the audience, organization, and conventions of the *Cisco Nexus 1000V Command Reference, Release 4.0(4)SV1(1)*, and how to obtain related documentation.

This chapter includes the following topics:

- [Audience, page iii](#)
- [Organization, page iii](#)
- [Document Conventions, page iv](#)
- [Related Documentation, page v](#)
- [Obtaining Documentation and Submitting a Service Request, page vi](#)

Audience

This publication is for experienced users who configure and maintain the Cisco Nexus 1000V.

Organization

This reference is organized as follows:

Chapter	Description
A Commands	Describes the commands that begin with the letter A.
B Commands	Describes the commands that begin with the letter B.
C Commands	Describes the commands that begin with the letter C.
D Commands	Describes the commands that begin with the letter D.
E Commands	Describes the commands that begin with the letter E.
F Commands	Describes the commands that begin with the letter F.
G Commands	Describes the commands that begin with the letter G.
I Commands	Describes the commands that begin with the letter I.
L Commands	Describes the commands that begin with the letter L.
M Commands	Describes the commands that begin with the letter M.

Text Part Number:

Send document comments to nexus1k-docfeedback@cisco.com.

Chapter	Description
N Commands	Describes the commands that begin with the letter N.
O Commands	Describes the commands that begin with the letter O.
P Commands	Describes the commands that begin with the letter P.
Q Commands	Describes the commands that begin with the letter Q.
R Commands	Describes the commands that begin with the letter R.
S Commands	Describes the commands that begin with the letter S.
Show Commands	Describes the show commands.
T Commands	Describes the commands that begin with the letter T.
U Commands	Describes the commands that begin with the letter U.
V Commands	Describes the commands that begin with the letter V.
W Commands	Describes the commands that begin with the letter W.

Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information that the switch displays are in screen font.
<code>boldface screen font</code>	Information you must enter is in boldface screen font.
<i><code>italic screen font</code></i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.

Send document comments to nexus1k-docfeedback@cisco.com.

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

**Tip**

Means *the following information will help you solve a problem*.

Related Documentation

Cisco Nexus 1000V includes the following documents available on Cisco.com:

General Information

Cisco Nexus 1000V Release Notes, Release 4.0(4)SV1(1)

Cisco Nexus 1000V and VMware Compatibility Information, Release 4.0(4)SV1(1)

Install and Upgrade

Cisco Nexus 1000V Software Installation Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Virtual Ethernet Module Software Installation Guide, Release 4.0(4)SV1(1)

Configuration Guides

Cisco Nexus 1000V License Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Getting Started Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Interface Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Layer 2 Switching Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Quality of Service Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Security Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V System Management Configuration Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V High Availability and Redundancy Reference, Release 4.0(4)SV1(1)

Reference Guides

Cisco Nexus 1000V Command Reference, Release 4.0(4)SV1(1)

Cisco Nexus 1000V MIB Quick Reference

Troubleshooting and Alerts

Cisco Nexus 1000V Troubleshooting Guide, Release 4.0(4)SV1(1)

Cisco Nexus 1000V Password Recovery Guide

Cisco NX-OS System Messages Reference

Send document comments to nexus1k-docfeedback@cisco.com.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.



A Commands

This chapter describes the Cisco Nexus 1000V commands that begin with A.

aaa authentication login console

To configure AAA authentication methods for console logins, use the **aaa authentication login console** command. To revert to the default, use the **no** form of this command.

```
aaa authentication login console {group group-list} [none] | local | none }
```

```
no aaa authentication login console {group group-list [none] | local | none }
```

Syntax Description

group	Specifies to use a server group for authentication.
<i>group-list</i>	Specifies a space-separated list of server groups. The list can include the following: <ul style="list-style-type: none">• radius for all configured RADIUS servers.• tacacs+ for all configured TACACS+ servers.• Any configured RADIUS or TACACS+ server group name.
none	Specifies to use the username for authentication.
local	Specifies to use the local database for authentication.

Defaults

local

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The **group radius**, **group tacacs+**, and **group group-list** methods refer to a set of previously defined RADIUS or TACACS+ servers. Use the **radius-server host** or **tacacs-server host** command to configure the host servers. Use the **aaa group server** command to create a named group of servers.

Use the **show aaa group** command to display the RADIUS server groups on the device.

If you specify more than one server group, the software checks each group in the order that you specify in the list.

If you specify the **group** method or **local** method and they fail, then the authentication can fail. If you specify the **none** method alone or after the **group** method, then the authentication always succeeds.

The command operates only in the default VDC (VDC 1).

Examples

This example shows how to configure the AAA authentication console login methods:

```
n1000v# config t
n1000v(config)# aaa authentication login console group radius
```

This example shows how to revert to the default AAA authentication console login method:

```
n1000v# config t
n1000v(config)# no aaa authentication login console group radius
```

Related Commands

Command	Description
aaa group server	Configures AAA server groups.
radius-server host	Configures RADIUS servers.
show aaa authentication	Displays AAA authentication information.
show aaa group	Displays the AAA server groups.
tacacs-server host	Configures TACACS+ servers.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

aaa authentication login default

To configure the default AAA authentication methods, use the **aaa authentication login default** command. To revert to the default, use the **no** form of this command.

```
aaa authentication login default {group group-list} [none] | local | none}
```

```
no aaa authentication login default {group group-list} [none] | local | none}
```

Syntax Description	group	Specifies a server group list to be used for authentication.
	<i>group-list</i>	Space-separated list of server groups that can include the following: <ul style="list-style-type: none"> • radius for all configured RADIUS servers. • tacacs+ for all configured TACACS+ servers. • Any configured RADIUS or TACACS+ server group name.
	none	(Optional) Specifies to use the username for authentication.
	local	Specifies to use the local database for authentication.

Defaults local

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The **group radius**, **group tacacs+**, and **group group-list** methods refer to a set of previously defined RADIUS or TACACS+ servers. Use the **radius-server host** or **tacacs-server host** command to configure the host servers. Use the **aaa group server** command to create a named group of servers.

Use the **show aaa group** command to display the RADIUS server groups on the device.

If you specify more than one server group, the software checks each group in the order that you specify in the list.

If you specify the **group** method or **local** method and they fail, then the authentication fails. If you specify the **none** method alone or after the **group** method, then the authentication always succeeds.

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure the AAA authentication console login method:

```
n1000v# config t
n1000v(config)# aaa authentication login default group radius
```

This example shows how to revert to the default AAA authentication console login method:

```
n1000v# config t
n1000v(config)# no aaa authentication login default group radius
```

Related Commands

Command	Description
aaa group server	Configures AAA server groups.
radius-server host	Configures RADIUS servers.
show aaa authentication	Displays AAA authentication information.
show aaa group	Displays the AAA server groups.
tacacs-server host	Configures TACACS+ servers.

Send document comments to nexus1k-docfeedback@cisco.com.

aaa authentication login error-enable

To configure an AAA authentication failure message to display on the console, use the **aaa authentication login error-enable** command. To remove the error message, use the **no** form of this command.

aaa authentication login error-enable

no aaa authentication login error-enable

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If none of the remote AAA servers respond when a user logs in, the authentication is processed by the local user database. If you have enabled the display, one of the following message is generated for the user:

```
Remote AAA servers unreachable; local authentication done.
Remote AAA servers unreachable; local authentication failed.
```

Examples This example shows how to enable the display of AAA authentication failure messages to the console:

```
n1000v# config t
n1000v(config)# aaa authentication login error-enable
```

This example shows how to disable the display of AAA authentication failure messages to the console:

```
n1000v# config t
n1000v(config)# no aaa authentication login error-enable
```

■ `aaa authentication login error-enable`

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	<code>show aaa authentication login error-enable</code>	Displays the status of the AAA authentication failure message display.

Send document comments to nexus1k-docfeedback@cisco.com.

aaa authentication login mschap

To enable Microsoft Challenge Handshake Authentication Protocol (MSCHAP) authentication at login, use the **aaa authentication login mschap** command. To disable MSCHAP, use the **no** form of this command.

aaa authentication login mschap

no aaa authentication login mschap

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enable MSCHAP authentication:

```
n1000v# config t
n1000v(config)# aaa authentication login mschap
```

This example shows how to disable MSCHAP authentication:

```
n1000v# config t
n1000v(config)# no aaa authentication login mschap
```

Related Commands	Command	Description
	show aaa authentication login mschap	Displays the status of MSCHAP authentication.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

aaa group server radius

To create a RADIUS server group, use the **aaa group server radius** command. To delete a RADIUS server group, use the **no** form of this command.

aaa group server radius *group-name*

no aaa group server radius *group-name*

Syntax Description	<i>group-name</i>	RADIUS server group name. The name is alphanumeric and case-sensitive. The maximum length is 64 characters.
---------------------------	-------------------	---

Defaults	None
-----------------	------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to create a RADIUS server group and enter RADIUS Server Configuration mode for configuring the specified server group:

```
n1000v# config t
n1000v(config)# aaa group server radius RadServer
n1000v(config-radius)#
```

This example shows how to delete a RADIUS server group:

```
n1000v# config t
n1000v(config)# no aaa group server radius RadServer
```

Related Commands	Command	Description
	show aaa groups	Displays server group information.
	radius-server host	Defines the IP address or hostname for a RADIUS server.

Send document comments to nexus1k-docfeedback@cisco.com.

aaa group server tacacs+

To create a TACACS+ server group, use the **aaa group server tacacs+** command. To delete a TACACS+ server group, use the **no** form of this command.

aaa group server tacacs+ *group-name*

no aaa group server tacacs+ *group-name*

Syntax Description	<i>group-name</i>	TACACS+ server group name. The name is alphanumeric and case-sensitive. The maximum length is 64 characters.
--------------------	-------------------	--

Defaults	None
----------	------

Command Modes	Global Configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You must enable TACACS+ using the tacacs+ enable command before you can configure TACACS+.
------------------	---

Examples This example shows how to create a TACACS+ server group:

```
n1000v# config t
n1000v(config)# aaa group server tacacs+ TacServer
n1000v(config-radius)#
```

This example shows how to delete a TACACS+ server group:

```
n1000v# config t
n1000v(config)# no aaa group server tacacs+ TacServer
```

Related Commands	Command	Description
	tacacs+ enable	Enables TACACS+.
	show aaa groups	Displays server group information.

Send document comments to nexus1k-docfeedback@cisco.com.



B Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter, B.

bandwidth (interface)

To set the inherited and received bandwidth value for an interface, use the **bandwidth** command. To restore the default value, use the **no** form of this command.

bandwidth {*kbps*}

no bandwidth {*kbps*}

Syntax Description	<i>kbps</i>	Intended bandwidth, in kilobits per second. Valid values are 1 to 10000000.
---------------------------	-------------	---

Defaults	1000000 kbps
-----------------	--------------

Command Modes	Interface Configuration (config-if)
----------------------	-------------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The bandwidth command sets an informational parameter to communicate only the current bandwidth to the higher-level protocols; you cannot adjust the actual bandwidth of an interface using this command.
-------------------------	--



Note

This is a routing parameter only. It does not affect the physical interface.

■ bandwidth (interface)

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure the bandwidth 30000 kbps:

```
n1000v(config-if)# bandwidth 30000
```

Related Commands

Command	Description
show interface	Displays the interface configuration information.

Send document comments to nexus1k-docfeedback@cisco.com.

banner motd

To configure a message of the day (MOTD) banner, use the **banner motd** command.

banner motd [*delimiting-character message delimiting-character*]

no banner motd [*delimiting-character message delimiting-character*]

Syntax Description

<i>delimiting-character</i>	The character used to signal the beginning and end of the message text, for example, in the following message, the delimiting character is #. #Testing the MOTD#
<i>message</i>	Specifies the banner message, restricted to 40 lines with a maximum of 80 characters in each line.

Defaults

“User Access Verification” is the default message of the day.

Command Modes

Configuration (config)

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The MOTD banner is displayed on the terminal before the login prompt whenever you log in.

The message is restricted to 40 lines and 80 characters per line.

To create a multiple-line MOTD banner, press Enter before typing the delimiting character to start a new line. You can enter up to 40 lines of text.

Follow these guidelines when choosing your delimiting character:

- Do not use the *delimiting-character* in the *message* string.
- Do not use " and % as delimiters.

Examples

This example shows how to configure and then display a banner message with the text, “Testing the MOTD.”

```
n1000v# config terminal
n1000v(config)# banner motd #Testing the MOTD#
n1000v(config)# show banner motd
Testing the MOTD
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to configure and then display a multiple-line MOTD banner:

```
n1000v(config)# banner motd #Welcome to authorized users.  
> Unauthorized access prohibited.#  
n1000v(config)# show banner motd  
Welcome to authorized users.  
Unauthorized access prohibited.
```

This example shows how to revert to the default MOTD banner:

```
n1000v# config terminal  
n1000v(config)# no banner motd  
n1000v(config)# show banner motd  
User Access Verification
```

Related Commands

Command	Description
show banner motd	Displays the MOTD banner.

Send document comments to nexus1k-docfeedback@cisco.com.

boot auto-copy

To enable automatic copying of boot image files to the standby supervisor module, use the **boot auto-copy** command. To disable automatic copying, use the **no** form of this command.

boot auto-copy

no boot auto-copy

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines When automatic copying of image files is enabled, the Cisco NX-OS software copies the image files referred to by the boot variable to the standby supervisor module. These image files must be present in local memory on the active supervisor module. For kickstart and system boot variables, only those image files that are configured for the standby supervisor module are copied.

Examples This example shows how to enable automatic copying of boot image files to the standby supervisor module:

```
n1000v# configure terminal
n1000v(config)# boot auto-copy
Auto-copy administratively enabled
```

Related Commands	Command	Description
	boot kickstart	Configures the kickstart boot variable.
	boot system	Configures the system boot variable.
	copy	Copies files.
	show boot	Displays boot variable configuration information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

boot kickstart

To configure the boot variable for the kickstart image, use the **boot kickstart** command. To clear the kickstart image boot variable, use the **no** form of this command.

```
boot kickstart [filesystem://directory] | directory]filename [sup-1] [sup-2]
```

```
no boot kickstart
```

Syntax Description	
<i>filesystem</i> :	(Optional) Name of a file system. Valid values are bootflash or slot0 .
<i>//directory</i>	(Optional) Name of a directory. The directory name is case sensitive.
<i>filename</i>	Name of the kickstart image file. The filename is case sensitive.
sup-1	(Optional) Configures the kickstart boot for the active supervisor module only.
sup-2	(Optional) Configures the kickstart boot for the standby supervisor module only.

Defaults Configures the kickstart boot variable for both supervisor modules.

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The kickstart boot variable is used for loading software images when booting up. You must copy the kickstart image to the device before you reload.

Examples This example shows how to configure the kickstart boot variable for both supervisor modules:

```
n1000v# configure terminal
n1000v(config)# boot kickstart bootflash:kickstart-image
```

This example shows how to configure the kickstart boot variable for the active supervisor module:

```
n1000v# configure terminal
n1000v(config)# boot kickstart bootflash:kickstart-image sup-1
```

This example shows how to clear the kickstart boot variable:

```
n1000v# configure terminal
n1000v(config)# no boot kickstart
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	boot system	Configures the boot variable for the system software image.
	copy	Copies files.
	show boot	Displays boot variable configuration information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

boot system

To configure the boot variable for the system image, use the **boot system** command. To clear the system image boot variable, use the **no** form of this command.

```
boot system [filesystem://directory] | directoryfilename [sup-1] [sup-2]
```

```
no boot system
```

Syntax Description	
<i>filesystem</i> :	(Optional) Name of a file system. Valid values are bootflash or slot0 .
<i>//directory</i>	(Optional) Name of a directory. The directory name is case sensitive.
<i>filename</i>	Name of the system image file. The filename is case sensitive.
sup-1	(Optional) Configures the system boot for the sup-1 supervisor module only.
sup-2	(Optional) Configures the system boot for the sup-2 supervisor module only.

Defaults Configures the system boot variable for both supervisor modules.

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The system boot variable is used for loading images when booting up. You must copy the system image to the device before you reload.

Examples This example shows how to configure the system boot variable for both supervisor modules:

```
n1000v# configure terminal
n1000v(config)# boot system bootflash:system-image
```

This example shows how to configure the system boot variable for the sup-1 supervisor module:

```
n1000v# configure terminal
n1000v(config)# boot system bootflash:system-image sup-1
```

This example shows how to clear the system boot variable:

```
n1000v# configure terminal
n1000v(config)# no boot system
```


Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	boot kickstart	Configures the boot variable for the kickstart software image.
	show boot	Displays boot variable configuration information.

Send document comments to nexus1k-docfeedback@cisco.com.



C Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter, C.

cache size

To specify a cache size for a Netflow flow monitor, use the **cache size** command. To remove the cache size for a flow monitor, use the **no** form of this command.

cache size *value*

no cache size *value*

Syntax Description

<i>value</i>	Size in number of entries. The range is 256 to 16384 entries.
--------------	---

Defaults

4096 entries

Command Modes

Netflow Monitor Configuration (**config-flow-monitor**)

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Use the **cache-size** command to limit the impact of the Netflow flow monitor cache on memory and performance.

Examples

This example shows how to configure the cache size for a Netflow flow monitor named MonitorTest, and then display the configuration:

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v# config t
n1000v(config)# flow monitor MonitorTest
n1000v(config-flow-monitor)# cache size 15000
n1000v(config-flow-monitor)# show flow monitor MonitorTestFlow
Monitor monitorTest:
  Use count: 0
  Inactive timeout: 600
  Active timeout: 1800
  Cache Size: 15000
n1000v(config-flow-monitor)#
```

This example shows how to remove a cache size from a flow monitor:

```
n1000v# config t
n1000v(config)# flow monitor MonitorTest
n1000v(config-flow-monitor)# no cache size
n1000v(config-flow-monitor)# show flow monitor MonitorTestFlow
n1000v(config-flow-monitor)#
Monitor monitorTest:
  Use count: 0
  Inactive timeout: 600
  Active timeout: 1800
  Cache Size: 4096
n1000v(config-flow-monitor)#
```

Related Commands

Command	Description
show flow monitor	Displays information about the flow monitor cache module.
flow monitor	Creates a flow monitor.
timeout	Specifies an aging timer and its value for aging entries from the cache.
record	Adds a flow record to the flow monitor.
exporter	Adds a flow exporter to the flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

capability

To set a particular profile capability, use the **capability** command. To remove the profile capability, use the **no** form of this command.

capability {uplink | l3control}

no capability [uplink | l3control]

Syntax Description

uplink	Sets the uplink capability for this profile.
l3control	Sets the L3AIPC capability for this profile. Used for configuring ERSPAN enabled port profiles for l3 control.

Defaults

None

Command Modes

Port Profile Configuration (config-port-prof)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

This command allows the port to be used as an uplink port. In vCenter Server, the port groups with uplink port profiles can be selected and assigned to physical ports (a vmnic or a pnic).



Note

If a port profile is configured as an uplink, then it cannot be used to configure VMware virtual ports.

Examples

This example shows how to configure a particular port profile capability:

```
n1000v(config-port-prof)# capability uplink
```

This example shows how to remove the port profile configuration:

```
n1000v(config)# no capability uplink
```

Related Commands

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
port-profile	Places you into CLI Global Configuration mode for configuring the specified port profile.
show port-profile name	Displays information about the port profile(s).

Send document comments to nexus1k-docfeedback@cisco.com.

cd

To change to a different directory from the one you are currently working in, use the **cd** command.

```
cd [filesystem:[//directory] | directory]
```

Syntax Description	
<i>filesystem:</i>	(Optional) Name of the file system. Valid file systems are bootflash and volatile .
<i>//directory</i>	(Optional) Name of the directory. The directory name is case sensitive.

Defaults	bootflash
----------	------------------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin
--------------------	---------------

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	<p>You can only change to the directories that are on the active supervisor module.</p> <p>Use the present working directory (pwd) command to verify the name of the directory you are currently working in.</p>
------------------	---

Examples	<p>This example shows how to change to a different directory on the current file system:</p>
----------	--

```
n1000v# cd my-scripts
```

This example shows how to change from the file system you are currently working in to a different file system:

```
n1000v# cd volatile:
```

This example shows how to revert back to the default directory, bootflash:

```
n1000v# cd
```

Related Commands	Command	Description
	pwd	Displays the name of the directory you are currently working in.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp advertise

To specify the CDP version to advertise, use the **cdp advertise** command. To remove the cdp advertise configuration, use the **no** form of this command.

cdp advertise {v1 | v2}

no cdp advertise [v1 | v2]

Syntax Description	v1	CDP Version 1.
	v2	CDP Version 2.

Defaults CDP Version 2

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to set CDP Version 1 as the version to advertise:

```
n1000v(config)# cdp advertise v1
```

This example shows how to remove CDP Version 1 as the configuration to advertise:

```
n1000v(config)# no cdp advertise v1
```

Related Commands	Command	Description
	show cdp global	Displays the CDP configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp enable (global)

To enable Cisco Discovery Protocol (CDP) globally on all interfaces and port channels, use the **cdp enable** command. To disable CDP globally, use the **no** form of this command.

cdp enable

no cdp enable

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines CDP can only be configured on physical interfaces and port channels.

Examples This example shows how to enable CDP globally and then show the CDP configuration:

```
n1000v# config t
n1000v(config)# cdp enable
n1000v(config)# show cdp global
Global CDP information:
  CDP enabled globally
  Refresh time is 60 seconds
  Hold time is 180 seconds
  CDPv2 advertisements is enabled
  DeviceID TLV in System-Name(Default) Format
```

This example shows how to disable CDP globally and then show the CDP configuration:

```
n1000v(config)# no cdp enable
n1000v# show cdp global
Global CDP information:
  CDP disabled globally
  Refresh time is 60 seconds
  Hold time is 180 seconds
  CDPv2 advertisements is enabled
  DeviceID TLV in System-Name(Default) Format
n1000v(config)#
```

■ **cdp enable (global)**

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show cdp global	Displays the CDP configuration.
	cdp enable (interface or port channel)	Enables CDP on an interface or port channel.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp enable (interface or port channel)

To enable Cisco Discovery Protocol (CDP) on an interface or port channel, use the **cdp enable** command. To disable it, use the **no cdp enable** form of this command.

cdp enable

no cdp enable

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Interface Configuration (config-if)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines CDP must be enabled globally before you configure the device ID format. CDP can only be configured on physical interfaces and port channels.

Examples This example shows how to enable CDP on port channel 2:

```
n1000v# config t
n1000v(config)# interface port-channel2
n1000v(config-if)# cdp enable
n1000v(config-if)#
```

This example shows how to disable CDP on mgmt0:

```
n1000v# config t
n1000v(config)# interface mgmt0
n1000v(config-if)# no cdp enable
n1000v(config-if)# show cdp interface mgmt0
    mgmt0 is up
    CDP disabled on interface
    Sending CDP packets every 60 seconds
    Holdtime is 180 seconds
n1000v(config-if)#
```

cdp enable (interface or port channel)

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show cdp interface	Displays the CDP configuration for an interface.
	show cdp neighbors	Displays your device from the upstream device.
	cdp advertise	Assigns the CDP version the interface will advertise—CDP Version 1 or CDP Version 2.
	cdp format device ID	Assigns the CDP device ID
	cdp holdtime	Sets the maximum amount of time that CDP holds onto neighbor information before discarding it.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp format device-id

To specify the device ID format for CDP, use the **cdp format device-id** command. To remove it, use the **no** form of this command.

```
cdp format device-id { mac-address | serial-number | system-name }
```

```
no cdp format device-id { mac-address | serial-number | system-name }
```

Syntax Description

mac-address	MAC address of the Chassis.
serial-number	Chassis serial number.
system-name	System name/Fully Qualified Domain Name (Default).

Defaults

System name/Fully Qualified Domain Name

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

CDP must be enabled globally before you configure the device ID format. You can configure CDP on physical interfaces and port channels only.

Examples

This example shows how to configure the CDP device ID with the MAC address format and then display the configuration:

```
n1000v(config)# cdp format device-id mac-address
n1000v(config)# show cdp global
Global CDP information:
CDP enabled globally
  Sending CDP packets every 5 seconds
  Sending a holdtime value of 10 seconds
  Sending CDPv2 advertisements is disabled
  Sending DeviceID TLV in Mac Address Format
```

This example shows how to remove the CDP device ID MAC address format from the configuration:

```
n1000v(config)# no cdp format device-id mac-address
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show cdp global	Displays CDP global configuration parameters.
show cdp interface	Displays the CDP configuration for an interface.
show cdp neighbors	Displays your device from the upstream device.
cdp advertise	Assigns the CDP version the interface will advertise—CDP Version 1 or CDP Version 2.
cdp enable interface	Enables CDP on an interface or port channel.
cdp holdtime	Sets the maximum amount of time that CDP holds onto neighbor information before discarding it.

Send document comments to nexus1k-docfeedback@cisco.com.

cdp holdtime

To do set the maximum amount of time that CDP holds onto neighbor information before discarding it, use the **cdp holdtime** command. To remove the CDP holdtime configuration, use the **no** form of this command.

cdp holdtime *seconds*

no cdp holdtime *seconds*

Syntax Description	<i>seconds</i>	The range is from 10 to 255 seconds.
--------------------	----------------	--------------------------------------

Defaults	180 seconds
----------	-------------

Command Modes	Global Configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	CDP must be enabled globally before you configure the device ID format. You can configure CDP on physical interfaces and port channels only.
------------------	--

Examples	This example shows how to set the CDP holdtime to 10 second:
----------	--

```
n1000v(config)# cdp holdtime 10
```

Examples	This example shows how to remove the CDP holdtime configuration:
----------	--

```
n1000v(config)# no cdp holdtime 10
```

Related Commands	Command	Description
	show cdp global	Displays CDP global configuration parameters.
	show cdp neighbors	Displays the upstream device from your device.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

cdp timer

To set the refresh time for CDP to send advertisements to neighbors, use the **cdp timer** command. To remove the CDP timer configuration, use the **no** form of this command.

cdp timer *seconds*

no cdp timer *seconds*

Syntax Description	<i>seconds</i>	The range is from 5 to 254 seconds.
---------------------------	----------------	-------------------------------------

Defaults	60 seconds
-----------------	------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure the CDP timer to 10 seconds:

```
n1000v(config)# cdp timer 10
```

This example shows how to remove the CDP timer configuration:

```
n1000v(config)# no cdp timer 10
```

Related Commands	Command	Description
	show cdp global	Displays CDP global configuration parameters.
	show cdp neighbors	Displays the upstream device from your device.

Send document comments to nexus1k-docfeedback@cisco.com.

channel-group auto (port profile)

To create and define a channel group for all interfaces belonging to a port profile, use the **channel-group auto** command. To remove the channel-group, use the **no** form of this command.

channel-group auto [*mode channel_mode*] [**sub-group cdp**]

no channel-group

Syntax Description	
mode <i>channel_mode</i>	(Optional) Specify a channeling mode: <ul style="list-style-type: none"> • on • active (uses LACP) • passive (uses LACP)
sub-group cdp	(Optional) Creates subgroups, using CDP, for managing the traffic flow when the port profile connects to two upstream switches, also called virtual port channel host mode (vPC-HM).

Defaults	
	None

Command Modes	
	Port Profile Configuration (config-port-prof)

SupportedUserRoles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The **channel-group auto** command creates a unique port channel for all interfaces belonging to the same module. The channel-group is automatically assigned when the port profile is assigned to the first interface. Each additional interface belonging to the same module is added to the same port-channel. In VMware environments, a different port channel is created for each module.

- The channel group mode must be set to **on**.
- When configuring a port channel for a port profile that connects to two upstream switches, also called virtual port channel host mode (vPC-HM):

- You know whether CDP is configured in the upstream switches.

If so, then CDP creates a subgroup for each upstream switch to manage its traffic separately.

If CDP is not configured in the upstream switch, then you must manually configure subgroups to manage the traffic flow on the separate switches.

Send document comments to nexus1k-docfeedback@cisco.com.

- If vPC-HM is not configured when port channels connect to two different upstream switches, then the VMs behind the Cisco Nexus 1000V receive duplicate packets from the network for broadcast/unknown floods/multicast.

vPC-HM can also be configured on the interface. For more information, see the *Cisco Nexus 1000V Interface Configuration Guide, Release 4.0(4)SV1(1)*.

Examples

This example shows how to configure a port channel for a port profile that connects to a single upstream switch, and then display the configuration:

```
n1000v# config t
n1000v(config)# port-profile AccessProf
n1000v(config-port-prof)# channel-group auto mode on
n1000v(config-port-prof)# show port-profile name AccessProf
port-profile AccessProf
  description: allaccess4
  status: disabled
  capability uplink: yes
  port-group: AccessProf
  config attributes:
    switchport mode access
    channel-group auto mode on
  evaluated config attributes:
    switchport mode access
    channel-group auto mode on
  assigned interfaces:
n1000v(config-port-prof)#
```

This example shows how to remove the channel group configuration from the port profile and then display the configuration:

```
n1000v# config t
n1000v(config)# port-profile AccessProf
n1000v(config-port-prof)# no channel-group
n1000v(config-port-prof)# show port-profile name AccessProf
port-profile AccessProf
  description: allaccess4
  status: disabled
  capability uplink: yes
  port-group: AccessProf
  config attributes:
    switchport mode access
  evaluated config attributes:
    switchport mode access
  assigned interfaces:
n1000v(config-port-prof)#
```

This example shows how to configure an uplink port profile, to be used by the physical NICs in the VEM, in vPC-HM when the ports in the port channel connect to two different upstream switches:

```
n1000v# config t
n1000v(config)# port-profile uplinkProf
n1000v(config-port-prof)# channel-group auto mode on sub-group cdp
n1000v(config-port-prof)# show port-profile name uplinkProf
port-profile uplinkProf
  description:
  status: disabled
  capability uplink: no
  capability l3control: no
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
system vlans: none
port-group:
max-ports: 32
inherit:
config attributes:
  channel-group auto mode on sub-group cdp
evaluated config attributes:
  channel-group auto mode on sub-group cdp
assigned interfaces:
n1000v(config-port-prof)#
```

Related Commands

Command	Description
show port-profile <i>name profile-name</i>	Displays the port profile configuration.
port-profile <i>profile-name</i>	Creates a port profile and places you into CLI Global Configuration mode for the named port profile.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

channel-group (interface)

To create a port channel group or to move an interface from one port channel group to another, use the **channel-group** command. To remove the channel group configuration from an interface, use the **no** form of this command.

channel-group *number* [**force**] [**mode** {**active** | **on** | **passive**}]

no channel-group [*number*]

Syntax Description	
<i>number</i>	Number of the channel group. The maximum number of port channels that can be configured is 256. The allowable range of channel group numbers that can be assigned is from 1 to 4096.
force	Forces the interface to join the channel group, although some parameters are not compatible. See Usage Guidelines below for information about the compatibility parameters and which ones can be forced.
mode	Specifies the port channel mode of the interface.
on	This is the default channel mode. All port channels that are not running LACP remain in this mode. If you attempt to change the channel mode to active or passive before enabling LACP, the device returns an error message. After you enable LACP globally, you enable LACP on each channel by configuring the channel mode as either active or passive. An interface in this mode does not initiate or respond to LACP packets. When an LACP attempts to negotiate with an interface in the on state, it does not receive any LACP packets and becomes an individual link with that interface; it does not join the channel group.
active	Specifies that when you enable the Link Aggregation Control Protocol (LACP), this command enables LACP on the specified interface. Interface is in active negotiating state, in which the port initiates negotiations with other ports by sending LACP packets.
passive	Specifies that when you enable LACP, this command enables LACP only if an LACP device is detected. The interface is in a passive negotiation state, in which the port responds to LACP packets that it receives but does not initiate LACP negotiation.

Defaults The default mode is **on**.

Command Modes Interface Configuration (config-if)

Supported User Roles network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

A port channel in the **on** channel mode is a pure port channel and can aggregate a maximum of eight ports. It does not run LACP.

If an existing port channel is not running LACP you cannot change the mode for it or any of its interfaces. If you try to do so, the channel mode remains **on** and an error message is generated.

When you delete the last physical interface from a port channel, the port channel remains. To delete the port channel completely, use the **no** form of the **port-channel** command.

When an interface joins a port channel, the following attributes are removed and replaced with the those of the port channel:

- Bandwidth
- Delay
- Extended Authentication Protocol over UDP
- VRF
- IP address
- MAC address
- Spanning Tree Protocol
- NAC
- Service policy
- Quality of Service (QoS)
- ACLs

The following attributes remain unaffected when an interface joins or leaves a port channel:

- Beacon
- Description
- CDP
- LACP port priority
- Debounce
- UDLD
- MDIX
- Rate mode
- Shutdown
- SNMP trap

You do not have to create a port channel interface before you assign a physical interface to a channel group. A port channel interface is created automatically when the channel group gets its first physical interface, if it is not already created.

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to add an interface to LACP channel group 5 in active mode:

```
n1000v(config-if)# channel-group 5 mode active
n1000v(config-if)#
```

Related Commands

Command	Description
show interface port-channel	Displays information about the traffic on the specified port channel interface.
show port-channel summary	Displays information on the port channels.
feature lacp	Enables the LACP feature globally
show lacp port-channel	Displays LACP information.
show port-channel compatibility-parameters	Displays the list of compatibility checks that the Cisco Nexus 1000V uses.

Send document comments to nexus1k-docfeedback@cisco.com.

check logflash

To check the compactFlash, use the **check logflash** command.

```
check logflash [bad-blocks]
```

Syntax Description	bad-blocks	(Optional) Finds bad blocks in compactFlash.
--------------------	------------	--

Defaults	None
----------	------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to check compactFlash:
----------	---

```
n1000v# check logflash
```

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

class (policy map type qos)

To add an existing Quality of Service (QoS) class to a policy map, use the **class** command. To remove a QoS class from a policy map, use the **no** form of this command.

```
class [type qos] {class-map-name | class-default} [insert-before [type qos]
before-class-map-name]

no class {class-map-name | class-default}
```

Syntax Description		
type qos	(Optional) Specifies the class type to be QoS. QoS is the default class type.	
<i>class-map-name</i>	Adds the specified name of an existing class to the policy map.	
class-default	Adds the class-default to a policy map. The class-default matches all traffic not classified in other classes.	
insert-before <i>before-class-map-name</i>	(Optional) Specifies the sequence of this class in the policy by identifying the class map it should precede. If not specified, the class is placed at the end of the list of classes in the policy. Policy actions in the first class that matches the traffic type are performed.	

Defaults

type QoS

The default is to reference a new class map at the end of the policy map.

The class named class-default matches all traffic not classified in other classes.

Command Modes

Policy Map Configuration (**config-pmap**)

Supported User Roles

network-admin

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Policy actions in the first class that matches the traffic type are performed.

The class named class-default matches all traffic not classified in other classes.

Examples

This example shows how to add a class map in sequence to the end of a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap)# class traffic_class2
n1000v(config-pmap-c-qos)#
```


Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to insert a class map in sequence before an existing class map in a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap-qos)# class insert-before traffic_class2 traffic_class1
n1000v(config-pmap-c-qos)#
```

This example shows how to add the class-default class map to a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap-qos)# class class-default
n1000v(config-pmap-c-qos)#
```

This example shows how to remove a class map reference from a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap)# no class traffic_class1
n1000v(config-pmap)#
```

Related Commands

Command	Description
policy-map	Creates or modifies a policy map.
set cos	Assigns a CoS to a QoS policy map.
set dscp	Assigns a DSCP value for a traffic class in a QoS policy map.
set precedence	Assigns a precedence value for the IP headers in a specific traffic class in a QoS policy map.
set discard-class	Assigns a discard-class value for a class of traffic in a QoS policy map.
show class-map qos	Displays class maps.
show policy-map	Displays policy maps and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

class-map

To create or modify a QoS class map that defines a class of traffic, use the **class-map** command. To remove a class map, use the **no** form of this command.

```
class-map [type qos] [match-any | match-all] class-map-name
```

```
no class-map [type qos] [match-any | match-all] class-map-name
```

Syntax Description		
type qos	(Optional) Specifies the component type QoS for the class map. By default, the class map type is QoS.	
match-any	(Optional) Specifies that if the packet matches any of the matching criteria configured for this class map, then this class map is applied to the packet.	
match-all	(Optional) Specifies that if the packet matches all the matching criteria configured for this class map, then this class map is applied to the packet. This is the default action if match-any is not specified.	
<i>class-map-name</i>	Name assigned to the class map. The name class-default is reserved.	

Defaults	
type QoS	
match-all	

Command Modes	
Global configuration (config)	

SupportedUserRoles	
network-admin	

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
Hyphen, underscore, and alphabetic characters are allowed in the class map name.	
Forty characters are the maximum allowed in the class map name.	
Characters in the class map name are case sensitive.	

Examples This example shows how to create a class map and enter the QoS class map configuration mode to configure the specified map:

```
n1000v# configure terminal
n1000v(config)# class-map my_class1
n1000v(config-cmap-qos)#
```

This example shows how to remove the QoS class map named *my_class1*:

```
n1000v(config)# no class-map my_class1
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config)#
```

Related Commands

Command	Description
show class-map qos	Displays class maps.
match class-map	Configures the traffic class by matching packets based on match criteria in another class map.
match packet length	Configures the traffic class by matching packets based on packet lengths.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear access-list counters

To clear the counters for IP and MAC access control list(s) (ACLs), use the **clear access-list counters** command.

```
clear access-list counters [access-list-name]
```

Syntax Description	<i>access-list-name</i> (Optional) Name of the ACL whose counters the device clears. The name can be up to 64 alphanumeric, case-sensitive characters.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If you specify an ACL, the name can be up to 64 alphanumeric, case-sensitive characters.
-------------------------	--

Examples	This example shows how to clear counters for all IP and MAC ACLs:
-----------------	---

```
n1000v# clear access-list counters
n1000v#
```

This example shows how to clear counters for an IP ACL named acl-ip-01:

```
n1000v# clear access-list counters acl-ip-01
n1000v#
```

Related Commands	Command	Description
	clear ip access-list counters	Clears counters for IP ACLs.
	clear mac access-list counters	Clears counters for MAC ACLs.
	show access-lists	Displays information about one or all IP and MAC ACLs.

Send document comments to nexus1k-docfeedback@cisco.com.

clear cdp

To clear Cisco Discovery Protocol(CDP) information on an interface, use the **clear cdp** command.

```
clear cdp {counters [interface slot/port] | table [interface slot/port]}
```

Syntax Description	counters	Clear CDP counters on all interfaces.
	interface <i>slot/port</i>	(Optional) Clear CDP counters on a specified interface .
	table	Clear CDP cache on all interfaces.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear CDP counters on all interfaces:

```
n1000V# clear cdp counters
```

This example shows how to clear CDP cache on all interfaces:

```
n1000V# clear cdp table
```

Related Commands	Command	Description
	show cdp all	Displays all interfaces that have CDP enabled.
	show cdp entry	Displays the CDP database entries
	show cdp global	Displays the CDP global parameters.
	show cdp interface <i>interface-type slot-port</i>	Displays the CDP interface status

Send document comments to nexus1k-docfeedback@cisco.com.

clear cli history

To clear the history of commands you have entered into the CLI, use the **clear cli history** command.

```
clear cli history
```

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use the **show cli history** command to display the history of the commands that you entered at the command-line interface (CLI).

Examples This example shows how to clear the command history:

```
n1000v# clear cli history
```

Related Commands	Command	Description
	show cli history	Displays the command history.

Send document comments to nexus1k-docfeedback@cisco.com.

clear cores

To clear the core files, use the **clear cores** command.

clear cores [**archive**]

Syntax Description	archive	(Optional) Clears the core file on the logflash filesystem.
--------------------	---------	---

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Use the show system cores command to display information about the core files.
------------------	---

Examples	This example shows how to clear the core file:
----------	--

```
n1000v# clear cores
```

Examples	This example shows how to clear the core on the logflash filesystem:
----------	--

```
n1000v# clear cores archive
```

Related Commands	Command	Description
	show system cores	Displays the core filename.
	system cores	Configures the core filename.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear counters

To clear interface counters, use the **clear counters** command.

```
clear counters [ interface {all | ethernet slot/port | loopback virtual-interface-number | mgmt |
port-channel port-channel-number | vethernet interface-number} ]
```

Syntax Description		
	interface	Clears interface counters.
	all	Clears all interface counters.
	ethernet <i>slot/port</i>	Clears Ethernet interface counters. The range is 1 to 66.
	loopback <i>virtual-interface-number</i>	Clears loopback interface counters. The range is 0 to 1023.
	mgmt	Clears the management interface (mgmt0).
	port-channel <i>port-channel-number</i>	Clears port-channel interfaces. The range is 1 to 4096.
	vethernet <i>interface-number</i>	Clears virtual Ethernet interfaces. The range is 1 to 1048575.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear the Ethernet interface counters:

```
n1000v(config)# clear counters ethernet 2/1
```

Related Commands	Command	Description
	show interface counters	Displays the interface status, which includes the counters.

Send document comments to nexus1k-docfeedback@cisco.com.

clear debug-logfile

To clear the contents of the debug logfile, use the **clear debug-logfile** command.

clear debug-logfile *filename*

Syntax Description	<i>filename</i>	Name of the debug logfile to clear.
---------------------------	-----------------	-------------------------------------

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear the debug logfile:

```
n1000v# clear debug-logfile syslogd_debugs
```

Related Commands	Command	Description
	debug logfile	
debug logging		Enable debug logging.
show debug logfile		Displays the contents of the debug logfile.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear flow exporter

To clear the statistics for a Flexible NetFlow flow exporter, use the **clear flow exporter** command in Any.

```
clear flow exporter { name exporter-name | exporter-name }
```

Syntax Description

name	Indicates that a flow exporter will be specified by name.
<i>exporter-name</i>	Name of an existing flow exporter.

Command Default

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

You must have already enabled traffic monitoring with Flexible NetFlow using an exporter before you can use the **clear flow exporter** command.

Examples

The following example clears the statistics for the flow exporter named NFC-DC-PHOENIX:

```
n1000v# clear flow exporter name NFC-DC-PHOENIX
n1000v#
```

Related Commands

Command	Description
clear flow exporter	Clears the statistics for exporters.
flow exporter	Creates a flow exporter.
show flow exporter	Displays flow exporter status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ip access-list counters

To clear the counters for IP access control lists (ACLs), use the **clear ip access-list counters** command.

```
clear ip access-list counters [access-list-name]
```

Syntax Description	<i>access-list-name</i> (Optional) Name of the IP ACL whose counters you want cleared. The name can be up to 64 alphanumeric, case-sensitive characters.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If specifying an ACL by name, it can be up to 64 alphanumeric, case-sensitive characters.
-------------------------	---

Examples This example shows how to clear counters for all IP ACLs:

```
n1000v# clear ip access-list counters
n1000v#
```

This example shows how to clear counters for an IP ACL named acl-ip-101:

```
n1000v# clear ip access-list counters acl-ip-101
n1000v#
```

Related Commands	Command	Description
	clear access-list counters	Clears counters for IP and MAC ACLs.
	clear mac access-list counters	Clears counters for MAC ACLs.
	show access-lists	Displays information about one or all IP and MAC ACLs.
	show ip access-lists	Displays information about one or all IP ACLs.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear ip igmp interface statistics

To clear the IGMP statistics for an interface, use the **clear ip igmp interface statistics** command.

```
clear ip igmp interface statistics [if-type if-number]
```

Syntax Description		
	<i>if-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>if-number</i>	(Optional) Interface number.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin network-operator
-----------------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
-------------------------	--

Examples	This example shows how to clear IGMP statistics for an interface:
-----------------	---

```
n1000v# clear ip igmp interface statistics ethernet 2/1
n1000v#
```

Related Commands	Command	Description
	show ip igmp interface	Displays information about IGMP interfaces.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear ip igmp snooping statistics vlan

To clear the IGMP snooping statistics for VLANs, use the **clear ip igmp snooping statistics vlan** command.

```
clear ip igmp snooping statistics vlan {vlan-id | all}
```

Syntax Description	
<i>vlan-id</i>	VLAN number. The range is from 1 to 3967 and 4048 to 4093.
all	Applies to all VLANs.

Defaults None

Command Modes Any

Supported User Roles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear IGMP snooping statistics for VLAN 1:

```
n1000v# clear ip igmp snooping statistics vlan 1
n1000v#
```

Related Commands	Command	Description
	show ip igmp snooping statistics vlan	Displays IGMP snooping statistics by VLAN.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear lacp counters

To clear the statistics for all interfaces for Link Aggregation Control Protocol (LACP) groups, use the **clear lacp counters** command.

```
clear lacp counters [interface port-channel channel-number]
```

Syntax Description	<i>channel-number</i> (Optional) LACP port-channel number. The range of values is from 1 to 4096.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	<p>If you clear counters for a specific port channel, the allowable port channel numbers are from 1 to 4096.</p> <p>If you do not specify a channel number, the LACP counters for all LACP port groups are cleared.</p> <p>If you clear counters for a static port-channel group, without the aggregation protocol enabled, the device ignores the command.</p>
-------------------------	---

Examples	This example shows how to clear all the LACP counters:
-----------------	--

```
n1000v(config)# clear lacp counters
n1000v(config) #
```

This example shows how to clear all LACP counters for the LACP port-channel group 20:

```
n1000v(config)# clear lacp counters interface port-channel 20
n1000v(config) #
```

Related Commands	Command	Description
	show lacp counters	Displays information about LACP statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

clear license

To uninstall a license file from a VSM, or to uninstall an evaluation license before installing a permanent license, use the **clear license** command.

clear license *filename*

Syntax Description	<i>filename</i>	Name of the license file to be uninstalled.
---------------------------	-----------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If a license is in use, you cannot uninstall it. Before uninstalling the license file, all licenses must first be transferred from the VEMs to the VSM license pool.



Caution

Service Disruption

When you uninstall a license file from a VSM, the vEthernet interfaces on the VEMs are removed from service and the traffic flowing to them from virtual machines is dropped. This traffic flow is not resumed until you add a new license file with licenses for the VEMs. We recommend notifying the server administrator that you are uninstalling a license and that this will cause the vEthernet interfaces to shut down.

Examples

This example shows how to remove the Enterprise.lic license file from a VSM:

```
n1000v# clear license Enterprise.lic
Clearing license Enterprise.lic:
SERVER this_host ANY
VENDOR cisco

Do you want to continue? (y/n) y
Clearing license ..done
n1000v#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show license	Displays license information.
	install license	Installs a license file(s) on a VSM
	svs license transfer src-vem	Transfers licenses from a source VEM to another VEM, or to the VSM pool of available licenses.

Send document comments to nexus1k-docfeedback@cisco.com.

clear line

To end a session on a specified vty, use the **clear line** command.

clear line *word*

Syntax Description	<i>word</i>	Specifies the vty name.
--------------------	-------------	-------------------------

Defaults	None
----------	------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin network-operator
--------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to end a session on a specified vty:
----------	---

```
n1000v(config)# clear line
```

Related Commands	Command	Description
	show users	Displays active user sessions.

■ clear logging logfile

Send document comments to nexus1k-docfeedback@cisco.com.

clear logging logfile

Use the **clear logging logfile** command to clear messages from the logging file.

clear logging logfile

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles Super user

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear messages from the logging file:

```
n1000v# clear logging logfile
n1000v#
```

Related Commands	Command	Description
	show logging logfile	Displays the logs in the local log file.

Send document comments to nexus1k-docfeedback@cisco.com.

clear logging session

Use the **clear logging session** command to clear the current logging session.

clear logging session

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles Super user

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear the current logging session:

```
n1000v# clear logging session
n1000v#
```

Related Commands	Command	Description
	show logging session	Displays logging session status

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear mac access-list counters

To clear the counters for MAC access control lists (ACLs), use the **clear mac access-list counters** command.

```
clear mac access-list counters [access-list-name]
```

Syntax Description	<i>access-list-name</i> (Optional) Name of the MAC ACL whose counters you want to clear. The name can be up to 64 alphanumeric, case-sensitive characters.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If you want counters cleared for a specific MAC ACL, the name can be up to 64 alphanumeric, case-sensitive characters.
-------------------------	--

Examples This example shows how to clear counters for all MAC ACLs:

```
n1000v# clear mac access-list counters
n1000v#
```

This example shows how to clear counters for a MAC ACL named acl-mac-0060:

```
n1000v# clear mac access-list counters acl-mac-0060
n1000v#
```

Related Commands	Command	Description
	clear access-list counters	Clears counters for IP and MAC ACLs.
	clear ip access-list counters	Clears counters for IP ACLs.
	show access-lists	Displays information about one or all IP and MAC ACLs.
	show mac access-lists	Displays information about one or all MAC ACLs.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear mac address-table dynamic

To clear the dynamic address entries from the MAC address table in Layer 2, use the **clear mac address-table dynamic** command.

```
clear mac address-table dynamic [[address mac_addr] [vlan vlan-id] [interface {type slot/port | port-channel number}]
```

Syntax Description	address <i>mac_addr</i>	(Optional) Specifies the MAC address to remove from the table. Use the format XXXX.XXXX.XXXX.
	vlan <i>vlan-id</i>	(Optional) Specifies the VLAN from which the MAC address should be removed from the table. The range of valid values is from 1 to 4094.
	interface { <i>type slot/port port-channel number</i> }]	(Optional) Specifies the interface. Use either the type of interface, the slot number, and the port number, or the port-channel number.

Defaults None

Command Modes Any

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use the **clear mac address-table dynamic** command with no arguments to remove all dynamic entries from the table.

To clear static MAC addresses from the table, use the **no mac address-table static** command.

If the **clear mac address-table dynamic** command is entered with no options, all dynamic addresses are removed. If you specify an address but do not specify an interface, the address is deleted from all interfaces. If you specify an interface but do not specify an address, the device removes all addresses on the specified interfaces.

Examples This example shows how to clear all the dynamic Layer 2 entries from the MAC address table:

```
n1000v(config)# clear mac address-table dynamic
n1000v(config) #
```

This example shows how to clear all the dynamic Layer 2 entries from the MAC address table for VLAN 20 on port 2/20:

clear mac address-table dynamic

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config)# clear mac address-table dynamic vlan 20 interface ethernet 2/20
n1000v(config)#
```

Related Commands

Command	Description
show mac address-table	Displays the information about the MAC address table.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ntp statistics

To clear the Network Time Protocol statistics, use the **clear ntp statistics** command.

```
clear ntp statistics {all-peers | io | local | memory}
```

Syntax Description		
	all-peers	Clear statistics for all NTP peers.
	io	Clear IO statistics.
	local	Clear local statistics.
	memory	Clear memory statistics.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear statistics for all NTP peers:

```
n1000v(config)# clear ntp statistics all-peers
```

Related Commands	Command	Description
	show ntp peers	Displays information about NTP peers.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear port-security

To clear dynamically-learned, secure MAC address(es), use the **clear port-security** command.

```
clear port-security {dynamic} {interface vethernet veth-number | address address} [vlan
vlan-id]
```

Syntax Description	dynamic	Specifies that you want to clear dynamically-learned, secure MAC addresses.
	interface vethernet veth-number	Specifies the interface of the dynamically learned, secure MAC addresses that you want to clear.
	address address	Specifies a single MAC address to be cleared, where <i>address</i> is the MAC address.
	vlan vlan-id	Specifies the VLAN of the secure MAC addresses to be cleared. Valid VLAN IDs are from 1 to 4096.

Defaults dynamic

Command Modes Any

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to remove dynamically learned, secure MAC addresses from the veth1 interface:

```
n1000v# config t
n1000v(config)# clear port-security dynamic interface veth 1
```

This example shows how to remove the dynamically learned, secure MAC address 0019.D2D0.00AE:

```
n1000v# config t
n1000v(config)# clear port-security dynamic address 0019.D2D0.00AE
```

Related Commands

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
debug port-security	Provides debugging information for port security.
show port-security	Shows information about port security.
switchport port-security	Enables port security on a Layer 2 interface.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clear qos statistics

To clear the counters for QoS statistics, use the **clear qos statistics** command.

```
clear qos statistics {interface [ethernet type/slot | vethernet number | port-channel number] }
                    [input type qos | output type qos]
```

Syntax Description	
interface	(Optional) Identifies a specific interface for which to clear statistics.
input type qos	(Optional) Clears only input QoS statistics.
output type qos	(Optional) Clears only output QoS statistics.

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If you do not specify an interface, the counters are cleared for all interfaces.
------------------	--

Examples	This example shows how to clear QoS statistics for all interfaces:
----------	--

```
n1000v# clear qos statistics
n1000v#
```

This example shows how to clear all input QoS statistics for veth2:

```
n1000v# clear qos statistics veth2 input type qos
n1000v#
```

Related Commands	Command	Description
	qos statistics	Enables or disables QoS statistics.
	show qos statistics	Displays QoS statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

clear ssh hosts

To clear the Secure Shell (SSH) host sessions, use the **clear ssh hosts** command.

clear ssh hosts

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear all SSH host sessions:

```
n1000v# clear ssh hosts
```

Related Commands	Command	Description
	ssh server enable	Enables the SSH server.

Send document comments to nexus1k-docfeedback@cisco.com.

clear system reset-reason

To clear the device reset-reason history, use the **clear system reset-reason** command.

clear system reset-reason

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to clear reset-reason history:

```
n1000v# clear system reset-reason
```

Related Commands	Command	Description
	show system reset-reason	Displays the device reset-reason history.

Send document comments to nexus1k-docfeedback@cisco.com.

clear user

To clear a user session, use the **clear user** command.

```
clear user user-id
```

Syntax Description	<i>user-id</i>	User identifier.
---------------------------	----------------	------------------

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Use the show users command to display the current user sessions on the device.
-------------------------	---

Examples	This example shows how to clear all SSH host sessions:
-----------------	--

```
n1000v# clear user user1
```

Related Commands	Command	Description
	show users	Displays the user session information.

Send document comments to nexus1k-docfeedback@cisco.com.

cli var name

To define a command line interface (CLI) variable for a terminal session, use the **cli var name** command. To remove the CLI variable, use the **no** form of this command.

cli var name *variable-name variable-text*

cli no var name *variable-name*

Syntax Description	variable-name	Name of the variable. The name is alphanumeric, case sensitive, and has a maximum of 31 characters.
	variable-text	Variable text. The text is alphanumeric, can contain spaces, and has a maximum of 200 characters.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You can reference a CLI variable using the following syntax:

`$(variable-name)`

Instances where you can use variables in include the following:

- Command scripts
- Filenames

You cannot reference a variable in the definition of another variable.

You can use the predefined variable, `TIMESTAMP`, to insert the time of day. You cannot change or remove the `TIMESTAMP` CLI variable.

You must remove a CLI variable before you can change its definition.

Examples This example shows how to define a CLI variable:

```
n1000v# cli var name testinterface interface 2/3
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to reference the `TIMESTAMP` variable:

```
n1000v# copy running-config > bootflash:run-config-$(TIMESTAMP).cnfg
```

This example shows how to remove a CLI variable:

```
n1000v# cli no var name testinterface interface 2/3
```

Related Commands

Command	Description
<code>show cli variables</code>	Displays the CLI variables.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clock set

To manually set the clock, use the **clock set** command.

clock set *time day month year*

Syntax Description		
<i>time</i>		Time of day. The format is <i>HH:MM:SS</i> .
<i>day</i>		Day of the month. The range is from 1 to 31.
<i>month</i>		Month of the year. The values are January, February, March, April, May, June, July, August, September, October, November, and December .
<i>year</i>		Year. The range is from 2000 to 2030.

Defaults None

Command Modes Any

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use this command when you cannot synchronize your device with an outside clock source, such as NTP.

Examples This example shows how to manually set the clock:

```
n1000v# clock set 9:00:00 1 June 2008
```

Related Commands	Command	Description
	show clock	Displays the clock time.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

clock summer-time

To configure the summer-time (daylight saving time) offset, use the **clock summer-time** command. To revert to the default, use the **no** form of this command.

```
clock summer-time zone-name start-week start-day start-month start-time end-week end-day
end-month end-time offset-minutes
```

```
no clock summer-time
```

Syntax Description

<i>zone-name</i>	Time zone string. The time zone string is a three-character string.
<i>start-week</i>	Week of the month to start the summer-time offset. The range is from 1 to 5.
<i>start-day</i>	Day of the month to start the summer-time offset. Valid values are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday .
<i>start-month</i>	Month to start the summer-time offset. Valid values are January, February, March, April, May, June, July, August, September, October, November, and December .
<i>start-time</i>	Time to start the summer-time offset. The format is <i>hh:mm</i> .
<i>end-week</i>	Week of the month to end the summer-time offset. The range is from 1 to 5.
<i>end-day</i>	Day of the month to end the summer-time offset. Valid values are Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday .
<i>end-month</i>	Month to end the summer-time offset. Valid values are January, February, March, April, May, June, July, August, September, October, November, and December .
<i>end-time</i>	Time to end the summer-time offset. The format is <i>hh:mm</i> .
<i>offset-minutes</i>	Number of minutes to offset the clock. The range is from 1 to 1440.

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure the offset for summer-time or daylight saving time:

```
n1000v# configure terminal
n1000v(config)# clock summer-time PDT 1 Sunday March 02:00 1 Sunday November 02:00 60
```

This example shows how to remove the summer-time offset:

```
n1000v# configure terminal
n1000v(config)# no clock summer-time
```

Related Commands

Command	Description
show clock	Displays clock summer-time offset configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

clock timezone

To configure the time zone offset from Coordinated Universal Time (UTC), use the **clock timezone** command. To revert to the default, use the **no** form of this command.

clock timezone *zone-name* *offset-hours* *offset-minutes*

no clock timezone

Syntax Description		
	<i>zone-name</i>	Zone name. The name is a 3-character string for the time zone acronym (for example, PST or EST).
	<i>offset-hours</i>	Number of hours offset from UTC. The range is from -23 to 23.
	<i>offset-minutes</i>	Number of minutes offset from UTC. The range is from 0 to 59.

Defaults None

Command Modes Any

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to configure the time zone offset from UTC:

```
n1000v# clock timezone EST 5 0
```

This example shows how to remove the time zone offset:

```
n1000v# no clock timezone
```

Related Commands	Command	Description
	show clock	Displays the clock time.

Send document comments to nexus1k-docfeedback@cisco.com.

collect counter

To configure the number of bytes or packets in a flow as a non-key field and collect the number of bytes or packets seen for a Flexible NetFlow flow record, use the **collect counter** command. To disable the counters, use the **no** form of this command.

```
collect counter {bytes [long] | packets [long]}
```

```
no collect counter {bytes [long] | packets [long]}
```

Syntax Description	bytes	Configures the number of bytes or packets seen in a flow as a non-key field and enables collecting the total number of bytes from the flow.
	long	(Optional) Enables collecting the total number of bytes from the flow using a 64 bit counter.
	packets	Configures the number of bytes seen in a flow as a non-key field and enables collecting the total number of packets from the flow.

Command Default This command is not enabled by default.

Command Modes Flow Record Configuration

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples The following example enables collecting the total number of bytes from the flows as a non-key field:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect counter bytes
```

The following example enables collecting the total number of bytes from the flows as a non-key field using a 64 bit counter:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect counter bytes long
```

The following example enables collecting the total number of packets from the flows as a non-key field:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect counter packets
```

Send document comments to nexus1k-docfeedback@cisco.com.

The following example enables collecting the total number of packets from the flows as a non-key field using a 64 bit counter:

```
n1000v(config)# flow record FLOW-RECORD-1  
n1000v(config-flow-record)# collect counter packets long
```

Related Commands

Command	Description
collect counter	Configures the counters as a non-key field and collects the counter values.
flow record	Creates a flow record.
show flow record	Displays flow record status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

collect timestamp sys-uptime

To collect the **TIMESTAMP SYS-UPTIME** for a NetFlow flow record, use the **collect timestamp sys-uptime** command. To disable the collection, use the **no** form of this command.

```
collect timestamp sys-uptime {first | last}
```

```
no collect timestamp sys-uptime {first | last}
```

Syntax Description	first	last
	Configures the sys-uptime for the time the first packet was seen from the flows as a non-key field and enables collecting time stamps based on the sys-uptime for the time the first packet was seen from the flows.	Configures the sys-uptime for the time the last packet was seen from the flows as a non-key field and enables collecting time stamps based on the sys-uptime for the time the most recent packet was seen from the flows.

Command Default This command is not enabled by default.

Command Modes Flow Record Configuration

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples The following example enables collecting the sys-uptime for the time the first packet was seen from the flows:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect timestamp sys-uptime first
```

The following example enables collecting the sys-uptime for the time the most recent packet was seen from the flows:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect timestamp sys-uptime last
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	flow record	Creates a flow record.
	show flow record	Displays flow record status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

collect transport tcp flags

To collect a Transmission Control Protocol (TCP) flags for a NetFlow flow record, use the **collect transport tcp flags** command. To disable the collection, use the **no** form of this command.

collect transport tcp flags

no collect transport tcp flags

Syntax Description This command has no arguments or keywords

Command Default This command is not enabled by default.

Command Modes Flow Record Configuration

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples The following example collects the TCP flags:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)# collect transport tcp flags
```

Related Commands	Command	Description
	flow record	Creates a flow record.
	show flow record	Displays flow record status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

configure terminal

To access configuration commands in the CLI Global Configuration mode, use the **configure terminal** command.

configure terminal

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The configuration changes you make in the Global Configuration mode are saved in the running configuration file. To save these changes persistently across reboots and restarts, you must copy them to the startup configuration file using the **copy running-config startup-config** command.

Examples This example shows how to access configuration commands in the CLI Global Configuration mode:

```
n1000v# configure terminal
n1000v(config)#
```

Related Commands	Command	Description
	where	Displays the current configuration mode context.
	pwd	Displays the name of the present working directory.
	copy run start	Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

connect

To initiate a connection with vCenter, use the **connect** command. To disconnect from vCenter, use the **no connect** form of this command.

connect

no connect

Syntax Description This command has no arguments or keywords.

Defaults no connect

Command Modes SVS Connect Configuration (config-svs-conn)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Upon connection to vCenter, if a username and password have not been configured for this connection, you are prompted to enter them.

There can be only one active connection at a time. If a previously-defined connection is up, an error message displays and the **connect** command is rejected until the previous connection is closed by entering **no connect**.

Examples This example shows how to connect to vCenter:

```
n1000v(config#) svs connection vcWest
n1000v(config-svs-conn#) protocol vmware-vim
n1000v(config-svs-conn#) remote hostname vcMain
n1000v(config-svs-conn#) vmware dvs datacenter-name HamiltonDC
n1000v(config-svs-conn#) connect
```

This example shows how to disconnect from vCenter:

```
n1000v(config#) svs connection vcWest
n1000v(config-svs-conn#) no connect
```

Related Commands	Command	Description
	show svs connections	Displays the current connections to the Cisco Nexus 1000V.

Send document comments to nexus1k-docfeedback@cisco.com.

control vlan

To assign a control VLAN to the Cisco Nexus 1000V domain, use the **control vlan** command. To remove the control VLAN, use the **no** form of this command.

control vlan *number*

no control vlan

Syntax Description	<i>number</i>	control VLAN number.
--------------------	---------------	----------------------

Defaults	None
----------	------

Command Modes	SVS Domain Configuration (config-svs-domain)
---------------	---

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Newly-created VLANs remain unused until Layer 2 ports are assigned to them. If you enter a VLAN ID that is assigned to an internally allocated VLAN, the CLI returns an error message.
------------------	---

Examples	This example shows how to configure control VLAN 70 for domain ID 32:
----------	---

```
n1000v# config t
n1000v(config)# svs-domain
n1000v(config-svs-domain)# domain id 32
n1000v(config-svs-domain)# control vlan 70
n1000v(config-svs-domain)#
```

This example shows how to remove control VLAN 70 from domain ID 32:

```
n1000v# config t
n1000v(config)# svs-domain
n1000v(config-svs-domain)# domain id 32
n1000v(config-svs-domain)# no control vlan 70
n1000v(config-svs-domain)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show vlan-id	Displays the configuration for the specified VLAN.
	svs-domain	Creates the domain and places you into CLI SVS Domain Configuration mode.
	domain id	Assigns a domain ID to the domain.
	packet vlan	Assigns a packet VLAN to the domain.
	show svs-domain	Displays the domain configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

copy

To copy a file from a source to a destination, use the **copy** command.

```
copy source-url destination-url
```

Syntax Description

<i>source-url</i>	Location URL (or variable) of the source file or directory to be copied. The source can be either local or remote, depending upon whether the file is being downloaded or uploaded.
<i>destination-url</i>	Destination URL (or variable) of the copied file or directory. The destination can be either local or remote, depending upon whether the file is being downloaded or uploaded.

The format of the source and destination URLs varies according to the file or directory location. You may enter either a command-line interface (CLI) variable for a directory or a filename that follows the Cisco NX-OS file system syntax (*filesystem:[/directory][/filename]*).

The following tables list URL prefix keywords by the file system type. If you do not specify a URL prefix keyword, the device looks for the file in the current directory.

Table 1 lists URL prefix keywords for bootflash and remote writable storage file systems.

Table 1 URL Prefix Keywords for Storage File Systems

Keyword	Source or Destination
bootflash: <i>[/module/]</i>	Source or destination URL for boot flash memory. The <i>module</i> argument value is sup-active , sup-local , sup-remote , or sup-standby .
ftp:	Source or destination URL for a FTP network server. The syntax for this alias is as follows: ftp: <i>[/server][/path]/filename</i>
scp:	Source or destination URL for a network server that supports Secure Shell (SSH) and accepts copies of files using the secure copy protocol (scp). The syntax for this alias is as follows: scp: <i>[/[username@]server][/path]/filename</i>
sftp:	Source or destination URL for an SSH FTP (SFTP) network server. The syntax for this alias is as follows: sftp: <i>[/[username@]server][/path]/filename</i>
tftp:	Source or destination URL for a TFTP network server. The syntax for this alias is as follows: tftp: <i>[/server[:port]][/path]/filename</i>

Send document comments to nexus1k-docfeedback@cisco.com.

Table 2 lists the URL prefix keywords for nonwritable file systems.

Table 2 URL Prefix Keywords for Special File Systems

Keyword	Source or Destination
core:	Local memory for core files. You can copy core files from the core: file system.
debug:	Local memory for debug files. You can copy core files from the debug: file system.
log:	Local memory for log files. You can copy log files from the log: file system.
system:	Local system memory. You can copy the running configuration to or from the system: file system. The system: file system is optional when referencing the running-config file in a command.
volatile:	Local volatile memory. You can copy files to or from the volatile: file system. All files in the volatile: memory are lost when the physical device reloads.

Defaults

The default name for the destination file is the source filename.

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The entire copying process may take several minutes, depending on the network conditions and the size of the file, and differs from protocol to protocol and from network to network.

The colon character (:) is required after the file system URL prefix keywords (such as **bootflash**).

In the URL syntax for **ftp:**, **scp:**, **sftp:**, and **tftp:**, the server is either an IP address or a host name.

Examples

This example shows how to copy a file within the same directory:

```
n1000v# copy file1 file2
```

This example shows how to copy a file to another directory:

```
n1000v# copy file1 my_files:file2
```

This example shows how to copy a file to another supervisor module:

```
n1000v# copy file1 bootflash://sup-remote/file1.bak
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to copy a file from a remote server:

```
n1000v# copy scp://10.10.1.1/image-file.bin bootflash:image-file.bin
```

Related Commands

Command	Description
cd	Changes the current working directory.
cli var name	Configures CLI variables for the session.
dir	Displays the directory contents.
move	Moves a file.
pwd	Displays the name of the current working directory.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

copy running-config startup-config

To copy the running configuration to the startup configuration, use the **copy running-config startup-config** command.

copy running-config startup-config

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use this command to save configuration changes in the running configuration to the startup configuration in persistent memory. When a device reload or switchover occurs, the saved configuration is applied.

Examples This example shows how to save the running configuration to the startup configuration:

```
n1000v# copy running-config startup-config
[#####] 100%
```

Related Commands	Command	Description
	show running-config	Displays the running configuration.
	show running-config diff	Displays the differences between the running configuration and the startup configuration.
	show startup-config	Displays the startup configuration.
	write erase	Erases the startup configuration in the persistent memory.



D Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter D.

deadtime

To configure the duration of time for which a non-reachable RADIUS or TACACS+ server is skipped, use the **deadtime** command. To revert to the default, use the **no** form of this command.

deadtime *minutes*

no deadtime *minutes*

Syntax Description	<i>minutes</i>	Number of minutes, from 0 to 1440, for the interval.
---------------------------	----------------	--

Defaults	0 minutes	
-----------------	-----------	--

Command Modes	RADIUS server group configuration (config-radius) TACACS+ server group configuration (config-tacacs+) Global Configuration (config)	
----------------------	--	--

SupportedUserRoles	network-admin	
---------------------------	---------------	--

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Before you can configure it, you must enable TACACS+ using the tacacs+ enable command. The dead-time can be configured either globally and applied to all RADIUS or TACACS+ servers; or per server group.
-------------------------	---

Send document comments to nexus1k-docfeedback@cisco.com.

If the dead-time interval for a RADIUS or TACACS+ server group is greater than zero (0), that value takes precedence over the global dead-time value.

Setting the dead-time interval to 0 disables the timer.

When the dead-time interval is 0 minutes, RADIUS and TACACS+ servers are not marked as dead even if they are not responding.

Examples

This example shows how to set the dead-time interval to 2 minutes for a RADIUS server group:

```
n1000v# config t
n1000v(config)# aaa group server radius RadServer
n1000v(config-radius)# deadtime 2
```

This example shows how to set a global dead-time interval to 5 minutes for all TACACS+ servers and server groups:

```
n1000v# config t
n1000v(config)# tacacs-server deadtime 5
n1000v(config)#
```

This example shows how to set the dead-time interval to 5 minutes for a TACACS+ server group:

```
n1000v# config t
n1000v(config)# aaa group server tacacs+ TacServer
n1000v(config-tacacs+)# deadtime 5
```

This example shows how to revert to the dead-time interval default:

```
n1000v# config t
n1000v(config)# feature tacacs+
n1000v(config)# aaa group server tacacs+ TacServer
n1000v(config-tacacs+)# no deadtime 5
```

Related Commands

Command	Description
aaa group server	Configures AAA server groups.
radius-server host	Configures a RADIUS server.
show radius-server groups	Displays RADIUS server group information.
show tacacs-server groups	Displays TACACS+ server group information.
tacacs+ enable	Enables TACACS+.
tacacs-server host	Configures a TACACS+ server.

Send document comments to nexus1k-docfeedback@cisco.com.

debug logfile

To direct the output of the **debug** commands to a specified file, use the **debug logfile** command. To revert to the default, use the **no** form of this command.

debug logfile *filename* [**size** *bytes*]

no debug logfile *filename* [**size** *bytes*]

Syntax Description

<i>filename</i>	Name of the file for debug command output. The filename is alphanumeric, case sensitive, and has a maximum of 64 characters.
size <i>bytes</i>	(Optional) Specifies the size of the logfile in bytes. The range is from 4096 to 4194304.

Defaults

Default filename: syslogd_debugs

Default file size: 4194304 bytes

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The logfile is created in the log: file system root directory.

Use the **dir log:** command to display the log files.

Examples

This example shows how to specify a debug logfile:

```
n1000v# debug logfile debug_log
```

This example shows how to revert to the default debug logfile:

```
n1000v# no debug logfile debug_log
```

Related Commands

Command	Description
dir	Displays the contents of a directory.
show debug	Displays the debug configuration.
show debug logfile	Displays the debug logfile contents.

Send document comments to nexus1k-docfeedback@cisco.com.

debug logging

To enable **debug** command output logging, use the **debug logging** command. To disable debug logging, use the **no** form of this command.

debug logging

no debug logging

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enable the output logging for the **debug** command:

```
n1000v# debug logging
```

This example shows how to disable the output logging for the **debug** command:

```
n1000v# no debug logging
```

Related Commands	Command	Description
	debug logfile	Configures the logfile for the debug command output.

Send document comments to nexus1k-docfeedback@cisco.com.

default switchport (port profile)

To remove a particular switchport characteristic from a port profile, use the **default switchport** command.

```
default switchport {mode | access vlan | trunk {native | allowed} vlan | private-vlan
                  {host-association | mapping [trunk]} | port-security}
```

Syntax Description		
mode	Removes the port mode characteristic from a port profile, which causes the port mode to revert to global or interface defaults (access mode). This is equivalent to executing the no switchport mode port-profile command.	
access vlan	Removes an access VLAN configuration.	
trunk allowedvlan	Removes trunking allowed VLAN characteristics.	
trunk native vlan	Removes trunking native VLAN characteristics.	
private-vlan host-association	Removes PVLAN host-association.	
private-vlan mapping	Removes PVLAN mapping.	
port-security	Removes port-security characteristics.	

Defaults None

Command Modes Port Profile Configuration (**config-port-prof**)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The functionality of this command is equivalent to using the no form of a specific switchport command. For example, the effect of the following commands is the same:

- **default switchport mode** command = **no switchport mode** command
- **default switchport access vlan** command = **no switchport access vlan** command
- **default switchport trunk native vlan** command = **no switchport trunk native vlan** command

Examples This example shows how to revert port profile ports to switch access ports.

```
n1000v(config-port-prof)# default switchport mode
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to remove the trunking allowed VLAN characteristics of a port profile.

```
n1000v(config-port-prof)# default switchport trunk allowed vlan
```

This example shows how to remove the private VLAN host association of a port profile.

```
n1000v(config-port-prof)# default switchport private-vlan host-association
```

This example shows how to remove port security characteristics of a port profile.

```
n1000v(config-port-prof)# default switchport port-security
```

Related Commands

Command	Description
show port-profile	Displays information about port profile(s).

Send document comments to nexus1k-docfeedback@cisco.com.

default shutdown (port profile)

To remove the admin status characteristic (config attribute) from a port-profile, use the **default shutdown** command. This will set the admin status of the interfaces inheriting this port-profile to the global or interface default (usually, the default admin status is shutdown).

default shutdown

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Port Profile Configuration (**config- port-prof**)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to change the ports in a port profile to the shutdown state:

```
n1000v# config t
n1000v# port-profile DataProfile
n1000v(config-port-prof)# default shutdown
n1000v(config-port-prof)# show port-profile name DataProfile
port-profile DataProfile
  description:
  status: enabled
  capability uplink: no
  capability l3control: no
  system vlans: none
  port-group: DataProfile
  max-ports: 32
  inherit:
  config attributes:
    switchport mode access
  evaluated config attributes:
    switchport mode access
  assigned interfaces:
    Vethernet1switch(config-port-prof)#
```

■ default shutdown (port profile)

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show port-profile	Displays the configuration for a port profile.

Send document comments to nexus1k-docfeedback@cisco.com.

default shutdown (interface)

To remove any interface-level override for the admin status, use the **default shutdown** command. This command removes any configuration for admin status entered previously. This allows the port-profile config to take effect.

default shutdown

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Interface Configuration (**config- if**)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to change the ports to the shutdown state:

```
n1000v# config t
n1000v(config)# interface ethernet 3/2
n1000v(config-if)# default shutdown
n1000v(config-if)#
```

Related Commands	Command	Description
	show running-config interface	Displays the configuration of an interface.

Send document comments to nexus1k-docfeedback@cisco.com.

default switchport port-security (VEthernet)

To remove any user configuration for the switchport port-security characteristic from a VEthernet interface, use the **default switchport port-security** command. This has the effect of setting the default (disabled) for port-security for that interface.

default switchport port-security

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Interface Configuration (**config-if**)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to disable port security on VEthernet 2:

```
n1000v# config t
n1000v(config)# interface veth 2
n1000v(config-if)# default switchport port-security
n1000v(config-if)#
```

Related Commands	Command	Description
	show running-config port-security	Displays the port security configuration.
	show port-security	Displays the port security status.

Send document comments to nexus1k-docfeedback@cisco.com.

delay

To assign an informational throughput delay value to an Ethernet interface, use the **delay** command. To remove delay value, use the **no delay** form of this command.

delay *value*

no delay [*value*]

Syntax Description

<i>delay_val</i>	Specifies the throughput delay time in tens of microseconds. Allowable values are between 1 and 16777215.
------------------	--

Defaults

None

Command Modes

Interface Configuration (**config-if**)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The actual Ethernet interface throughput delay time does not change when you set this value—the setting is for informational purposes only.

Examples

This example shows how to assign the delay time to an Ethernet slot 3 port 1 interface:

```
n1000v# config t
n1000v(config)# interface ethernet 3/1
n1000v(config-if)# delay 10000
n1000v(config-if)#
```

This example shows how to remove the delay time configuration:

```
n1000v# config t
n1000v(config)# interface ethernet 3/1
n1000v(config-if)# no delay 10000
n1000v(config-if)#
```

Related Commands

Command	Description
show interface	Displays configuration information for an interface.

Send document comments to nexus1k-docfeedback@cisco.com.

delete

To delete a file, use the **delete** command.

```
delete [filesystem://directory/] | directory/filename
```

Syntax Description	
<i>filesystem</i> :	(Optional) Name of the file system. Valid values are bootflash or volatile .
<i>//directory/</i>	(Optional) Name of the directory. The directory name is case sensitive.
<i>filename</i>	Name of the file. The name is case sensitive.

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Use the dir command to locate the file you that want to delete.
-------------------------	--

Examples	This example shows how to delete a file: n1000v# delete bootflash:old_config.cfg
-----------------	--

Related Commands	Command	Description
	dir	Displays the contents of a directory.

Send document comments to nexus1k-docfeedback@cisco.com.

deny (IPv4)

To create an IPv4 ACL rule that denies traffic matching its conditions, use the **deny** command. To remove a rule, use the **no** form of this command.

General Syntax

```
[sequence-number] deny protocol source destination [dscp dscp | precedence precedence]
```

```
no deny protocol source destination [dscp dscp | precedence precedence]
```

```
no sequence-number
```

Internet Control Message Protocol

```
[sequence-number] deny icmp source destination [icmp-message] [dscp dscp | precedence precedence]
```

Internet Group Management Protocol

```
[sequence-number] deny igmp source destination [igmp-message] [dscp dscp | precedence precedence]
```

Internet Protocol v4

```
[sequence-number] deny ip source destination [dscp dscp | precedence precedence]
```

Transmission Control Protocol

```
[sequence-number] deny tcp source [operator port [port] | portgroup portgroup] destination  
[operator port [port] | portgroup portgroup] [dscp dscp | precedence precedence] [fragments]  
[log] [time-range time-range-name] [flags] [established]
```

User Datagram Protocol

```
[sequence-number] deny udp source operator port [port] destination [operator port [port]] [dscp  
dscp | precedence precedence]
```

Send document comments to nexus1k-docfeedback@cisco.com.

Syntax Description	
<i>sequence-number</i>	<p>(Optional) Sequence number of the deny command, which causes the device to insert the command in that numbered position in the access list. Sequence numbers maintain the order of rules within an ACL.</p> <p>A sequence number can be any integer between 1 and 4294967295.</p> <p>By default, the first rule in an ACL has a sequence number of 10.</p> <p>If you do not specify a sequence number, the device adds the rule to the end of the ACL and assigns a sequence number that is 10 greater than the sequence number of the preceding rule.</p> <p>Use the resequence command to reassign sequence numbers to rules.</p>
<i>protocol</i>	<p>Name or number of the protocol of packets that the rule matches. Valid numbers are from 0 to 255. Valid protocol names are the following keywords:</p> <ul style="list-style-type: none"> • icmp—Specifies that the rule applies to ICMP traffic only. When you use this keyword, the <i>icmp-message</i> argument is available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument. • igmp—Specifies that the rule applies to IGMP traffic only. When you use this keyword, the <i>igmp-type</i> argument is available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument. • ip—Specifies that the rule applies to all IPv4 traffic. When you use this keyword, only the other keywords and arguments that apply to all IPv4 protocols are available. They include the following: <ul style="list-style-type: none"> – dscp – precedence • tcp—Specifies that the rule applies to TCP traffic only. When you use this keyword, the <i>flags</i> and <i>operator</i> arguments are available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument. • udp—Specifies that the rule applies to UDP traffic only. When you use this keyword, the <i>operator</i> argument is available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument.
<i>source</i>	<p>Source IPv4 addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.</p>
<i>destination</i>	<p>Destination IPv4 addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.</p>

Send document comments to nexus1k-docfeedback@cisco.com.

dscp <i>dscp</i>	<p>(Optional) Specifies that the rule matches only those packets with the specified 6-bit differentiated services value in the DSCP field of the IP header. The <i>dscp</i> argument can be one of the following numbers or keywords:</p> <ul style="list-style-type: none">• 0–63—The decimal equivalent of the 6 bits of the DSCP field. For example, if you specify 10, the rule matches only those packets that have the following bits in the DSCP field: 001010.• af11—Assured Forwarding (AF) class 1, low drop probability (001010)• af12—AF class 1, medium drop probability (001100)• af13—AF class 1, high drop probability (001110)• af21—AF class 2, low drop probability (010010)• af22—AF class 2, medium drop probability (010100)• af23—AF class 2, high drop probability (010110)• af31—AF class 3, low drop probability (011010)• af32—AF class 3, medium drop probability (011100)• af33—AF class 3, high drop probability (011110)• af41—AF class 4, low drop probability (100010)• af42—AF class 4, medium drop probability (100100)• af43—AF class 4, high drop probability (100110)• cs1—Class-selector (CS) 1, precedence 1 (001000)• cs2—CS2, precedence 2 (010000)• cs3—CS3, precedence 3 (011000)• cs4—CS4, precedence 4 (100000)• cs5—CS5, precedence 5 (101000)• cs6—CS6, precedence 6 (110000)• cs7—CS7, precedence 7 (111000)• default—Default DSCP value (000000)• ef—Expedited Forwarding (101110)
-------------------------	---

Send document comments to nexus1k-docfeedback@cisco.com.

precedence <i>precedence</i>	<p>(Optional) Specifies that the rule matches only packets that have an IP Precedence field with the value specified by the <i>precedence</i> argument. The <i>precedence</i> argument can be a number or a keyword, as follows:</p> <ul style="list-style-type: none"> • 0–7—Decimal equivalent of the 3 bits of the IP Precedence field. For example, if you specify 3, the rule matches only packets that have the following bits in the DSCP field: 011. • critical—Precedence 5 (101) • flash—Precedence 3 (011) • flash-override—Precedence 4 (100) • immediate—Precedence 2 (010) • internet—Precedence 6 (110) • network—Precedence 7 (111) • priority—Precedence 1 (001) • routine—Precedence 0 (000)
<i>icmp-message</i>	<p>(ICMP only: Optional) ICMP message type that the rule matches. This argument can be an integer from 0 to 255 or one of the keywords listed under “ICMP Message Types” in the “Usage Guidelines” section.</p>
<i>igmp-message</i>	<p>(IGMP only: Optional) IGMP message type that the rule matches. The <i>igmp-message</i> argument can be the IGMP message number, which is an integer from 0 to 15. It can also be one of the following keywords:</p> <ul style="list-style-type: none"> • dvmp—Distance Vector Multicast Routing Protocol • host-query—Host query • host-report—Host report • pim—Protocol Independent Multicast • trace—Multicast trace

Send document comments to nexus1k-docfeedback@cisco.com.

<i>operator port</i> [<i>port</i>]	<p>(Optional; TCP and UDP only) Rule matches only packets that are from a source port or sent to a destination port that satisfies the conditions of the <i>operator</i> and <i>port</i> arguments. Whether these arguments apply to a source port or a destination port depends upon whether you specify them after the <i>source</i> argument or after the <i>destination</i> argument.</p> <p>The <i>port</i> argument can be the name or the number of a TCP or UDP port. Valid numbers are integers from 0 to 65535. For listings of valid port names, see “TCP Port Names” and “UDP Port Names” in the “Usage Guidelines” section.</p> <p>A second <i>port</i> argument is required only when the <i>operator</i> argument is a range. The <i>operator</i> argument must be one of the following keywords:</p> <ul style="list-style-type: none"> • eq—Matches only if the port in the packet is equal to the <i>port</i> argument. • gt—Matches only if the port in the packet is greater than and not equal to the <i>port</i> argument. • lt—Matches only if the port in the packet is less than and not equal to the <i>port</i> argument. • neq—Matches only if the port in the packet is not equal to the <i>port</i> argument. • range—Requires two <i>port</i> arguments and matches only if the port in the packet is equal to or greater than the first <i>port</i> argument and equal to or less than the second <i>port</i> argument.
<i>flags</i>	<p>(TCP only; Optional) TCP control bit flags that the rule matches. The value of the <i>flags</i> argument must be one or more of the following keywords:</p> <ul style="list-style-type: none"> • ack • fin • psh • rst • syn • urg

Defaults

A newly created IPv4 ACL contains no rules.

If you do not specify a sequence number, the device assigns the rule a sequence number that is 10 greater than the last rule in the ACL.

Command Modes

IPv4 ACL configuration (**config-acl**)

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Send document comments to nexus1k-docfeedback@cisco.com.

Usage Guidelines

When the device applies an IPv4 ACL to a packet, it evaluates the packet with every rule in the ACL. The device enforces the first rule that has conditions that are satisfied by the packet. When the conditions of more than one rule are satisfied, the device enforces the rule with the lowest sequence number.

Source and Destination

You can specify the *source* and *destination* arguments in one of several ways. In each rule, the method that you use to specify one of these arguments does not affect how you specify the other argument. When you configure a rule, use the following methods to specify the *source* and *destination* arguments:

- **Address and network wildcard**—You can use an IPv4 address followed by a network wildcard to specify a host or a network as a source or destination. The syntax is as follows:

```
IPv4-address network-wildcard
```

The following example shows how to specify the *source* argument with the IPv4 address and network wildcard for the 192.168.67.0 subnet:

```
switch(config-acl)# deny tcp 192.168.67.0 0.0.0.255 any
```

- **Address and variable-length subnet mask**—You can use an IPv4 address followed by a variable-length subnet mask (VLSM) to specify a host or a network as a source or destination. The syntax is as follows:

```
IPv4-address/prefix-len
```

The following example shows how to specify the *source* argument with the IPv4 address and VLSM for the 192.168.67.0 subnet:

```
switch(config-acl)# deny udp 192.168.67.0/24 any
```

- **Host address**—You can use the **host** keyword and an IPv4 address to specify a host as a source or destination. The syntax is as follows:

```
host IPv4-address
```

This syntax is equivalent to *IPv4-address/32* and *IPv4-address 0.0.0.0*.

The following example shows how to specify the *source* argument with the **host** keyword and the 192.168.67.132 IPv4 address:

```
switch(config-acl)# deny icmp host 192.168.67.132 any
```

- **Any address**—You can use the **any** keyword to specify that a source or destination is any IPv4 address. For examples of the use of the **any** keyword, see the examples in this section. Each example shows how to specify a source or destination by using the **any** keyword.

ICMP Message Types

The *icmp-message* argument can be the ICMP message number, which is an integer from 0 to 255. It can also be one of the following keywords:

- **administratively-prohibited**—Administratively prohibited
- **alternate-address**—Alternate address
- **conversion-error**—Datagram conversion
- **dod-host-prohibited**—Host prohibited
- **dod-net-prohibited**—Net prohibited
- **echo**—Echo (ping)
- **echo-reply**—Echo reply

Send document comments to nexus1k-docfeedback@cisco.com.

- **general-parameter-problem**—Parameter problem
- **host-isolated**—Host isolated
- **host-precedence-unreachable**—Host unreachable for precedence
- **host-redirect**—Host redirect
- **host-tos-redirect**—Host redirect for ToS
- **host-tos-unreachable**—Host unreachable for ToS
- **host-unknown**—Host unknown
- **host-unreachable**—Host unreachable
- **information-reply**—Information replies
- **information-request**—Information requests
- **mask-reply**—Mask replies
- **mask-request**—Mask requests
- **mobile-redirect**—Mobile host redirect
- **net-redirect**—Network redirect
- **net-tos-redirect**—Net redirect for ToS
- **net-tos-unreachable**—Network unreachable for ToS
- **net-unreachable**—Net unreachable
- **network-unknown**—Network unknown
- **no-room-for-option**—Parameter required but no room
- **option-missing**—Parameter required but not present
- **packet-too-big**—Fragmentation needed and DF set
- **parameter-problem**—All parameter problems
- **port-unreachable**—Port unreachable
- **precedence-unreachable**—Precedence cutoff
- **protocol-unreachable**—Protocol unreachable
- **reassembly-timeout**—Reassembly timeout
- **redirect**—All redirects
- **router-advertisement**—Router discovery advertisements
- **router-solicitation**—Router discovery solicitations
- **source-quench**—Source quenches
- **source-route-failed**—Source route failed
- **time-exceeded**—All time-exceeded messages
- **timestamp-reply**—Time-stamp replies
- **timestamp-request**—Time-stamp requests
- **traceroute**—Traceroute
- **ttl-exceeded**—TTL exceeded
- **unreachable**—All unreachables

Send document comments to nexus1k-docfeedback@cisco.com.

TCP Port Names

When you specify the *protocol* argument as **tcp**, the *port* argument can be a TCP port number, which is an integer from 0 to 65535. It can also be one of the following keywords:

bgp—Border Gateway Protocol (179)
chargen—Character generator (19)
cmd—Remote commands (rcmd, 514)
daytime—Daytime (13)
discard—Discard (9)
domain—Domain Name Service (53)
drip—Dynamic Routing Information Protocol (3949)
echo—Echo (7)
exec—EXEC (rsh, 512)
finger—Finger (79)
ftp—File Transfer Protocol (21)
ftp-data—FTP data connections (2)
gopher—Gopher (7)
hostname—NIC hostname server (11)
ident—Ident Protocol (113)
irc—Internet Relay Chat (194)
klogin—Kerberos login (543)
kshell—Kerberos shell (544)
login—Login (rlogin, 513)
lpd—Printer service (515)
nntp—Network News Transport Protocol (119)
pim-auto-rp—PIM Auto-RP (496)
pop2—Post Office Protocol v2 (19)
pop3—Post Office Protocol v3 (11)
smtp—Simple Mail Transport Protocol (25)
sunrpc—Sun Remote Procedure Call (111)
tacacs—TAC Access Control System (49)
talk—Talk (517)
telnet—Telnet (23)
time—Time (37)
uucp—UNIX-to-UNIX Copy Program (54)
whois—WHOIS/NICNAME (43)
www—World Wide Web (HTTP, 8)

Send document comments to nexus1k-docfeedback@cisco.com.

UDP Port Names

When you specify the *protocol* argument as **udp**, the *port* argument can be a UDP port number, which is an integer from 0 to 65535. It can also be one of the following keywords:

biff—Biff (mail notification, comsat, 512)
bootpc—Bootstrap Protocol (BOOTP) client (68)
bootps—Bootstrap Protocol (BOOTP) server (67)
discard—Discard (9)
dnsix—DNSIX security protocol auditing (195)
domain—Domain Name Service (DNS, 53)
echo—Echo (7)
isakmp—Internet Security Association and Key Management Protocol (5)
mobile-ip—Mobile IP registration (434)
nameserver—IEN116 name service (obsolete, 42)
netbios-dgm—NetBIOS datagram service (138)
netbios-ns—NetBIOS name service (137)
netbios-ss—NetBIOS session service (139)
non500-isakmp—Internet Security Association and Key Management Protocol (45)
ntp—Network Time Protocol (123)
pim-auto-rp—PIM Auto-RP (496)
rip—Routing Information Protocol (router, in.routed, 52)
snmp—Simple Network Management Protocol (161)
snmptrap—SNMP Traps (162)
sunrpc—Sun Remote Procedure Call (111)
syslog—System Logger (514)
tacacs—TAC Access Control System (49)
talk—Talk (517)
tftp—Trivial File Transfer Protocol (69)
time—Time (37)
who—Who service (rwho, 513)
xdmcp—X Display Manager Control Protocol (177)

Examples

This example shows how to configure an IPv4 ACL named `acl-lab-01` with rules that deny all TCP and UDP traffic from the 10.23.0.0 and 192.168.37.0 networks to the 10.176.0.0 network and a final rule that permits all other IPv4 traffic:

```
n1000v# config t
n1000v(config)# ip access-list acl-lab-01
n1000v(config-acl)# deny tcp 10.23.0.0/16 10.176.0.0/16
n1000v(config-acl)# deny udp 10.23.0.0/16 10.176.0.0/16
n1000v(config-acl)# deny tcp 192.168.37.0/16 10.176.0.0/16
n1000v(config-acl)# deny udp 192.168.37.0/16 10.176.0.0/16
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config-acl)# permit ip any any
```

Related Commands	Command	Description
	ip access-list	Configures an IPv4 ACL.
	permit (IPv4)	Configures a permit rule in an IPv4 ACL.
	remark	Configures a remark in an IPv4 ACL.
	show ip access-list	Displays all IPv4 ACLs or one IPv4 ACL.
	statistics per-entry	Enables collection of statistics for each entry in an ACL.

Send document comments to nexus1k-docfeedback@cisco.com.

deny (MAC)

To create a MAC access control list (ACL)+ rule that denies traffic matching its conditions, use the **deny** command. To remove a rule, use the **no** form of this command.

```
[sequence-number] deny source destination [protocol] [cos cos-value] [vlan VLAN-ID]
```

```
no deny source destination [protocol] [cos cos-value] [vlan VLAN-ID]
```

```
no sequence-number
```

Syntax Description

<i>sequence-number</i>	(Optional) Sequence number of the deny command, which causes the device to insert the command in that numbered position in the access list. Sequence numbers maintain the order of rules within an ACL. A sequence number can be any integer between 1 and 4294967295. By default, the first rule in an ACL has a sequence number of 10. If you do not specify a sequence number, the device adds the rule to the end of the ACL and assigns a sequence number that is 10 greater than the sequence number of the preceding rule. Use the resequence command to reassign sequence numbers to rules.
<i>source</i>	Source MAC addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.
<i>destination</i>	Destination MAC addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.
<i>protocol</i>	(Optional) Protocol number that the rule matches. Valid protocol numbers are 0x0 to 0xffff. For listings of valid protocol names, see “MAC Protocols” in the “Usage Guidelines” section.
cos <i>cos-value</i>	(Optional) Specifies that the rule matches only packets with an IEEE 802.1Q header that contains the Class of Service (CoS) value given in the <i>cos-value</i> argument. The <i>cos-value</i> argument can be an integer from 0 to 7.
vlan <i>VLAN-ID</i>	(Optional) Specifies that the rule matches only packets with an IEEE 802.1Q header that contains the VLAN ID given. The <i>VLAN-ID</i> argument can be an integer from 1 to 4094.

Defaults

A newly created MAC ACL contains no rules.

If you do not specify a sequence number, the device assigns the rule a sequence number that is 10 greater than the last rule in the ACL.

Command Modes

MAC ACL Configuration (**config-mac-acl**)

Supported User Roles

network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

When the device applies a MAC ACL to a packet, it evaluates the packet with every rule in the ACL. The device enforces the first rule that has conditions that are satisfied by the packet. When the conditions of more than one rule are satisfied, the device enforces the rule with the lowest sequence number.

Source and Destination

You can specify the *source* and *destination* arguments in one of two ways. In each rule, the method that you use to specify one of these arguments does not affect how you specify the other argument. When you configure a rule, use the following methods to specify the *source* and *destination* arguments:

- Address and mask—You can use a MAC address followed by a mask to specify a single address or a group of addresses. The syntax is as follows:

MAC-address *MAC-mask*

The following example specifies the *source* argument with the MAC address 00c0.4f03.0a72:

```
n1000v(config-acl)# deny 00c0.4f03.0a72 0000.0000.0000 any
```

The following example specifies the *destination* argument with a MAC address for all hosts with a MAC vendor code of 00603e:

```
n1000v(config-acl)# deny any 0060.3e00.0000 0000.0000.0000
```

- Any address—You can use the **any** keyword to specify that a source or destination is any MAC address. For examples of the use of the **any** keyword, see the examples in this section. Each of the examples shows how to specify a source or destination by using the **any** keyword.

MAC Protocols

The *protocol* argument can be the MAC protocol number or a keyword. The protocol number is a four-byte hexadecimal number prefixed with 0x. Valid protocol numbers are from 0x0 to 0xffff. Valid keywords are the following:

- **aarp**—Appletalk ARP (0x80f3)
- **appletalk**—Appletalk (0x809b)
- **decnet-iv**—DECnet Phase IV (0x6003)
- **diagnostic**—DEC Diagnostic Protocol (0x6005)
- **etype-6000**—EtherType 0x6000 (0x6000)
- **etype-8042**—EtherType 0x8042 (0x8042)
- **ip**—Internet Protocol v4 (0x0800)
- **lat**—DEC LAT (0x6004)
- **lavc-sca**—DEC LAVC, SCA (0x6007)
- **mop-console**—DEC MOP Remote console (0x6002)
- **mop-dump**—DEC MOP dump (0x6001)
- **vines-echo**—VINES Echo (0x0baf)

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure a MAC ACL named mac-ip-filter with rules that permit any non-IPv4 traffic between two groups of MAC addresses:

```
n1000v# config t
n1000v(config)# mac access-list mac-ip-filter
n1000v(config-mac-acl)# deny 00c0.4f00.0000 0000.00ff.ffff 0060.3e00.0000 0000.00ff.ffff
ip
n1000v(config-mac-acl)# permit any any
```

Related Commands

Command	Description
mac access-list	Configures a MAC ACL.
permit (MAC)	Configures a deny rule in a MAC ACL.
remark	Configures a remark in an ACL.
show mac access-list	Displays all MAC ACLs or one MAC ACL.
statistics per-entry	Enables collection of statistics for each entry in an ACL.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

description (interface)

To do add a description for the interface and save it in the running configuration, use the **description** command. To remove the interface description, use the **no** form of this command.

description *text*

no description

Syntax Description	<i>text</i>	Describes the interface. The maximum number of characters is 80.
--------------------	-------------	--

Defaults	None
----------	------

Command Modes	interface configuration (config-if)
---------------	-------------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	.
------------------	---

Examples	<p>This example shows how to add the description for the interface and save it in the running configuration.:</p> <pre>n1000v(config-if)# description Ethernet port 3 on module 1</pre> <p>This example shows how to remove the interface description.</p> <pre>n1000v(config-if)# no description Ethernet port 3 on module 1</pre>
----------	---

Related Commands	Command	Description
	show interface	Displays the interface status, including the description.

Send document comments to nexus1k-docfeedback@cisco.com.

description (NetFlow)

To add a description to a flow record, flow monitor, or flow exporter, use the **description** command. To remove the description, use the **no** form of this command.

description *line*

no description

Syntax Description	<i>line</i>	Description of up to 63 characters.
--------------------	-------------	-------------------------------------

Defaults	None
----------	------

Command Modes	NetFlow flow record (config-flow-record) NetFlow flow exporter (config-flow-exporter) Netflow flow monitor (config-flow-monitor)
---------------	--

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to add a description to a flow record:

```
n1000v# config t
n1000v(config)# flow record RecordTest
n1000v(config-flow-record)# description Ipv4flow
```

This example shows how to add a description to a flow exporter:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# description ExportHamilton
```

This example shows how to add a description to a flow monitor:

```
n1000v# config t
n1000v(config)# flow monitor MonitorTest
n1000v(config-flow-monitor)# description Ipv4Monitor
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	flow exporter	Creates a Flexible NetFlow flow exporter.
	flow record	Creates a Flexible NetFlow flow record.
	flow monitor	Creates a Flexible NetFlow flow monitor.
	show flow exporter	Displays information about the NetFlow flow exporter.
	show flow record	Displays information about NetFlow flow records.
	show flow monitor	Displays information about the NetFlow flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

description (QoS)

To add a description to a QoS class map, policy map, use the **description** command. To remove the description, use the **no** form of this command.

description *text*

no description *text*

Syntax Description	<i>text</i>
	Description, of up to 200 characters, for the class map or policy map.

Defaults	None
----------	------

Command Modes	QoS Class Map Configuration (config-cmap-qos) QoS Policy Map Configuration (config-pmap-qos)
---------------	---

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to add a description to a policy map:

```
n1000v(config)# policy-map my_policy1
n1000v(config-pmap)# description this policy applies to input packets
n1000v(config-pmap)#
```

Related Commands	Command	Description
	class-map	Creates or modifies a class map.
	policy-map	Creates or modifies a policy map.

Send document comments to nexus1k-docfeedback@cisco.com.

description (role)

To add a description for a role, use the **description** command. To remove a description of a role, use the **no** form of this command.

description *string*

no description

Syntax Description	<i>string</i>	Describes the role. The string can include spaces.

Defaults	None

Command Modes	Role Configuration (config-role)

SupportedUserRoles	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to add a description to a role: n1000v(config-role)# description admin

Examples	This example shows how to remove the role description: n1000v(config-role)# no description admin

Related Commands	Command	Description
	show role	Displays a role configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

description (SPAN)

To add a description to a SPAN session, use the **description** command. To remove the description, use the **no** form of this command.

description *string*

no description

Syntax Description	<i>string</i>	Specifies a description of up to 32 alphanumeric characters.
--------------------	---------------	--

Defaults	Blank (no description)
----------	------------------------

Command Modes	SPAN Monitor Configuration (config-monitor)
---------------	--

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to add a description to a SPAN session:

```
n1000v# config t
n1000v(config)# monitor session 8
n1000v(config-monitor)# description span_session_8a
n1000v(config-monitor)#
```

This example shows how to remove a description from a SPAN session:

```
n1000v# config t
n1000v(config)# monitor session 8
n1000v(config)# no description span_session_8a
n1000v(config-monitor)#
```

Related Commands	Command	Description
	show monitor session	Displays session information.

Send document comments to nexus1k-docfeedback@cisco.com.

destination (NetFlow)

To add a destination IP address or VRF to a NetFlow flow exporter, use the **destination** command. To remove the IP address or VRF, use the **no** form of this command.

```
destination {ipaddr | ipv6addr} [use-vrf vrf_name]
```

```
no destination
```

Syntax Description		
	<i>ipaddr</i>	Destination IP address for collector.
	<i>ipv6addr</i>	Destination IPv6 address for collector.
	use-vrf <i>vrf_name</i>	(Optional) Optional VRF label + VRF Label.

Defaults	None
----------	------

Command Modes	NetFlow Flow Exporter Configuration (config-flow-exporter)
---------------	---

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to add a destination IP address to a Netflow flow exporter:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# destination 192.0.2.1
```

This example shows how to remove the IP address from a flow exporter:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# no destination 192.0.2.1
```

Related Commands	Command	Description
	flow exporter	Creates a Flexible NetFlow flow exporter.
	flow record	Creates a Flexible NetFlow flow record.
	flow monitor	Creates a Flexible NetFlow flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

destination interface (SPAN)

To configure the port(s) in a SPAN session to act as destination(s) for copied source packets, use the **destination interface** command. To remove the destination interface, use the **no** form of this command.

destination interface *type number(s)_or_range*

no destination interface *type number(s)_or_range*

Syntax Description		
ethernet <i>slot/port_or_range</i>	Designates the SPAN destination(s) Ethernet interface(s).	
port-channel <i>number(s)_or_range</i>	Designates the SPAN destination(s) port channel(s).	
vethernet <i>number(s)_or_range</i>	Designates the SPAN destination(s) virtual Ethernet interface(s).	

Defaults None

Command Modes SPAN Monitor Configuration (**config-monitor**)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

SPAN destination ports must already be configured as either access or trunk ports.

SPAN sessions are created in the shut state by default.

When you create a SPAN session that already exists, any additional configuration is added to that session. To make sure the session is cleared of any previous configuration, you can delete the session first using the command, **no monitor session**.

Examples

This example shows how to configure ethernet interfaces 2/5 and 3/7 in a SPAN session to act as destination(s) for copied source packets:

```
n1000v# config t
n1000v(config)# monitor session 8
n1000v(config-monitor)# destination interface ethernet 2/5, ethernet 3/7
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to remove the SPAN configuration from destination interface ethernet 2/5:

```
n1000v# config t
n1000v(config)# monitor session 8
n1000v(config-monitor)# no destination interface ethernet 2/5
```

Related Commands

Command	Description
show interface	Displays the interface trunking configuration for the specified destination interface.
show monitor	Displays Ethernet SPAN information.
monitor session	Starts the specified SPAN monitor session(s).

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

dir

To display the contents of a directory or file, use the **dir** command.

dir [**bootflash:** | **debug:** | **log:** | **volatile:**]

Syntax Description	
bootflash:	(Optional) Directory or filename.
debug:	(Optional) Directory or filename on expansion flash.
log:	(Optional) Directory or filename on log flash.
volatile:	(Optional) Directory or filename on volatile flash.

Defaults	
	None

Command Modes	
	Any

SupportedUserRoles	
	network-admin network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
	Use the pwd command to identify the directory you are currently working in. Use the cd command to change the directory you are currently working in.

Examples	
	This example shows how to display the contents of the bootflash: directory n1000v# dir bootflash:

Related Commands	Command	Description
	cd	Changes the current working directory.
	pwd	Displays the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

domain id

To assign a domain-id, use the **domain id** command. To remove a domain-id, use the **no** form of this command.

domain id *number*

no domain id

Syntax Description	<i>number</i>	Specifies the domain-id number. The allowable domain IDs are 1 to 4095.
--------------------	---------------	---

Defaults	None
----------	------

Command Modes	Domain Configuration (config-svs-domain)
---------------	---

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	During installation of the Cisco Nexus 1000V the setup utility prompts you to configure a domain, including the domain ID and control and packet VLANs.
------------------	---

Examples	This example shows how to assign a domain id:
----------	---

```
n1000v# config t
n1000v(config)# svs-domain
n1000v(config-svs-domain)# domain-id number 32
n1000v(config-svs-domain)#
```

This example shows how to remove the domain-id:

```
n1000v# config t
n1000v(config)# svs-domain
n1000v(config-svs-domain)# no domain-id number 32
n1000v(config-svs-domain)#
```

Related Commands	Command	Description
	show svs domain	Displays domain configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

dscp (NetFlow)

To add a differentiated services codepoint (DSCP) to a NetFlow flow exporter, use the **dscp** command. To remove the DSCP, use the **no** form of this command.

dscp *value*

no dscp

Syntax Description	<i>value</i>	Specifies a DSCP between 0 and 63.
---------------------------	--------------	------------------------------------

Defaults	None
-----------------	------

Command Modes	Netflow Flow Exporter Configuration (config-flow-exporter)
----------------------	---

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
-------------------------	--

Examples	This example shows how to configure DSCP for a Netflow flow exporter:
-----------------	---

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# dscp 2
n1000v(config-flow-exporter)#
```

This example shows how to remove DSCP from the Netflow flow exporter:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# no dscp 2
n1000v(config-flow-exporter)#
```

Related Commands	Command	Description
	flow exporter	Creates a Flexible NetFlow flow exporter.
	flow record	Creates a Flexible NetFlow flow record.
	flow monitor	Creates a Flexible NetFlow flow monitor.
	show flow exporter	Displays information about the NetFlow flow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.



E Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter E.

echo

To echo an argument back to the terminal screen, use the **echo** command.

```
echo [backslash-interpret] [text]
```

Syntax Description		
-e	(Optional) Interprets any character following a backslash character (\) as a formatting option.	
backslash-interpret	(Optional) Interprets any character following a backslash character (\) as a formatting option.	
<i>text</i>	(Optional) Text string to display. The text string is alphanumeric, case sensitive, can contain spaces, and has a maximum length of 200 characters. The text string can also contain references to CLI variables.	

Defaults	
	Displays a blank line.

Command Modes	
	Any

SupportedUserRoles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Send document comments to nexus1k-docfeedback@cisco.com.

Usage Guidelines

You can use this command in a command script to display information while the script is running.

Table 1 lists the formatting keywords that you can insert in the text when you include the `-e` or `backslash-interpret` keyword.

Table 1 **Formatting Options for the echo Command**

Formatting Option	Description
<code>\b</code>	Back spaces.
<code>\c</code>	Removes the new line character at the end of the text string.
<code>\f</code>	Inserts a form feed character.
<code>\n</code>	Inserts a new line character.
<code>\r</code>	Returns to the beginning of the text line.
<code>\t</code>	Inserts a horizontal tab character.
<code>\v</code>	Inserts a vertical tab character.
<code>\\</code>	Displays a backslash character.
<code>\nnn</code>	Displays the corresponding ASCII octal character.

Examples

This example shows how to display a blank line at the command prompt:

```
n1000v# echo
```

This example shows how to display a line of text at the command prompt:

```
n1000v# echo Script run at $(TIMESTAMP).
Script run at 2008-08-12-23.29.24.
```

This example shows how to use a formatting option in the text string:

```
n1000v# echo backslash-interpret This is line #1. \nThis is line #2.
This is line #1.
This is line #2.
```

Related Commands

Command	Description
<code>run-script</code>	Runs command scripts.

Send document comments to nexus1k-docfeedback@cisco.com.

end

To exit a configuration mode and return to Privileged EXEC mode, use the **end** command.

end

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin network-operator
---------------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	This command differs from the exit command in that the exit command returns you to the configuration mode you were previously in. The end command always takes you completely out of configuration mode and places you in Privileged EXEC mode.
-------------------------	--

Examples	This example shows how to end the session in Global Configuration mode and return to Privileged EXEC mode:
-----------------	--

```
n1000v(config)# end
n1000v#
```

This example shows how to end the session in Interface Configuration mode and return to Privileged EXEC mode:

```
n1000v(config-if)# end
n1000v#
```

Related Commands	Command	Description
	exit	Exits the current command mode and returns you to the previous command mode.

Send document comments to nexus1k-docfeedback@cisco.com.

exit

To exit a configuration mode or exit the CLI, use the **exit** command.

exit

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to exit Global Configuration mode. The CLI returns you to the EXEC mode.

```
n1000v(config)# exit
n1000v#
```

This example shows how to exit Interface Configuration mode. The CLI returns you to the Global Configuration mode.

```
n1000v(config-if)# exit
n1000v(config)#
```

This example shows how to exit the CLI.

```
n1000v# exit
```

Related Commands	Command	Description
	end	Returns to the EXEC command mode.

Send document comments to nexus1k-docfeedback@cisco.com.

exec-timeout

To configure the length of time, in minutes, that an inactive Telnet or SSH session remains open before it is automatically shut down, use the **exec-timeout** command. To remove an exec timeout setting, use the **no** form of this command.

exec-timeout *time*

no exec-timeout [*time*]

Syntax Description	<i>time</i>	Timeout time, in minutes. The range of valid values is 0 to 525600. If a session remains inactive longer than this specified time period, then it is automatically closed.
---------------------------	-------------	---

Defaults	No timeout is configured.
-----------------	---------------------------

Command Modes	Console Configuration (config-console)
----------------------	---

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	When you set <i>time</i> to 0, exec timeout is disabled.
-------------------------	--

Examples	This example shows how to configure an inactive session timeout for the console port:
-----------------	---

```
n1000v# configure terminal
n1000v(config)# line console
n1000v(config-com1)# exec-timeout 20
```

This example shows how to configure an inactive session timeout for the virtual terminal:

```
n1000v# configure terminal
n1000v(config)# line vty
n1000v(config-line)# exec-timeout 20
```

This example shows how to remove an exec timeout on the console port:

```
n1000v(config)# configure terminal
DocTeamVSM(config)# line console
n1000v(config-console)# no exec-timeout
n1000v(config-console)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show terminal	Displays the terminal configuration, including the timeout value.
	show users	Displays the currently active user sessions.



F Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter F.

find

To find filenames beginning with a specific character string, use the **find** command.

find *filename-prefix*

Syntax Description	<i>filename-prefix</i>	The beginning characters of a filename or the entire filename. The filename prefix is case sensitive.
---------------------------	------------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The find command searches all subdirectories under the current working directory. You can use the cd and pwd commands to navigate to the starting directory.
-------------------------	---

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to display filenames beginning with ospf:

```
n1000v# find ospf
/usr/bin/find: ./lost+found: Permission denied
./ospf-gr.cfg
./ospfgrconfig
./ospf-gr.conf
```

Related Commands

Command	Description
cd	Changes the current working directory.
pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

flow exporter

To create or modify a NetFlow flow exporter defining where and how Flow Records are exported to the NetFlow Collector Server, use the **flow exporter** command. To remove a flow exporter, use the **no** form of this command.

flow exporter *exporter-name*

no flow exporter *exporter-name*

Syntax Description

<i>exporter-name</i>	Name of the flow exporter that is created or modified.
----------------------	--

Defaults

Flow exporters are not present in the configuration until you create them.

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

The following example shows how to create and configure FLOW-EXPORTER-1:

```
n1000v(config)# flow exporter FLOW-EXPORTER-1
n1000v(config-flow-exporter)# description located in Pahrump, NV
n1000v(config-flow-exporter)# destination A.B.C.D
n1000v(config-flow-monitor)# dscp 32
n1000v(config-flow-monitor)# source mgmt0
n1000v(config-flow-monitor)# transport udp 59
n1000v(config-flow-monitor)# version 9
```

The following example shows how to remove FLOW-EXPORTER-1:

```
n1000v(config)# no flow exporter FLOW-EXPORTER-1
n1000v(config)#
```

Related Commands

Command	Description
clear flow exporter	Clears the flow monitor.
show flow exporter	Displays flow monitor status and statistics.
description	Adds a description to a flow record, flow monitor, or flow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
destination	Adds a destination IP address to a NetFlow flow exporter.
dscp	Adds a differentiated services codepoint (DSCP) to a flow exporter.
source mgmt	Adds the management interface to a flow exporter designating it as the source for NetFlow flow records.
transport udp	Adds a destination UDP port used to reach the NetFlow collector to a flow exporter.
version 9	Designates NetFlow export version 9 in the NetFlow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

flow monitor

To create a Flexible NetFlow flow monitor, or to modify an existing Flexible NetFlow flow monitor, and enter Flexible NetFlow flow monitor configuration mode, use the **flow monitor** command. To remove a Flexible NetFlow flow monitor, use the **no** form of this command.

flow monitor *monitor-name*

no flow monitor *monitor-name*

Syntax Description

<i>monitor-name</i>	Name of the flow monitor that is created or modified.
---------------------	---

Defaults

Flow monitors are not present in the configuration until you create them.

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Flow monitors are the Flexible NetFlow component that is applied to interfaces to perform network traffic monitoring. Flow monitors consist of a record that you add to the flow monitor after you create the flow monitor, and a cache that is automatically created at the time the flow monitor is applied to the first interface. Flow data is collected from the network traffic during the monitoring process based on the key and non-key fields in the record which is configured for the flow monitor and stored in the flow monitor cache.

Once you enter the flow monitor configuration mode, the prompt changes to the following:

```
n1000v(config-flow-monitor)#
```

Within the flow monitor configuration mode, the following keywords and arguments are available to configure the flow monitor:

- **cache**—Specifies the cache size, from 256 to 16384 entries.
- **description** *description*—Provides a description for this flow monitor; maximum of 63 characters.
- **exit**—Exits from the current configuration mode.
- **exporter** *name*—Specifies the name of an exporter to export records.
- **no**—Negates a command or sets its defaults.
- **record** {*record-name* | **netflow ipv4** *collection-type* | **netflow-original**}—Specifies a flow record to use as follows:
 - *record-name*—Name of a record.

Send document comments to nexus1k-docfeedback@cisco.com.

- **netflow ipv4 collection-type**—Specifies the traditional IPv4 NetFlow collection schemes as follows:
 - original-input**—Specifies the traditional IPv4 input NetFlow.
 - original-output**—Specifies the traditional IPv4 output NetFlow
 - protocol-port**—Specifies the protocol and ports aggregation scheme.
- **netflow-original**—Specifies the traditional IPv4 input NetFlow with origin autonomous systems.
- **timeout { active | inactive }**—Specifies a flow timeout period as follows:
 - **active**—Specifies an active or long timeout in the range of 60 to 4092 seconds.
 - **inactive**—Specifies an inactive or normal timeout in the range of 15 to 4092 seconds.

The **netflow-original** and **original-input** keywords are the same and are equivalent to the following commands:

- **match ipv4 source address**
- **match ipv4 destination address**
- **match ip tos**
- **match ip protocol**
- **match transport source-port**
- **match transport destination-port**
- **match interface input**
- **collect counter bytes**
- **collect counter packet**
- **collect timestamp sys-uptime first**
- **collect timestamp sys-uptime last**
- **collect interface output**
- **collect transport tcp flags**

The **original-output** keywords are the same as **original-input** keywords except for the following:

- **match interface output** (instead of match interface input)
- **collect interface input** (instead of collect interface output)

Examples

The following examples creates and configures a flow monitor named FLOW-MONITOR-1:

```
n1000v(config)# flow monitor FLOW-MONITOR-1
n1000v(config-flow-monitor)# description monitor location las vegas, NV
n1000v(config-flow-monitor)# exporter exporter-name1
n1000v(config-flow-monitor)# record test-record
n1000v(config-flow-monitor)# netflow ipv4 original-input
```

Related Commands

Command	Description
clear flow monitor	Clears the flow monitor.
show flow monitor	Displays flow monitor status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

flow record

To create a Flexible NetFlow flow record, or to modify an existing Flexible NetFlow flow record, and enter Flexible NetFlow flow record configuration mode, use the **flow record** command. To remove a Flexible NetFlow flow record, use the **no** form of this command.

flow record *record-name*

no flow record *record-name*

Syntax Description

<i>record-name</i>	Name of the flow record that is created or modified.
--------------------	--

Defaults

Flow records are not present in the configuration until you create them.

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Flexible NetFlow uses key and non-key fields just as original NetFlow does to create and populate flows in a cache. In Flexible NetFlow a combination of key and non-key fields is called a record. Original NetFlow and Flexible NetFlow both use the values in key fields in IP datagrams, such as the IP source or destination address and the source or destination transport protocol port, as the criteria for determining when a new flow must be created in the cache while network traffic is being monitored. A flow is defined as a stream of packets between a given source and a given destination. New flows are created whenever NetFlow analyzes a packet that has a unique value in one of the key fields.

Once you enter the flow record configuration mode, the prompt changes to the following:

```
n1000v(config-flow-record)#
```

Within the flow record configuration mode, the following keywords and arguments are available to configure the flow record:

- **collect**—Specifies a non-key field. See the **collect** command for additional information.
- **description** *description*—Provides a description for this flow record; maximum of 63 characters.
- **exit**—Exits from the current configuration mode.
- **match**—Specifies a key field. See the **match** command for additional information.
- **no**—Negates a command or sets its defaults.

Cisco NX-OS enables the following match fields by default when you create a flow record:

- **match interface input**

Send document comments to nexus1k-docfeedback@cisco.com.

- **match interface output**
- **match flow direction**

Examples

The following example creates a flow record named FLOW-RECORD-1, and enters Flexible NetFlow flow record configuration mode:

```
n1000v(config)# flow record FLOW-RECORD-1
n1000v(config-flow-record)#
```

Related Commands

Command	Description
clear flow monitor	Clears the flow monitor.
flow monitor	Creates a flow monitor.
show flow monitor	Displays flow monitor status and statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

format

To format an external Flash device to erase the contents and restore it to its factory-shipped state, use the **format** command.

format *filesystem:*

Syntax Description	<i>filesystem:</i>	Name of the file system. The valid values are bootflash , logflash , slot0 , usb1 , or usb2 .
---------------------------	--------------------	--

Defaults	None
-----------------	------

Command Modes	any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You can use this command only in the default virtual device context (VDC).
-------------------------	--

Examples This example shows how to format an external Flash device:

```
n1000v# format slot0:
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	dir	Displays the directory contents.
	pwd	Displays the name of the current working directory.

■ from (table map)

Send document comments to nexus1k-docfeedback@cisco.com.

from (table map)

To specify a set of mappings of input field values to output field values in a table map, use the **from** command.

from *source-value to dest-value*

Syntax Description

<i>source-value</i>	Specifies the source value in the range from 0 to 63.
<i>dest-value</i>	Specifies the destination value in the range from 0 to 63.

Defaults

None

Command Modes

Table map configuration

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to create a mapping from three source values to the corresponding destination values:

```
n1000v(config)# table-map cir-markdown-map
n1000v(config-tmap)# from 0 to 7
n1000v(config-tmap)# from 1 to 6
n1000v(config-tmap)# from 2 to 5
```

Related Commands

Command	Description
show table-map	Displays table maps.



G Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter G.

gunzip

To uncompress a compressed file, use the **gunzip** command.

gunzip *filename*

Syntax Description

<i>filename</i>	Name of a file. The filename is case sensitive.
-----------------	---

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The compressed filename must have the .gz extension.
You do not have to enter the .gz extension as part of the filename.
The Cisco NX-OS software uses Lempel-Ziv 1977 (LZ77) coding for compression.

Examples

This example shows how to uncompress a compressed file:

```
n1000v# gunzip run_cfg.cfg
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	dir	Displays the directory contents.
	gzip	Compresses a file.

Send document comments to nexus1k-docfeedback@cisco.com.

gzip

To compress a file, use the **gzip** command.

gzip *filename*

Syntax Description	<i>filename</i>	Name of a file. The filename is case sensitive.
---------------------------	-----------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	After you use this command, the file is replaced with the compressed filename that has the .gz extension. The Cisco NX-OS software uses Lempel-Ziv 1977 (LZ77) coding for compression.
-------------------------	--

Examples	This example shows how to compress a file: n1000v# gzip run_cfg.cfg
-----------------	---

Related Commands	Command	Description
	dir	Displays the directory contents.
gunzip	Uncompresses a compressed file.	

Send document comments to nexus1k-docfeedback@cisco.com.



I Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter I.

install certificate

To install a certificate, use the **install certificate** command. To remove a certificate, use the **no** form of this command.

```
install certificate { bootflash: | default }
```

```
no install certificate
```

Syntax Description

bootflash:	Specifies the path.
default	Specifies the default certificate.

Defaults

No certificate is installed.

Command Modes

SVS connection configuration (config-svs-conn)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Only one SVS connection can be created.

Examples

This example shows how to install a certificate:

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v# configure terminal
n1000v(config)# svcs connect s1
n1000v(config-svs-conn)# install certificate default
n1000v(config-svs-conn)#
```

This example shows how to remove a certificate:

```
n1000v# configure terminal
n1000v(config)# svcs connect s1
n1000v(config-svs-conn)# no install certificate default
n1000v(config-svs-conn)#
```

Related Commands

Command	Description
show svcs	Displays SVS information.

Send document comments to nexus1k-docfeedback@cisco.com.

install license bootflash:

To install a license file(s) on a VSM, use the **install license bootflash:** command.

install license bootflash: *filename*

Syntax Description	<i>filename</i>	(Optional) Specify a name for the license file. If you do not specify a name, then the license is installed using the default name.
---------------------------	-----------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin network-operator
---------------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

- Usage Guidelines**
- You must first uninstall an evaluation license if one is present on your VSM. For more information, see the *Cisco Nexus 1000V License Configuration Guide, Release 4.0(4)SV1(1)*.
 - You must be logged in to the active VSM console port.
 - This command installs the license file using the name, `license_file.lic`. You can specify a different name.
 - If you are installing multiple licenses for the same VSM, also called license stacking, make sure that each license key file name is unique.
 - Repeat this procedure for each additional license file you are installing, or stacking, on the VSM.

Examples This example shows how to install a license to bootflash on a VSM and then display the installed file:

```
n1000v# install license bootflash:license_file.lic
Installing license ..done
n1000v# show license file license.lic
SERVER this_host ANY
VENDOR cisco
INCREMENT NEXUS1000V_LAN_SERVICES_PKG cisco 1.0 permanent 1 \
  HOSTID=VDH=1575337335122974806 \
  NOTICE="<LicFileID>license.lic</LicFileID><LicLineID>0</LicLineID> \
  <PAK>PAK12345678</PAK>" SIGN=3AF5C2D26E1A
n1000v#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show license file	Verifies the license installation by displaying the license configured for the VSM.
	clear license	Uninstalls a license, that is, removes it from the VSM and shuts down the Ethernet interfaces to the VEMs covered by that license.
	logging level license	Designates the level of severity at which license messages should be logged.
	install license	Installs a license file(s) on a VSM
	svs license transfer src-vem	Transfers licenses from a source VEM to another VEM, or to the VSM pool of available licenses.

Send document comments to nexus1k-docfeedback@cisco.com.

interface control

To configure the control interface and enter interface configuration mode, use the **interface control** command.

interface control0

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global configuration (config)
Interface configuration (config-if)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enter the interface configuration mode to configure the control interface:

```
n1000v(config)# interface control0
n1000v(config-if)#
```

Related Commands	Command	Description
	show interface control0	Displays information about the traffic on the control interface.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

interface ethernet

To configure an Ethernet interface, use the **interface ethernet** command.

interface ethernet *slot/port*

Syntax Description	<i>slot/port</i>	Specifies the slot number and port number for the Ethernet interface.
--------------------	------------------	---

Defaults	None
----------	------

Command Modes	Global Configuration (config) Interface Configuration (config-if)
---------------	--

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to access the interface command mode for configuring the Ethernet interface on slot 2, port 1:
----------	---

```
n1000v# config t
n1000v(config)# interface ethernet 2/1
n1000v(config-if)#
```

Related Commands	Command	Description
	show interface ethernet <i>slot/port</i>	Displays information about the Ethernet interface.

Send document comments to nexus1k-docfeedback@cisco.com.

interface loopback

To create and configure a loopback interface, use the **interface loopback** command. To remove a loopback interface, use the **no** form of this command.

interface loopback *number*

no interface loopback *number*

Syntax Description	<i>number</i>	Identifying interface number; valid values are from 0 to 1023.
--------------------	---------------	--

Defaults	None
----------	------

Command Modes	Global Configuration (config) Interface Configuration (config-if)
---------------	--

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to create a loopback interface:

```
n1000v(config)# interface loopback 50
n1000v(config-if)#
```

Related Commands	Command	Description
	show interface loopback	Displays information about the traffic on the specified loopback interface.

Send document comments to nexus1k-docfeedback@cisco.com.

interface mgmt

To configure the management interface and enter interface configuration mode, use the **interface management** command.

```
interface mgmt0
```

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global Configuration (config)
Interface Configuration (config-if)

SupportedUserRoles network-admin

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enter the interface configuration mode to configure the management interface:

```
n1000v(config)# interface mgmt0
n1000v(config-if)#
```

Command	Description
show interface mgmt0	Displays information about the traffic on the management interface.

Send document comments to nexus1k-docfeedback@cisco.com.

interface port-channel

To create a port-channel interface and enter interface configuration mode, use the **interface port-channel** command. To remove a logical port-channel interface or subinterface, use the **no** form of this command.

interface port-channel *channel-number*

no interface port-channel *channel-number*

Syntax Description	<i>channel-number</i> Channel number that is assigned to this port-channel logical interface. The range of valid values is from 1 to 4096.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Global Configuration (config) Interface Configuration (config-if)
----------------------	--

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use the **interface port-channel** command to create or delete port-channel groups and to enter the interface configuration mode for the port channel.

A port can belong to only one channel group.

When you use the **interface port-channel** command, follow these guidelines:

- If you are using CDP, you must configure it only on the physical interface and not on the port-channel interface.
- If you do not assign a static MAC address on the port-channel interface, a MAC address is automatically assigned. If you assign a static MAC address and then later remove it, the MAC address is automatically assigned.
- The MAC address of the port channel is the address of the first operational port added to the channel group. If this first-added port is removed from the channel, the MAC address comes from the next operational port added, if there is one.

Examples This example shows how to create a port-channel group interface with channel-group number 50:

```
n1000v(config)# interface port-channel 50
n1000v(config-if)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show interface port-channel	Displays information on traffic on the specified port-channel interface.
	show port-channel summary	Displays information on the port channels.

Send document comments to nexus1k-docfeedback@cisco.com.

interface vethernet

To create a virtual Ethernet interface and enter interface configuration mode, use the **interface vethernet** command. To remove a virtual Ethernet interface, use the **no** form of this command.

interface vethernet *number*

no interface vethernet *number*

Syntax Description	<i>number</i>	Identifying interface number; valid values are from 1 to 1048575.
---------------------------	---------------	---

Defaults	None
-----------------	------

Command Modes	Global Configuration (config) Interface Configuration (config-if)
----------------------	--

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to create a virtual Ethernet interface:

```
n1000v(config)# interface vethernet 50
n1000v(config-if)#
```

Related Commands	Command	Description
	show interface vethernet <i>number</i>	Displays information about the traffic on the specified virtual Ethernet interface.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip access-list

To create an access list, use the **ip access-list** command. To remove an access list, use the **no** form of this command.

ip access-list {*name* | **match-local-traffic**}

no ip access-list {*name* | **match-local-traffic**}

Syntax Description

<i>name</i>	List name.
match-local-traffic	Enables access list matching for locally generated traffic.

Defaults

No access list exists.

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to create an access list:

```
n1000v(config)# configure terminal
n1000v(config)# ip access-list acl1
n1000v(config)#
```

Related Commands

Command	Description
show access-lists	Displays access lists.

Send document comments to nexus1k-docfeedback@cisco.com.

ip address

To create an IP route, use the **ip address** command. To remove an IP address, use the **no** form of this command.

ip address {*address mask* | *prefix*} {*next-hop* | *next-hop-prefix* | *interface-type interface-number*} [**tag** *tag-value* | *preference*]

no ip address {*address mask* | *prefix*} {*next-hop* | *next-hop-prefix* | *interface-type interface-number*} [**secondary** | **tag** *tag-value* | *preference*]

Syntax Description		
<i>address</i>	IP address, in format A.B.C.D.	
<i>mask</i>	IP network mask, in format A.B.C.D.	
<i>prefix</i>	IP prefix and network mask length, in format A.B.C.D./LEN.	
<i>next-hop</i>	IP next-hop address, in format A.B.C.D.	
<i>next-hop-prefix</i>	IP next-hop prefix in format A.B.C.D./LEN.	
<i>interface-type</i>	Interface type.	
<i>interface-number</i>	Interface or subinterface number.	
secondary	(Optional) Configures additional IP addresses on the interface.	
tag	(Optional) Specifies a supply tag.	
<i>tag-value</i>	Supply tag value. The range of valid values is 0 to 4294967295. The default is 0.	
<i>preference</i>	(Optional) Route preference.	

Defaults None

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to create an IP address:

```
n1000v(config)# configure terminal
n1000v(config)# ip address 209.165.200.225 255.255.255.224 x
n1000v(config)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show ip interface A.B.C.D.	Displays interfaces for local IP addresses.

Send document comments to nexus1k-docfeedback@cisco.com.

ip directed-broadcast

To enable IP directed broadcast, use the **ip directed-broadcast** command. To disable IP directed broadcast, use the **no** form of this command.

ip directed-broadcast

no ip directed-broadcast

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Interface Configuration (config-if)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enable IP directed broadcast:

```
n1000v# configure terminal
n1000v(config)# interface mgmt 0
n1000v(config-if)# ip directed-broadcast
n1000v(config-if)#
```

Related Commands	Command	Description
	show ip interface	Displays IP interface information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip flow monitor

To enable a Flexible NetFlow flow monitor for traffic that the router is receiving or forwarding, use the **ip flow monitor** interface configuration mode command. To disable a Flexible NetFlow flow monitor, use the **no** form of this command.

```
ip flow monitor monitor-name {input | output}
```

```
no ip flow monitor monitor-name {input | output}
```

Syntax Description	<i>monitor-name</i>	Name of a flow monitor that you previously configured.
	input	Monitors traffic that the routers is receiving on the interface.
	output	Monitors traffic that the routers is transmitting on the interface.

Defaults Disabled.

Command Modes Interface Configuration (config-if)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You must have already created a flow monitor by using the **flow monitor** command before you can apply the flow monitor to an interface with the **ip flow monitor** command to enable traffic monitoring with Flexible NetFlow.

Examples The following example enables a flow monitor for monitoring input traffic:

```
n1000v(config)# interface ethernet0/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 input
```

The following example enables a flow monitor for monitoring output traffic:

```
n1000v(config)# interface ethernet0/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 output
```

The following example enables the same flow monitor on the same interface for monitoring input and output traffic:

```
n1000v(config)# interface ethernet0/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 input
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 output
```

Send document comments to nexus1k-docfeedback@cisco.com.

The following example enables two different flow monitors on the same interface for monitoring input and output traffic:

```
n1000v(config)# interface ethernet0/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 input
n1000v(config-if)# ip flow monitor FLOW-MONITOR-2 output
```

The following example enables the same flow monitor on two different interfaces for monitoring input and output traffic:

```
n1000v(config)# interface ethernet0/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 input
n1000v(config)# interface ethernet1/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 output
```

The following example enables two different flow monitors on two different interfaces for monitoring input and output traffic:

```
n1000v(config)# interface ethernet0/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-1 input
n1000v(config)# interface ethernet1/0
n1000v(config-if)# ip flow monitor FLOW-MONITOR-2 output
```

Related Commands

Command	Description
flow exporter	Creates a flow exporter.
flow monitor	Creates a flow monitor.
flow record	Creates a flow record.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip igmp snooping (Global)

To enable IGMP snooping, use the **ip igmp snooping** command. To disable IGMP snooping, use the **no** form of this command.

ip igmp snooping

no ip igmp snooping

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If the global configuration of IGMP snooping is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

Examples This example shows how to enable IGMP snooping:

```
n1000v(config)# ip igmp snooping
n1000v(config)#
```

This example shows how to disable IGMP snooping:

```
n1000v(config)# no ip igmp snooping
n1000v(config)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip igmp snooping (VLAN)

To enable IGMP snooping on a VLAN interface, use the **ip igmp snooping** command. To disable IGMP snooping on the interface, use the **no** form of this command.

ip igmp snooping

no ip igmp snooping

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If the global configuration of IGMP snooping is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

Examples This example shows how to enable IGMP snooping on a VLAN interface:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping
n1000v(config-vlan)#
```

This example shows how to disable IGMP snooping on a VLAN interface:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip igmp snooping explicit-tracking

To enable tracking of IGMPv3 membership reports from individual hosts for each port on a per-VLAN basis, use the **ip igmp snooping explicit-tracking** command. To disable tracking, use the **no** form of this command.

ip igmp snooping explicit-tracking

no ip igmp snooping explicit-tracking

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enable tracking of IGMPv3 membership reports on a VLAN interface:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping explicit-tracking
n1000v(config-vlan)#
```

This example shows how to disable IGMP snooping on a VLAN interface:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping explicit-tracking
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip igmp snooping fast-leave

To enable support of IGMPv2 hosts that cannot be explicitly tracked because of the host report suppression mechanism of the IGMPv2 protocol, use the **ip igmp snooping fast-leave** command. To disable support of IGMPv2 hosts, use the **no** form of this command.

ip igmp snooping fast-leave

no ip igmp snooping fast-leave

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines When you enable fast leave, the IGMP software assumes that no more than one host is present on each VLAN port.

Examples This example shows how to enable support of IGMPv2 hosts:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping fast-leave
n1000v(config-vlan)#
```

This example shows how to disable support of IGMPv2 hosts:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping fast-leave
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip igmp snooping last-member-query-interval

To configure a query interval in which the software removes a group, use the **ip igmp snooping last-member-query-interval** command. To reset the query interval to the default, use the **no** form of this command.

ip igmp snooping last-member-query-interval *interval*

no ip igmp snooping last-member-query-interval [*interval*]

Syntax Description	<i>interval</i>	Query interval in seconds. The range is from 1 to 25. The default is 1.
--------------------	-----------------	---

Defaults	The query interval is 1.
----------	--------------------------

Command Modes	VLAN configuration (config-vlan)
---------------	----------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure a query interval in which the software removes a group:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping last-member-query-interval 3
n1000v(config-vlan)#
```

This example shows how to reset a query interval to the default:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping last-member-query-interval
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip igmp snooping mrouter interface

To configure a static connection to a multicast router, use the **ip igmp snooping mrouter interface** command. To remove the static connection, use the **no** form of this command.

ip igmp snooping mrouter interface *if-type if-number*

no ip igmp snooping mrouter interface *if-type if-number*

Syntax Description		
	<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.

Defaults None

Command Modes VLAN configuration (config-vlan)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The interface to the router must be in the selected VLAN.

Examples This example shows how to configure a static connection to a multicast router:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping mrouter interface ethernet 2/1
n1000v(config-vlan)#
```

This example shows how to remove a static connection to a multicast router:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping mrouter interface ethernet 2/1
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip igmp snooping report-suppression (Global)

To configure IGMPv1 or GMPv2 report suppression for VLANs, use the **ip igmp snooping report-suppression** command. To remove IGMPv1 or GMPv2 report suppression, use the **no** form of this command.

ip igmp snooping report-suppression

no ip igmp snooping report-suppression

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure IGMPv1 or GMPv2 report suppression for VLANs:

```
n1000v(config)# ip igmp snooping report-suppression
```

This example shows how to remove IGMPv1 or GMPv2 report suppression:

```
n1000v(config)# no ip igmp snooping report-suppression
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip igmp snooping report-suppression (VLAN)

To configure IGMPv1 or GMPv2 report suppression for VLANs, use the **ip igmp snooping report-suppression** command. To remove IGMPv1 or GMPv2 report suppression, use the **no** form of this command.

ip igmp snooping report-suppression

no ip igmp snooping report-suppression

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure IGMPv1 or GMPv2 report suppression for VLANs:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping report-suppression
n1000v(config-vlan)#
```

This example shows how to remove IGMPv1 or GMPv2 report suppression:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping report-suppression
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip igmp snooping static-group

To configure a Layer 2 port of a VLAN as a static member of a multicast group, use the **ip igmp snooping static-group** command. To remove the static member, use the **no** form of this command.

ip igmp snooping static-group *group* **interface** *if-type if-number*

no ip igmp snooping static-group *group* **interface** *if-type if-number*

Syntax Description	
<i>group</i>	Group IP address.
interface	Specifies interface for static group.
<i>if-type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>if-number</i>	Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.

Defaults None

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You can specify the interface by the type and the number, such as ethernet slot/port.

Examples This example shows how to configure a static member of a multicast group:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping static-group 230.0.0.1 interface ethernet 2/1
n1000v(config-vlan)#
```

This example shows how to remove a static member of a multicast group:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping static-group 230.0.0.1 interface ethernet 2/1
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip igmp snooping v3-report-suppression (Global)

To configure IGMPv3 report suppression and proxy reporting, use the **ip igmp snooping v3-report-suppression** command. To remove IGMPv3 report suppression and proxy reporting, use the **no** form of this command.

ip igmp snooping v3-report-suppression

no ip igmp snooping v3-report-suppression

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure IGMPv3 report suppression and proxy reporting:

```
n1000v(config)# ip igmp snooping v3-report-suppression
```

This example shows how to remove IGMPv3 report suppression and proxy reporting:

```
n1000v(config)# no ip igmp snooping v3-report-suppression
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ip igmp snooping v3-report-suppression (VLAN)

To configure IGMPv3 report suppression and proxy reporting for VLANs, use the **ip igmp snooping v3-report-suppression** command. To remove IGMPv3 report suppression, use the **no** form of this command.

ip igmp snooping v3-report-suppression

no ip igmp snooping v3-report-suppression

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure IGMPv3 report suppression and proxy reporting for VLANs:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# ip igmp snooping v3-report-suppression
n1000v(config-vlan)#
```

This example shows how to remove IGMPv3 report suppression and proxy reporting for VLANs:

```
n1000v(config)# vlan 1
n1000v(config-vlan)# no ip igmp snooping v3-report-suppression
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show ip igmp snooping	Displays IGMP snooping information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip port access-group

To create an access group, use the **ip port access-group** command. To remove access control, use the **no** form of this command.

ip port access-group *name* {**in** | **out**}

no ip port access-group *name* {**in** | **out**}

Syntax Description	<i>name</i>	Group name. The range of valid values is 1 to 64.
	in	Specifies inbound traffic.
	out	Specifies outbound traffic.

Defaults No access group exists.

Command Modes Port profile configuration (config-port-prof)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You create an access group to specify in an ACL the access control of packets.

Examples This example shows how to create an access group:

```
n1000v# configure terminal
n1000v(config)# port-profile 1
n1000v(config-port-prof)# ip port access-group group1 in
n1000v(config-port-prof)#
```

Related Commands	Command	Description
	show access-lists	Displays access lists.
	show port-profile	Displays port profile information.

Send document comments to nexus1k-docfeedback@cisco.com.

ip source-route

To enable an IP source route, use the **ip source-route** command. To disable an IP source route, use the **no** form of this command.

ip source-route

no ip source-route

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enable an IP source route:

```
n1000v(config)# configure terminal
n1000v(config)# ip source-route
n1000v(config)#
```

Related Commands	Command	Description
	show ip static-route	Displays static routes.



L Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter L.

line console

To enter console configuration mode, use the **line console** command. To exit console configuration mode, use the **no** form of this command.

line console

no line console

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enter console configuration mode:

```
n1000v# configure terminal
n1000v(config)# line console
n1000v(config-console)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

line vty

To enter line configuration mode, use the **line vty** command. To exit line configuration mode, use the **no** form of this command.

line vty

no line vty

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enter line configuration mode:

```
n1000v# configure terminal
n1000v(config)# line vty
n1000v(config-line)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

logging console

Use the **logging console** command to enable logging messages to the console session.

To disable logging messages to the console session, use the **no** form of this command.

logging console [*severity-level*]

no logging console

Syntax Description

severity-level The severity level at which you want messages to be logged. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable *the highest level*
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition
6	Informational	Informational message only
7	Debugging	Appears during debugging only

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to enable logging messages with a severity level of 4 (warning) or higher to the console session:

```
n1000v# configure terminal
n1000v(config)# logging console 4
n1000v(config)#
```

Related Commands

Command	Description
show logging console	Displays the console logging configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

logging event

Use the **logging event** command to log interface events.

```
logging event {link-status | trunk-status} {enable | default}
```

```
no logging event {link-status | trunk-status} {enable | default}
```

Syntax	Description
link-status	Log all up/down and change status messages.
trunk-status	Log all trunk status messages.
default	The default logging configuration is used.
enable	Enables interface logging to override the port level logging configuration.

Defaults None

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to log interface events:

```
n1000v# configure terminal
n1000v(config)# logging event link-status default
n1000v(config)#
```

Related Commands	Command	Description
	show logging	Displays the logging configuration and contents of logfile.

Send document comments to nexus1k-docfeedback@cisco.com.

logging level

Use the **logging level** command to enable the logging of messages as follows:

- from a named facility (such as license or aaa)
- of a specified severity level or higher

To disable the logging of messages, use the **no** form of this command.

logging level *facility severity-level*

no logging level *facility severity-level*

Syntax Description

<i>facility</i>	Names the <i>facility</i> .
<i>severity-level</i>	The severity level at which you want messages to be logged. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable *the highest level*
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition
6	Informational	Informational message only
7	Debugging	Appears during debugging only

Defaults

None

Command Modes

Global Configuration

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Send document comments to nexus1k-docfeedback@cisco.com.

Usage Guidelines

To apply the same severity level to all facilities, use the following command:

- **logging level all** *level_number*

To list the available facilities for which messages can be logged, use the following command:

- **logging level ?**

Examples

This example shows how to enable logging messages from the AAA facility that have a severity level of 0 through 2:

```
n1000v# configure terminal
n1000v(config)# logging level aaa 2
n1000v(config)#
```

This example shows how to enable logging messages from the license facility with a severity level of 0 through 4; and then display the license logging configuration:

```
n1000v# configure terminal
n1000v(config)# logging level license 4
n1000v(config)# show logging level license
Facility           Default Severity      Current Session Severity
-----
licmgr              6                      4

0(emergencies)     1(alerts)             2(critical)
3(errors)          4(warnings)           5(notifications)
6(information)     7(debugging)
```

```
n1000v(config)#
```

Related Commands

Command	Description
show logging level	Displays the facility logging level configuration.
logging level ?	Lists the available facilities for which messages can be logged.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

logging logfile

Use the **logging logfile** command to configure the log file used to store system messages.

To remove a configuration, use the **no** form of this command.

logging logfile *logfile-name severity-level [size bytes]*

no logging logfile [*logfile-name severity-level [size bytes]*]

Syntax Description

logfile-name Specifies the name of the log file that stores system messages.

severity-level The severity level at which you want messages to be logged. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable *the highest level*
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition
6	Informational	Informational message only
7	Debugging	Appears during debugging only

size bytes (Optional) Specifies the log file size in bytes, from 4096 to 10485760 bytes. The default file size is 10485760 bytes.

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure a log file named *logfile* to store system messages and set its severity level to 4:

```
n1000v# config t
n1000v(config)# logging logfile logfile 4
n1000v(config)#
```

Related Commands

Command	Description
show logging logfile	Displays the contents of the log file.

Send document comments to nexus1k-docfeedback@cisco.com.

logging module

To start logging of module messages to the log file, use the **logging module** command. To stop module log messages, use the **no** form of this command.

logging module [*severity*]

no logging module [*severity*]

Syntax	Description																											
<i>severity-level</i>	<p>The severity level at which you want messages to be logged. If you do not specify a severity level, the default is used. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.</p> <p>Severity levels are as follows:</p> <table border="1"> <thead> <tr> <th>Level</th> <th>Designation</th> <th>Definition</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Emergency</td> <td>System unusable *the highest level*</td> </tr> <tr> <td>1</td> <td>Alert</td> <td>Immediate action needed</td> </tr> <tr> <td>2</td> <td>Critical</td> <td>Critical condition—default level</td> </tr> <tr> <td>3</td> <td>Error</td> <td>Error condition</td> </tr> <tr> <td>4</td> <td>Warning</td> <td>Warning condition</td> </tr> <tr> <td>5</td> <td>Notification</td> <td>Normal but significant condition (the default)</td> </tr> <tr> <td>6</td> <td>Informational</td> <td>Informational message only</td> </tr> <tr> <td>7</td> <td>Debugging</td> <td>Appears during debugging only</td> </tr> </tbody> </table>	Level	Designation	Definition	0	Emergency	System unusable *the highest level*	1	Alert	Immediate action needed	2	Critical	Critical condition—default level	3	Error	Error condition	4	Warning	Warning condition	5	Notification	Normal but significant condition (the default)	6	Informational	Informational message only	7	Debugging	Appears during debugging only
Level	Designation	Definition																										
0	Emergency	System unusable *the highest level*																										
1	Alert	Immediate action needed																										
2	Critical	Critical condition—default level																										
3	Error	Error condition																										
4	Warning	Warning condition																										
5	Notification	Normal but significant condition (the default)																										
6	Informational	Informational message only																										
7	Debugging	Appears during debugging only																										

Defaults
<p>Disabled</p> <p>If you start logging of module messages, and do not specify a severity, then the default is used, Notification (5).</p>

Command Modes
Global Configuration (config)

Supported User Roles
network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to start logging of module messages to the log file at the default severity level (severity 4):

```
n1000v# configure terminal
n1000v(config)# logging module
n1000v(config)#
```

This example shows how to stop the logging of module messages to the log file:

```
n1000v# configure terminal
n1000v(config)# no logging module
n1000v#
```

Related Commands

Command	Description
show logging module	Displays the current configuration for logging module messages to the log file.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

logging monitor

Use the **logging monitor** command to enable the logging of messages to the monitor (terminal line). This configuration applies to telnet and SSH sessions.

To disable monitor logging, use the **no** form of this command.

logging monitor [*severity-level*]

no logging monitor

Syntax Description

severity-level

The severity level at which you want messages to be logged. If you do not specify a severity level, the default is used. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable *the highest level*
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition (the default)
6	Informational	Informational message only
7	Debugging	Appears during debugging only

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

Network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to enable monitor log messages:

```
n1000v# configure terminal
n1000v(config)# logging monitor
n1000v(config)#
```

Related Commands

Command	Description
show logging monitor	Displays the monitor logging configuration.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

logging server

Use the **logging server** command to designate and configure a remote server for logging system messages. Use the **no** form of this command to remove or change the configuration,

```
logging server host0 [i1 [use-vrf s0 [facility {auth | authpriv | cron | daemon | ftp | kernel | local0
| local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user |
uucp}]]]
```

```
no logging server host0 [i1 [use-vrf s0 [facility {auth | authpriv | cron | daemon | ftp | kernel |
local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user |
uucp}]]]
```

Syntax

Description	<i>host0</i>
	Hostname/IPv4/IPv6 address of the Remote Syslog Server.
	<i>i1</i> (Optional) 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug.
	use-vrf <i>s0</i> (Optional) Enter VRF name, default is management + VRF name,default management.
	facility (Optional) Facility to use when forwarding to server.
	auth Use auth facility.
	authpriv Use authpriv facility.
	cron Use Cron/at facility.
	daemon Use daemon facility.
	ftp Use file transfer system facility.
	kernel Use kernel facility.
	local0 Use local0 facility.
	local1 Use local1 facility.
	local2 Use local2 facility.
	local3 Use local3 facility.
	local4 Use local4 facility.
	local5 Use local5 facility.
	local6 Use local6 facility.
	local7 Use local7 facility.
	lpr Use lpr facility.
	mail Use mail facility.
	news Use USENET news facility.
	syslog Use syslog facility.
	user Use user facility.
	uucp Use Unix-to-Unix copy system facility.

Defaults

None

Send document comments to nexus1k-docfeedback@cisco.com.

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to configure a remote syslog server at a specified IPv4 address, using the default outgoing facility:

```
n1000v# configure terminal
n1000v(config)# logging server 172.28.254.253
n1000v(config)#
```

This example shows how to configure a remote syslog server at a specified host name, with severity level 5 or higher:

```
n1000v# configure terminal
n1000v(config)# logging server syslogA 5
n1000v(config)#
```

Related Commands	Command	Description
	show logging server	Displays the current server configuration for logging system messages.

Send document comments to nexus1k-docfeedback@cisco.com.

logging timestamp

To set the unit of measure for the system messages timestamp, use the **logging timestamp** command. To restore the default unit of measure, use the **no** form of this command.

logging timestamp { **microseconds** | **milliseconds** | **seconds** }

no logging timestamp { **microseconds** | **milliseconds** | **seconds** }

Syntax	Description
microseconds	Timestamp in micro-seconds.
milliseconds	Timestamp in milli-seconds.
seconds	Timestamp in seconds (Default).

Defaults Seconds

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to set microseconds as the unit of measure for the system messages timestamp:

```
n1000v# configure terminal
n1000v(config)# logging timestamp microseconds
n1000v(config)#
```

Related Commands	Command	Description
	show logging timestamp	Displays the logging timestamp configuration.



M Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter M.

mac access-list

To create a MAC ACL, use the **mac access-list** command. To remove the MAC ACL, use the **no** form of this command.

mac access-list *name*

no mac access-list *name*

Syntax Description

<i>name</i>	List name. The range of valid values is 1 to 64.
-------------	--

Defaults

The MAC ACL does not exist.

Command Modes

Global Configuration (config)

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to create a MAC ACL:

```
n1000v# configure terminal
n1000v(config)# mac access-list a11
n1000v(config)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show access-list	Displays access list information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

mac address-table aging-time

To configure the aging time for entries in the Layer 2 table, use the **mac address-table aging-time** command. To return to the default settings, use the **no** form of this command.

mac address-table aging-time *seconds* [**vlan** *vlan-id*]

no mac address-table aging-time [**vlan** *vlan-id*]

Syntax Description	<i>seconds</i>	Aging time for MAC table entries for Layer 2. The range is from 120 to 918000 seconds. The default is 1800 seconds. Entering 0 disables the aging time.
	vlan <i>vlan-id</i>	(Optional) Specifies the VLAN to apply the changed aging time.

Defaults	1800 seconds
-----------------	--------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Enter **0** seconds to disable the aging process.

The age value may be rounded off to the nearest multiple of 5 seconds. If the system rounds the value to a different value from that specified by the user (from the rounding process), the system returns an informational message.

When you use this command in the global configuration mode, the age values of all VLANs for which a configuration has not been specified are modified and those VLANs with specifically modified aging times are not modified. When you use the **no** form of this command without the VLAN parameter, only those VLANs that have not been specifically configured for the aging time reset to the default value. Those VLANs with specifically modified aging times are not modified.

When you use this command and specify a VLAN, the aging time for only the specified VLAN is modified. When you use the **no** form of this command and specify a VLAN, the aging time for the VLAN is returned to the current *global* configuration for the aging time, which may or may not be the default value of 300 seconds depending if the global configuration of the device for aging time has been changed.

Aging time is counted from the last time that the switch detected the MAC address.

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to change the length of time an entry remains in the MAC address table to 500 seconds for the entire device:

```
n1000v(config)# mac address-table aging-time 500
n1000v(config)#
```

Related Commands

Command	Description
show mac address-table	Displays information about the MAC address table.
clear mac address-table aging-time	Displays information about the MAC address aging time.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

mac address-table static

To configure a static entry for the Layer 2 MAC address table, use the **mac address-table static** command. To delete the static entry, use the **no** form of this command.

```
mac address-table static mac-address vlan vlan-id {[drop | interface {type slot/port | port-channel number}]}
```

```
no mac address-table static {address mac_addr} {vlan vlan-id}
```

Syntax Description

<i>mac-address</i>	Specifies the MAC address to add to the table. Use the format XXXX.XXXX.XXXX.
vlan <i>vlan-id</i>	Specifies the VLAN to apply static MAC address; valid values are from 1 to 4094.
drop	Drops all traffic that is received from and going to the configured MAC address in the specified VLAN.
<i>type slot/port</i>	(Optional) Specifies the interface. Use the type of interface, the slot number, and the port number.
port-channel <i>number</i>	(Optional) Specifies the interface. Use the port-channel number.

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

You cannot apply the **mac address-table static** *mac-address* **vlan** *vlan-id* **drop** command to a multicast MAC address.

The output interface specified cannot be a VLAN interface or a Switched Virtual Interface (SVI).

Use the **no** form to remove entries that are profiled by the combination of specified entry information.

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to add a static entry to the MAC address table:

```
n1000v(config)# mac address-table static 0050.3e8d.6400 vlan 3 interface ethernet 2/1
n1000v(config)#
```

Related Commands

Command	Description
<code>show mac address-table</code>	Displays information about MAC address table.

Send document comments to nexus1k-docfeedback@cisco.com.

mac port access-group

To enable access control for port groups, use the **mac port access-group** command. To disable access control for port groups, use the **no** form of this command.

```
mac port access-group name {in | out}
```

```
no mac port access-group name {in | out}
```

Syntax Description	
<i>name</i>	Group name. The range of valid values is 1 to 64.
in	Specifies inbound traffic.
out	Specifies outbound traffic.

Defaults Access control for packets is not specified.

Command Modes Port profile configuration (config-port-prof)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enable access control for port groups:

```
n1000v# configure terminal
n1000v(config)# port-profile 1
n1000v(config-port-prof)# mac port access-group groupOne in
n1000v(config-port-prof)#
```

Related Commands	Command	Description
	show mac	Displays MAC information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

match (ACL)

To define ACL matching criteria, use the **match** command. To remove matching criteria, use the **no** form of this command.

```
match { {access-group name name} | {[not] cos cos-list} | {[not] dscp {dscp-list | dscp-enum}+}
| {[not] precedence {precedence-list | prec-enum}+} | {[not] discard-class discard-class-list}
| {[not] qos-group qos-group-list} | {[not] class-map cmap-name} | {[not] packet length
len-list} | {[not] ip rtp port-list}}
```

```
no match { {access-group name acl-name} | {[not] cos cos-list} | {[not] dscp {dscp-list |
dscp-enum}+} | {[not] precedence {precedence-list | prec-enum}+} | {[not] discard-class
discard-class-list} | {[not] qos-group qos-group-list} | {[not] class-map cmap-name} | {[not]
packet length len-list} | {[not] ip rtp port-list}}
```

Syntax Description

access-group	Specifies the access group.
name	Specifies the ACL name.
<i>name</i>	ACL name. The range of valid values is 1 to 64.
not	(Optional) Negates the match result.
cos	IEEE 802.1Q CoS (Class of Service).
<i>cos-list</i>	List of CoS values. The range of valid values is 0 to 7.
dscp	DSCP in IP(v4) and IPv6 packets.
<i>dscp-list</i>	List of DSCP values.
<i>dscp-enum</i>	.
precedence	Precedence in IP(v4) and IPv6 packets.
<i>precedence-list</i>	List of precedence values.
<i>prec-enum</i>	.
discard-class	Discard class + List of discard-class values.
<i>discard-class-list</i>	
qos-group	Qos-group + List of qos-group values.
<i>qos-group-list</i>	
class-map	Class map + Match class-map name.
<i>cmap-name</i>	
packet	Packet.
length	Length of IP datagram.
<i>len-list</i>	list of IP packet length.
ip	IP.
rtp	Real Time Protocol.
<i>port-list</i>	UDP port list that are using RTP.

Defaults

None

Send document comments to nexus1k-docfeedback@cisco.com.

Command Modes Class map configuration (config-cmap-qos)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to configure a class-map match criteria:

```
n1000v(config)# class-map cl_map1
n1000v(config-cmap-qos)# match access-group name ac_gr1
n1000v(config-cmap-qos)#
```

This example shows how to remove the class-map match criteria:

```
n1000v(config)# class-map cl_map1
n1000v(config-cmap-qos)# no match access-group name ac_gr1
n1000v(config-cmap-qos)#
```

Related Commands	Command	Description
	show class map	Displays class map information.

Send document comments to nexus1k-docfeedback@cisco.com.

match ip (NetFlow)

To define IP matching criteria for a NetFlow flow record, use the **match ip** command. To remove the matching criteria, use the **no** form of this command.

```
match ip {protocol | tos}
```

```
no match ip {protocol | tos}
```

Syntax Description	protocol	Protocol.
	tos	Type of service.

Defaults	None
----------	------

Command Modes	Flow Record Configuration (config-flow-record)
---------------	--

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure IP matching criteria for a NetFlow flow record and then display the result:

```
n1000v# config t
n1000v(config)# flow record RecordTest
n1000v(config-flow-record)# match ip protocol
n1000v(config-flow-record)# show flow record
Flow record RecordTest:
  No. of users: 0
  Template ID: 0
  Fields:
    match ip protocol
    match interface input
    match interface output
    match flow direction
doc-n1000v(config-flow-record)#
```

This example shows how to remove the IP matching criteria for a NetFlow flow record a and then display the result:

```
n1000v# config t
n1000v(config)# flow record RecordTest
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config-flow-record)# no match ip protocol
n1000v(config-flow-record)# show flow record
Flow record RecordTest:
  No. of users: 0
  Template ID: 0
  Fields:
    match interface input
    match interface output
    match flow direction
doc-n1000v(config-flow-record)#
```

Related Commands

Command	Description
show flow record [<i>name</i>]	Displays a NetFlow flow record configuration.
match ipv4	Defines IPv4 matching criteria for a NetFlow flow record
match transport	Defines transport matching criteria for a NetFlow flow record

Send document comments to nexus1k-docfeedback@cisco.com.

match ipv4 (NetFlow)

To define IPv4 matching criteria for a NetFlow flow record, use the **match ipv4** command. To remove the matching criteria, use the **no** form of this command.

```
match ipv4 {source | destination} address
```

```
no match ipv4 {source | destination} address
```

Syntax Description	source	Source Address.
	destination	Destination Address.
	address	Address.

Defaults	None
----------	------

Command Modes	Flow Record Configuration (config-flow-record)
---------------	--

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure IPv4 matching criteria for a NetFlow flow record and then display the result:

```
n1000v# config t
n1000v(config)# flow record RecordTest
n1000v(config-flow-record)# match ipv4 destination address
n1000v(config-flow-record)# show flow record
Flow record RecordTest:
  Description: Ipv4flow
  No. of users: 0
  Template ID: 0
  Fields:
    match ipv4 destination address
    match interface input
    match interface output
    match flow direction
    collect counter packets
n1000v(config-flow-record)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to remove the IPv4 matching criteria for a NetFlow flow record a and then display the result:

```
n1000v# config t
n1000v(config)# flow record RecordTest
n1000v(config-flow-record)# no match ipv4 destination address
n1000v(config-flow-record)# show flow record
Flow record RecordTest:
  No. of users: 0
  Template ID: 0
  Fields:
    match interface input
    match interface output
    match flow direction
doc-n1000v(config-flow-record)#
```

Related Commands

Command	Description
show flow record [<i>name</i>]	Displays a NetFlow flow record configuration.
match ip	Defines IP matching criteria for a NetFlow flow record
match transport	Defines transport matching criteria for a NetFlow flow record

Send document comments to nexus1k-docfeedback@cisco.com.

match transport (NetFlow)

To define transport matching criteria for a NetFlow flow record, use the **match transport** command. To remove the matching criteria, use the **no** form of this command.

```
match transport { destination-port | source-port }
```

```
no match transport { destination-port | source-port }
```

Syntax Description

destination-port	Transport destination port.
source-port	Transport source port.

Defaults

None

Command Modes

Flow Record Configuration (config-flow-record)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to configure transport matching criteria for a NetFlow flow record and then display the result:

```
n1000v# config t
n1000v(config)# flow record RecordTest
n1000v(config-flow-record)# match transport destination-port
n1000v(config-flow-record)# show flow record
Flow record RecordTest:
  Description: Ipv4flow
  No. of users: 0
  Template ID: 0
  Fields:
    match ipv4 destination-port
    match interface input
    match interface output
    match flow direction
    collect counter packets
n1000v(config-flow-record)#
```


Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to remove the transport matching criteria for a NetFlow flow record a and then display the result:

```
n1000v# config t
n1000v(config)# flow record RecordTest
n1000v(config-flow-record)# no match transport destination-port
n1000v(config-flow-record)# show flow record
Flow record RecordTest:
  No. of users: 0
  Template ID: 0
  Fields:
    match interface input
    match interface output
    match flow direction
doc-n1000v(config-flow-record)#
```

Related Commands

Command	Description
show flow record [<i>name</i>]	Displays a NetFlow flow record configuration.
match ip	Defines IP matching criteria for a NetFlow flow record
match ipv4	Defines IPv4 matching criteria for a NetFlow flow record

Send document comments to nexus1k-docfeedback@cisco.com.

media

To specify the media type of a VLAN as Ethernet, use the **media** command. To remove the type, use the **no** form of this command.

media ethernet

no media

Syntax Description	ethernet	Specifies Ethernet media type.
--------------------	----------	--------------------------------

Defaults	None
----------	------

Command Modes	VLAN configuration (config-vlan)
---------------	----------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to configure media type:

```
n1000v# configure terminal
n1000v(config)# media ethernet
n1000v(config)#
```

Related Commands	Command	Description
	show vlan	Displays VLAN information.

Send document comments to nexus1k-docfeedback@cisco.com.

mkdir

To create a new directory, use the **mkdir** command.

```
mkdir {bootflash: | debug: | volatile:}
```

Syntax Description	
bootflash:	Specifies bootflash as the directory name.
debug:	Specifies debug as the directory name.
volatile:	Specifies volatile as the directory name.

Defaults	None
----------	------

Command Modes	EXEC
---------------	------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to create the bootflash: directory:

```
n1000v# mkdir bootflash:
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	dir	Displays the directory contents.
	pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

module vem

To execute commands on the VEM module, use the **module vem** command.

module vem *module-number* **execute** *line* [*line*]

Syntax Description	
<i>module-number</i>	Specifies the module number. The range is 3 to 66.
execute	Specifies the command to execute on the VEM.
<i>line</i>	The name of the command to be remotely executed.

Defaults	
	None

Command Modes	
	EXEC

SupportedUserRoles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples	
	This example shows how to execute the show port-profile command remotely on the VEM module: <pre>n1000v# module vem 3 execute vemcmd show</pre>

Related Commands	Command	Description
	show module vem	Displays Virtual Ethernet Module information.

Send document comments to nexus1k-docfeedback@cisco.com.

monitor session

To enter the Monitor Configuration mode for configuring an Ethernet switch port analyzer (SPAN) session for analyzing traffic between ports, use the monitor session command.

To disable monitoring a SPAN session(s), use the no form of this command.

```
monitor session {session-number [shut | type erspan-source] | all shut}
```

```
no monitor session {session-number [shut | type erspan-source] | all shut}
```

Syntax Description

<i>session-number</i>	Specifies the session number for monitoring a switched port. SPAN sessions are numbered from 1 to 64.
shut	(Optional) Shuts the selected session.
type	(Optional) Specifies a session type.
erspan-source	(Optional) Creates an erspan source session
all	Specify all sessions for monitoring a switched port.

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to enter the Monitor Configuration mode for configuring SPAN session number 2 for analyzing traffic between ports:

```
n1000v# configuration t
n1000v(config)# monitor session 2
n1000v(config-monitor)#
```

This example shows how to remove the configuration for SPAN session 2 for analyzing traffic between ports:

```
n1000v# configuration t
n1000v(config)# no monitor session 2
n1000v(config)#
```

Related Commands

Command	Description
show monitor	Displays Ethernet SPAN information.

Send document comments to nexus1k-docfeedback@cisco.com.

move

To move a file from one directory to another, use the **move** command.

```
move [filesystem://module][directory/] | directory/source-filename
      { {filesystem://module}[directory/] | directory/}[destination-filename] | target-filename }
```

Syntax Description

<i>filesystem</i> :	(Optional) Name of a file system. The name is case sensitive.
<i>//module</i> /	(Optional) Identifier for a supervisor module. Valid values are sup-active , sup-local , sup-remote , or sup-standby . The identifiers are case sensitive.
<i>directory</i> /	(Optional) Name of a directory. The name is case sensitive.
<i>source-filename</i>	Name of the file to move. The name is case sensitive.
<i>destination-filename</i>	(Optional) Name of the destination file. The name is alphanumeric, case sensitive, and has a maximum of 64 characters.

Defaults

The default name for the destination file is the same as the source filename.

Command Modes

any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

You can make a copy of a file by using the **copy** command.



Tip

You can rename a file by moving it within the same directory.

Examples

This example shows how to move a file to another directory:

```
n1000v# move file1 my_files:file2
```

This example shows how to move a file to another file system:

```
n1000v# move file1 slot0:
```

This example shows how to move a file to another supervisor module:

```
n1000v# move file1 bootflash://sup-remote/file1.bak
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	cd	Changes the current working directory.
	copy	Makes a copy of a file.
	dir	Displays the directory contents.
	pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

mtu

To configure the maximum transmission unit (MTU) size for an interface, use the **mtu** command. To remove the configured MTU size from the interface, use the **no** form of this command.

mtu *size*

no mtu *size*

Syntax Description	<i>size</i>	Specifies the MTU size. The range is 1500 to 9000.
Defaults	1500 Bytes	
Command Modes	Interface Configuration (config-if)	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Examples	<p>This example shows how to set the MTU size to 2000:</p> <pre>n1000v# configure terminal n1000v(config)# configure interface port-channel 2 n1000v(config-if)# mtu 2000</pre>	
Related Commands	Command	Description
	show interface	Displays information about the interface, which includes MTU size.



N Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter N.

name

To name a VLAN, use the **name** command. To remove a VLAN name, use the **no** form of this command.

name *name*

no name

Syntax Description

name VLAN name. The range of valid values is 1 to 32.

Defaults

The VLAN has no name.

Command Modes

VLAN configuration (config-vlan)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to name a VLAN:

```
n1000v# configure terminal
n1000v(config)# vlan 10
n1000v(config-vlan)# name v10
(config-vlan)#
```

name

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show vlan	Displays VLAN information.

Send document comments to nexus1k-docfeedback@cisco.com.

ntp enable

To enable NTP, use the **ntp enable** command. To disable, use the **no** command form.

ntp enable

no ntp enable

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enable NTP:

```
n1000v# ntp enable
```

This example shows how to disable NTP:

```
n1000v# no ntp enable
```

Related Commands	Command	Description
	ntp server	Configures a remote NTP server.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ntp peer

To do configure the Network Time Protocol peer, use the **ntp peer** command. To remove the peer, use the **no** form of this command.

ntp peer *host* [*prefer*] [**use-vrf** *vrf*]

no ntp peer *host* [**prefer**] [**use-vrf** *vrf*]

Syntax Description		
	<i>host</i>	Hostname or IP address of the NTP peer.
	prefer	(Optional) Specifies this peer as the preferred peer.
	use-vrf <i>vrf</i>	(Optional) Specifies the virtual routing and forwarding (VRF) used to reach this peer.

Defaults	
	None

Command Modes	
	Global Configuration (config)

Supported User Roles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure an NTP peer:

```
n1000v(config)# ntp peer 192.0.2.2
```

Related Commands	Command	Description
	show ntp peer	Displays information about the NTP peer.

Send document comments to nexus1k-docfeedback@cisco.com.

ntp server

To do configure a Network Time Protocol server, use the **ntp server** command. To remove the server, use the **no** form of this command.

ntp server *host* [**prefer**] [**use-vrf** *vrf*]

no ntp server *host* [**prefer**] [**use-vrf** *vrf*]

Syntax Description		
<i>host</i>		Hostname or IP address of the NTP server.
prefer		(Optional) Specifies this server as the preferred server.
use-vrf <i>vrf</i>		(Optional) Specifies the virtual routing and forwarding (VRF) used to reach this peer.

Defaults	
	None

Command Modes	
	Global Configuration (config)

Supported User Roles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure an NTP server:

```
n1000v(config)# ntp server 192.0.2.2
```

Related Commands	Command	Description
	show ntp peer	Displays information about the NTP peer.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

ntp source

To do configure the Network Time Protocol source, use the **ntp source** command. To remove the NTP source, use the **no** form of this command.

ntp source *addr*

no ntp source *addr*

Syntax Description	<i>addr</i>	IPv4 or IPv6 address of the source. The IPv4 address format is dotted decimal, x.x.x.x. The IPv6 address format is hex A:B::C:D.
Defaults	None	
Command Modes	Global Configuration (config)	
SupportedUserRoles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines		
Examples	<p>This example shows how to configure the NTP source:</p> <pre>n1000v(config)# ntp source 192.0.2.3</pre> <p>This example shows how to remove the NTP source:</p> <pre>n1000v(config)# no ntp source 192.0.2.3</pre>	
Related Commands	Command	Description
	show ntp source	Displays information about the NTP source.



O Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter O.

option exporter-stats timeout

To specify a timeout period for resending NetFlow flow exporter data, use the **option exporter-stats timeout** command. To remove the timeout period, use the **no** form of this command.

option exporter-stats timeout *time*

no option exporter-stats timeout

Syntax Description

<i>time</i>	A time period between 1 and 86400 seconds.
-------------	--

Defaults

None

Command Modes

Netflow Flow Exporter Version 9 Configuration (**config-flow-exporter-version-9**)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to configure a 3600-second timeout period for resending NetFlow flow exporter data:

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# option exporter-stats timeout 3600
```

This example shows how to remove the timeout period for resending NetFlow flow exporter data:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# no option exporter-stats timeout
n1000v(config-flow-exporter)#
```

Related Commands

Command	Description
version 9	Designates NetFlow export version 9 in the NetFlow exporter.
option interface-table timeout	Specifies a timeout resend period for the NetFlow flow exporter interface table.
template data timeout	Specifies a timeout resend period for NetFlow flow exporter template data.
flow exporter	Creates a Flexible NetFlow flow exporter.
flow record	Creates a Flexible NetFlow flow record.
flow monitor	Creates a Flexible NetFlow flow monitor.
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

option interface-table timeout

To specify the timeout period for resending the NetFlow flow exporter interface table, use the **option interface-table timeout** command. To remove the timeout period, use the **no** form of this command.

option interface-table timeout *time*

no option interface-table timeout

Syntax Description	<i>time</i>	A time period between 1 and 86400 seconds.
Defaults	None	
Command Modes	Netflow Flow Exporter Version 9 Configuration (config-flow-exporter-version-9)	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines		
Examples	<p>This example shows how to configure a 3600 second timeout period for resending the NetFlow flow exporter interface table:</p> <pre>n1000v# config t n1000v(config)# flow exporter ExportTest n1000v(config-flow-exporter)# version 9 n1000v(config-flow-exporter-version-9)# option exporter-stats timeout 3600</pre> <p>This example shows how to remove the timeout period for resending the NetFlow flow exporter interface table:</p> <pre>n1000v# config t n1000v(config)# flow exporter ExportTest n1000v(config-flow-exporter)# version 9 n1000v(config-flow-exporter-version-9)# no option exporter-stats timeout n1000v(config-flow-exporter)#</pre>	
Related Commands	Command	Description
	version 9	Designates NetFlow export version 9 in the NetFlow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
option exporter-stats timeout	Specifies a timeout resend period for NetFlow flow exporter data.
template data timeout	Specifies a timeout resend period for NetFlow flow exporter template data.
flow exporter	Creates a Flexible NetFlow flow exporter.
flow record	Creates a Flexible NetFlow flow record.
flow monitor	Creates a Flexible NetFlow flow monitor.
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.



P Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter P.

packet vlan

To identify a packet VLAN, use the **packet vlan** command. To remove the packet vlan, use the **no** form of this command.

packet vlan {*vlan-number*}

no packet vlan {*vlan-number*}

Syntax Description	<i>vlan-number</i> Specifies the packet VLAN ID. The range of values is 1 to 3967 and 4048 to 4093.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	SVS Domain (config-svs-domain)
----------------------	--------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to create packet VLAN 261:

```
n1000v# configure terminal
n1000v(config)# svs-domain
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config-svs-domain) # packet vlan 261
n1000v(config-svs-domain) #
```

This example shows how to remove the packet VLAN 261:

```
n1000v# configure terminal
n1000v(config) # svs-domain
n1000v(config-svs-domain) # no packet vlan 261
n1000v(config-svs-domain) #
```

Related Commands

Command	Description
show running-config	Displays information about the running configuration on the switch.

Send document comments to nexus1k-docfeedback@cisco.com.

permit (IPv4)

To create an IPv4 access control list (ACL) rule that permits traffic matching its conditions, use the **permit** command. To remove a rule, use the **no** form of this command.

General Syntax

```
[sequence-number] permit protocol source destination [dscp dscp | precedence precedence]  
no permit protocol source destination [dscp dscp | precedence precedence]  
no sequence-number
```

Internet Control Message Protocol

```
[sequence-number] permit icmp source destination [icmp-message] [dscp dscp | precedence precedence]
```

Internet Group Management Protocol

```
[sequence-number] permit igmp source destination [igmp-message] [dscp dscp | precedence precedence]
```

Internet Protocol v4

```
[sequence-number] permit ip source destination [dscp dscp | precedence precedence]
```

Transmission Control Protocol

```
[sequence-number] permit tcp source [operator port [port] | portgroup portgroup] destination  
[operator port [port] | portgroup portgroup] [dscp dscp | precedence precedence]
```

User Datagram Protocol

```
[sequence-number] permit udp source [operator port [port] | portgroup portgroup] destination  
[operator port [port] | portgroup portgroup] [dscp dscp | precedence precedence]
```

Send document comments to nexus1k-docfeedback@cisco.com.

Syntax Description	<p><i>sequence-number</i> (Optional) Sequence number of the permit command, which causes the device to insert the command in that numbered position in the access list. Sequence numbers maintain the order of rules within an ACL.</p> <p>A sequence number can be any integer between 1 and 4294967295.</p> <p>By default, the first rule in an ACL has a sequence number of 10.</p> <p>If you do not specify a sequence number, the device adds the rule to the end of the ACL and assigns a sequence number that is 10 greater than the sequence number of the preceding rule.</p> <p>Use the resequence command to reassign sequence numbers to rules.</p>
<i>protocol</i>	<p>Name or number of the protocol of packets that the rule matches. Valid numbers are from 0 to 255. Valid protocol names are the following keywords:</p> <ul style="list-style-type: none"> • icmp—Specifies that the rule applies to ICMP traffic only. When you use this keyword, the <i>icmp-message</i> argument is available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument. • igmp—Specifies that the rule applies to IGMP traffic only. When you use this keyword, the <i>igmp-type</i> argument is available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument. • ip—Specifies that the rule applies to all IPv4 traffic. When you use this keyword, only the other keywords and arguments that apply to all IPv4 protocols are available. They include the following: <ul style="list-style-type: none"> – dscp – precedence • tcp—Specifies that the rule applies to TCP traffic only. When you use this keyword, the <i>flags</i> and <i>operator</i> arguments and the portgroup and established keywords are available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument. • udp—Specifies that the rule applies to UDP traffic only. When you use this keyword, the <i>operator</i> argument and the portgroup keyword are available, in addition to the keywords that are available for all valid values of the <i>protocol</i> argument.
<i>source</i>	<p>Source IPv4 addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.</p>
<i>destination</i>	<p>Destination IPv4 addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.</p>

Send document comments to nexus1k-docfeedback@cisco.com.

dscp <i>dscp</i>	<p>(Optional) Specifies that the rule matches only those packets with the specified 6-bit differentiated services value in the DSCP field of the IP header. The <i>dscp</i> argument can be one of the following numbers or keywords:</p> <ul style="list-style-type: none">• 0–63—The decimal equivalent of the 6 bits of the DSCP field. For example, if you specify 10, the rule matches only those packets that have the following bits in the DSCP field: 001010.• af11—Assured Forwarding (AF) class 1, low drop probability (001010)• af12—AF class 1, medium drop probability (001100)• af13—AF class 1, high drop probability (001110)• af21—AF class 2, low drop probability (010010)• af22—AF class 2, medium drop probability (010100)• af23—AF class 2, high drop probability (010110)• af31—AF class 3, low drop probability (011010)• af32—AF class 3, medium drop probability (011100)• af33—AF class 3, high drop probability (011110)• af41—AF class 4, low drop probability (100010)• af42—AF class 4, medium drop probability (100100)• af43—AF class 4, high drop probability (100110)• cs1—Class-selector (CS) 1, precedence 1 (001000)• cs2—CS2, precedence 2 (010000)• cs3—CS3, precedence 3 (011000)• cs4—CS4, precedence 4 (100000)• cs5—CS5, precedence 5 (101000)• cs6—CS6, precedence 6 (110000)• cs7—CS7, precedence 7 (111000)• default—Default DSCP value (000000)• if—Expedited Forwarding (101110)
-------------------------	--

Send document comments to nexus1k-docfeedback@cisco.com.

precedence <i>precedence</i>	<p>(Optional) Specifies that the rule matches only packets that have an IP Precedence field with the value specified by the <i>precedence</i> argument. The <i>precedence</i> argument can be a number or a keyword, as follows:</p> <ul style="list-style-type: none"> • 0–7—Decimal equivalent of the 3 bits of the IP Precedence field. For example, if you specify 3, the rule matches only packets that have the following bits in the DSCP field: 011. • critical—Precedence 5 (101) • flash—Precedence 3 (011) • flash-override—Precedence 4 (100) • immediate—Precedence 2 (010) • internet—Precedence 6 (110) • network—Precedence 7 (111) • priority—Precedence 1 (001) • routine—Precedence 0 (000)
<i>icmp-message</i>	<p>(ICMP only: Optional) ICMP message type that the rule matches. This argument can be an integer from 0 to 255 or one of the keywords listed under “ICMP Message Types” in the “Usage Guidelines” section.</p>
<i>igmp-message</i>	<p>(IGMP only: Optional) IGMP message type that the rule matches. The <i>igmp-message</i> argument can be the IGMP message number, which is an integer from 0 to 15. It can also be one of the following keywords:</p> <ul style="list-style-type: none"> • dvmp—Distance Vector Multicast Routing Protocol • host-query—Host query • host-report—Host report • pim—Protocol Independent Multicast • trace—Multicast trace

Send document comments to nexus1k-docfeedback@cisco.com.

<i>operator port</i> [<i>port</i>]	<p>(Optional; TCP and UDP only) Rule matches only packets that are from a source port or sent to a destination port that satisfies the conditions of the <i>operator</i> and <i>port</i> arguments. Whether these arguments apply to a source port or a destination port depends upon whether you specify them after the <i>source</i> argument or after the <i>destination</i> argument.</p> <p>The <i>port</i> argument can be the name or the number of a TCP or UDP port. Valid numbers are integers from 0 to 65535. For listings of valid port names, see “TCP Port Names” and “UDP Port Names” in the “Usage Guidelines” section.</p> <p>A second <i>port</i> argument is required only when the <i>operator</i> argument is a range. The <i>operator</i> argument must be one of the following keywords:</p> <ul style="list-style-type: none"> • eq—Matches only if the port in the packet is equal to the <i>port</i> argument. • gt—Matches only if the port in the packet is greater than and not equal to the <i>port</i> argument. • lt—Matches only if the port in the packet is less than and not equal to the <i>port</i> argument. • neq—Matches only if the port in the packet is not equal to the <i>port</i> argument. • range—Requires two <i>port</i> arguments and matches only if the port in the packet is equal to or greater than the first <i>port</i> argument and equal to or less than the second <i>port</i> argument.
<i>flags</i>	<p>(TCP only; Optional) TCP control bit flags that the rule matches. The value of the <i>flags</i> argument must be one or more of the following keywords:</p> <ul style="list-style-type: none"> • ack • fin • psh • rst • syn • urg

Defaults

A newly created IPv4 ACL contains no rules.

If you do not specify a sequence number, the device assigns to the rule a sequence number that is 10 greater than the last rule in the ACL.

Command Modes

IPv4 ACL configuration

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Send document comments to nexus1k-docfeedback@cisco.com.

Usage Guidelines

When the device applies an IPv4 ACL to a packet, it evaluates the packet with every rule in the ACL. The device enforces the first rule that has conditions that are satisfied by the packet. When the conditions of more than one rule are satisfied, the device enforces the rule with the lowest sequence number.

Source and Destination

You can specify the *source* and *destination* arguments in one of several ways. In each rule, the method you use to specify one of these arguments does not affect how you specify the other. When you configure a rule, use the following methods to specify the *source* and *destination* arguments:

- **Address and network wildcard**—You can use an IPv4 address followed by a network wildcard to specify a host or a network as a source or destination. The syntax is as follows:

```
IPv4-address network-wildcard
```

The following example shows how to specify the *source* argument with the IPv4 address and network wildcard for the 192.168.67.0 subnet:

```
n1000v(config-acl)# permit tcp 192.168.67.0 0.0.0.255 any
```

- **Address and variable-length subnet mask**—You can use an IPv4 address followed by a variable-length subnet mask (VLSM) to specify a host or a network as a source or destination. The syntax is as follows:

```
IPv4-address/prefix-len
```

The following example shows how to specify the *source* argument with the IPv4 address and VLSM for the 192.168.67.0 subnet:

```
n1000v(config-acl)# permit udp 192.168.67.0/24 any
```

- **Host address**—You can use the **host** keyword and an IPv4 address to specify a host as a source or destination. The syntax is as follows:

```
host IPv4-address
```

This syntax is equivalent to *IPv4-address/32* and *IPv4-address 0.0.0.0*.

The following example shows how to specify the *source* argument with the **host** keyword and the 192.168.67.132 IPv4 address:

```
n1000v(config-acl)# permit icmp host 192.168.67.132 any
```

- **Any address**—You can use the **any** keyword to specify that a source or destination is any IPv4 address. For examples of the use of the **any** keyword, see the examples in this section. Each example shows how to specify a source or destination by using the **any** keyword.

ICMP Message Types

The *icmp-message* argument can be the ICMP message number, which is an integer from 0 to 255. It can also be one of the following keywords:

- **administratively-prohibited**—Administratively prohibited
- **alternate-address**—Alternate address
- **conversion-error**—Datagram conversion
- **dod-host-prohibited**—Host prohibited
- **dod-net-prohibited**—Net prohibited
- **echo**—Echo (ping)
- **echo-reply**—Echo reply

Send document comments to nexus1k-docfeedback@cisco.com.

- **general-parameter-problem**—Parameter problem
- **host-isolated**—Host isolated
- **host-precedence-unreachable**—Host unreachable for precedence
- **host-redirect**—Host redirect
- **host-tos-redirect**—Host redirect for ToS
- **host-tos-unreachable**—Host unreachable for ToS
- **host-unknown**—Host unknown
- **host-unreachable**—Host unreachable
- **information-reply**—Information replies
- **information-request**—Information requests
- **mask-reply**—Mask replies
- **mask-request**—Mask requests
- **mobile-redirect**—Mobile host redirect
- **net-redirect**—Network redirect
- **net-tos-redirect**—Net redirect for ToS
- **net-tos-unreachable**—Network unreachable for ToS
- **net-unreachable**—Net unreachable
- **network-unknown**—Network unknown
- **no-room-for-option**—Parameter required but no room
- **option-missing**—Parameter required but not present
- **packet-too-big**—Fragmentation needed and DF set
- **parameter-problem**—All parameter problems
- **port-unreachable**—Port unreachable
- **precedence-unreachable**—Precedence cutoff
- **protocol-unreachable**—Protocol unreachable
- **reassembly-timeout**—Reassembly timeout
- **redirect**—All redirects
- **router-advertisement**—Router discovery advertisements
- **router-solicitation**—Router discovery solicitations
- **source-quench**—Source quenches
- **source-route-failed**—Source route failed
- **time-exceeded**—All time exceeded messages
- **timestamp-reply**—Timestamp replies
- **timestamp-request**—Timestamp requests
- **traceroute**—Traceroute
- **ttl-exceeded**—TTL exceeded
- **unreachable**—All unreachables

Send document comments to nexus1k-docfeedback@cisco.com.

TCP Port Names

When you specify the *protocol* argument as **tcp**, the *port* argument can be a TCP port number, which is an integer from 0 to 65535. It can also be one of the following keywords:

bgp—Border Gateway Protocol (179)
chargen—Character generator (19)
cmd—Remote commands (rcmd, 514)
daytime—Daytime (13)
discard—Discard (9)
domain—Domain Name Service (53)
drip—Dynamic Routing Information Protocol (3949)
echo—Echo (7)
exec—Exec (rsh, 512)
finger—Finger (79)
ftp—File Transfer Protocol (21)
ftp-data—FTP data connections (2)
gopher—Gopher (7)
hostname—NIC hostname server (11)
ident—Ident Protocol (113)
irc—Internet Relay Chat (194)
klogin—Kerberos login (543)
kshell—Kerberos shell (544)
login—Login (rlogin, 513)
lpd—Printer service (515)
nntp—Network News Transport Protocol (119)
pim-auto-rp—PIM Auto-RP (496)
pop2—Post Office Protocol v2 (19)
pop3—Post Office Protocol v3 (11)
smtp—Simple Mail Transport Protocol (25)
sunrpc—Sun Remote Procedure Call (111)
tacacs—TAC Access Control System (49)
talk—Talk (517)
telnet—Telnet (23)
time—Time (37)
uucp—UNIX-to-UNIX Copy Program (54)
whois—WHOIS/NICNAME (43)
www—World Wide Web (HTTP, 8)

Send document comments to nexus1k-docfeedback@cisco.com.

UDP Port Names

When you specify the *protocol* argument as **udp**, the *port* argument can be a UDP port number, which is an integer from 0 to 65535. It can also be one of the following keywords:

biff—Biff (mail notification, comsat, 512)
bootpc—Bootstrap Protocol (BOOTP) client (68)
bootps—Bootstrap Protocol (BOOTP) server (67)
discard—Discard (9)
dnsix—DNSIX security protocol auditing (195)
domain—Domain Name Service (DNS, 53)
echo—Echo (7)
isakmp—Internet Security Association and Key Management Protocol (5)
mobile-ip—Mobile IP registration (434)
nameserver—IEN116 name service (obsolete, 42)
netbios-dgm—NetBIOS datagram service (138)
netbios-ns—NetBIOS name service (137)
netbios-ss—NetBIOS session service (139)
non500-isakmp—Internet Security Association and Key Management Protocol (45)
ntp—Network Time Protocol (123)
pim-auto-rp—PIM Auto-RP (496)
rip—Routing Information Protocol (router, in.routed, 52)
snmp—Simple Network Management Protocol (161)
snmptrap—SNMP Traps (162)
sunrpc—Sun Remote Procedure Call (111)
syslog—System Logger (514)
tacacs—TAC Access Control System (49)
talk—Talk (517)
tftp—Trivial File Transfer Protocol (69)
time—Time (37)
who—Who service (rwho, 513)
xdmcp—X Display Manager Control Protocol (177)

Examples

This example shows how to configure an IPv4 ACL named `acl-lab-01` with rules permitting all TCP and UDP traffic from the 10.23.0.0 and 192.168.37.0 networks to the 10.176.0.0 network:

```
n1000v# config t
n1000v(config)# ip access-list acl-lab-01
n1000v(config-acl)# permit tcp 10.23.0.0/16 10.176.0.0/16
n1000v(config-acl)# permit udp 10.23.0.0/16 10.176.0.0/16
n1000v(config-acl)# permit tcp 192.168.37.0/16 10.176.0.0/16
n1000v(config-acl)# permit udp 192.168.37.0/16 10.176.0.0/16
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to configure an IPv4 ACL named `acl-eng-to-marketing` with a rule that permits all IP traffic from an IP-address object group named `eng_workstations` to an IP-address object group named `marketing_group`:

```
n1000v# config t
n1000v(config)# ip access-list acl-eng-to-marketing
n1000v(config-acl)# permit ip addrgroup eng_workstations addrgroup marketing_group
```

Related Commands

Command	Description
deny (IPv4)	Configures a deny rule in an IPv4 ACL.
ip access-list	Configures an IPv4 ACL.
remark	Configures a remark in an ACL.
show ip access-list	Displays all IPv4 ACLs or one IPv4 ACL.
statistics per-entry	Enables collection of statistics for each entry in an ACL.

Send document comments to nexus1k-docfeedback@cisco.com.

permit (MAC)

To create a MAC ACL rule that permits traffic matching its conditions, use the **permit** command. To remove a rule, use the **no** form of this command.

```
[sequence-number] permit source destination [protocol] [cos cos-value] [vlan VLAN-ID]
```

```
no permit source destination [protocol] [cos cos-value] [vlan VLAN-ID]
```

```
no sequence-number
```

Syntax Description

<i>sequence-number</i>	(Optional) Sequence number of the permit command, which causes the device to insert the command in that numbered position in the access list. Sequence numbers maintain the order of rules within an ACL. A sequence number can be any integer between 1 and 4294967295. By default, the first rule in an ACL has a sequence number of 10. If you do not specify a sequence number, the device adds the rule to the end of the ACL and assigns a sequence number that is 10 greater than the sequence number of the preceding rule. Use the resequence command to reassign sequence numbers to rules.
<i>source</i>	Source MAC addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.
<i>destination</i>	Destination MAC addresses that the rule matches. For details about the methods that you can use to specify this argument, see “Source and Destination” in the “Usage Guidelines” section.
<i>protocol</i>	(Optional) Protocol number that the rule matches. Valid protocol numbers are 0x0 to 0xffff. For listings of valid protocol names, see “MAC Protocols” in the “Usage Guidelines” section.
cos <i>cos-value</i>	(Optional) Specifies that the rule matches only packets with an IEEE 802.1Q header that contains the Class of Service (CoS) value given in the <i>cos-value</i> argument. The <i>cos-value</i> argument can be an integer from 0 to 7.
vlan <i>VLAN-ID</i>	(Optional) Specifies that the rule matches only packets with an IEEE 802.1Q header that contains the VLAN ID given. The <i>VLAN-ID</i> argument can be an integer from 1 to 4094.

Defaults

None

Command Modes

MAC ACL configuration

Supported User Roles

network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

A newly created MAC ACL contains no rules.

If you do not specify a sequence number, the device assigns a sequence number that is 10 greater than the last rule in the ACL.

When the device applies a MAC ACL to a packet, it evaluates the packet with every rule in the ACL. The device enforces the first rule that has conditions that are satisfied by the packet. When the conditions of more than one rule are satisfied, the device enforces the rule with the lowest sequence number.

Source and Destination

You can specify the *source* and *destination* arguments in one of two ways. In each rule, the method you use to specify one of these arguments does not affect how you specify the other. When you configure a rule, use the following methods to specify the *source* and *destination* arguments:

- Address and mask—You can use a MAC address followed by a mask to specify a single address or a group of addresses. The syntax is as follows:

MAC-address *MAC-mask*

The following example specifies the *source* argument with the MAC address 00c0.4f03.0a72:

```
n1000v(config-acl)# permit 00c0.4f03.0a72 0000.0000.0000 any
```

The following example specifies the *destination* argument with a MAC address for all hosts with a MAC vendor code of 00603e:

```
n1000v(config-acl)# permit any 0060.3e00.0000 0000.0000.0000
```

- Any address—You can use the **any** keyword to specify that a source or destination is any MAC address. For examples of the use of the **any** keyword, see the examples in this section. Each of the examples shows how to specify a source or destination by using the **any** keyword.

MAC Protocols

The *protocol* argument can be the MAC protocol number or a keyword. The protocol number is a four-byte hexadecimal number prefixed with 0x. Valid protocol numbers are from 0x0 to 0xffff. Valid keywords are the following:

- **aarp**—Appletalk ARP (0x80f3)
- **appletalk**—Appletalk (0x809b)
- **decnet-iv**—DECnet Phase IV (0x6003)
- **diagnostic**—DEC Diagnostic Protocol (0x6005)
- **etype-6000**—Ethertype 0x6000 (0x6000)
- **etype-8042**—Ethertype 0x8042 (0x8042)
- **ip**—Internet Protocol v4 (0x0800)
- **lat**—DEC LAT (0x6004)
- **lavc-sca**—DEC LAVC, SCA (0x6007)
- **mop-console**—DEC MOP Remote console (0x6002)
- **mop-dump**—DEC MOP dump (0x6001)

Send document comments to nexus1k-docfeedback@cisco.com.

- **vines-echo**—VINES Echo (0x0baf)

Examples

This example shows how to configure a MAC ACL named `mac-ip-filter` with a rule that permits all IPv4 traffic between two groups of MAC addresses:

```
n1000v# config t
n1000v(config)# mac access-list mac-ip-filter
n1000v(config-mac-acl)# permit 00c0.4f00.0000 0000.00ff.ffff 0060.3e00.0000 0000.00ff.ffff
ip
```

Related Commands

Command	Description
deny (MAC)	Configures a deny rule in a MAC ACL.
mac access-list	Configures a MAC ACL.
remark	Configures a remark in an ACL.
statistics per-entry	Enables collection of statistics for each entry in an ACL.
show mac access-list	Displays all MAC ACLs or one MAC ACL.

Send document comments to nexus1k-docfeedback@cisco.com.

ping

To determine the network connectivity to another device using IPv4 addressing, use the **ping** command.

```
ping [dest-ipv4-address | hostname | multicast multicast-group-address interface [ethernet
slot/port | loopback number | mgmt0 | port-channel channel-number | vethernet number]]
[count {number | unlimited}] [df-bit] [interval seconds] [packet-size bytes] [source
src-ipv4-address] [timeout seconds] [vrf vrf-name]
```

Syntax Description		
<i>dest-ipv4-address</i>		IPv4 address of destination device. The format is <i>A.B.C.D</i> .
<i>hostname</i>		Hostname of destination device. The hostname is case sensitive.
multicast		Multicast ping.
<i>multicast-group-address</i>		Multicast group address. The format is <i>A.B.C.D</i> .
interface		Specifies the interface to send the multicast packet.
ethernet <i>slot/port</i>		Specifies the slot and port number for the Ethernet interface.
loopback <i>number</i>		Specifies a virtual interface number from 0 to 1023.
mgmt0		Specifies the management interface.
port-channel <i>channel-number</i>		Specifies a port-channel interface in the range 1 to 4096.
vethernet <i>number</i>		Specifies a virtual Ethernet interface in the range 1 to 1048575.
count		(Optional) Specifies the number of transmissions to send.
<i>number</i>		Number of pings. The range is from 1 to 655350. The default is 5.
unlimited		Allows an unlimited number of pings.
df-bit		(Optional) Enables the do-not-fragment bit in the IPv4 header. The default is disabled.
interval <i>seconds</i>		(Optional) Specifies the interval in seconds between transmissions. The range is from 0 to 60. The default is 1 second.
packet-size <i>bytes</i>		(Optional) Specifies the packet size in bytes to transmit. The range is from 1 to 65468. The default is 56 bytes.
source <i>scr-ipv4-address</i>		(Optional) Specifies the source IPv4 address to use. The format is <i>A.B.C.D</i> . The default is the IPv4 address for the management interface of the device.
timeout <i>seconds</i>		(Optional) Specifies the nonresponse timeout interval in seconds. The range is from 1 to 60. The default is 2 seconds.
vrf <i>vrf-name</i>		(Optional) Specifies the virtual routing and forwarding (VRF) name. The default is the default VRF.

Defaults

For the default values, see the “Syntax Description” section for this command.

Command Modes

Any

SupportedUserRoles

network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines To determine the network connectivity to another device using IPv6 addressing, use the **ping6** command.

Examples This example shows how to determine connectivity to another device using IPv4 addressing:

```
n1000v# ping 172.28.231.246 vrf management
PING 172.28.231.246 (172.28.231.246): 56 data bytes
Request 0 timed out
64 bytes from 172.28.231.246: icmp_seq=1 ttl=63 time=0.799 ms
64 bytes from 172.28.231.246: icmp_seq=2 ttl=63 time=0.597 ms
64 bytes from 172.28.231.246: icmp_seq=3 ttl=63 time=0.711 ms
64 bytes from 172.28.231.246: icmp_seq=4 ttl=63 time=0.67 ms

--- 172.28.231.246 ping statistics ---
5 packets transmitted, 4 packets received, 20.00% packet loss
round-trip min/avg/max = 0.597/0.694/0.799 ms
```

Related Commands	Command	Description
	ping6	Determines connectivity to another device using IPv6 addressing.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

police

To control traffic rates, use the **police** command. To remove control, use the **no** form of this command.

```
police {{{cir} {cir [bps|kbits|mbps|gbps] | percent cir-percent} [[bc] {committed-burst
[bytes|kbytes|mbytes|ms|us]}] [pir {pir- [bps2|kbits2|mbps2|gbps2] | percent pir-percent}
[[be] {extended-burst [bytes2|kbytes2|mbytes2|ms2|us2]}]}] [conform {transmit |
set-prec-transmit {precedence-number} | set-dscp-transmit {dscp-value | dscp-number} |
set-cos-transmit cos-value | set-discard-class-transmit discard-class-value |
set-qos-transmit qos-group-value} [exceed {drop1 | set exc-from-field exc-to-field table
cir-markdown-map}]] [violate {drop2 | set vio-from-field vio-to-field table2
pir-markdown-map}]]}}
```

```
no police {{{cir} {cir [bps|kbits|mbps|gbps] | percent cir-percent} [[bc] {committed-burst
[bytes|kbytes|mbytes|ms|us]}] [pir {pir [bps2|kbits2|mbps2|gbps2] | percent pir-percent}
[[be] {extended-burst [bytes2|kbytes2|mbytes2|ms2|us2]}]}] [conform {transmit |
set-prec-transmit {precedence-number} | set-dscp-transmit {dscp-value | dscp-number} |
set-cos-transmit cos-value | set-discard-class-transmit discard-class-value |
set-qos-transmit qos-group-value} [exceed {drop1 | set exc-from-field exc-to-field table
cir-markdown-map}]] [violate {drop2 | set vio-from-field vio-to-field table2
pir-markdown-map}]]}}
```

Syntax Description

cir	(Optional) Specifies CIR (Committed Information Rate).
<i>cir</i>	Committed Information Rate in bps or kbits or mbps or gbps .
bps	(Optional) Specifies bits per second.
kbits	(Optional) Specifies kilobits per second.
mbps	(Optional) Specifies megabits per second.
gbps	(Optional) Specifies gigabits per second.
percent	Specifies CIR (Committed Information Rate) percentage.
<i>cir-percent</i>	CIR percentage.
bc	(Optional) Specifies BC (Burst Commit).
<i>committed-burst</i>	Packet burst.
bytes	(Optional) Specifies burst size in bytes.
kbytes	(Optional) Specifies burst size in kilobytes.
mbytes	(Optional) Specifies burst size in megabytes.
ms	(Optional) Specifies burst interval in milliseconds.
us	(Optional) Specifies burst interval in microseconds.
pir	(Optional) Specifies PIR (Peak Information Rate).
<i>pir</i>	Peak Information Rate in bps or kbits or mbps or gbps .
bps2	(Optional) Specifies bits per second.
kbits2	(Optional) Specifies kilobits per second.
mbps2	(Optional) Specifies megabits per second.
gbps2	(Optional) Specifies gigabits per second.
be	(Optional) Specifies extended burst.
<i>extended-burst</i>	Extended packet burst.

Send document comments to nexus1k-docfeedback@cisco.com.

ms2	(Optional) Specifies burst interval in milliseconds.
us2	(Optional) Specifies burst interval in microseconds.
conform	(Optional) Specifies a conform action.
transmit	Specifies packet transmission.
set-prec-transmit	Specifies a precedence and transmits it.
<i>precedence-number</i>	Precedence number. The following are valid numbers: <ul style="list-style-type: none"> • 0—Routine precedence • 1—Priority precedence • i2—Immediate precedence • 3—Flash precedence • 4—Flash override precedence • 5—Critical precedence • 6—Internetwork control precedence • 7— Network control precedence
set-dscp-transmit	Specifies a DSCP (Differentiated Services Code Point) and transmits it.
<i>dscp-number</i>	DSCP number or code. The range of valid values is 1 to 63. You can also set DSCP to one of the following codes: <ul style="list-style-type: none"> • af11—AF11 dscp (001010) • af12—AF12 dscp (001100) • af13—AF13 dscp (001110) • af21—AF21 dscp (010010) • af22—AF22 dscp (010100) • af23—AF23 dscp (010110) • af31—AF31 dscp (011010) • af32—AF32 dscp (011100) • af33—AF33 dscp (011110) • af41—AF41 dscp (100010) • af42—AF42 dscp (100100) • af43—AF43 dscp (100110) • cs1—CS1(precedence 1) dscp (001000) • cs2—CS2(precedence 2) dscp (010000) • cs3—CS3(precedence 3) dscp (011000) • cs4—CS4(precedence 4) dscp (100000) • cs5—CS5(precedence 5) dscp (101000) • cs6—CS6(precedence 6) dscp (110000) • cs7—CS7(precedence 7) dscp (111000) • default—default dscp (000000) • ef—EF dscp (101110)

Send document comments to nexus1k-docfeedback@cisco.com.

set-cos-transmit	Specifies a CoS number and transmits it.
<i>cos-value</i>	CoS group number. The range of valid values is 0 to 7.
set-discard-class-transmit	Specifies a discard class number and transmits it.
<i>discard-class-value</i>	The discard class number. The range of valid values is 0 to 63.
set-qos-transmit	Specifies a QoS group number and transmits it.
<i>qos-group-value</i>	QoS group number. The range of valid values is 0 to 126.
exceed	(Optional) Specifies an exceed action.
drop1	Specifies that packets are to be dropped.
set	Specifies a particular value in a table or markdown map.
<i>exc-from-field</i>	.
<i>exc-to-field</i>	.
table	.
cir-markdown-map	.
violate	(Optional) Specifies a violate action.
drop2	.Specifies that packets are to be dropped.
<i>vio-from-field</i>	.
<i>vio-to-field</i>	.
table2	.
pir-markdown-map	.

Defaults

None

Command Modes

Policy map configuration (config-pmap-c-qos)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to control traffic rates:

```
n1000v# configure terminal
n1000v(config)# policy-map pm10
n1000v(config-pmap-qos)# class class-default
n1000v(config-pmap-c-qos)# police 100000 bps 10000 bytes
n1000v(config-pmap-c-qos)#
```

Related Commands

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
show qos	Displays QoS information.

Send document comments to nexus1k-docfeedback@cisco.com.

policy-map

To create and configure policy maps, use the **policy-map** command. To remove policy maps, use the **no** form of this command.

policy-map {*name* | **type qos** *name*}

no policy-map {*name* | **type qos** *name*}

Syntax Description	
<i>name</i>	Policy map name. The range of valid values is 1 to 40.
type qos	Specifies the policy map type as QoS.

Defaults The policy map does not exist.

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines When you create or configure a policy map, you automatically enter configure policy map mode.

Examples This example shows how to create policy maps:

```
n1000v# configure terminal
n1000v(config)# policy-map pm20
n1000v(config-pmap-qos)#
```

This example shows how to remove policy maps:

```
n1000v# configure terminal
n1000v(config)# no policy-map pm20
n1000v(config)#
```

Related Commands	Command	Description
	show policy-map	Displays policy map information.

Send document comments to nexus1k-docfeedback@cisco.com.

port-channel load-balance ethernet

To set the load-balancing method among the interfaces in the channel-group bundle, use the **port-channel load-balance ethernet** command. To return the system priority to the default value, use the **no** form of this command.

port-channel load-balance ethernet *method* [**module** *slot*]

no port-channel load-balance ethernet [*method* [**module** *slot*]]

Syntax Description	<i>method</i>	Load-balancing method. See the “Usage Guidelines” section for a list of valid values.
	module	(Optional) Specifies a module number. The range is 1 to 66.

Defaults	Layer 2 packets— source-mac Layer 3 packets— source-mac
----------	--

Command Modes	Global Configuration (config)
---------------	-------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines When you do not specify a module, you are configuring load balancing for the entire device. When you use the **module** parameter, you are configuring load balancing for the specified modules

Valid *method* values are as follows:

- **dest-ip-port**—Loads distribution on the destination IP address and L4 port.
- **dest-ip-port-vlan**—Loads distribution on the destination IP address, L4 port, and VLAN.
- **destination-ip-vlan**—Loads distribution on the destination IP address and VLAN
- **destination-mac**—Loads distribution on the destination MAC address.
- **destination-port**—Loads distribution on the destination L4 port.
- **source-dest-ip-port**—Loads distribution on the source and destination IP address and L4 port.
- **source-dest-ip-port-vlan**—Loads distribution on the source and destination IP address, L4 port, and VLAN.
- **source-dest-ip-vlan**—Loads distribution on the source and destination IP address and VLAN.
- **source-dest-mac**—Loads distribution on the source and destination MAC address.
- **source-dest-port**—Loads distribution on the source and destination L4 port.

Send document comments to nexus1k-docfeedback@cisco.com.

- **source-ip-port**—Loads distribution on the source IP address.
- **source-ip-port-vlan**—Loads distribution on the source IP address, L4, and VLAN
- **source-ip-vlan**—Loads distribution on the source IP address and VLAN.
- **source-mac**—Loads distribution on the source MAC address.
- **source-port**—Loads distribution on the source port.
- **source-virtual-port-id**—Loads distribution on the source virtual port ID.
- **vlan-only**—Loads distribution on the VLAN only.

Use the **module** argument to configure the module independently for port-channeling and load-balancing mode. When you do this, the remaining module use the current load-balancing method configured for the entire device, or the default method if you have not configured a method for the entire device. When you enter the **no** argument in conjunction with a **module** argument, the load-balancing method for the specified module takes the current load-balancing method that is in use for the entire device. If you configured a load-balancing method for the entire device, the specified module uses that configured method, rather than the default **source-mac**. The per module configuration takes precedence over the load-balancing method configured for the entire device.

Use the option that provides the balance criteria with the greatest variety in your configuration. For example, if the traffic on a port channel is going only to a single MAC address and you use the destination MAC address as the basis of port channel load balancing, the port channel always chooses the same link in that port channel; using source addresses or IP addresses might result in better load balancing.

Examples

This example shows how to set the load-balancing method for the entire device to use the source port:

```
n1000v(config)# port-channel load-balance ethernet src-port
n1000v(config)#
```

Related Commands

Command	Description
show port-channel load-balance	Displays information on port-channel load balancing.

Send document comments to nexus1k-docfeedback@cisco.com.

port-profile

To create a port profile and enter port-profile configuration mode, use the **port-profile** command. To remove the port profile configuration, use the **no** form of this command.

port-profile *name*

no port-profile *name*

Syntax Description	<i>name</i>	Specifies the port profile name. The name can be up to 80 characters in length.
--------------------	-------------	---

Defaults	None
----------	------

Command Modes	Global Configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The port profile name must be unique for each port profile on the Nexus 1000V.
------------------	--

Examples	This example shows how to create a port profile with the name AccessProf:
----------	---

```
n1000v# configure terminal
n1000v(config)# port-profile AccessProf
n1000v(config-port-prof)
```

This example shows how to remove the port profile with the name AccessProf:

```
n1000v# configure terminal
n1000v(config)# no port-profile AccessProf
n1000v(config)
```

Related Commands	Command	Description
	show port-profile name	Displays information about the port profiles.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

private-vlan association

To configure an association between a primary and secondary private VLAN, use the **private-vlan association** command. To remove the association, use the **no** form of this command.

private-vlan association [{**add** | **remove**}] *secondary-vlan-ids*

no private-vlan association [*secondary-vlan-ids*]

Syntax Description

add	Adds a secondary VLAN to a private VLAN list.
remove	Removes a secondary VLAN from a private VLAN list.
<i>secondary-vlan-ids</i>	IDs of the secondary VLANs to be added or removed.

Defaults

None

Command Modes

VLAN (config-vlan)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

You must enable the private VLAN feature (**feature private-vlan** command) before the private VLAN commands are visible in the CLI for configuration.

Examples

This example shows how to associate primary VLAN 202 with secondary VLAN 303:

```
n1000v#configure t
n1000v(config)# vlan 202
n1000v(config-vlan)# private-vlan association add 303
n1000v(config-vlan)#
```

Related Commands

Command	Description
private-vlan primary	Designates the private VLAN as primary.
private-vlan {community isolated}	Designates the private VLAN as community or isolated.
show vlan private-vlan	Displays the private VLAN configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

private-vlan { community | isolated}

To designate a VLAN as either a community or isolated private VLAN, use the **private-vlan {community | isolated}** command. To remove the configuration, use the **no** form of this command.

```
private-vlan { community | isolated }
```

```
no private-vlan { community | isolated }
```

Syntax Description	community	Description
	community	Designates the VLAN as a community private VLAN.
	isolated	Designates the VLAN as an isolated private VLAN.

Defaults	None

Command Modes	VLAN (config-vlan)

Supported User Roles	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You must enable the private VLAN feature (feature private-vlan command) before the private VLAN commands are visible in the CLI for configuration.

Examples	This example shows how to configure VLAN 303 as a community private VLAN:
	<pre>n1000v#configure t n1000v(config)# vlan 303 n1000v(config-vlan)# private-vlan community n1000v(config-vlan)#</pre>

Related Commands	Command	Description
	private-vlan primary	Designates the private VLAN as primary.
	private-vlan association	Configures an association between a primary VLAN and a secondary VLAN
	show vlan private-vlan	Displays the private VLAN configuration.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

private-vlan primary

To designate a private VLAN as a primary VLAN, use the **private-vlan primary** command. To remove the configuration, use the **no** form of this command.

private-vlan primary

no private-vlan primary

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes VLAN (config-vlan)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You must enable the private VLAN feature (**feature private-vlan** command) before the private VLAN commands are visible in the CLI for configuration.

Examples This example shows how to configure VLAN 202 as the primary VLAN in a private VLAN:

```
n1000v#configure t
n1000v(config)# vlan 202
n1000v(config-vlan)# private-vlan primary
n1000v(config-vlan)# show vlan private-vlan
Primary Secondary Type Ports
-----
202 primary
n1000v(config-vlan)#
```

Related Commands	Command	Description
	private-vlan { community isolated }	Designates the private VLAN as community or isolated.
	show vlan private-vlan	Displays the private VLAN configuration.
	private-vlan association	Associates a primary and secondary private VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

protocol vmware-vim

To enable the VMware VI SDK, use the **protocol vmware-vim** command. To disable the VMware VI SDK, use the **no** form of this command.

protocol vmware-vim

no protocol vmware-vim

Syntax Description This command has no arguments or keywords.

Defaults The VMware VI SDK is disabled.

Command Modes SVS connection configuration (config-svs-conn)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The VMware VI SDK is published by VMware and it allows clients to talk to VMware vCenter. You must first create an SVS connection before you enable the VMware VI SDK.

Examples This example shows how to enable the VMware VI SDK.:

```
n1000v# configure terminal
n1000v(config)# svs connection svsl
n1000v(config-svs-conn)# protocol vmware-vim
n1000v(config-svs-conn)#
```

Related Commands	Command	Description
	show svs connection	Displays SVS connection information.

Send document comments to nexus1k-docfeedback@cisco.com.

pwd

To view the current directory, use the **pwd** command.

pwd

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to view the current directory:

```
n1000v# pwd
bootflash:
n1000v#
```




Q Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter Q.

qos statistics

To enable the recording of QoS statistics, use the **qos statistics** command. To disable the recording of QoS statistics, use the **no** form of this command.

qos statistics

no qos statistics

Syntax Description This command has no arguments or keywords.

Defaults QoS statistics are not recorded.

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enable the recording of QoS statistics:

```
n1000v# configure terminal
n1000v(config)# qos statistics
n1000v(config)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show qos	Displays QoS informaton.



R Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter R.

radius-server deadtime

To configure the dead-time interval for all RADIUS servers used by a device, use the **radius-server deadtime** command. To revert to the default, use the **no** form of this command.

radius-server deadtime *minutes*

no radius-server deadtime *minutes*

Syntax Description	<i>minutes</i>	Number of minutes for the dead-time interval. The range is from 1 to 1440 minutes.
---------------------------	----------------	--

Defaults	0 minutes
-----------------	-----------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The dead-time interval is the number of minutes before the device checks a RADIUS server that was previously unresponsive.
-------------------------	--

Send document comments to nexus1k-docfeedback@cisco.com.

**Note**

The default idle timer value is 0 minutes. When the idle time interval is 0 minutes, periodic RADIUS server monitoring is not performed.

Examples

This example shows how to configure the global dead-time interval for all RADIUS servers to perform periodic monitoring:

```
n1000v# config t
n1000v(config)# radius-server deadtime 5
```

This example shows how to revert to the default for the global dead-time interval for all RADIUS servers and disable periodic server monitoring:

```
n1000v# config t
n1000v(config)# no radius-server deadtime 5
```

Related Commands

Command	Description
show radius-server	Displays RADIUS server information.

Send document comments to nexus1k-docfeedback@cisco.com.

radius-server directed-request

To allow users to send authentication requests to a specific RADIUS server when logging in, use the **radius-server directed request** command. To revert to the default, use the **no** form of this command.

radius-server directed-request

no radius-server directed-request

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You can specify the *username@vrfname:hostname* during login, where *vrfname* is the virtual routing and forwarding (VRF) instance to use and *hostname* is the name of a configured RADIUS server. The username is sent to the RADIUS server for authentication.

Examples This example shows how to allow users to send authentication requests to a specific RADIUS server when logging in:

```
n1000v# config t
n1000v(config)# radius-server directed-request
```

This example shows how to disallow users to send authentication requests to a specific RADIUS server when logging in:

```
n1000v# config t
n1000v(config)# no radius-server directed-request
```

Related Commands	Command	Description
	show radius-server directed-request	Displays the directed request RADIUS server configuration.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

radius-server host

To configure RADIUS server parameters, use the **radius-server host** command. To revert to the default, use the **no** form of this command.

```
radius-server host {hostname | ipv4-address | ipv6-address}
  [key [0 | 7] shared-secret [pac]] [accounting]
  [acct-port port-number] [auth-port port-number] [authentication] [retransmit count]
  [test {idle-time time | password password | username name}]
  [timeout seconds [retransmit count]]
```

```
no radius-server host {hostname | ipv4-address | ipv6-address}
  [key [0 | 7] shared-secret [pac]] [accounting]
  [acct-port port-number] [auth-port port-number] [authentication] [retransmit count]
  [test {idle-time time | password password | username name}]
  [timeout seconds [retransmit count]]
```

Syntax Description

<i>hostname</i>	RADIUS server Domain Name Server (DNS) name. The name is alphanumeric, case sensitive, and has a maximum of 256 characters.
<i>ipv4-address</i>	RADIUS server IPv4 address in the <i>A.B.C.D</i> format.
<i>ipv6-address</i>	RADIUS server IPv6 address in the <i>X:X:X::X</i> format.
key	(Optional) Configures the RADIUS server preshared secret key.
0	(Optional) Configures a preshared key specified in clear text to authenticate communication between the RADIUS client and server. This is the default.
7	(Optional) Configures a preshared key specified in encrypted text (indicated by 7) to authenticate communication between the RADIUS client and server.
<i>shared-secret</i>	Preshared key to authenticate communication between the RADIUS client and server. The preshared key can include any printable ASCII characters (white spaces are not allowed), is case sensitive, and has a maximum of 63 characters.
pac	(Optional) Enables the generation of Protected Access Credentials (PAC) on the RADIUS Cisco Access Control Server (ACS) for use with Cisco TrustSec.
accounting	(Optional) Configures accounting.
acct-port <i>port-number</i>	(Optional) Configures the RADIUS server port for accounting. The range is from 0 to 65535.
auth-port <i>port-number</i>	(Optional) Configures the RADIUS server port for authentication. The range is from 0 to 65535.
authentication	(Optional) Configures authentication.
retransmit <i>count</i>	(Optional) Configures the number of times that the device tries to connect to a RADIUS server(s) before reverting to local authentication. The range is from 1 to 5 times and the default is 1 time.
test	(Optional) Configures parameters to send test packets to the RADIUS server.
idle-time <i>time</i>	Specifies the time interval (in minutes) for monitoring the server. The range is from 1 to 1440 minutes.
password <i>password</i>	Specifies a user password in the test packets. The password is alphanumeric, case sensitive, and has a maximum of 32 characters.

Send document comments to nexus1k-docfeedback@cisco.com.

username <i>name</i>	Specifies a username in the test packets. The is alphanumeric, not case sensitive, and has a maximum of 32 characters.
timeout <i>seconds</i>	Specifies the timeout (in seconds) between retransmissions to the RADIUS server. The default is 5 seconds and the range is from 1 to 60 seconds.

Defaults

Parameter	Default
Accounting port	1813
Authentication port	1812
Accounting	enabled
Authentication	enabled
Retransmission count	1
Idle-time	none
Server monitoring	disabled
Timeout	5 seconds
Test username	test
Test password	test

Command Modes

Global Configuration (config)

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

When the idle time interval is 0 minutes, periodic RADIUS server monitoring is not performed.

Examples

This example shows how to configure RADIUS server authentication and accounting parameters:

```
n1000v# config terminal
n1000v(config)# radius-server host 10.10.2.3 key HostKey
n1000v(config)# radius-server host 10.10.2.3 auth-port 2003
n1000v(config)# radius-server host 10.10.2.3 acct-port 2004
n1000v(config)# radius-server host 10.10.2.3 accounting
n1000v(config)# radius-server host radius2 key 0 abcd
n1000v(config)# radius-server host radius3 key 7 1234
n1000v(config)# radius-server host 10.10.2.3 test idle-time 10
n1000v(config)# radius-server host 10.10.2.3 test username tester
n1000v(config)# radius-server host 10.10.2.3 test password 2B9ka5
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show radius-server	Displays RADIUS server information.

Send document comments to nexus1k-docfeedback@cisco.com.

radius-server key

To configure a RADIUS shared secret key, use the **radius-server key** command. To remove a configured shared secret, use the **no** form of this command.

radius-server key [0 | 7] *shared-secret*

no radius-server key [0 | 7] *shared-secret*

Syntax Description		
	0	(Optional) Configures a preshared key specified in clear text to authenticate communication between the RADIUS client and server.
	7	(Optional) Configures a preshared key specified in encrypted text to authenticate communication between the RADIUS client and server.
	<i>shared-secret</i>	Preshared key used to authenticate communication between the RADIUS client and server. The preshared key can include any printable ASCII characters (white spaces are not allowed), is case sensitive, and has a maximum of 63 characters.

Defaults Clear text

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You must configure the RADIUS preshared key to authenticate the switch on the RADIUS server. The length of the key is restricted to 63 characters and can include any printable ASCII characters (white spaces are not allowed). You can configure a global key to be used for all RADIUS server configurations on the switch. You can override this global key assignment for an individual host by using the **key** keyword in the **radius-server host** command.

Examples This example shows how to provide various scenarios to configure RADIUS authentication:

```
n1000v# config terminal
n1000v(config)# radius-server key AnyWord
n1000v(config)# radius-server key 0 AnyWord
n1000v(config)# radius-server key 7 public pac
```

■ radius-server key

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show radius-server	Displays RADIUS server information.

Send document comments to nexus1k-docfeedback@cisco.com.

radius-server retransmit

To specify the number of times that the device should try a request with a RADIUS server, use the **radius-server retransmit** command. To revert to the default, use the **no** form of this command.

radius-server retransmit *count*

no radius-server retransmit *count*

Syntax Description	<i>count</i>	Number of times that the device tries to connect to a RADIUS server(s) before reverting to local authentication. The range is from 1 to 5 times.
--------------------	--------------	--

Defaults	1 retransmission
----------	------------------

Command Modes	Global Configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure the number of retransmissions to RADIUS servers:

```
n1000v# config t
n1000v(config)# radius-server retransmit 3
```

This example shows how to revert to the default number of retransmissions to RADIUS servers:

```
n1000v# config t
n1000v(config)# no radius-server retransmit 3
```

Related Commands	Command	Description
	show radius-server	Displays RADIUS server information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

radius-server timeout

To specify the time between retransmissions to the RADIUS servers, use the **radius-server timeout** command. To revert to the default, use the **no** form of this command.

radius-server timeout *seconds*

no radius-server timeout *seconds*

Syntax Description	<i>seconds</i>	Number of seconds between retransmissions to the RADIUS server. The range is from 1 to 60 seconds.
Defaults	5 seconds	
Command Modes	Global Configuration (config)	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines		
Examples	<p>This example shows how to configure the timeout interval:</p> <pre>n1000v# config t n1000v(config)# radius-server timeout 30</pre> <p>This example shows how to revert to the default interval:</p> <pre>n1000v# config t n1000v(config)# no radius-server timeout 30</pre>	
Related Commands	Command	Description
	show radius-server	Displays RADIUS server information.

Send document comments to nexus1k-docfeedback@cisco.com.

rate-mode dedicated

To set the dedicated rate mode for the specified ports, use the **rate-mode dedicated** command.

rate-mode dedicated

no rate-mode

Syntax Description This command has no arguments or keywords.

Command Default Shared rate mode is the default.

Command Modes Interface Configuration (config-if)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use the **rate-mode dedicated** command to set the dedicated rate mode for the specified ports. On a 32-port 10-Gigabit Ethernet module, each set of four ports can handle 10 gigabits per second (Gb/s) of bandwidth. You can use the rate-mode parameter to dedicate that bandwidth to the first port in the set of four ports or share the bandwidth across all four ports.



Note

When you dedicate the bandwidth to one port, you must first administratively shut down the ports in the group, change the rate mode to dedicated, and then bring the dedicated port administratively up.

[Table 1-1](#) identifies the ports that are grouped together to share each 10 Gb/s of bandwidth and which port in the group can be dedicated to utilize the entire bandwidth.

Table 1-1 *Dedicated and Shared Ports*

Ports Groups that Can Share Bandwidth	Ports that Can be Dedicated to Each 10-Gigabit Ethernet of Bandwidth
1, 3, 5, 7	1
2, 4, 6, 8	2
9, 11, 13, 15	9
10, 12, 14, 16	10

Send document comments to nexus1k-docfeedback@cisco.com.

Table 1-1 **Dedicated and Shared Ports**

Ports Groups that Can Share Bandwidth	Ports that Can be Dedicated to Each 10-Gigabit Ethernet of Bandwidth
17, 19, 21, 23	17
18, 20, 22, 24	18
25, 27, 29, 31	25
26, 28, 30, 32	26

When you enter the **rate-mode dedicated** command, the full bandwidth of 10 Gb is dedicated to one port. When you dedicate the bandwidth, all subsequent commands for the port are for dedicated mode.

Examples

This example shows how to configure the dedicated rate mode for Ethernet ports 4/17, 4/19, 4/21, and 4/23:

```
n1000v# config t
n1000v(config)# interface ethernet 4/17, ethernet 4/19, ethernet 4/21, ethernet 4/23
n1000v(config-if)# shutdown
n1000v(config-if)# interface ethernet 4/17
n1000v(config-if)# rate-mode dedicated
n1000v(config-if)# no shutdown
n1000v(config-if)#
```

Related Commands

Command	Description
show interface	Displays interface information, which includes the current rate mode dedicated.

Send document comments to nexus1k-docfeedback@cisco.com.

record

To configure a flow record, use the **record** command. To remove the flow record configuration, use the **no** form of the command.

```
record {name | netflow ipv4 {original-input | original-output | protocol-port} | netflow-original}
```

```
no record {name | netflow ipv4 {original-input | original-output | protocol-port} | netflow-original}
```

Syntax Description

<i>name</i>	Specifies the name of a new flow record.
netflow ipv4	Specifies a predefined flow record that uses traditional IPv4 NetFlow collection schemes.
original-input	Specifies a predefined flow record that uses traditional IPv4 input NetFlow.
original-output	Specifies a predefined flow record that uses traditional IPv4 output NetFlow.
protocol-port	Specifies the flow record that uses the protocol and ports aggregation scheme for the record.
netflow-original	Specifies a flow record that uses traditional IPv4 input NetFlow with origin ASs.

Defaults

None

Command Modes

Flow monitor (config-flow-monitor)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

A flow record defines the information that NetFlow gathers, such as packets in the flow and the types of counters gathered per flow. You can define new flow records or use the pre-defined flow record.

Examples

This example shows how to configure a flow record to use a the predefined traditional IPv4 input NetFlow record:

```
n1000v# config t
n1000v(config)# flow monitor testmon
n1000v(config-flow-monitor)# record netflow ipv4 original-input
n1000v(config-flow-monitor)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to remove the predefined traditional IPv4 input NetFlow flow record configuration:

```
n1000v# config t
n1000v(config)# flow monitor testmon
n1000v(config-flow-monitor)# no record netflow ipv4 original-input
n1000v(config-flow-monitor)#
```

Related Commands

Command	Description
show flow monitor	Displays NetFlow monitor configuration information.
show flow record	Displays NetFlow record configuration information.

Send document comments to nexus1k-docfeedback@cisco.com.

reload module

To reload a module in the device, use the **reload module** command.

```
reload module slot [force-dnld]
```

Syntax Description	slot	Chassis slot number.
	force-dnld	(Optional) Forces the download of software to the module.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Use the **show hardware** command to display information about the hardware on your device.

Examples This example shows how to reload a module:

```
n1000v# reload module 2
```

Related Commands	Command	Description
	show version	Displays information about the software version.

Send document comments to nexus1k-docfeedback@cisco.com.

remote

To connect to remote machines, use the **remote** command. To disconnect, use the **no** form of this command.

remote { **ip address** *address* | **hostname** *name* }

no remote { **ip address** *address* | **hostname** *name* }

Syntax Description

ipaddress	Specifies an IP address.
<i>address</i>	IPv4 address. The format is A.B.C.D.
hostname	Specifies the remote host name.
<i>name</i>	Host name. The range of valid values is 1 to 128.

Defaults

None

Command Modes

SVS connection configuration (config-svs-conn)

SupportedUserRoles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to connect to a remote machine:

```
n1000v# configure terminal
n1000v(config)# svs connection svconn1
n1000v(config-svs-conn)# remote hostname server1
n1000v(config-svs-conn)#
```

Related Commands

Command	Description
show svcs	Displays SVS information.

Send document comments to nexus1k-docfeedback@cisco.com.

resequence

To resequence an ACL, use the **resequence** command.

```
resequence { ip name start-number increment | mac name start-number increment }
```

Syntax Description	Parameter	Description
	ip	Specifies the IP address.
	access-list	Specifies the access list.
	<i>name</i>	Name of the list.
	<i>start-number</i>	Starting sequence number.
	<i>increment</i>	Step increment.

Defaults None

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to MAC ACL:

```
n1000v# configure terminal
n1000v(config)# resequence mac access-list aclOne 1 2
n1000v(config)#
```

Related Commands	Command	Description
	show acl	Displays ACLs.

Send document comments to nexus1k-docfeedback@cisco.com.

rmdir

To remove a directory, use the **rmdir** command.

```
rmdir [filesystem:[//module/]]directory
```

Syntax Description		
<i>filesystem:</i>	(Optional) Name of a file system. The name is case sensitive.	
<i>//module/</i>	(Optional) Identifier for a supervisor module. Valid values are sup-active , sup-local , sup-remote , or sup-standby . The identifiers are case sensitive.	
<i>directory</i>	Name of a directory. The name is case sensitive.	

Defaults Removes the directory from the current working directory.

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to remove a directory:

```
n1000v# rmdir my_files
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	dir	Displays the directory contents.
	pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

run-script

To run a script in bootflash: or volatile:, use the **run-script** command.

```
run-script { bootflash: | volatile: } filename
```

Syntax Description	
bootflash:	Specifies bootflash:.
volatile:	Specifies volatile:.
<i>filename</i>	Name of the command file. The name is case sensitive.

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples	This example shows how to run a script file called Sample on the volatile flash:
----------	--

```
n1000v(config)# run-script volatile:Sample
n1000v(config)#
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	copy	Copies files.
	dir	Displays the directory contents.
	pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.



S Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter S.

send

To send a message to an open session, use the **send** command.

```
send {message | session device message}
```

Syntax Description

<i>message</i>	Message.
session	Specifies a specific session.
<i>device</i>	Device type.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin
network-operator

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to send a message to an open session:

```
n1000v# send session sessionOne testing  
n1000v#
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show banner	Displays a banner.

Send document comments to nexus1k-docfeedback@cisco.com.

session-limit

To limit the number of VSH sessions, use the **session-limit** command. To remove the limit, use the **no** form of this command.

session-limit *number*

no session-limit *number*

Syntax Description	<i>number</i>	Number of VSH sessions. The range of valid values is 1 to 64
--------------------	---------------	--

Defaults	No limit is set.
----------	------------------

Command Modes	Line configuration (config-line)
---------------	----------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to limit the number of VSH sessions:

```
n1000v# configure terminal
n1000v(config)# line vty
n1000v(config-line)# session-limit 10
n1000v(config-line)#
```

This example shows how to remove the limit:

```
n1000v# configure terminal
n1000v(config)# line vty
n1000v(config-line)# no session-limit 10
n1000v(config-line)#
```

Send document comments to nexus1k-docfeedback@cisco.com.

service-policy

To configure a service policy for an interface, use the **service-policy** command. To remove the service policy configuration, use the **no** form of this command.

```
service-policy { input name [no-stats] | output name [no-stats] | type qos { input name [no-stats] | output name [no-stats] } }
```

```
no service-policy { input name [no-stats] | output name [no-stats] | type qos { input name [no-stats] | output name [no-stats] } }
```

Syntax Description

input	Specifies an input service policy.
<i>name</i>	Policy name. The range of valid values is 1 to 40.
no-stats	(Optional) Specifies no statistics.
output	Specifies an output service policy.
type qos	Specifies a QoS service policy.

Defaults

No service policy exists.

Command Modes

Interface Configuration (config-if)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to configure a service policy for an interface:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 10
n1000v(config-if)# service-policy type qos input sp10 no-stats
n1000v(config-if)#
```

This example shows how to remove a service policy configuration for an interface:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 10
n1000v(config-if)# no service-policy type qos input sp10 no-stats
n1000v(config-if)#
```

Related Commands

Command	Description
show running interface	Displays interface configuration information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

set

To set QoS class attributes, use the **set** command. To remove class attributes, use the **no** form of this command.

```
set {{ cos cos-val } | { dscp [tunnel] { dscp-val | dscp-enum } } | { precedence [tunnel] { prec-val |
prec-enum } } | { discard-class dis-class-val } | { qos-group qos-grp-val } | { { cos cos } | { dscp
dscp } | { precedence precedence } | { discard-class discard-class } } table table-map-name } |
{ cos1 { { dscp table cos-dscp-map } | { precedence table cos-precedence-map } |
{ discard-class table cos-discard-class-map } } } | { dscp1 { { cos table dscp-cos-map } | { prec3
table dscp-precedence-map } | { dis-class3 table dscp-discard-class-map } } } | { prec1 { { cos3
table precedence-cos-map } | { dscp3 table precedence-dscp-map } | { dis-class3 table
precedence-discard-class-map } } } | { dis-class1 { { cos3 table discard-class-cos-map } |
{ dscp3 table discard-class-dscp-map } | { prec3 table discard-class-precedence-map } } } }
```

```
no set {{ cos cos-val } | { dscp [tunnel] { dscp-val | dscp-enum } } | { precedence [tunnel] { prec-val |
prec-enum } } | { discard-class dis-class-val } | { qos-group qos-grp-val } | { { cos cos } | { dscp
dscp } | { precedence precedence } | { discard-class discard-class } } table table-map-name } |
{ cos1 { { dscp table cos-dscp-map } | { precedence table cos-precedence-map } |
{ discard-class table cos-discard-class-map } } } | { dscp1 { { cos table dscp-cos-map } | { prec3
table dscp-precedence-map } | { dis-class3 table dscp-discard-class-map } } } | { prec1 { { cos3
table precedence-cos-map } | { dscp3 table precedence-dscp-map } | { dis-class3 table
precedence-discard-class-map } } } | { dis-class1 { { cos3 table discard-class-cos-map } |
{ dscp3 table discard-class-dscp-map } | { prec3 table discard-class-precedence-map } } } }
```

Syntax Description

cos	Specifies IEEE 802.1Q CoS (Class of Service).
<i>cos-value</i>	CoS value. The range of valid values is 0 to 7.
dscp	Specifies DSCP (Differentiated Services Code Point) in IPv4 and IPv6 packets.
tunnel	(Optional) Specifies DSCP in tunnel encapsulation.
<i>dscp-value</i>	DSCP value.
<i>dscp-enum</i>	
precedence	Precedence in IP(v4) and IPv6 packets.
<i>prec-val</i>	IP Precedence value.
<i>prec-enum</i>	.
discard-class	Discard class + Discard class value.
<i>dis-class-val</i>	
qos-group	Qos-group + Qos-group value.
<i>qos-grp-val</i>	
table	Table defining mapping from input to output + Table-map name.
<i>table-map-name</i>	
cos1	IEEE 802.1Q class of service.
cos-dscp-map	Cos to DSCP Mutation map.
cos-precedence-map	Cos to Precedence Mutation map.
cos-discard-class-map	Cos to Discard Class Mutation map.

Send document comments to nexus1k-docfeedback@cisco.com.

dscp1	DSCP in IP(v4) and IPv6 packets.
dscp-cos-map	DSCP to COS Mutation map.
prec3	Precedence in IP(v4) and IPv6 packets.
dscp-precedence-map	DSCP to Precedence Mutation map.
dis-class3	Discard class.
dscp-discard-class-map	DSCP to Discard Class Mutation map.
prec1	Precedence in IP(v4) and IPv6 packets.
cos3	IEEE 802.1Q class of service.
precedence-cos-map	Precedence to COS Mutation map.
dscp3	DSCP in IP(v4) and IPv6 packets.
precedence-dscp-map	Precedence to DSCP Mutation map.
precedence-discard-class-map	Precedence to Discard Class Mutation map.
dis-class1	Discard class.
discard-class-cos-map	Discard Class to COS Mutation map.
discard-class-dscp-map	Discard Class to DSCP Mutation map.
discard-class-precedence-map	Discard Class to Precedence Mutation map.

Defaults

None

Command Modes

Policy Map Class Configuration (config-pmap-c-qos)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to set class attributes:

```
n1000v# configure terminal
n1000v(config)# policy-map pml
n1000v(config-pmap-qos)# class class-default
n1000v(config-pmap-c-qos)# set qos-group 1
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config-pmap-c-qos)#
```

This example shows how to remove class attributes:

```
n1000v# configure terminal
n1000v(config)# policy-map pm1
n1000v(config-pmap-qos)# class class-default
n1000v(config-pmap-c-qos)# no set qos-group 1
n1000v(config-pmap-c-qos)#
```

Related Commands

Command	Description
show policy-map	Displays policy maps.

Send document comments to nexus1k-docfeedback@cisco.com.

setup

To use the Basic System Configuration Dialog for creating or modifying your system configuration file, use the **setup** command.

setup

Syntax Description

This command has no arguments or keywords, but the Basic System Configuration Dialog prompts you for complete setup information (see the example below).

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The Basic System Configuration Dialog assumes the factory defaults. Keep this in mind when using it to modify an existing configuration.

All changes made to your configuration are summarized for you at the completion of the setup sequence with an option to save the changes or not.

You can exit the setup sequence at any point by pressing Ctrl-C.

Examples

This example shows how to use the setup command to create or modify a basic system configuration:

```
n1000v# setup
```

```
Enter the domain id<1-4095>: 400
```

```
Enter HA role[standalone/primary/secondary]: standalone
```

```
[#####] 100%
```

```
---- Basic System Configuration Dialog ----
```

```
This setup utility will guide you through the basic configuration of
the system. Setup configures only enough connectivity for management
of the system.
```

```
*Note: setup is mainly used for configuring the system initially,
```

Send document comments to nexus1k-docfeedback@cisco.com.

when no configuration is present. So setup always assumes system defaults and not the current system configuration values.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no): y

Create another login account (yes/no) [n]: n

Configure read-only SNMP community string (yes/no) [n]: n

Configure read-write SNMP community string (yes/no) [n]: n

Enter the switch name : n1000v

Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]:

Mgmt0 IPv4 address :

Configure the default gateway? (yes/no) [y]: n

Configure advanced IP options? (yes/no) [n]:

Enable the telnet service? (yes/no) [y]:

Enable the ssh service? (yes/no) [n]:

Configure the ntp server? (yes/no) [n]:

Configure vem feature level? (yes/no) [n]:

Configure svcs domain parameters? (yes/no) [y]:

Enter SVS Control mode (L2 / L3) : L2

Invalid SVS Control Mode

Enter SVS Control mode (L2 / L3) : L2

Enter control vlan <1-3967, 4048-4093> : 400

Enter packet vlan <1-3967, 4048-4093> : 405

The following configuration will be applied:

```
switchname n1000v
telnet server enable
no ssh server enable
svs-domain
  svcs mode L2
  control vlan 400
  packet vlan 405
  domain id 400
vlan 400
vlan 405
```

Would you like to edit the configuration? (yes/no) [n]:

Use this configuration and save it? (yes/no) [y]: n

n1000v#

Related Commands

Command	Description
show running-config	Displays the running configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

shutdown

To shutdown VLAN switching, use the **shutdown** command. To turn on VLAN switching, use the **no** form of this command.

shutdown

no shutdown

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes VLAN configuration (config-vlan)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to shutdown VLAN switching:

```
n1000v# configure terminal
n1000v(config)# vlan 10
n1000v(config-vlan)# shutdown
n1000v(config-vlan)#
```

This example shows how to turn on VLAN switching:

```
n1000v# configure terminal
n1000v(config)# vlan 10
n1000v(config-vlan)# no shutdown
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show vlan	Displays VLAN information.

Send document comments to nexus1k-docfeedback@cisco.com.

sleep

To set a sleep time, use the **sleep** command.

sleep *time*

Syntax Description	<i>time</i> Sleep time, in seconds. The range of valid values is 0 to 2147483647.
---------------------------	---

Defaults	Sleep time is not set.
-----------------	------------------------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin network-operator
---------------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	When you set <i>time</i> to 0, sleep is disabled.
-------------------------	---

Examples	This example shows how to set a sleep time:
-----------------	---

```
n1000v# sleep 100
n1000v#
```

This example shows how to disable sleep:

```
n1000v# sleep 0
n1000v#
```

Send document comments to nexus1k-docfeedback@cisco.com.

ssh

To create a Secure Shell (SSH) session, use the **ssh** command.

```
ssh [username@]{ipv4-address | hostname} [vrf vrf-name]
```

Syntax Description		
<i>username</i>	(Optional) Username for the SSH session. The user name is not case sensitive.	
<i>ipv4-address</i>	IPv4 address of the remote device.	
<i>hostname</i>	Hostname of the remote device. The hostname is case sensitive.	
vrf <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) name to use for the SSH session. The VRF name is case sensitive.	

Defaults Default VRF

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The NX-OS software supports SSH version 2.

Examples This example shows how to start an SSH session:

```
n1000v# ssh 10.10.1.1 vrf management
The authenticity of host '10.10.1.1 (10.10.1.1)' can't be established.
RSA key fingerprint is 9b:d9:09:97:f6:40:76:89:05:15:42:6b:12:48:0f:d6.
Are you sure you want to continue connecting (yes/no)? yes
Warning: Permanently added '10.10.1.1' (RSA) to the list of known hosts.
User Access Verification
Password:
```

Related Commands	Command	Description
	clear ssh session	Clears SSH sessions.
	ssh server enable	Enables the SSH server.

Send document comments to nexus1k-docfeedback@cisco.com.

ssh key

To create a Secure Shell (SSH) server key for a virtual device context (VDC), use the **ssh key** command. To remove the SSH server key, use the **no** form of this command.

```
ssh key {dsa [force] | rsa [length [force]]}
```

```
no ssh key [dsa | rsa]
```

Syntax Description	Parameter	Description
	dsa	Specifies the Digital System Algorithm (DSA) SSH server key.
	force	(Optional) Forces the replacement of an SSH key.
	rsa	Specifies the Rivest, Shamir, and Adelman (RSA) public-key cryptography SSH server key.
	<i>length</i>	(Optional) Number of bits to use when creating the SSH server key. The range is from 768 to 2048.

Defaults 1024-bit length

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The NX-OS software supports SSH version 2.
If you want to remove or replace an SSH server key, you must first disable the SSH server using the **no ssh server enable** command.

Examples This example shows how to create an SSH server key using DSA:

```
n1000v# config t
n1000v(config)# ssh key dsa
generating dsa key(1024 bits).....
..
generated dsa key
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to create an SSH server key using RSA with the default key length:

```
n1000v# config t
n1000v(config)# ssh key rsa
generating rsa key(1024 bits).....
.
generated rsa key
```

This example shows how to create an SSH server key using RSA with a specified key length:

```
n1000v# config t
n1000v(config)# ssh key rsa 768
generating rsa key(768 bits).....
.
generated rsa key
```

This example shows how to replace an SSH server key using DSA with the force option:

```
n1000v# config t
n1000v(config)# no ssh server enable
n1000v(config)# ssh key dsa force
deleting old dsa key.....
generating dsa key(1024 bits).....
.
generated dsa key
n1000v(config)# ssh server enable
```

This example shows how to remove the DSA SSH server key:

```
n1000v# config t
n1000v(config)# no ssh server enable
XML interface to system may become unavailable since ssh is disabled
n1000v(config)# no ssh key dsa
n1000v(config)# ssh server enable
```

This example shows how to remove all SSH server keys:

```
n1000v# config t
n1000v(config)# no ssh server enable
XML interface to system may become unavailable since ssh is disabled
n1000v(config)# no ssh key
n1000v(config)# ssh server enable
```

Related Commands

Command	Description
show ssh key	Displays the SSH server key information.
ssh server enable	Enables the SSH server.

Send document comments to nexus1k-docfeedback@cisco.com.

ssh server enable

To enable the Secure Shell (SSH) server, use the **ssh server enable** command. To disable the SSH server, use the **no** form of this command.

ssh server enable

no ssh server enable

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The NX-OS software supports SSH version 2.

Examples This example shows how to enable the SSH server:

```
n1000v# config t
n1000v(config)# ssh server enable
```

This example shows how to disable the SSH server:

```
n1000v# config t
n1000v(config)# no ssh server enable
XML interface to system may become unavailable since ssh is disabled
```

Related Commands	Command	Description
	show ssh server	Displays the SSH server key information.

Send document comments to nexus1k-docfeedback@cisco.com.

state (VLAN)

To set the operational state of a VLAN, use the **state** command. To disable state configuration, use the **no** form of this command.

```
state { active | suspend }
```

```
no state
```

Syntax Description	active	Specifies the active state.
	suspend	Specifies the suspended state.

Defaults	None
----------	------

Command Modes	VLAN configuration (config-vlan)
---------------	----------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to set the operational state of a VLAN:

```
n1000v# configure terminal
n1000v(config)# vlan 10
n1000v(config-vlan)# state active
n1000v(config-vlan)#
```

This example shows how to disable state configuration:

```
n1000v# configure terminal
n1000v(config)# vlan 10
n1000v(config-vlan)# no state
n1000v(config-vlan)#
```

Related Commands	Command	Description
	show vlan	Displays VLAN information.

Send document comments to nexus1k-docfeedback@cisco.com.

state (Port Profile)

To set the operational state of a port profile, use the **state** command.

state enabled

Syntax	Description
enabled	Enables or disables the port profile.

Defaults
Disabled

Command Modes
Port profile configuration (config-port-prof)

Supported User Roles
network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to enable or disable the operational state of a port profile:

```
n1000v# configure terminal
n1000v(config)# port-profile testprofile
n1000v(config-port-prof)# state enabled
n1000v(config-port-prof)#
```

Related Commands	Command	Description
	show port-profile	Displays port profile information.

Send document comments to nexus1k-docfeedback@cisco.com.

statistics per-entry

To collect statistics for each ACL entry, use the **statistics per-entry** command. To remove statistics, use the **no** form of this command.

statistics per-entry

no statistics per-entry

Syntax Description This command has no arguments or keywords.

Defaults No statistics are collected.

Command Modes ACL configuration (config-acl)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to collect statistics for each ACL entry:

```
n1000v# configure terminal
n1000v(config)# ip access-list 1
n1000v(config-acl)# statistics per-entry
n1000v(config-acl)#
```

This example shows how to remove statistics:

```
n1000v# configure terminal
n1000v(config)# ip access-list 1
n1000v(config-acl)# no statistics per-entry
n1000v(config-acl)#
```

Related Commands	Command	Description
	show statistics	Displays statistics.

Send document comments to nexus1k-docfeedback@cisco.com.

svs connection

To enable an SVS connection, use the **svs connection** command. To disable an SVS connection, use the **no** form of this command.

svs connection *name*

no svs connection *name*

Syntax Description	<i>name</i>	Connection name.
--------------------	-------------	------------------

Defaults	None
----------	------

Command Modes	Global Configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Only one SVS connection can be enabled per session.
------------------	---

Examples This example shows how to enable an SVS connection:

```
n1000v# configure terminal
n1000v(config)# svs connection conn1
n1000v(config-svs-conn)#
```

This example shows how to disable an SVS connection:

```
n1000v# configure terminal
n1000v(config)# no svs connection conn1
n1000v(config)#
```

Related Commands	Command	Description
	show svs	Displays SVS information.

Send document comments to nexus1k-docfeedback@cisco.com.

svl-domain

To configure an SVS domain and enter SVS domain configuration mode, use the **svl-domain** command.

svl-domain

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enter SVS domain configuration mode to configure an SVS domain:

```
n1000v# configure terminal
n1000v(config)# svl-domain
n1000v(config-svl-domain)#
```

Related Commands	Command	Description
	show svl	Displays SVS information.

Send document comments to nexus1k-docfeedback@cisco.com.

svs license transfer src-vem

To transfer licenses from a specified source VEM to another VEM, or to transfer an unused license to the VSM license pool, use the **svs license transfer src-vem** command.

```
svs license transfer src-vem module number [ dst-vem module number | license_pool ]
```

Syntax Description	Parameter	Description
	dst-vem <i>module-number</i>	Specifies the VEM to receive the transferred license.
	license_pool	Transfers a license back to the VSM license pool.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

- Usage Guidelines**
- Licenses cannot be transferred to a VEM unless there are sufficient licenses in the pool for all CPUs on that VEM.
 - When licenses are successfully transferred from one VEM to another, then the following happens:
 - The virtual Ethernet interfaces on the source VEM are removed from service.
 - The virtual Ethernet interfaces on the destination VEM are brought into service.
 - When licenses are successfully transferred from a VEM to the VSM license pool, then the following happens:
 - The virtual Ethernet interfaces on the source VEM are removed from service.

Send document comments to nexus1k-docfeedback@cisco.com.**Examples**

This example shows how to transfer a license from VEM 3 to VEM 5, and then display the license configuration:

```
n1000v# config t
n1000v(config)# svs license transfer src-vem 3 dst-vem 5
n1000v(config)# show license usage NEXUS1000V_LAN_SERVICES_PKG
Application
-----
VEM 5 - Socket 1
VEM 5 - Socket 2
VEM 4 - Socket 1
VEM 4 - Socket 2
-----

n1000v#
```

This example shows how to transfer a license from VEM 3 to the VSM license pool, and then display the license configuration:

```
n1000v# config t
n1000v(config)# svs license transfer src-vem 3 license_pool
n1000v(config)# show license usage NEXUS1000V_LAN_SERVICES_PKG
Application
-----
VEM 4 - Socket 1
VEM 4 - Socket 2
-----

n1000v#
```

Related Commands

Command	Description
show license usage	Displays the number and location of CPU licenses in use on your VEMs.
logging level license	Designates the level of severity at which license messages should be logged.
install license	Installs a license file(s) on a VSM
svs license transfer src-vem	Transfers licenses from a source VEM to another VEM, or to the VSM pool of available licenses.

Send document comments to nexus1k-docfeedback@cisco.com.

svs license volatile

To enable volatile licenses so that, whenever a VEM is taken out of service, its licenses are returned to the VSM pool of available licenses, use the **svs license volatile** command. To disable volatile licenses, use the **no** form of this command.

svs license volatile

no svs license volatile

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines



Caution

Service Disruption

Volatile licenses are removed from a VEM during a loss in connectivity and are not returned to the VEM when connectivity resumes. Cisco recommends that the volatile license feature remain disabled and that you, instead, transfer unused licenses using the **svs license transfer src-vem** command.

Examples This example shows how to enable the volatile license feature for a VSM:

```
n1000v(config)# svs license volatile
n1000v(config)#
```

This example shows how to disable the volatile license feature for a VSM:

```
n1000v(config)# no svs license volatile
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show license	Displays the license configuration for the VSM.
	logging level license	Designates the level of severity at which license messages should be logged.
	install license	Installs a license file(s) on a VSM
	svl license transfer src-vem	Transfers licenses from a source VEM to another VEM, or to the VSM pool of available licenses.

Send document comments to nexus1k-docfeedback@cisco.com.

switchname

To configure the hostname for the device, use the **switchname** command. To revert to the default, use the **no** form of this command.

switchname *name*

no switchname

Syntax Description	<i>name</i>	Name for the device. The name is alphanumeric, case sensitive, can contain special characters, and can have a maximum of 32 characters.
--------------------	-------------	---

Defaults	switch
----------	--------

Command Modes	Global Configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The Cisco NX-OS software uses the hostname in command-line interface (CLI) prompts and in default configuration filenames.

The **switchname** command performs the same function as the **hostname** command.

Examples This example shows how to configure the device hostname:

```
n1000v# configure terminal
n1000v(config)# switchname Engineering2
Engineering2(config)#
```

This example shows how to revert to the default device hostname:

```
Engineering2# configure terminal
Engineering2(config)# no switchname
n1000v(config)#
```

Related Commands	Command	Description
	hostname	Configures the device hostname.
	show switchname	Displays the device hostname.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

switchport access vlan

To set the access mode of an interface, use the **switchport access vlan** command. To remove access mode configuration, use the **no** form of this command.

switchport access vlan *id*

no switchport access vlan

Syntax Description	<i>id</i> VLAN identification number. The range of valid values is 1 to 3967.
---------------------------	---

Defaults	Access mode is not set.
-----------------	-------------------------

Command Modes	Interface Configuration (config-if) Port Profile Configuration (config-port-prof)
----------------------	--

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to set the access mode of an interface:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 1
n1000v(config-if)# switchport access vlan 10
n1000v(config-if)#
```

This example shows how to remove access mode configuration:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 1
n1000v(config-if)# no switchport access vlan
n1000v(config-if)#
```

Related Commands	Command	Description
	show interface	Displays interface information.

Send document comments to nexus1k-docfeedback@cisco.com.

switchport mode

To set the port mode of an interface, use the **switchport mode** command. To remove the port mode configuration, use the **no** form of this command.

```
switchport mode {access | private-vlan {host | promiscuous} | trunk}
```

```
no switchport mode {access | private-vlan {host | promiscuous} | trunk}
```

Syntax Description

access	Sets port mode access.
private-vlan	Sets the port mode to private VLAN.
host	Sets the port mode private VLAN to host.
promiscuous	Sets the port mode private VLAN to promiscuous.
trunk	Sets the port mode to trunk.

Defaults

Switchport mode is not set.

Command Modes

Interface Configuration (config-if)
Port Profile Configuration (config-port-prof)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Examples

This example shows how to set the port mode of an interface:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 1
n1000v(config-if)# switchport mode private-vlan host
n1000v(config-if)#
```

This example shows how to remove mode configuration:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 1
n1000v(config-if)# no switchport mode private-vlan host
n1000v(config-if)#
```

Related Commands

Command	Description
show interface	Displays interface information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

switchport port-security

To set the port security characteristics of an interface, use the **switchport port-security** command. To remove the port security configuration, use the **no** form of this command.

switchport port-security [**aging** {**time** *time* | **type** {**absolute** | **inactivity**}}] | **mac-address** {*address* [**vlan** *id*] | **sticky**} | **maximum** *number* [**vlan** *id*] | **violation** {**protect** | **shutdown**}}

no switchport port-security [**aging** {**time** *time* | **type** {**absolute** | **inactivity**}}] | **mac-address** {*address* [**vlan** *id*] | **sticky**} | **maximum** *number* [**vlan** *id*] | **violation** {**protect** | **shutdown**}}

Syntax Description		
aging		Configures port security aging characteristics.
time		Specifies the port security aging time.
<i>time</i>		Aging time in minutes, in the range of 0 to 1440.
type		Specifies the type of timers.
absolute		Specifies an absolute timer.
inactivity		Specifies an inactivity timer.
mac-address		Specifies a 48-bit MAC address in the format <i>HHHH.HHHH.HHHH</i> .
<i>address</i>		
vlan		Specifies the VLAN where the MAC address should be secured.
<i>id</i>		VLAN identification number. The range of valid values is 1 to 4094.
sticky		Specifies a sticky MAC address.
maximum		Specifies the maximum number of addresses, in the range of 1 to 1025.
<i>number</i>		
violation		Specifies the security violation mode.
protect		Specifies the security violation protect mode.
shutdown		Specifies the security violation shutdown mode.

Defaults None

Command Modes Interface Configuration (config-if)
Port Profile Configuration (config-port-prof)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to set the port security aging inactivity timer:

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v# configure terminal
n1000v(config)# interface vethernet 1
n1000v(config-if)# switchport port-security aging type inactivity
n1000v(config-if)#
```

This example shows how to remove the port security aging inactivity timer:

```
n1000v# configure terminal
n1000v(config)# interface vethernet 1
n1000v(config-if)# no switchport port-security aging type inactivity
n1000v(config-if)#
```

Related Commands

Command	Description
show interface	Displays interface information.
show port-security	Displays port security information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

switchport private-vlan host-association

To define a private VLAN association for an isolated or community port, use the **switchport private-vlan host-association** command. To remove the private VLAN association from the port, use the **no** form of this command.

```
switchport private-vlan host-association {primary-vlan-id} {secondary-vlan-id}
```

```
no switchport private-vlan host-association
```

Syntax Description

<i>primary-vlan-id</i>	Number of the primary VLAN of the private VLAN relationship.
<i>secondary-vlan-id</i>	Number of the secondary VLAN of the private VLAN relationship.

Defaults

None

Command Modes

Interface Configuration (config-if)
Port Profile Configuration (config-port-prof)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

There is no run-time effect on the port unless it is in private VLAN-host mode. If the port is in private VLAN-host mode but neither of the VLANs exist, the command is allowed but the port is made inactive. The port also may be inactive when the association between the private VLANs is suspended.

The secondary VLAN may be an isolated or community VLAN.

Examples

This example shows how to configure a host private VLAN port with a primary VLAN (VLAN 18) and a secondary VLAN (VLAN 20):

```
n1000v(config-if)# switchport private-vlan host-association 18 20
n1000v(config-if)#
```

This example shows how to remove the private VLAN association from the port:

```
n1000v(config-if)# no switchport private-vlan host-association
n1000v(config-if)#
```

Related Commands

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
<code>show vlan private-vlan [type]</code>	Displays information on private VLANs.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

switchport private-vlan mapping

To define the private VLAN association for a promiscuous port, use the **switchport private-vlan mapping** command. To clear all mapping from the primary VLAN, use the **no** form of this command.

```
switchport private-vlan mapping {primary-vlan-id} {[add] secondary-vlan-list |
remove secondary-vlan-list}
```

```
no switchport private-vlan mapping
```

Syntax Description		
	<i>primary-vlan-id</i>	Number of the primary VLAN of the private VLAN relationship.
	add	Associates the secondary VLANs to the primary VLAN.
	<i>secondary-vlan-list</i>	Number of the secondary VLAN of the private VLAN relationship.
	remove	Clears the association between the secondary VLANs and the primary VLAN.

Defaults	
	None

Command Modes	
	Interface Configuration (config-if) Port Profile Configuration (config-port-prof)

SupportedUserRoles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
	There is no run-time effect on the port unless it is in private VLAN-promiscuous mode. If the port is in private VLAN-promiscuous mode but the primary VLAN does not exist, the command is allowed but the port is made inactive.

The secondary VLAN may be an isolated or community VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to configure the associate primary VLAN 18 to secondary isolated VLAN 20 on a private VLAN promiscuous port:

```
n1000v(config-if)# switchport private-vlan mapping 18 20
n1000v(config-if)#
```

This example shows how to add a VLAN to the association on the promiscuous port:

```
n1000v(config-if)# switchport private-vlan mapping 18 add 21
n1000v(config-if)#
```

This example shows how to remove the all private VLAN association from the port:

```
n1000v(config-if)# no switchport private-vlan mapping
n1000v(config-if)#
```

Related Commands

Command	Description
show interface switchport	Displays information on all interfaces configured as switchports.
show interface private-vlan mapping	Displays the information about the private VLAN mapping for VLAN interfaces, or SVIs.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

switchport private-vlan mapping trunk

To designate the primary private VLAN, use the **switchport private-vlan trunk mapping trunk** command. To remove the primary private VLAN, use the **no** form of this command.

switchport private-vlan trunk native vlan *id*

no switchport private-vlan trunk native vlan

Syntax Description	<i>id</i>	VLAN identification number. The range of valid values is 1 to 3967.
Defaults	None	
Command Modes	Interface Configuration (config-if) Port Profile Configuration (config-port-prof)	
Supported User Roles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines	When you use this command, you must either add a secondary VLAN, or remove a VLAN.	
Examples	<p>This example shows how to designate the primary private VLAN:</p> <pre>n1000v# configure terminal n1000v(config)# interface vethernet 1 n1000v(config-if)# n1000v(config-if)# switchport private-vlan mapping trunk 10 add 11 n1000v(config-if)#</pre> <p>This example shows how to remove the primary private VLAN:</p> <pre>n1000v# configure terminal n1000v(config)# interface vethernet 1 n1000v(config-if)# n1000v(config-if)# no switchport private-vlan mapping trunk 10 n1000v(config-if)#</pre>	
Related Commands	Command	Description
	show vlan	Displays VLAN information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

switchport trunk allowed vlan

To set the list of allowed VLANs on the trunking interface, use the **switchport trunk allowed vlan** command. To allow *all* VLANs on the trunking interface, use the **no** form of this command.

switchport trunk allowed vlan {*vlan-list* | **all** | **none** | [**add** | **except** | **remove** {*vlan-list*}]}

no switchport trunk allowed vlan

Syntax Description	<i>vlan-list</i>	Allowed VLANs that transmit through this interface in tagged format when in trunking mode; the range of valid values is from 1 to 4094.
all		Allows all appropriate VLANs to transmit through this interface in tagged format when in trunking mode.
none		Blocks all VLANs transmitting through this interface in tagged format when in trunking mode.
add		(Optional) Adds the defined list of VLANs to those currently set instead of replacing the list.
except		(Optional) Allows all VLANs to transmit through this interface in tagged format when in trunking mode except the specified values.
remove		(Optional) Removes the defined list of VLANs from those currently set instead of replacing the list.

Defaults All VLANs

Command Modes Interface Configuration (config-if)
Port Profile Configuration (config-port-prof)

SupportedUserRoles network-admin

Send document comments to nexus1k-docfeedback@cisco.com.

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

You must enter the **switchport** command without any keywords to configure the LAN interface as a Layer 2 interface before you can enter the **switchport trunk allowed vlan** command. This action is required only if you have not entered the **switchport** command for the interface.

If you remove VLAN 1 from a trunk, the trunk interface continues to send and receive management traffic in VLAN 1.

Examples

This example shows how to add a series of consecutive VLANs to the list of allowed VLANs on a trunking port:

```
n1000v(config-if)# switchport trunk allowed vlan add 40-50
n1000v(config-if)#
```

Related Commands

Command	Description
show interface switchport	Displays the administrative and operational status of a switching (nonrouting) port.

Send document comments to nexus1k-docfeedback@cisco.com.

switchport trunk native vlan

To configure trunking parameters on an interface, use the **switchport trunk native vlan** command. To remove the configuration, use the **no** form of this command.

switchport trunk native vlan *id*

no switchport trunk native vlan

Syntax Description	<i>id</i>	VLAN identification number. The range of valid values is 1 to 3967.
Defaults	None	
Command Modes	Interface Configuration (config-if) Port Profile Configuration (config-port-prof)	
SupportedUserRoles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Examples	This example shows how to configure trunking parameters on an interface: <pre>n1000v# configure terminal n1000v(config)# interface vethernet 10 n1000v(config-if)# switchport trunk native vlan 20 n1000v(config-if)#</pre>	
Related Commands	Command	Description
	show vlan	Displays VLAN information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

system redundancy role

To configure a redundancy role for the VSM, use the **system redundancy role** command. To revert to the default setting, use the **no** form of the command.

```
system redundancy role {primary | secondary | standalone}
```

```
no system redundancy role {primary | secondary | standalone}
```

Syntax Description		
	primary	Specifies the primary redundant VSM.
	secondary	Specifies the secondary redundant VSM.
	standalone	Specifies no redundant VSM.

Command Default	None
-----------------	------

Command Modes	EXEC
---------------	------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
------------------	--

Examples	This example shows how to configure no redundant VSM: <pre>n1000v# system redundancy role standalone n1000v#</pre>
----------	---

Related Commands	Command	Description
	show system redundancy	Displays the system redundancy status.

Send document comments to nexus1k-docfeedback@cisco.com.

system switchover

To switch over to the standby supervisor, use the **system switchover** command.

system switchover

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to switch over to the standby supervisor:

```
n1000v# system switchover
n1000v#
```

Related Commands	Command	Description
	show system redundancy	Displays the system redundancy status.

Send document comments to nexus1k-docfeedback@cisco.com.



Show Commands

This chapter describes the Cisco Nexus 1000V show commands.



Note

This chapter is a work in progress and does not yet include all show commands.

show aaa accounting

To display the AAA accounting configuration, use the **show aaa accounting** command.

show aaa accounting

Syntax Description

This command has no arguments or keywords.

Defaults

None

Command Modes

Any

SupportedUserRoles

network-admin
network-operator

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to display the accounting configuration:

```
n1000v# show aaa accounting
      default: local
n1000v#
```

Related Commands

Command	Description
aaa accounting login	Configures the console or default login accounting method.
show running-config aaa [all]	Displays the AAA configuration as it currently exists in the running configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

show aaa authentication

To display the configuration for AAA authentication, use the **show aaa authentication** command.

show aaa authentication [**login error-enable** | **login mschap**]

Syntax Description	
login error-enable	(Optional) Displays the authentication login error message enable configuration.
login mschap	(Optional) Displays the authentication login MS-CHAP enable configuration.

Defaults None

Command Modes Any

Supported User Roles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to display the configured authentication parameters:

```
n1000v# show aaa authentication
      default: local
      console: local
```

This example shows how to display the authentication-login error-enable configuration:

```
n1000v# show aaa authentication login error-enable
disabled
```

This example shows how to display the authentication-login MSCHAP configuration:

```
n1000v# show aaa authentication login mschap
disabled
```

Related Commands	Command	Description
	aaa authentication login	Configures the console or default login authentication method.
	show running-config aaa [all]	Displays the AAA configuration as it currently exists in the running configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

show aaa groups

To display the configured AAA server groups, use the **show aaa groups** command.

show aaa groups

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display AAA group information:

```
n1000v# show aaa groups
radius
TacServer
```

Related Commands	Command	Description
	aaa group	Configures an AAA server group.
	show running-config aaa [all]	Displays the AAA configuration as it currently exists in the running configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

show accounting log

To display the accounting log contents, use the **show accounting log** command.

show accounting log [*size*] [**start-time** *year month day HH:MM:SS*]

Syntax Description	
<i>size</i>	(Optional) Size of the log to display in bytes. The range is from 0 to 250000.
start-time <i>year month day HH:MM:SS</i>	(Optional) Specifies a start time as follows. <ul style="list-style-type: none"> • The year is shown in the yyyy format, such as 2009. • The month is shown in the three-letter English abbreviation, such as Feb. • The day of the month is shown as a number from 1 to 31. • Hours, minutes, and seconds are shown in the standard 24-hour format, such as 16:00:00.

Defaults	
	None

Command Modes	
	Any

SupportedUserRoles	
	network-admin network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to display the entire accounting log:

```
n1000v# show accounting log
Wed Jul 22 02:09:44 2009:update:vsh.3286:root:configure terminal ; port-profile Unused_Or_Quarantine_Uplink ; capability uplink (SUCCESS)
Wed Jul 22 07:57:50 2009:update:171.71.55.185@pts/2:admin:configure terminal ; flow record newflowrecord (SUCCESS)
Wed Jul 22 08:48:57 2009:start:swordfish-build1.cisco.com@pts:admin:
Wed Jul 22 08:49:03 2009:stop:swordfish-build1.cisco.com@pts:admin:shell terminated gracefully
Wed Jul 22 08:50:36 2009:update:171.71.55.185@pts/2:admin:configure terminal ; no flow record newflowrecord (SUCCESS)
Thu Jul 23 07:21:50 2009:update:vsh.29016:root:configure terminal ; port-profile Unused_Or_Quarantine_Veth ; state enabled (SUCCESS)
Thu Jul 23 10:25:19 2009:start:171.71.55.185@pts/5:admin:
Thu Jul 23 11:07:37 2009:update:171.71.55.185@pts/5:admin:enabled aaa user default role enabled/disabled
doc-n1000v(config)#
```

This example shows how to display 400 bytes of the accounting log:

```
n1000v# show accounting log 400

Sat Feb 16 21:15:24 2008:update:/dev/pts/1_172.28.254.254:admin:show accounting log start-time 2008 Feb 16 18:31:21
Sat Feb 16 21:15:25 2008:update:/dev/pts/1_172.28.254.254:admin:show system uptime
Sat Feb 16 21:15:26 2008:update:/dev/pts/1_172.28.254.254:admin:show clock
```

This example shows how to display the accounting log starting at 16:00:00 on February 16, 2008:

```
n1000v(config)# show accounting log start-time 2008 Feb 16 16:00:00

Sat Feb 16 16:00:18 2008:update:/dev/pts/1_172.28.254.254:admin:show logging log file start-time 2008 Feb 16 15:59:16
Sat Feb 16 16:00:26 2008:update:/dev/pts/1_172.28.254.254:admin:show accounting log start-time 2008 Feb 16 12:05:16
Sat Feb 16 16:00:27 2008:update:/dev/pts/1_172.28.254.254:admin:show system uptime
Sat Feb 16 16:00:28 2008:update:/dev/pts/1_172.28.254.254:admin:show clock
Sat Feb 16 16:01:18 2008:update:/dev/pts/1_172.28.254.254:admin:show logging log file start-time 2008 Feb 16 16:00:16
Sat Feb 16 16:01:26 2008:update:/dev/pts/1_172.28.254.254:admin:show accounting log start-time 2008 Feb 16 12:05:16
Sat Feb 16 16:01:27 2008:update:/dev/pts/1_172.28.254.254:admin:show system uptime
Sat Feb 16 16:01:29 2008:update:/dev/pts/1_172.28.254.254:admin:show clock
Sat Feb 16 16:02:18 2008:update:/dev/pts/1_172.28.254.254:admin:show logging log file start-time 2008 Feb 16 16:01:16
Sat Feb 16 16:02:26 2008:update:/dev/pts/1_172.28.254.254:admin:show accounting log start-time 2008 Feb 16 12:05:16
Sat Feb 16 16:02:28 2008:update:/dev/pts/1_172.28.254.254:admin:show system uptime
```

Related Commands

Command	Description
clear accounting log	Clears the accounting log.

Send document comments to nexus1k-docfeedback@cisco.com.

show cdp

To display your Cisco Discovery Protocol (CDP) configuration, use the **show cdp** command.

```
show cdp {all | entry {all | name s0} | global | interface if0 | traffic interface if2}
```

Syntax Description		
all		Display all interfaces in CDP database.
entry		Display CDP entries in database.
name <i>name</i>		Display a specific CDP entry matching a name.
global		Display CDP parameters for all interfaces.
interface <i>interface</i>		Display CDP parameters for a specified interface.
traffic interface <i>interface</i>		Display CDP traffic statistics.

Defaults None

Command Modes Any

Supported User Roles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display the global CDP configuration:

```
n1000v(config)# show cdp global
Global CDP information:
  CDP enabled globally
  Sending CDP packets every 5 seconds
  Sending a holdtime value of 10 seconds
  Sending CDPv2 advertisements is disabled
  Sending DeviceID TLV in Mac Address Format
```

This example shows how to display the CDP configuration for a specified interface:

```
n1000v(config)# show cdp interface ethernet 2/3
Ethernet2/3 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to display the CDP traffic statistics for a specified interface:

```
n1000v(config)# show cdp traffic interface ethernet 2/3
-----
Traffic statistics for Ethernet2/3
Input Statistics:
  Total Packets: 98
  Valid CDP Packets: 49
    CDP v1 Packets: 49
    CDP v2 Packets: 0
  Invalid CDP Packets: 49
    Unsupported Version: 49
    Checksum Errors: 0
    Malformed Packets: 0

Output Statistics:
  Total Packets: 47
    CDP v1 Packets: 47
    CDP v2 Packets: 0
  Send Errors: 0
```

This example shows how to display CDP parameters for all interfaces:

```
n1000v# show cdp all
Ethernet2/2 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
Ethernet2/3 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
Ethernet2/4 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
Ethernet2/5 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
Ethernet2/6 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
mgmt0 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

Related Commands

Command	Description
show cdp neighbors	Displays the configuration and capabilities of upstream devices.
cdp enable	In interface mode, enables CDP on an interface. In EXEC mode, enables CDP for your device.
cdp advertise	Assigns the CDP version to advertise.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show cdp neighbors

To display the configuration and capabilities of upstream devices, use the **show cdp neighbors** command.

show cdp neighbors [interface *if*] detail

Syntax Description	
interface <i>if</i>	(Optional) Show CDP neighbors for a specified interface.
detail	Show the detailed configuration of all CDP neighbors.

Defaults None

Command Modes Any

Supported User Roles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to display the configuration and capabilities of upstream devices:

```
n1000v(config)# show cdp neighbors
Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute

Device ID           Local Intrfce   Hldtme   Capability   Platform   Port ID
swordfish-6k-2     Eth2/2         169      R S I       WS-C6503-E Gig1/14
swordfish-6k-2     Eth2/3         139      R S I       WS-C6503-E Gig1/15
swordfish-6k-2     Eth2/4         135      R S I       WS-C6503-E Gig1/16
swordfish-6k-2     Eth2/5         177      R S I       WS-C6503-E Gig1/17
swordfish-6k-2     Eth2/6         141      R S I       WS-C6503-E Gig1/18
```

This example shows how to display configuration and capabilities of upstream devices for a specific interface:

```
n1000v(config)# show cdp neighbors interface ethernet 2/3
Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
```

Send document comments to nexus1k-docfeedback@cisco.com.

s - Supports-STP-Dispute

Device ID	Local Intrfce	Hldtme	Capability	Platform	Port ID
swordfish-6k-2	Eth2/3	173	R S I	WS-C6503-E	Gig1/15

Related Commands

Command	Description
show cdp	Displays the CDP configuration and capabilities for your device.
cdp enable	In interface mode, enables CDP on an interface. In EXEC mode, enables CDP for your device.
cdp advertise	Assigns the CDP version to advertise.

Send document comments to nexus1k-docfeedback@cisco.com.

show interface counters trunk

To display the counters for Layer 2 switch port trunk interfaces, use the **show interface counters trunk** command.

```
show interface {ethernet slot/port} counters trunk
```

Syntax Description	ethernet <i>slot/port</i>	Specifies the module number and port number for the trunk interface that you want to display.
--------------------	---------------------------	---

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The device supports only IEEE 802.1Q encapsulation. This command also displays the counters for trunk port channels.
------------------	--

Examples	This example shows how to display the counters for a trunk interface. This display shows the frames transmitted and received through the trunk interface, as well as the number of frames with the wrong trunk encapsulation:
----------	---

```
n1000v# show interface ethernet 2/9 counters trunk
```

```
-----
Port                TrunkFramesTx   TrunkFramesRx   WrongEncap
-----
Ethernet2/9         0                0                0
n1000v#
```

Related Commands	Command	Description
	clear counters interface	Clears the counters for the specified interfaces.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show interface port-channel

To display descriptive information about port channels, use the **show interface port-channel** command.

```
show interface port-channel channel-number [brief | description | flowcontrol | status |
switchport | trunk]
```

Syntax Description	
<i>channel-number</i>	Number of the port-channel group. Valid values are from 1 to 4096.
brief	(Optional) Specifies the summary information for specified port channels.
description	(Optional) Specifies the description of specified port channels.
flowcontrol	(Optional) Specifies information about the flow-control status control for specified port channels and the statistics on received and transmitted flow-control pause packets.
status	(Optional) Specifies information about the status for specified port channels.
switchport	(Optional) Specifies information for specified Layer 2 port channels including access and trunk modes.
trunk	(Optional) Specifies information for specified Layer 2 port channels on the trunk mode.

Defaults None

Command Modes Any

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines To display more statistics for the specified port channels, use the **show interface port-channel counters** command.

Examples This example shows how to display information for a specific port channel. This command displays statistical information gathered on the port channel at 1-minute intervals:

```
n1000v(config)# show interface port-channel 50
port-channel50 is down (No operational members)
  Hardware is Port-Channel, address is 0000.0000.0000 (bia 0000.0000.0000)
  MTU 1500 bytes, BW 100000 Kbit, DLY 10 usec,
```

Send document comments to nexus1k-docfeedback@cisco.com.

```

    reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ARPA
Port mode is access
auto-duplex, auto-speed
Beacon is turned off
Input flow-control is off, output flow-control is off
Switchport monitor is off
Members in this channel: Eth2/10
Last clearing of "show interface" counters 2d71.2uh
5 minute input rate 0 bytes/sec, 0 packets/sec
5 minute output rate 0 bytes/sec, 0 packets/sec
Rx
  0 input packets 0 unicast packets 0 multicast packets
  0 broadcast packets 0 jumbo packets 0 storm suppression packets
  0 bytes
Tx
  0 output packets 0 multicast packets
  0 broadcast packets 0 jumbo packets
  0 bytes
  0 input error 0 short frame 0 watchdog
  0 no buffer 0 runt 0 CRC 0 ecc
  0 overrun 0 underrun 0 ignored 0 bad etype drop
  0 bad proto drop 0 if down drop 0 input with dribble
  0 input discard
  0 output error 0 collision 0 deferred
  0 late collision 0 lost carrier 0 no carrier
  0 babble
  0 Rx pause 0 Tx pause 0 reset

```

This example shows how to display a brief description for a specific port channel, including the mode for the port channel, the status, speed, and protocol:

```
n1000v# show interface port-channel 5 brief
```

```

-----
Port-channel VLAN  Type Mode   Status Reason                Speed Protocol
Interface
-----
                eth  access down    No operational members  auto(D) lACP

```

This example shows how to display the description for a specific port channel:

```
n1000v# show interface port-channel 5 description
```

```

-----
Interface          Description
-----
port-channel5      test

```

This example shows how to display the flow-control information for a specific port channel:

```
n1000v# show interface port-channel 50 flowcontrol
```

```

-----
Port      Send FlowControl  Receive FlowControl  RxPause TxPause
        admin   oper   admin   oper
-----
Po50      off     off    off     off         0       0

```

This example shows how to display the status of a specific port channel:

```
n1000v# show interface port-channel 5 status
```

```

-----
Port      Name          Status  Vlan    Duplex  Speed  Type

```

Send document comments to nexus1k-docfeedback@cisco.com.

```
-----
                                test          down    1          auto    auto    --
```

This example shows how to display information for a specific Layer 2 port channel:

```
n1000v# show interface port-channel 50 switchport
Name: port-channel50
  Switchport: Enabled
  Switchport Monitor: Not enabled
  Operational Mode: trunk
  Access Mode VLAN: 1 (default)
  Trunking Native Mode VLAN: 1 (default)
  Trunking VLANs Enabled: 1-3967,4048-4093
  Administrative private-vlan primary host-association: none
  Administrative private-vlan secondary host-association: none
  Administrative private-vlan primary mapping: none
  Administrative private-vlan secondary mapping: none
  Administrative private-vlan trunk native VLAN: none
  Administrative private-vlan trunk encapsulation: dot1q
  Administrative private-vlan trunk normal VLANs: none
  Administrative private-vlan trunk private VLANs: none
  Operational private-vlan: none
```

This command displays information for Layer 2 port channels in both the access and trunk modes.

When you use this command for a routed port channel, the device returns the following message:

```
Name: port-channel20
  Switchport: Disabled
```

This example shows how to display information for a specific Layer 2 port channel that is in trunk mode:

```
n1000v# show interface port-channel 5 trunk

n1000v# show interface port-channel 50 trunk
port-channel50 is down (No operational members)
  Hardware is Ethernet, address is 0000.0000.0000
  MTU 1500 bytes, BW 100000 Kbit, DLY 10 usec
  Port mode is access
  Speed is auto-speed
  Duplex mode is auto
  Beacon is turned off
  Receive flow-control is off, Send flow-control is off
  Rate mode is dedicated
Members in this channel: Eth2/10
  Native Vlan: 1
  Allowed Vlans: 1-3967,4048-4093
```

This command displays information for only Layer 2 port channels in the trunk modes; you cannot display information about Layer 2 port channels in the access mode with this command.

Related Commands

Command	Description
show interface port-channel counters	Displays the statistics for channel groups.
show port-channel summary	Displays summary information for all channel groups.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show interface port-channel counters

To display information about port-channel statistics, use the **show interface port-channel counters** command.

```
show interface port-channel channel-number counters [brief | detailed [all | snmp] | errors
[snmp] | trunk]
```

Syntax Description	
<i>channel-number</i>	Number of the port-channel group. Valid values are from 1 to 4096.
brief	(Optional) Specifies the rate MB/s and total frames for specified port channels.
detailed	(Optional) Specifies the nonzero counters for specified port channels.
all	(Optional) Specifies the counters for specified port channels.
snmp	(Optional) Specifies the SNMP MIB values for specified port channels.
errors	(Optional) Specifies the interface error counters for specified port channels.
trunk	(Optional) Specifies the interface trunk counters for specified port channels.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines This command displays statistics for all port channels including LACP-enabled port channels and those port channels that are not associated with an aggregation protocol.

Examples This example shows how to display the counters for a specific port channel. This display shows the transmitted and received unicast and multicast packets:

```
n1000v# show interface port-channel 2 counters

Port          InOctets   InUcastPkts  InMcastPkts  InBcastPkts
Po2           6007       1             31            1

Port          OutOctets   OutUcastPkts  OutMcastPkts  OutBcastPkts
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
Po2          4428          1          25          1
n1000v#
```

This example shows how to display the brief counters for a specific port channel. This display shows the transmitted and received rate and total frames:

```
n1000v# show interface port-channel 20 counters brief
```

```
-----
Interface          Input (rate is 1 min avg)  Output (rate is 1 min avg)
-----
                   Rate      Total          Rate      Total
                   MB/s    Frames        MB/s    Frames
-----
port-channel20     0        0            0        0
-----
```

This example shows how to display all the detailed counters for a specific port channel:

```
n1000v# show interface port-channel 20 counters detailed all
```

```
port-channel20
 64 bit counters:
 0.          rxHCTotalPkts = 0
 1.          txHCTotalPkts = 0
 2.          rxHCUnicastPkts = 0
 3.          txHCUnicastPkts = 0
 4.          rxHCMulticastPkts = 0
 5.          txHCMulticastPkts = 0
 6.          rxHCBroadcastPkts = 0
 7.          txHCBroadcastPkts = 0
 8.          rxHCOctets = 0
 9.          txHCOctets = 0
10.         rxTxHCPkts64Octets = 0
11.         rxTxHCpkts65to127Octets = 0
12.         rxTxHCpkts128to255Octets = 0
13.         rxTxHCpkts256to511Octets = 0
14.         rxTxHCpkts512to1023Octets = 0
15.         rxTxHCpkts1024to1518Octets = 0
16.         rxTxHCpkts1519to1548Octets = 0
17.         rxHCTrunkFrames = 0
18.         txHCTrunkFrames = 0
19.         rxHCDropEvents = 0
```

```
All Port Counters:
 0.          InPackets = 0
 1.          InOctets = 0
 2.          InUcastPkts = 0
 3.          InMcastPkts = 0
 4.          InBcastPkts = 0
 5.          InJumboPkts = 0
 6.          StormSuppressPkts = 0
 7.          OutPackets = 0
 8.          OutOctets = 0
 9.          OutUcastPkts = 0
10.          OutMcastPkts = 0
11.          OutBcastPkts = 0
12.          OutJumboPkts = 0
13.          rxHCPkts64Octets = 0
14.          rxHCPkts65to127Octets = 0
15.          rxHCPkts128to255Octets = 0
16.          rxHCPkts256to511Octets = 0
17.          rxHCpkts512to1023Octets = 0
18.          rxHCpkts1024to1518Octets = 0
19.          rxHCpkts1519to1548Octets = 0
20.          txHCPkts64Octets = 0
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
21.          txHCPkts65to127Octets = 0
22.          txHCPkts128to255Octets = 0
23.          txHCPkts256to511Octets = 0
24.          txHCpkts512to1023Octets = 0
25.          txHCpkts1024to1518Octets = 0
26.          txHCpkts1519to1548Octets = 0
27.          ShortFrames = 0
28.          Collisions = 0
29.          SingleCol = 0
30.          MultiCol = 0
31.          LateCol = 0
32.          ExcessiveCol = 0
33.          LostCarrier = 0
34.          NoCarrier = 0
35.          Runts = 0
36.          Giants = 0
37.          InErrors = 0
38.          OutErrors = 0
39.          InputDiscards = 0
40.          BadEtypeDrops = 0
41.          IfDownDrops = 0
42.          InUnknownProtos = 0
43.          txCRC = 0
44.          rxCRC = 0
45.          Symbol = 0
46.          txDropped = 0
47.          TrunkFramesTx = 0
48.          TrunkFramesRx = 0
49.          WrongEncap = 0
50.          Babbles = 0
51.          Watchdogs = 0
52.          ECC = 0
53.          Overruns = 0
54.          Underruns = 0
55.          Dribbles = 0
56.          Deferred = 0
57.          Jabbers = 0
58.          NoBuffer = 0
59.          Ignored = 0
60.          bpduOutLost = 0
61.          cos0OutLost = 0
62.          cos1OutLost = 0
63.          cos2OutLost = 0
64.          cos3OutLost = 0
65.          cos4OutLost = 0
66.          cos5OutLost = 0
67.          cos6OutLost = 0
68.          cos7OutLost = 0
69.          RxPause = 0
70.          TxPause = 0
71.          Resets = 0
72.          SQETest = 0
73.          InLayer3Routed = 0
74.          InLayer3RoutedOctets = 0
75.          OutLayer3Routed = 0
76.          OutLayer3RoutedOctets = 0
77.          OutLayer3Unicast = 0
78.          OutLayer3UnicastOctets = 0
79.          OutLayer3Multicast = 0
80.          OutLayer3MulticastOctets = 0
81.          InLayer3Unicast = 0
82.          InLayer3UnicastOctets = 0
83.          InLayer3Multicast = 0
84.          InLayer3MulticastOctets = 0
```

Send document comments to nexus1k-docfeedback@cisco.com.

```

85.          InLayer3AverageOctets = 0
86.          InLayer3AveragePackets = 0
87.          OutLayer3AverageOctets = 0
88.          OutLayer3AveragePackets = 0

```

This example shows how to display the error counters for a specific port channel:

```
n1000v# show interface port-channel 5 counters errors
```

```

-----
Port          Align-Err      FCS-Err      Xmit-Err      Rcv-Err      UnderSize  OutDiscards
-----
Po5              0              0              0              0              0              0
-----
Port          Single-Col    Multi-Col     Late-Col      Exces-Col     Carri-Sen    Runts
-----
Po5              0              0              0              0              0              0
-----
Port          Giants      SQETest-Err  Deferred-Tx  IntMacTx-Er  IntMacRx-Er  Symbol-Err
-----
              0              --              0              0              0              0
-----

```

This example shows how to display information about the trunk interfaces for a specific port channel:

```
n1000v# show interface port-channel 5 counters trunk
```

```

-----
Port          TrunkFramesTx  TrunkFramesRx  WrongEncap
-----
port-channel5      0              0              0
-----

```

Related Commands

Command	Description
clear counters	Clears the statistics for all interfaces that belong to a specific channel group.
interface port-channel <i>channel-number</i>	

Send document comments to nexus1k-docfeedback@cisco.com.

show interface switchport

To display information about switchport interfaces, use the **show interface switchport** command.

show interface [*ethernet slot number*] **port-channel** *channel number* **switchport**

Syntax Description		
ethernet <i>slot number</i>	(Optional) Specify the slot number for the display of an ethernet switchport interface.	
port- channel <i>channel-number</i>	(Optional) Specify the channel number for the display of a port channel switchport interface.	

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If you do not specify an interface, this command displays information about all Layer 2 interfaces, including access, trunk, and port channel interfaces and all private VLAN ports.

Examples This example shows how to display information for all Layer 2 interfaces:

```
n1000v# show interface switchport
Name: Ethernet2/5
  Switchport: Enabled
  Switchport Monitor: Not enabled
  Operational Mode: access
  Access Mode VLAN: 1 (default)
  Trunking Native Mode VLAN: 1 (default)
  Trunking VLANs Enabled: 1-3967,4048-4093
  Administrative private-vlan primary host-association: none
  Administrative private-vlan secondary host-association: none
  Administrative private-vlan primary mapping: none
  Administrative private-vlan secondary mapping: none
  Administrative private-vlan trunk native VLAN: none
  Administrative private-vlan trunk encapsulation: dot1q
  Administrative private-vlan trunk normal VLANs: none
  Administrative private-vlan trunk private VLANs: none
  Operational private-vlan: none

Name: Ethernet2/9
  Switchport: Enabled
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
Switchport Monitor: Not enabled
Operational Mode: trunk
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Trunking VLANs Enabled: 1-3967,4048-4093
Administrative private-vlan primary host-association: none
Administrative private-vlan secondary host-association: none
Administrative private-vlan primary mapping: none
Administrative private-vlan secondary mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk private VLANs: none
Operational private-vlan: none
```

```
Name: port-channel5
Switchport: Enabled
Switchport Monitor: Not enabled
Operational Mode: access
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Trunking VLANs Enabled: 1-3967,4048-4093
Administrative private-vlan primary host-association: none
Administrative private-vlan secondary host-association: none
Administrative private-vlan primary mapping: none
Administrative private-vlan secondary mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk private VLANs: none
Operational private-vlan: none
```

```
n1000v#
```

Related Commands

Command	Description
switchport mode	Sets the specified interfaces as either Layer 2 access or trunk interfaces.
show interface counters	Displays statistics for a specified Layer 2 interface.

Send document comments to nexus1k-docfeedback@cisco.com.

show interface trunk

To display information about all the trunk interfaces, use the **show interface trunk** command.

```
show interface [ethernet type/slot | port-channel channel-number] trunk [module number | vlan vlan-id]
```

Syntax Description

ethernet <i>type/slot</i> port-channel <i>channel-number</i>	(Optional) Type and number of the interface you want to display.
module <i>number</i>	(Optional) Specifies the module number.
vlan <i>vlan-id</i>	(Optional) Specifies the VLAN number.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

If you do not specify an interface, a module number or a VLAN number, the system displays information for all trunk interfaces.

This command displays information about all Layer 2 trunk interfaces and trunk port-channel interfaces.

Use the **show interface counters** command to display statistics for the specified Layer 2 interface.

Examples

This example shows how to display information for all Layer 2 trunk interfaces:

```
n1000v(config)# show interface trunk
```

```
-----
Port      Native  Status      Port
         Vlan
-----
Eth2/9    1       trunking    --
Eth2/10   1       trnk-bndl   Po50
Po50      1       not-trunking --
-----
```

```
-----
Port      Vlans Allowed on Trunk
-----
```

■ show interface trunk

Send document comments to nexus1k-docfeedback@cisco.com.

```
Eth2/9      1-3967,4048-4093
Eth2/10     1-3967,4048-4093
Po50        1-3967,4048-4093
```

```
-----
Port        STP Forwarding
-----
```

```
Eth2/9      none
Eth2/10     none
Po50        none
```

```
n1000v#
```

Related Commands

Command	Description
switchport mode trunk	Sets the specified interfaces as Layer 2 trunk interfaces.

Send document comments to nexus1k-docfeedback@cisco.com.

show ip dhcp snooping statistics

To display statistics related to the Dynamic Host Configuration Protocol (DHCP), use the **show ip dhcp snooping statistics** command.

show ip dhcp snooping statistics

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Before you can configure DHCP, you must enable the feature using the **feature dhcp** command.

Examples This example shows how to display statistics related to DHCP:

```
n1000v# show ip dhcp snooping statistics
Packets processed 0
Packets received through cfsoe 0
Packets forwarded 0
Total packets dropped 0
Packets dropped from untrusted ports 0
Packets dropped due to MAC address check failure 0
Packets dropped due to Option 82 insertion failure 0
Packets dropped due to o/p intf unknown 0
Packets dropped which were unknown 0
Packets dropped due to dhcp relay not enabled 0
Packets dropped due to no binding entry 0
Packets dropped due to interface error/no interface 0
Packets dropped due to max hops exceeded 0
n1000v#
```

Related Commands	Command	Description
	ip dhcp snooping	Globally enables DHCP snooping on the device.
	show ip dhcp snooping	Displays general information about DHCP snooping.

show ip dhcp snooping statistics

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
show ip dhcp snooping binding	Displays IP-MAC address bindings, including the static IP source entries.
feature dhcp	Enables the DHCP snooping feature on the device.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show ip igmp snooping explicit-tracking vlan

To display IGMPv3 snooping explicit tracking information for a VLAN, use the **show ip igmp snooping explicit-tracking vlan** command.

```
show ip igmp snooping explicit-tracking vlan vlan-id
```

Syntax Description	<i>vlan-id</i>	Specifies a VLAN ID.
--------------------	----------------	----------------------

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

Related Commands	Command	Description
	show ip igmp snooping	Ensures that IGMP snooping is enabled on the VLAN.
	show ip igmp snooping groups	Verifies if the Cisco Nexus 1000V is configured correctly and is ready to forward multicast traffic.
	show ip igmp snooping mrouter	Displays multicast router ports on the VLAN.
	show ip igmp snooping querier	Displays IGMP snooping queriers enabled on the VLAN

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show ip igmp snooping groups

To verify if the Cisco Nexus 1000V is configured correctly and is ready to forward multicast traffic, use the **show ip igmp snooping groups** command.

show ip igmp snooping groups

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines When troubleshooting multicast IGMP issues, execute this command and look for the letter R under the port heading. The R indicates that the Virtual Supervisor Module (VSM) has learned the uplink router port from the IGMP query that was sent by the upstream switch, which means that the Cisco Nexus 1000V is ready to forward multicast traffic.

Examples This example shows how to ensure that IGMP snooping is enabled on the VLAN:

```
n1000v# show ip igmp snooping groups
Type: S - Static, D - Dynamic, R - Router port

Vlan  Group Address      Ver  Type  Port list
59    */*                   v3   R     Po1
n1000v#n1000v#
```

Related Commands	Command	Description
	show cdp neighbor	Displays the configuration and capabilities of upstream devices.
	module vem execute	Remotely executes commands on the Virtual Ethernet Module (VEM) from the Cisco Nexus 1000V.
	show ip igmp snooping	Ensures that IGMP snooping is enabled on the VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

show ip igmp snooping mrouter

To display VLAN multicast router ports, use the **show ip igmp snooping mrouter** command.

```
show ip igmp snooping mrouter [vlan vlan-id]
```

Syntax Description	
vlan <i>vlan-id</i>	Specifies a VLAN and its ID.

Defaults	
	None

Command Modes	
	Any

SupportedUserRoles	
	network-admin network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

Related Commands	Command	Description
	show ip igmp snooping	Ensures that IGMP snooping is enabled on the VLAN.
	show ip igmp snooping groups	Verifies if the Cisco Nexus 1000V is configured correctly and is ready to forward multicast traffic.
	show ip igmp snooping explicit-tracking vlan	Display IGMP snooping information for a VLAN.
	show ip igmp snooping querier	Displays IGMP snooping queriers enabled on the VLAN

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show ip igmp snooping querier

To display IGMP snooping querier information, use the **show ip igmp snooping querier** command.

```
show ip igmp snooping querier [vlan vlan-id]
```

Syntax Description	
vlan <i>vlan-id</i>	Specifies a VLAN and its ID.

Defaults	
None	

Command Modes	
Any	

SupportedUserRoles	
network-admin network-operator	

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	

Examples	

Related Commands	Command	Description
	show ip igmp snooping	Ensures that IGMP snooping is enabled on the VLAN.
	show ip igmp snooping groups	Verifies if the Cisco Nexus 1000V is configured correctly and is ready to forward multicast traffic.
	show ip igmp snooping explicit-tracking vlan	Display IGMP snooping information for a VLAN.
	show ip igmp snooping mrouter	Displays multicast router ports on the VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

show lacp counters

To display information about Link Aggregation Control Protocol (LACP) statistics, use the **show lacp counters** command.

show lacp counters [**interface port-channel** *channel-number*]

Syntax Description	<i>channel-number</i> (Optional) Number of the LACP channel group. Valid values are from 1 to 4096.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If you do not specify the *channel-number*, all channel groups are displayed.

Examples This example shows how to display the LACP statistics for a specific channel group:

```
n1000v# show lacp counters interface port-channel 1
```

```

LACPDUs          Marker      Marker Response   LACPDUs
Port             Sent       Recv    Sent    Recv    Sent   Recv    Pkts Err
-----
port-channel1
Ethernet1/1      554        536      0        0        0        0        0
Ethernet1/2      527        514      0        0        0        0        0
Ethernet1/3      535        520      0        0        0        0        0
Ethernet1/4      515        502      0        0        0        0        0
Ethernet1/5      518        505      0        0        0        0        0
Ethernet1/6      540        529      0        0        0        0        0
Ethernet1/7      541        530      0        0        0        0        0
Ethernet1/8      547        532      0        0        0        0        0
Ethernet1/9      544        532      0        0        0        0        0
Ethernet1/10     513        501      0        0        0        0        0
Ethernet1/11     497        485      0        0        0        0        0
Ethernet1/12     493        486      0        0        0        0        0
Ethernet1/13     492        485      0        0        0        0        0
Ethernet1/14     482        481      0        0        0        0        0
Ethernet1/15     481        476      0        0        0        0        0
Ethernet1/16     482        477      0        0        0        0        0

```

■ show lacp counters

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	clear lacp counters	Clears the statistics for all LACP interfaces or those interfaces that belong to a specific LACP channel group.

Send document comments to nexus1k-docfeedback@cisco.com.

show lacp interface

To display information about specific Link Aggregation Control Protocol (LACP) interfaces, use the **show lacp interface** command.

show lacp interface ethernet *slot/port*

Syntax Description	<i>slot/port</i>	Slot number and port number for the interface you want to display.
---------------------------	------------------	--

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The LACP_Activity field displays whether the link is configured in the active or passive port-channel mode.

The Port Identifier field displays the port priority as part of the information. The part of the information in this field is the port number. The following example shows how to identify the port priority and the port number:

```
Port Identifier=0x8000,0x101
```

The port priority value is 0x8000, and the port number value is 0x101 in this example.

Examples

This example shows how to display the LACP statistics for a specific channel group:

```
n1000v# show lacp interface ethernet 1/1

n1000v(config-if-range)# show lacp interface eth1/1
Interface Ethernet1/1 is up
Channel group is 1 port channel is Po1
  PDUs sent: 556
  PDUs rcvd: 538
  Markers sent: 0
  Markers rcvd: 0
  Marker response sent: 0
  Marker response rcvd: 0
  Unknown packets rcvd: 0
  Illegal packets rcvd: 0
Lag Id: [ [(8000, 0-11-11-22-22-74, 0, 8000, 101), (8000, 0-11-11-22-22-75, 0, 8000, 401)] ]
```

Send document comments to nexus1k-docfeedback@cisco.com.

Operational as aggregated link since Wed Jun 11 20:37:59 2008

```

Local Port: Eth1/1   MAC Address= 0-11-11-22-22-74
  System Identifier=0x8000,0-11-11-22-22-74
  Port Identifier=0x8000,0x101
  Operational key=0
  LACP_Activity=active
  LACP_Timeout=Long Timeout (30s)
  Synchronization=IN_SYNC
  Collecting=true
  Distributing=true
  Partner information refresh timeout=Long Timeout (90s)
Actor Admin State=
Actor Oper State=
Neighbor: 4/1
  MAC Address= 0-11-11-22-22-75
  System Identifier=0x8000,0-11-11-22-22-75
  Port Identifier=0x8000,0x401
  Operational key=0
  LACP_Activity=active
  LACP_Timeout=Long Timeout (30s)
  Synchronization=IN_SYNC
  Collecting=true
  Distributing=true
Partner Admin State=
Partner Oper State=

```

Related Commands

Command	Description
show port-channel summary	Displays information about all port-channel groups.

Send document comments to nexus1k-docfeedback@cisco.com.

show lacp neighbor

To display information about Link Aggregation Control Protocol (LACP) neighbors, use the **show lacp neighbor** command.

show lacp neighbor [**interface port-channel** *channel-number*]

Syntax Description	
<i>channel-number</i>	Port-channel number for the LACP neighbor that you want to display. The range of values is from 1 to 4096.

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If you do not specify the <i>channel-number</i> , all channel groups are displayed.
------------------	---

Examples This example shows how to display the information about the LACP neighbors for a specific port channel:

```
n1000v# show lacp neighbor interface port-channel 1
Flags: S - Device is sending Slow LACPDUs F - Device is sending Fast LACPDUs
      A - Device is in Active mode      P - Device is in Passive mode
port-channell neighbors
Partner's information
Port      Partner
System ID Partner
Eth1/1    32768,0-11-11-22-22-750x401    44817    SA
LACP Partner
Port Priority Partner
32768      Oper Key
          0x0
          Partner
          Port State
          0x3d
Partner's information
Port      Partner
System ID Partner
Eth1/2    32768,0-11-11-22-22-750x402    44817    SA
LACP Partner
Port Priority Partner
32768      Oper Key
          0x0
          Partner
          Port State
          0x3d
```

■ show lacp neighbor

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show port-channel summary	Displays information about all port-channel groups.

Send document comments to nexus1k-docfeedback@cisco.com.

show lacp port-channel

To display information about Link Aggregation Control Protocol (LACP) port channels, use the **show lacp port-channel** command.

```
show lacp port-channel [interface port-channel channel-number]
```

Syntax Description	<i>channel-number</i> Port-channel number for the LACP channel group that you want to display. The range of values is from 1 to 4096.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	If you do not specify the <i>channel-number</i> , all channel groups are displayed.
-------------------------	---

Examples	This example shows how to display the information about LACP port channels:
-----------------	---

```
n1000v# show lacp port-channel

port-channel1
  Local System Identifier=0x8000,0-11-11-22-22-74
  Admin key=0x0
  Operational key=0x0
  Partner System Identifier=0x8000,0-11-11-22-22-75
  Operational key=0x0
  Max delay=0
  Aggregate or individual=1
port-channel2
  Local System Identifier=0x8000,0-11-11-22-22-74
  Admin key=0x1
  Operational key=0x1
  Partner System Identifier=0x8000,0-11-11-22-22-75
  Operational key=0x1
  Max delay=0
  Aggregate or individual=1
```

■ show lacp port-channel

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands

Command	Description
show port-channel summary	Displays information about all port-channel groups.

Send document comments to nexus1k-docfeedback@cisco.com.

show lacp system-identifier

To display the Link Aggregation Control Protocol (LACP) system identifier for the device, use the **show lacp system-identifier** command.

show lacp system-identifier

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines The LACP system ID is the combination of the configurable LACP system priority value and the MAC address.

Each system that runs LACP has an LACP system priority value. You can accept the default value of 32768 for this parameter, or you can configure a value between 1 and 65535. LACP uses the system priority with the MAC address to form the system ID and also uses the system priority during negotiation with other devices. A higher system priority value means a lower priority.

The system ID is different for each virtual device context (VDC).

Examples This example shows how to display the information about the LACP port channel for a specific port channel:

```
n1000v> show lacp system-identifier
8000,AC-12-34-56-78-90
```

Related Commands	Command	Description
	lacp system-priority	Sets the system priority for LACP.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show logging logfile

To display the contents of the log file, use the **show logging logfile** command.

show logging logfile [**start-time** *time* | **end-time** *time*]

Syntax Description	start-time	(Optional)Specify the starting time for which you want the logfile displayed.
	end-time	(Optional) Specify the ending time for which you want the logfile displayed.
	time	Specify the time as follows:
	Time	Description
	yyyy	Specify the year.
	mmm	Specify the month, for example, <i>jan, feb, mar</i> .
	dd	Specify the day of month, for example <i>01</i> .
	hh:mm:ss	Specify the hour, minutes, seconds, for example, <i>04:00:00</i> .

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to display the contents of the logfile:

```
n1000v# show logging logfile start-time 2009 Aug 23 22:00:00 end-time 2009 Aug 24 24:00:00
2009 Aug 23 22:58:00 doc-n1000v %PORTPROFILE-5-SYNC_COMPLETE: Sync completed.
2009 Aug 24 23:53:15 doc-n1000v %MODULE-5-MOD_OK: Module 3 is online (serial: )
2009 Aug 24 23:53:15 doc-n1000v %PLATFORM-5-MOD_STATUS: Module 3 current-status is MOD_S
TATUS_ONLINE/OK
n1000v#
```

Related Commands	Command	Description
	logging logfile	Configures the log file used to store system messages.

Send document comments to nexus1k-docfeedback@cisco.com.

show logging module

To display the current configuration for logging module messages to the log file, use the **show logging module** command.

show logging module

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display the configuration for logging of messages to the log file:

```
n1000v# show logging module
Logging linecard:          disabled
n1000v#
```

Related Commands	Command	Description
	logging module	Starts logging of module messages to the log file.

Send document comments to nexus1k-docfeedback@cisco.com.

show logging server

To display the current server configuration for logging system messages, use the **show logging server** command.

show logging server

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display the :

```
n1000v# show logging server
Logging server:                enabled
{172.28.254.253}
  server severity:             notifications
  server facility:             local7
  server VRF:                  management
n1000v#
```

Related Commands	Command	Description
	logging server	Designates a remote server for system message logging, and configures it.

Send document comments to nexus1k-docfeedback@cisco.com.

show logging timestamp

To display the unit of measure used in the system messages timestamp, use the **show logging timestamp** command.

show logging timestamp

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display the unit of measure used in the system messages timestamp:

```
n1000v# show logging timestamp
Logging timestamp:          Seconds
n1000v#
```

Related Commands	Command	Description
	logging timestamp	Sets the unit of measure for the system messages timestamp.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-channel compatibility-parameters

To display the parameters that must be the same among the member ports in order to join a port channel, use the **show port-channel compatibility parameters** command.

show port-channel compatibility-parameters

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines When you add an interface to a channel group, the software checks certain interface attributes to ensure that the interface is compatible with the channel group. For example, you cannot add a Layer 3 interface to a Layer 2 channel group. The software also checks a number of operational attributes for an interface before allowing that interface to participate in the port-channel aggregation.

This command displays the list of compatibility checks that the system uses.

Using the **channel-group** command, you can force ports with incompatible parameters to join the port channel as long as the following parameters are the same:

- (Link) speed capability
- Speed configuration
- Duplex capability
- Duplex configuration
- Flow-control capability
- Flow-control configuration



Note

See the **channel-group** command for information about forcing ports to join a port channel.

Examples This example shows how to display the list of compatibility checks that the system makes before an interface to a channel group:

```
n1000v# show port-channel compatibility-parameters
```


Send document comments to nexus1k-docfeedback@cisco.com.*** port mode**

Members must have the same port mode configured, either E or AUTO. If they are configured in AUTO port mode, they have to negotiate E mode when they come up. If a member negotiates a different mode, it will be suspended.

*** speed**

Members must have the same speed configured. If they are configured in AUTO speed, they have to negotiate the same speed when they come up. If a member negotiates a different speed, it will be suspended.

*** MTU**

Members have to have the same MTU configured. This only applies to ethernet port-channel.

*** MEDIUM**

Members have to have the same medium type configured. This only applies to ethernet port-channel.

*** Span mode**

Members must have the same span mode.

*** sub interfaces**

Members must not have sub-interfaces.

*** Duplex Mode**

Members must have same Duplex Mode configured.

*** Ethernet Layer**

Members must have same Ethernet Layer (switchport/no-switchport) configured.

*** Span Port**

Members cannot be SPAN ports.

*** Storm Control**

Members must have same storm-control configured.

*** Flow Control**

Members must have same flowctrl configured.

*** Capabilities**

Members must have common capabilities.

*** port**

Members port VLAN info.

*** port**

Members port does not exist.

*** switching port**

Send document comments to nexus1k-docfeedback@cisco.com.

Members must be switching port, Layer 2.

* port access VLAN

Members must have the same port access VLAN.

* port native VLAN

Members must have the same port native VLAN.

* port allowed VLAN list

Members must have the same port allowed VLAN list.

Related Commands

Command	Description
channel-group	Adds or removes interfaces to port-channel groups and assigns the port-channel mode to the interface.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-channel database

To display information about the current running of the port channels, use the **show port-channel database** command.

show port-channel database [**interface port-channel** *channel-number*]

Syntax Description

channel-number Port-channel number for the information that you want to display. The range of values is from 1 to 4096.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

If you do not specify the *channel-number*, all channel groups are displayed. This command displays Link Aggregation Control Protocol (LACP)-enabled ports channels and port channels without an associated aggregation protocol.

Examples

This example shows how to display information on the current running of all port channels:

```
n1000v# show port-channel database
port-channel5
  Administrative channel mode is active
  Operational channel mode is active
  Last membership update is successful
  1 ports in total, 0 ports up
  Age of the port-channel is 1d:16h:18m:50s
  Time since last bundle is 1d:16h:18m:56s
  Last bundled member is
  Ports:  Ethernet2/5          [down]

port-channel20
  Administrative channel mode is active
  Operational channel mode is active
  Last membership update is successful
  1 ports in total, 0 ports up
  Age of the port-channel is 1d:16h:18m:50s
  Time since last bundle is 1d:16h:18m:56s
  Last bundled member is
  Ports:  Ethernet2/20        [down]
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to display information on the current running of a specific port channel:

```
n1000v# show port-channel database interface port-channel 20
port-channel20
  Administrative channel mode is active
  Operational channel mode is active
  Last membership update is successful
  1 ports in total, 0 ports up
  Age of the port-channel is 1d:16h:23m:14s
  Time since last bundle is 1d:16h:23m:20s
  Last bundled member is
  Ports:   Ethernet2/20           [down]
```

Related Commands

Command	Description
show port-channel summary	Displays a summary of information about all port channels.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-channel load-balance

To display information about load-balancing using port channels, use the **show port-channel load-balance** command.

show port-channel load-balance [**forwarding-path interface port-channel** *channel-number*]

Syntax Description	
forwarding-path interface port-channel	(Optional) Identifies the port in the port channel that forwards the packet.
<i>channel-number</i>	Port-channel number for the load-balancing forwarding path that you want to display. The range of values is from 1 to 4096.

Defaults	
	None

Command Modes	
	Any

Supported User Roles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display information about the current port-channel load balancing for the system:

```
n1000v# show port-channel load-balance
```

```
Port Channel Load-Balancing Configuration:
System: source-dest-ip-vlan
```

```
Port Channel Load-Balancing Addresses Used Per-Protocol:
Non-IP: source-dest-mac
IP: source-dest-ip-vlan
```

Related Commands	Command	Description
	port-channel load-balance ethernet	Configures load balancing using port channels.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show port-channel rbh-distribution

To display information about the Result Bundle Hash (RBH) for port channels, use the **show port-channel rbh-distribution** command.

show port-channel rbh-distribution [**interface port-channel** *channel-number*]

Syntax Description	<i>channel-number</i>	Port-channel number for the information the you want to display. The range of values is from 1 to 4096.
---------------------------	-----------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	The RBH value ranges from 0 to 7 and is shared among port members in a port channel.
-------------------------	--

Examples This example shows how to display RBH distribution for a specific port channel:

```
n1000v# show port-channel rbh-distribution interface port-channel 4
```

ChanId	Member port	RBH values	Num of buckets
4	Eth3/13	4,5,6,7	4
4	Eth3/14	0,1,2,3	4

Related Commands	Command	Description
	port-channel summary	Displays summary information on port channels.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-channel summary

To display summary information about the port channels, use the **show port-channel summary** command.

show port-channel summary

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines If the Link Aggregation Control Protocol (LACP) is not enabled, the output shows **NONE** in the Protocol column of the display.

A channel-group interface can be in the following operational states:

- Down—The interface is down because it is administratively shut down or some other reason not related to port channels.
- Individual—The interface is part of a port channel but unable to aggregate into a port channel because of protocol exchange problems.
 - This interface continues to forward traffic as an individual link.
 - STP is aware of this interface.
- Suspended—The operational parameters of the interface are not compatible with the port channel. This interface is not forwarding traffic, although the physical MAC link state is still up.
- Switched—The interface is switched.
- Up (port channel)—The port channel is up.
- Up in port channel (members)—The port member of the port channel is up.
- Hot standby (LACP only)—The interface is eligible to join the port group if one of the interfaces currently participating in the LACP channel goes down.
 - This interface does not forward data traffic, only protocol data units (PDUs).
 - This interface does not run STP.
- Module-removed—The module has been removed.

Send document comments to nexus1k-docfeedback@cisco.com.

- Routed—The interface is routed.

Examples

This example shows how to display summary information for the port channels:

```
n1000v# show port-channel summary
Flags:  D - Down          P - Up in port-channel (members)
        I - Individual   H - Hot-standby (LACP only)
        s - Suspended    r - Module-removed
        S - Switched     R - Routed
        U - Up (port-channel)
```

```
-----
Group Port-      Type      Protocol  Member Ports
Channel
-----
5      Po5 (SD)    Eth       LACP      Eth2/5 (D)
20     Po20 (RD)   Eth       LACP      Eth2/20 (D)
```

Related Commands

Command	Description
show port-channel usage	Displays the port-channel numbers used and available.
show port-channel traffic	Displays transmitted and received unicast, multicast, and broadcast percentages for the port channels.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-channel traffic

To display traffic statistics for port channels, use the **show port-channel traffic** command.

show port-channel traffic [**interface port-channel** *channel-number*]

Syntax Description	<i>channel-number</i> Port-channel number for the traffic statistics that you want to display. The range of values is from 1 to 4096.
---------------------------	---

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines This command displays the percentage of transmitted and received unicast, multicast, and broadcast traffic on the port channel.

If you do not specify the *channel-number*, information for all port channels is displayed.

Examples This example shows how to display the traffic statistics for all port channels:

```
n1000v(config)# show port-channel traffic
ChanId      Port  Rx-Ucst Tx-Ucst Rx-Mcst Tx-Mcst Rx-Bcst Tx-Bcst
-----
      5   Eth2/5   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
-----
     20  Eth2/20   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
```

This example shows how to display the traffic statistics for a specific port channel:

```
n1000v(config)# show port-channel traffic interface port-channel 5
ChanId      Port  Rx-Ucst Tx-Ucst Rx-Mcst Tx-Mcst Rx-Bcst Tx-Bcst
-----
      5   Eth2/5   0.0%   0.0%   0.0%   0.0%   0.0%   0.0%
```

Related Commands	Command	Description
	port-channel summary	Displays summary information about port channels.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-channel usage

To display the port-channel numbers used and available, use the **show port-channel usage** command.

show port-channel usage

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines This command displays port-channel numbers used and available in the virtual device context (VDC) that you are monitoring.

The number of port-channel numbers available across all VDCs for the entire system is from 1 to 4096.

Examples This example shows how to display the usage for all port channels:

```
n1000v# show port-channel usage
Totally 2 port-channel numbers used
=====
Used   :   5 , 20
Unused:   1 - 4 , 6 - 19 , 21 - 4096
n1000v#
```

Related Commands	Command	Description
	port-channel summary	Displays summary information about port channels.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-security address

To display information about all secure MAC-addresses in the system, use the **show port-security address** command.

show port-security address *interface-id*

Syntax Description	
interface vethernet	(Optional) Limits the secure MAC address information to a specific vEthernet interface.
interface ethernet	(Optional) Limits the secure MAC address information to a specific Ethernet interface.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to use the **show port-security address** command to view information about all MAC addresses in the system:

```
n1000v# show port-security address
Total Secured Mac Addresses in System (excluding one mac per port) : 0
Max Addresses limit in System (excluding one mac per port) : 8192
-----
Secure Mac Address Table
-----
Vlan Mac Address Type Ports Remaining Age
(mins)
-----
1 0054.AAB3.770F STATIC port-channell 0
1 00EE.378A.ABCE STATIC Ethernet1/4 0
=====
n1000v#
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to use the **show port-security address** command to view the MAC addresses secured by the port security feature on the Ethernet 1/4 interface:

```
n1000v# show port-security address interface ethernet 1/4
Secure Mac Address Table
-----
Vlan Mac Address Type Ports Remaining Age
(mins)
-----
1 00EE.378A.ABCE STATIC Ethernet1/4 0
-----
n1000v#
```

This example shows how to use the **show port-security address** command to view the MAC addresses secured by the port security feature on the vethernet1 interface:

```
n1000v# show port-security address interface vethernet 1
Total Secured Mac Addresses in System (excluding one mac per port) : 0
Max Addresses limit in System (excluding one mac per port) : 8192
-----
Secure Mac Address Table
-----
Vlan Mac Address Type Ports Remaining age
(mins)
-----
65 0050.56B7.7DE2 DYNAMIC Vethernet1 0
=====
n1000v#
```

Related Commands

Command	Description
clear port-security	Clears dynamically learned, secure MAC addresses.
switchport port-security	Enables port security on a Layer 2 interface.
show port-security	Shows information about port security.
show port-security interface	Displays information about secure interfaces.
show running-config port-security	Displays port-security configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

show port-security interface

To display information about the secure interfaces on the system, use the **show port-security interface** command.

show port-security interface *interface-id*

Syntax Description	<i>interface-id</i>	Interface ID.
--------------------	---------------------	---------------

Defaults	None
----------	------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin network-operator
--------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

This example shows how to use the **show port-security interface** command to view the status of the port security feature on the Ethernet 1/4 interface:

```
n1000v# show port-security interface ethernet 1/4
Port Security : Enabled
Port Status : Secure Down
Violation Mode : Shutdown
Aging Time : 0 mins
Aging Type : Absolute
Maximum MAC Addresses : 5
Total MAC Addresses : 1
Configured MAC Addresses : 1
Sticky MAC Addresses : 0
Security violation count : 0
n1000v#
```

Related Commands	Command	Description
	clear port-security	Clears dynamically learned, secure MAC addresses.
	switchport port-security	Enables port security on a Layer 2 interface.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
show port-security	Shows information about port security.
show port-security address	Displays secure MAC addresses of the interfaces.
show running-config port-security	Displays port-security configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

show running-config interface port-channel

To display the running configuration for a specific port channel, use the **show running-config interface port-channel** command.

```
show running-config interface port-channel {channel-number}
```

Syntax Description

channel-number Number of the port-channel group. The range of values is from 1 to 4096.

Defaults

None

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples

The following example shows how to display the running configuration for port channel 10:

```
n1000v(config)# show running-config interface port-channel 10
version 4.0(4)SV1(1)

interface port-channel10
  switchport
  switchport mode trunk
```

Related Commands

Command	Description
show port-channel summary	Displays a summary of port-channel information.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

show running-config vlan

To display the running configuration for a specified VLAN, use the **show running-config vlan** command.

show running-config vlan *vlan-id*

Syntax Description	<i>vlan-id</i>	VLAN ID number or range of VLANs. Valid VLAN IDs are 1-4094 or ranges are 1-5, 10 or 2-5, 7-19.
--------------------	----------------	---

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how display the running configuration for VLAN100:

```
n1000v(config)# show running-config vlan 100
version 4.2(1)SV1(4)
vlan 100
n1000v(config)#
```

Related Commands	Command	Description
	show vlan	Displays VLAN information.
	vlan	Creates a VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

show system error-id

To display detailed information on system error codes, use the **show system error-id** command.

```
show system error-id {list | error-code}
```

Syntax Description	list	Displays brief information for all the system error messages.
	<i>error-code</i>	Displays description about a specific error code.

Defaults	None
----------	------

Command Modes	Any
---------------	-----

Supported User Roles	network-admin network-operator
----------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display detailed information about error code 0x401e0008:

```
n1000v# show system error-id 0x401e0008
Error Facility: sysmgr
Error Description: request was aborted, standby disk may be full
n1000v#
```

Related Commands	Command	Description
	show system vem feature level	Displays the current software release supported.
	show system redundancy status	Displays the system redundancy status.
	system vlan	Adds the system VLAN to this port profile.
	show system resources	Displays the system resources.

■ show system error-id

Send document comments to nexus1k-docfeedback@cisco.com.



T Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter T.

tacacs-server deadtime

To set a periodic time interval where a nonreachable (nonresponsive) TACACS+ server is monitored for responsiveness, use the **tacacs-server deadtime** command. To disable the monitoring of the nonresponsive TACACS+ server, use the **no** form of this command.

tacacs-server deadtime *minutes*

no tacacs-server deadtime *minutes*

Syntax Description	<i>time</i>	Specifies the time interval in minutes. The range is from 1 to 1440.
Defaults	0 minutes	
Command Modes	Global Configuration (config)	
SupportedUserRoles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Setting the time interval to zero disables the timer. If the dead-time interval for an individual TACACS+ server is greater than zero (0), that value takes precedence over the value set for the server group.

When the dead-time interval is 0 minutes, TACACS+ server monitoring is not performed unless the TACACS+ server is part of a server group and the dead-time interval for the group is greater than 0 minutes.

Send document comments to nexus1k-docfeedback@cisco.com.

In Global Configuration mode, you must first enable the TACACS+ feature, using the **tacacs+ enable** command, before you can use any of the other TACACS+ commands to configure the feature.

Examples

This example shows how to configure the dead-time interval and enable periodic monitoring:

```
n1000v# config terminal
n1000v(config)# tacacs-server deadtime 10
```

This example shows how to revert to the default dead-time interval and disable periodic monitoring:

```
n1000v# config terminal
n1000v(config)# no tacacs-server deadtime 10
```

Related Commands

Command	Description
deadtime	Sets a dead-time interval for monitoring a nonresponsive TACACS+ server.
show tacacs-server	Displays TACACS+ server information.
tacacs+ enable	Enables TACACS+.

Send document comments to nexus1k-docfeedback@cisco.com.

tacacs-server directed-request

To allow users to send authentication requests to a specific TACACS+ server when logging in, use the **radius-server directed request** command. To revert to the default, use the **no** form of this command.

tacacs-server directed-request

no tacacs-server directed-request

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines In Global Configuration mode, you must first enable the TACACS+ feature, using the **tacacs+ enable** command, before you can use any of the other TACACS+ commands to configure the feature.

The user can specify the *username@vrfname:hostname* during login, where *vrfname* is the virtual routing and forwarding (VRF) name to use and *hostname* is the name of a configured TACACS+ server. The username is sent to the server name for authentication.



Note If you enable the directed-request option, the NX-OS device uses only the RADIUS method for authentication and not the default local method.

Examples This example shows how to allow users to send authentication requests to a specific TACACS+ server when logging in:

```
n1000v# config t
n1000v(config)# tacacs-server directed-request
```

This example shows how to disallow users to send authentication requests to a specific TACACS+ server when logging in:

```
n1000v# config t
n1000v(config)# no tacacs-server directed-request
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show tacacs-server directed request	Displays a directed request TACACS+ server configuration.
	tacacs+ enable	Enables TACACS+.

Send document comments to nexus1k-docfeedback@cisco.com.

tacacs-server host

To configure TACACS+ server host parameters, use the **tacacs-server host** command in configuration mode. To revert to the defaults, use the **no** form of this command.

```
tacacs-server host {hostname | ipv4-address | ipv6-address}
  [key [0 | 7] shared-secret] [port port-number]
  [test {idle-time time | password password | username name}]
  [timeout seconds]
```

```
no tacacs-server host {hostname | ipv4-address | ipv6-address}
  [key [0 | 7] shared-secret] [port port-number]
  [test {idle-time time | password password | username name}]
  [timeout seconds]
```

Syntax Description

<i>hostname</i>	TACACS+ server Domain Name Server (DNS) name. The name is alphanumeric, case sensitive, and has a maximum of 256 characters.
<i>ipv4-address</i>	TACACS+ server IPv4 address in the <i>A.B.C.D</i> format.
<i>ipv6-address</i>	TACACS+ server IPv6 address in the <i>X:X:X::X</i> format.
key	(Optional) Configures the TACACS+ server's shared secret key.
0	(Optional) Configures a preshared key specified in clear text (indicated by 0) to authenticate communication between the TACACS+ client and server. This is the default.
7	(Optional) Configures a preshared key specified in encrypted text (indicated by 7) to authenticate communication between the TACACS+ client and server.
<i>shared-secret</i>	Preshared key to authenticate communication between the TACACS+ client and server. The preshared key is alphanumeric, case sensitive, and has a maximum of 63 characters.
port <i>port-number</i>	(Optional) Configures a TACACS+ server port for authentication. The range is from 1 to 65535.
test	(Optional) Configures parameters to send test packets to the TACACS+ server.
idle-time <i>time</i>	(Optional) Specifies the time interval (in minutes) for monitoring the server. The time range is 1 to 1440 minutes.
password <i>password</i>	(Optional) Specifies a user password in the test packets. The password is alphanumeric, case sensitive, and has a maximum of 32 characters.
username <i>name</i>	(Optional) Specifies a user name in the test packets. The username is alphanumeric, case sensitive, and has a maximum of 32 characters.
timeout <i>seconds</i>	(Optional) Configures a TACACS+ server timeout period (in seconds) between retransmissions to the TACACS+ server. The range is from 1 to 60 seconds.

Defaults

Parameter	Default
Idle-time	disabled

Send document comments to nexus1k-docfeedback@cisco.com.

Server monitoring	disabled
Timeout	1 seconds
Test username	test
Test password	test

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You must use the **tacacs+ enable** command before you configure TACACS+.
When the idle time interval is 0 minutes, periodic TACACS+ server monitoring is not performed.

Examples This example shows how to configure TACACS+ server host parameters:

```
n1000v# config terminal
n1000v(config)# tacacs-server host 10.10.2.3 key HostKey
n1000v(config)# tacacs-server host tacacs2 key 0 abcd
n1000v(config)# tacacs-server host tacacs3 key 7 1234
n1000v(config)# tacacs-server host 10.10.2.3 test idle-time 10
n1000v(config)# tacacs-server host 10.10.2.3 test username tester
n1000v(config)# tacacs-server host 10.10.2.3 test password 2B9ka5
```

Related Commands	Command	Description
	show tacacs-server	Displays TACACS+ server information.
	tacacs+ enable	Enables TACACS+.

Send document comments to nexus1k-docfeedback@cisco.com.

tacacs-server key

To configure a global TACACS+ shared secret key, use the **tacacs-server key** command. To removed a configured shared secret, use the **no** form of this command.

tacacs-server key [0 | 7] *shared-secret*

no tacacs-server key [0 | 7] *shared-secret*

Syntax Description		
	0	(Optional) Configures a preshared key specified in clear text to authenticate communication between the TACACS+ client and server. This is the default.
	7	(Optional) Configures a preshared key specified in encrypted text to authenticate communication between the TACACS+ client and server.
	<i>shared-secret</i>	Preshared key to authenticate communication between the TACACS+ client and server. The preshared key is alphanumeric, case sensitive, and has a maximum of 63 characters.

Defaults None

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You must configure the TACACS+ preshared key to authenticate the device on the TACACS+ server. The length of the key is restricted to 63 characters and can include any printable ASCII characters (white spaces are not allowed). You can configure a global key to be used for all TACACS+ server configurations on the device. You can override this global key assignment by using the **key** keyword in the **tacacs-server host** command.

You must use the **tacacs+ enable** command before you configure TACACS+.

Examples The following example shows how to configure TACACS+ server shared keys:

```
n1000v# config terminal
n1000v(config)# tacacs-server key AnyWord
n1000v(config)# tacacs-server key 0 AnyWord
n1000v(config)# tacacs-server key 7 public
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show tacacs-server	Displays TACACS+ server information.
	tacacs+ enable	Enables TACACS+.

Send document comments to nexus1k-docfeedback@cisco.com.

tacacs-server timeout

To specify the time between retransmissions to the TACACS+ servers, use the **tacacs-server timeout** command. To revert to the default, use the **no** form of this command.

tacacs-server timeout *seconds*

no tacacs-server timeout *seconds*

Syntax Description	<i>seconds</i>	Seconds between retransmissions to the TACACS+ server. The range is from 1 to 60 seconds.
---------------------------	----------------	---

Defaults	5 seconds
-----------------	-----------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	You must use the tacacs+ enable command before you configure TACACS+.
-------------------------	--

Examples This example shows how to configure the TACACS+ server timeout value:

```
n1000v# config terminal
n1000v(config)# tacacs-server timeout 3
```

This example shows how to revert to the default TACACS+ server timeout value:

```
n1000v# config terminal
n1000v(config)# no tacacs-server timeout 3
```

Related Commands	Command	Description
	show tacacs-server	Displays TACACS+ server information.
	tacacs+ enable	Enables TACACS+.

Send document comments to nexus1k-docfeedback@cisco.com.

tail

To display the last lines of a file, use the **tail** command.

```
tail [filesystem:[//module/]][directory/]filename lines
```

Syntax Description		
<i>filesystem:</i>	(Optional) Name of a file system. The name is case sensitive.	
<i>//module/</i>	(Optional) Identifier for a supervisor module. Valid values are sup-active , sup-local , sup-remote , or sup-standby . The identifiers are case sensitive.	
<i>directory/</i>	(Optional) Name of a directory. The name is case sensitive.	
<i>filename</i>	Name of the command file. The name is case sensitive.	
<i>lines</i>	(Optional) Number of lines to display. The range is from 0 to 80.	

Defaults	
10 lines	

Command Modes	
Any	

SupportedUserRoles	
network-admin	

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to display the last 10 lines of a file:

```
n1000v# tail bootflash:startup.cfg
ip arp inspection filter marp vlan 9
ip dhcp snooping vlan 13
ip arp inspection vlan 13
ip dhcp snooping
ip arp inspection validate src-mac dst-mac ip
ip source binding 10.3.2.2 0f00.60b3.2333 vlan 13 interface Ethernet2/46
ip source binding 10.2.2.2 0060.3454.4555 vlan 100 interface Ethernet2/10
logging level dhcp_snoop 6
logging level eth_port_channel 6
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to display the last 20 lines of a file:

```
n1000v# tail bootflash:startup.cfg 20
area 99 virtual-link 1.2.3.4
router rip Enterprise
router rip foo
    address-family ipv4 unicast
router bgp 33.33
event manager applet sctest
monitor session 1
monitor session 2
ip dhcp snooping vlan 1
ip arp inspection vlan 1
ip arp inspection filter marp vlan 9
ip dhcp snooping vlan 13
ip arp inspection vlan 13
ip dhcp snooping
ip arp inspection validate src-mac dst-mac ip
ip source binding 10.3.2.2 0f00.60b3.2333 vlan 13 interface Ethernet2/46
ip source binding 10.2.2.2 0060.3454.4555 vlan 100 interface Ethernet2/10
logging level dhcp_snoop 6
logging level eth_port_channel 6
```

Related Commands

Command	Description
cd	Changes the current working directory.
copy	Copies files.
dir	Displays the directory contents.
pwd	Displays the name of the current working directory.

Send document comments to nexus1k-docfeedback@cisco.com.

telnet

To create a Telnet session, use the **telnet** command.

```
telnet {ipv4-address | hostname} [port-number] [vrf vrf-name]
```

Syntax Description		
<i>ipv4-address</i>		IPv4 address of the remote device.
<i>hostname</i>		Hostname of the remote device. The name is alphanumeric, case sensitive, and has a maximum of 64 characters.
<i>port-number</i>		(Optional) Port number for the Telnet session. The range is from 1 to 65535.
vrf <i>vrf-name</i>		(Optional) Specifies the virtual routing and forwarding (VRF) name to use for the Telnet session. The name is case sensitive.

Defaults	
	Port 23
	Default VRF

Command Modes	
	Any

Supported User Roles	
	network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
	To use this command, you must enable the Telnet server using the telnet server enable command.

Examples This example shows how to start a Telnet session using an IPv4 address:

```
n1000v# telnet 10.10.1.1 vrf management
```

Related Commands	Command	Description
	clear line	Clears Telnet sessions.
	telnet server enable	Enables the Telnet server.

Send document comments to nexus1k-docfeedback@cisco.com.

telnet server enable

To enable the Telnet server, use the **telnet server enable** command. To disable the Telnet server, use the **no** form of this command.

telnet server enable

no telnet server enable

Syntax Description This command has no arguments or keywords.

Defaults Enabled

Command Modes Global Configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to enable the Telnet server:

```
n1000v# config t
n1000v(config)# telnet server enable
```

This example shows how to disable the Telnet server:

```
n1000v# config t
n1000v(config)# no telnet server enable
XML interface to system may become unavailable since ssh is disabled
```

Related Commands	Command	Description
	show telnet server	Displays the Telnet server configuration.
	telnet	Creates a Telnet session.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

template data timeout

To designate a timeout period for resending NetFlow template data, use the **template data timeout** command. To remove the timeout period, use the **no** form of this command.

template data timeout *time*

no template data timeout

Syntax Description	<i>time</i> A time period between 1 and 86400 seconds.
---------------------------	--

Defaults	None
-----------------	------

Command Modes	Netflow Flow Exporter Version 9 Configuration (config-flow-exporter-version-9)
----------------------	---

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
-------------------------	--

Examples	This example shows how to configure a 3600-second timeout period for resending NetFlow flow exporter template data:
-----------------	---

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# template data timeout 3600
```

This example shows how to remove the timeout period for resending NetFlow flow exporter template data:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# no template data timeout
n1000v(config-flow-exporter)#
```

Related Commands	Command	Description
	version 9	Designates NetFlow export version 9 in the NetFlow exporter.
	flow exporter	Creates a Flexible NetFlow flow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
option exporter-stats timeout	Specifies a timeout resend period for NetFlow flow exporter data.
option interface-table timeout	Specifies a timeout resend period for the NetFlow flow exporter interface table.
flow record	Creates a Flexible NetFlow flow record.
flow monitor	Creates a Flexible NetFlow flow monitor.
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

terminal event-manager bypass

To bypass the CLI event manager, use the **terminal event-manager bypass** command.

terminal event-manager bypass

Syntax Description This command has no arguments or keywords.

Defaults Event manager is enabled.

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to disable the CLI event manager:

```
n1000v# terminal event-manager bypass
n1000v#
```

Related Commands	Command	Description
	show terminal	Displays terminal configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

terminal length

To set the number of lines that appear on the screen, use the **terminal length** command.

terminal length *number*

Syntax Description	<i>number</i>	Number of lines. The range of valid values is 0 to 511.
--------------------	---------------	---

Defaults	28 lines
----------	----------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin network-operator
--------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Set <i>number</i> to 0 to disable pausing.
------------------	--

Examples	This example shows how to set the number of lines that appear on the screen:
----------	--

```
n1000v# terminal length 60
n1000v#
```

Related Commands	Command	Description
	show terminal	Displays the terminal configuration.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

terminal session-timeout

To set session timeout, use the **terminal session-timeout** command.

terminal session-timeout *time*

Syntax Description	<i>time</i>	Timeout time, in seconds. The range of valid values is 0 to 525600.
--------------------	-------------	---

Defaults	None
----------	------

Command Modes	Any
---------------	-----

SupportedUserRoles	network-admin network-operator
--------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	Set <i>time</i> to 0 to disable timeout.
------------------	--

Examples	This example shows how to set session timeout:
----------	--

```
n1000v# terminal session-timeout 100
n1000v#
```

Related Commands	Command	Description
	show terminal	Displays the terminal configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

terminal terminal-type

To specify the terminal type, use the **terminal terminal-type** command.

terminal terminal-type *type*

Syntax Description	<i>type</i> Terminal type.
---------------------------	----------------------------

Defaults	None
-----------------	------

Command Modes	Any
----------------------	-----

SupportedUserRoles	network-admin network-operator
---------------------------	-----------------------------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples	This example shows how to specify the terminal type:
-----------------	--

```
n1000v# terminal terminal-type vt100
n1000v#
```

Related Commands	Command	Description
	show terminal	Displays the terminal configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

terminal tree-update

To update the main parse tree, use the **terminal tree-update** command.

terminal tree-update

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples This example shows how to update the main parse tree:

```
n1000v# terminal tree-update
n1000v#
```

Related Commands	Command	Description
	show terminal	Displays the terminal configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

terminal width

To set terminal width, use the **terminal width** command.

terminal width *number*

Syntax Description	<i>number</i>	Number of characters on a single line. The range of valid values is 24 to 511.
Defaults	102 columns	
Command Modes	Any	
Supported User Roles	network-admin network-operator	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Examples	This example shows how to set terminal width: n1000v# terminal width 60 n1000v#	
Related Commands	Command	Description
	show terminal	Displays the terminal configuration.

Send document comments to nexus1k-docfeedback@cisco.com.

test aaa

To test for AAA on a RADIUS server or server group, use the **test aaa** command.

```
test aaa {group group-name user-name password | server radius address {user-name password |  
vrf vrf-name user-name password}}
```

Syntax	Description
group	Specifies an AAA server group.
<i>group-name</i>	AAA server group name. The range of valid values is 1 to 32.
<i>user-name</i>	User name. The range of valid values is 1 to 32.
<i>password</i>	User password. The range of valid values is 1 to 32.
server	Specifies an AAA server.
radius	Specifies a RADIUS server.
<i>address</i>	IP address or DNS name.
vrf	Specifies a virtual route.
<i>vrf-name</i>	Virtual route.name.

Defaults	Value
Defaults	None

Command Modes	Value
Command Modes	Any

Supported User Roles	Value
Supported User Roles	network-admin network-operator

Command History	Release	Modification
Command History	4.0(4)SV1(1)	This command was introduced.

Examples	Description
Examples	This example shows how to test for AAA on RADIUS server:

```
n1000v# test aaa server radius ts1 vrf route1 user1 9w8e7r  
n1000v#
```

Related Commands	Command	Description
Related Commands	show aaa	Displays AAA information.

Send document comments to nexus1k-docfeedback@cisco.com.

traceroute

To discover the routes that packets take when traveling to an IPv4 address, use the **traceroute** command.

```
traceroute {dest-ipv4-addr | hostname} [vrf vrf-name] [show-mpls-hops] [source src-ipv4-addr]
```

Syntax	Description
<i>dest-ipv4-addr</i>	IPv4 address of the destination device. The format is <i>A.B.C.D</i> .
<i>hostname</i>	Name of the destination device. The name is case sensitive.
vrf <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) to use. The name is case sensitive.
show-mpls-hops	(Optional) Displays the Multiprotocol Label Switching (MPLS) hops.
source <i>src-ipv4-addr</i>	(Optional) Specifies a source IPv4 address. The format is <i>A.B.C.D</i> .

Defaults

Uses the default VRF.
Does not show the MPLS hops.
Uses the management IPv4 address for the source address.

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

To use IPv6 addressing for discovering the route to a device, use the **traceroute6** command.

Examples

This example shows how to discover a route to a device:

```
n1000v# traceroute 172.28.255.18 vrf management
traceroute to 172.28.255.18 (172.28.255.18), 30 hops max, 40 byte packets
 1 172.28.230.1 (172.28.230.1) 0.746 ms 0.595 ms 0.479 ms
 2 172.24.114.213 (172.24.114.213) 0.592 ms 0.51 ms 0.486 ms
 3 172.20.147.50 (172.20.147.50) 0.701 ms 0.58 ms 0.486 ms
 4 172.28.255.18 (172.28.255.18) 0.495 ms 0.43 ms 0.482 ms
```

Related Commands

Command	Description
traceroute6	Discovers the route to a device using IPv6 addressing.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

transport udp (NetFlow)

To add a destination UDP port from the NetFlow exporter to the collector, use the **transport udp** command. To remove the port, use the **no** form of this command.

transport udp *portnumber*

no transport udp

Syntax Description	<i>portnumber</i> Destination UDP number from 1 to 65535.														
Defaults	None														
Command Modes	Netflow Flow Exporter Configuration (config-flow-exporter)														
Supported User Roles	network-admin														
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(4)SV1(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(4)SV1(1)	This command was introduced.										
Release	Modification														
4.0(4)SV1(1)	This command was introduced.														
Usage Guidelines	Avoid using well-known ports 1-1024 when possible.														
Examples	<p>This example shows how to add UDP 200 to the flow exporter:</p> <pre>n1000v(config)# flow exporter ExportTest n1000v(config-flow-exporter)# transport udp 200</pre> <p>This example shows how to remove UDP 200 from the flow exporter:</p> <pre>n1000v(config)# flow exporter ExportTest n1000v(config-flow-exporter)# no transport udp 200</pre>														
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>flow exporter</td> <td>Creates a Flexible NetFlow flow exporter.</td> </tr> <tr> <td>flow record</td> <td>Creates a Flexible NetFlow flow record.</td> </tr> <tr> <td>flow monitor</td> <td>Creates a Flexible NetFlow flow monitor.</td> </tr> <tr> <td>show flow exporter</td> <td>Displays information about the NetFlow flow exporter.</td> </tr> <tr> <td>show flow record</td> <td>Displays information about NetFlow flow records.</td> </tr> <tr> <td>show flow monitor</td> <td>Displays information about the NetFlow flow monitor.</td> </tr> </tbody> </table>	Command	Description	flow exporter	Creates a Flexible NetFlow flow exporter.	flow record	Creates a Flexible NetFlow flow record.	flow monitor	Creates a Flexible NetFlow flow monitor.	show flow exporter	Displays information about the NetFlow flow exporter.	show flow record	Displays information about NetFlow flow records.	show flow monitor	Displays information about the NetFlow flow monitor.
Command	Description														
flow exporter	Creates a Flexible NetFlow flow exporter.														
flow record	Creates a Flexible NetFlow flow record.														
flow monitor	Creates a Flexible NetFlow flow monitor.														
show flow exporter	Displays information about the NetFlow flow exporter.														
show flow record	Displays information about NetFlow flow records.														
show flow monitor	Displays information about the NetFlow flow monitor.														



U Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter U.

username

To create and configure a user account, use the **username** command. To remove a user account, use the **no** form of this command.

username *user-id* [**expire** *date*] [**password** [**0** | **5**] *password*] [**role** *role-name*]

username *user-id* [**sshkey** {*key* | **file** *filename*}]

no username *user-id*

Syntax Description

<i>user-id</i>	User identifier for the user account. The <i>user-id</i> argument is a case-sensitive, alphanumeric character string with a maximum length of 28 characters. Note The NX-OS software does not allowed the “#” and “@” characters in the <i>user-id</i> argument text string.
expire <i>date</i>	(Optional) Specifies the expire date for the user account. The format for the <i>date</i> argument is YYYY-MM-DD.
password	(Optional) Specifies a password for the account. The default is no password.
0	(Optional) Specifies that the password is in clear text. Clear text passwords are encrypted before they are saved to the running configuration.
5	(Optional) Specifies that the password is in encrypted format. Encrypted passwords are not changed before they are saved to the running configuration.
<i>password</i>	Password string. The password is alphanumeric, case sensitive, and has a maximum of 64 characters. Note Clear text passwords cannot include the dollar sign (\$) special character.
role <i>role-name</i>	(Optional) Specifies the user role. The <i>role-name</i> argument is case sensitive.
sshkey	(Optional) Specifies an SSH key for the user account.

Send document comments to nexus1k-docfeedback@cisco.com.

<i>key</i>	SSH key string.
file <i>filename</i>	Specifies the name of a file that contains the SSH key string.

Defaults

Unless specified, usernames have is no expire date, password, or SSH key.

The default role is the admin user role.

You cannot delete the default admin user role. Also, you cannot change the expire date or remove the network-admin role for the default admin user role.

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

The NX-OS software accepts only strong passwords when you have password-strength checking enabled using the **password strength-check** command. The characteristics of a strong password include the following:

- At least eight characters long
- Does not contain many consecutive characters (such as “abcd”)
- Does not contain many repeating characters (such as “aaabbb”)
- Does not contain dictionary words
- Does not contain proper names
- Contains both uppercase and lowercase characters
- Contains numbers



Caution

If you do not specify a password for the user account, the user might not be able to log in to the account.

Examples

This example shows how to create a user account with a password and a user role:

```
n1000v# config t
n1000v(config)# username user1 password Ci5co321 role network-admin
```

This example shows how to configure the SSH key for a user account:

```
n1000v# config t
n1000v(config)# username user1 sshkey file bootflash:key_file
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	password strength-check	Checks the password security strength.
	show user-account	Displays the user account configuration.

Send document comments to nexus1k-docfeedback@cisco.com.



V Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter V.

vem

To configure a Virtual Ethernet Module (VEM) and enter VEM slot configuration mode, use the **vem** command. To remove a VEM configuration, use the **no** form of this command.

vem *module-number* [- *module-number*]

no vem *module-number* [- *module-number*]

Syntax Description

<i>module-number</i>	Specifies a module number. The range of valid values is 3 to 66.
----------------------	--

Defaults

None

Command Modes

Global Configuration (config)

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Specify a range of VEMs by using a dash. For example, 3-9 or 20-30.

Examples

This example shows how to create a VEM and enter the VEM slot configuration mode:

```
n1000v# configure terminal
n1000v(config)# vem 10
```

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v(config-vem-slot)#
```

This example shows how to remove a VEM:

```
n1000v# configure terminal  
n1000v(config)# no vem 10  
n1000v(config)#
```

Related Commands

Command	Description
show module vem	Displays information about the VEM module.

Send document comments to nexus1k-docfeedback@cisco.com.

version 9

To designate NetFlow export version 9 in the NetFlow exporter, use the **version 9** command. To remove version 9, use the **no version 9** form of this command.

version 9

no version 9

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes NetFlow flow exporter (config-flow-exporter)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples This example shows how to configure version 9 for a Netflow flow exporter:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)#
```

This example shows how to remove version 9 from the Netflow flow exporter:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# no version 9
n1000v(config-flow-exporter)#
```

Related Commands	Command	Description
	option exporter-stats timeout	Specifies a timeout resend period for NetFlow flow exporter data.
	option interface-table timeout	Specifies a timeout resend period for the NetFlow flow exporter interface table.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
template data timeout	Specifies a timeout resend period for NetFlow flow exporter template data.
flow exporter	Creates a Flexible NetFlow flow exporter.
flow record	Creates a Flexible NetFlow flow record.
flow monitor	Creates a Flexible NetFlow flow monitor.
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

vlan

To create a VLAN and enter the VLAN configuration mode, use the **vlan** command. To remove a VLAN, use the **no** form of this command.

```
vlan {id | dot1Q tag native}
```

```
no vlan {id | dot1Q tag native}
```

Syntax	Description
<i>id</i>	VLAN identification number. The range of valid values is 1 to 4094.
dot1Q tag native	Specifies an IEEE 802.1Q virtual LAN.

Defaults The default VLAN is VLAN 1.

Command Modes Global Configuration (config)

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines Specify a VLAN range by using a dash. For example, 1-9 or 20-30.

Examples This example shows how to create a VLAN and enter the VLAN configuration mode:

```
n1000v# configure terminal
n1000v(config)# vlan 10
n1000v(config-vlan)#
```

This example shows how to remove a VLAN:

```
n1000v# configure terminal
n1000v(config)# no vlan 10
n1000v(config)#
```

Related Commands	Command	Description
	show vlan	Displays VTP VLAN status.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

vmware dvs datacenter-name

To create a VMware virtual switch, use the **vmware dvs datacenter-name** command. To remove the virtual switch, use the **no** form of this command.

vmware dvs datacenter-name *name*

no vmware dvs

Syntax Description	<i>name</i> Switch name.						
Defaults	None						
Command Modes	SVS connection configuration (config-svs-conn)						
SupportedUserRoles	network-admin						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(4)SV1(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(4)SV1(1)	This command was introduced.		
Release	Modification						
4.0(4)SV1(1)	This command was introduced.						
Usage Guidelines	To create a virtual switch, you must be in the SVS connection configuration mode. Use the svs connection command to create a connection and enter that mode. The number of SVS connections that can be created is limited to one.						
Examples	<p>This example shows how to create a VMware virtual switch:</p> <pre>n1000v# configure terminal n1000v(config)# svs connect s1 n1000v(config-svs-conn)# vmware dvs datacenter-name dc1 n1000v(config-svs-conn)#</pre> <p>This example shows how to remove a VMware virtual switch:</p> <pre>n1000v# configure terminal n1000v(config)# svs connect s1v n1000v(config-svs-conn)# no vmware dvs datacenter-name dc1 n1000v(config-svs-conn)#</pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show svs</td> <td>Displays SVS information.</td> </tr> <tr> <td>show vmware</td> <td>Displays VMware information.</td> </tr> </tbody> </table>	Command	Description	show svs	Displays SVS information.	show vmware	Displays VMware information.
Command	Description						
show svs	Displays SVS information.						
show vmware	Displays VMware information.						

Send document comments to nexus1k-docfeedback@cisco.com.

vmware max-ports

To create the maximum number of ports for the VMware port profile, use the **vmware max-ports** command. To remove the maximum port configuration, use the **no** form of this command.

vmware max-ports *number*

no vmware max-ports *number*

Syntax Description	<i>number</i>	Specifies the maximum number of ports. The range of valid values is 1 to 1024.
Defaults	32 ports	
Command Modes	Port profile configuration (config-port-prof)	
SupportedUserRoles	network-admin	
Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.
Usage Guidelines	To specify the maximum number of VMware ports to configure, you must be in port profile configuration mode.	
Examples	<p>This example shows how to set the maximum number of VMware ports in a port profile:</p> <pre>n1000v# configure terminal n1000v(config)# port-profile testprofile n1000v(config-port-prof)# vmware max-ports 100 n1000v(config-port-prof)#</pre> <p>This example shows how to remove the maximum VMware ports configuration:</p> <pre>n1000v# configure terminal n1000v(config)# port-profile testprofile n1000v(config-port-prof)# no vmware max-ports 100 n1000v(config-port-prof)#</pre>	
Related Commands	Command	Description
	show port-profile name	Displays configuration information about a particular port-profile.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

vmware port-group

To create a VMware port group, use the **vmware port-group** command. To remove the VMware port group, use the **no** form of this command.

vmware port-group *name*

no vmware port-group *name*

Syntax Description	<i>name</i>	Specifies the name of the VMware port group.
--------------------	-------------	--

Defaults	None
----------	------

Command Modes	Port profile configuration (config-port-prof)
---------------	---

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	To create the VMware port group, you must be in port profile configuration mode.
------------------	--

Examples	This example shows how to create a VMware port group:
----------	---

```
n1000v# configure terminal
n1000v(config)# port-profile testprofile
n1000v(config-port-prof)# vmware port-group testgroup
n1000v(config-port-prof)#
```

This example shows how to remove the VMware port group:

```
n1000v# configure terminal
n1000v(config)# port-profile testprofile
n1000v(config-port-prof)# no vmware port-group testgoup
n1000v(config-port-prof)#
```

Related Commands	Command	Description
	show port-profile name	Displays configuration information about a particular port-profile.

Send document comments to nexus1k-docfeedback@cisco.com.

vmware vc extension-key

To create an extension key, use the **vmware vc extension-key** command.

vmware vc extension-key *key*

Syntax Description	<i>key</i> Extension key number. The range of valid values is 1 to 80.				
Defaults	The key does not exist.				
Command Modes	Global Configuration (config)				
SupportedUserRoles	network-admin				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(4)SV1(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(4)SV1(1)	This command was introduced.
Release	Modification				
4.0(4)SV1(1)	This command was introduced.				
Usage Guidelines	An extension key is used to connect to an instance of Virtual Center.				
Examples	<p>This example shows how to create an extension key:</p> <pre>n1000v# configure terminal n1000v(config)# vmware vc extension-key 10 n1000v(config)#</pre>				
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show vmware vc extension-key</td> <td>Displays extension key information.</td> </tr> </tbody> </table>	Command	Description	show vmware vc extension-key	Displays extension key information.
Command	Description				
show vmware vc extension-key	Displays extension key information.				

Send document comments to nexus1k-docfeedback@cisco.com.



W Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter W.

where

To display your current context in the command-line interface (CLI), use the **where** command.

where [**detail**]

Syntax Description

detail	(Optional) Displays detailed context information.
---------------	---

Defaults

Displays summary context information.

Command Modes

Any

Supported User Roles

network-admin

Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

This command helps you to keep track where you are in the CLI and how you got to that place.

Examples

This example shows how to display summary context information:

```
n1000v(config-if)# where  
?conf; interface Ethernet2/3      admin@switch%default
```

Send document comments to nexus1k-docfeedback@cisco.com.

This example shows how to display detailed context information:

```
n1000v(config-if)# where detail
?conf; interface Ethernet2/3      admin@switch%default
mode:                             conf
                                   interface Ethernet2/3
username:                          admin
vdc:                                switch
routing-context vrf: default
```

Send document comments to nexus1k-docfeedback@cisco.com.

write erase

To erase configurations in persistent memory areas, use the **write erase** command.

write erase [boot | debug]

Syntax	Description
boot	(Optional) Erases only the boot variable and mgmt0 interface configuration.
debug	(Optional) Erases only the debug configuration.

Defaults Erases all configuration in persistent memory except for the boot variable, mgmt0 interface, and debug configuration.

Command Modes Any

Supported User Roles network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines You can use this command to erase the startup configuration in the persistent memory when information is corrupted or otherwise unusable. Erasing the startup configuration returns the device to its initial state, except for the boot variable, mgmt0 interface, and debug configurations. You have to explicitly erase those configurations with the **boot** and **debug** options.

Examples This example shows how to erase the startup configuration:

```
n1000v(config)# write erase
Warning: This command will erase the startup-configuration.
Do you wish to proceed anyway? (y/n) [n] y
```

This example shows how to erase the boot variable and mgmt0 interface configuration in the persistent memory:

```
n1000v(config)# write erase boot
```

This example shows how to erase the debug configuration in the persistent memory:

```
n1000v(config)# write erase debug
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	copy running-config startup-config	Copies the running configuration to the startup configuration.
	show running-config	Displays the startup configuration.