



## **Segment Routing Command Reference for Cisco 8000 Series Routers**

**First Published:** 2020-03-13

**Last Modified:** 2024-01-31

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## CONTENTS

---

### PREFACE

#### **Preface** vii

Changes to This Document vii

Communications, Services, and Additional Information vii

---

### CHAPTER 1

#### **Segment Routing Commands** 1

adjacency-sid 3

bgp best-path sr-policy 4

clear segment-routing local-block discrepancy all 5

distribute link-state (IS-IS) 6

fast-reroute 7

hw-module profile segment-routing srv6 mode 9

isis prefix-attributes n-flag-clear 11

l2-adjacency sid 12

microloop avoidance rib-update-delay 13

microloop avoidance segment-routing 15

performance-measurement interface 16

performance-measurement liveness-detection 17

performance-measurement liveness-profile 19

performance-measurement delay-profile 21

performance-measurement protocol twamp-light measurement delay 24

ping mpls nil-fec labels 26

ping sr-mpls 28

prefix-sid 30

prefix-unreachable 32

partition-detect 34

summary-prefix 35

segment-routing bundle-member-adj-sid 37

segment-routing global-block 38

segment-routing local-block 40

segment-routing mapping-server 42

segment-routing mpls 44

segment-routing prefix-sid-map advertise-local 45

segment-routing prefix-sid-map receive disable 47

show isis segment-routing prefix-sid-map 49

show mrrib nsf private 51

show ospf route flex-algo 53

show ospf segment-routing prefix-sid-map 59

show performance-measurement history 61

show segment-routing srv6 sid 64

show segment-routing local-block inconsistencies 65

show segment-routing mapping-server prefix-sid-map 66

traceroute mpls nil-fec labels 68

traceroute sr-mpls 70

---

CHAPTER 2

**Segment Routing Traffic Engineering Commands 73**

affinity-map 74

autoroute include ipv6 all 75

bgp prefix-path-label ignore 76

binding-sid 77

distribute link-state (SRTE) 78

distribute link-state 79

hw-module profile cef sropt enable 80

kshortest-paths 82

neighbor sr-policy name targeted 83

on-demand constraints 84

on-demand dynamic affinity sid-algorithm 85

on-demand dynamic affinity disjoint-path 86

on-demand maximum-sid-depth 88

on-demand source-address 89

on-demand steering 90

policy binding-sid	91
policy candidate-paths	92
policy candidate-paths constraints disjoint-path	93
policy candidate-paths constraints resources	95
policy color	96
policy source-address	97
policy steering	98
resource-list	99
segment-list	100
separate-next-hop	101
steering labeled-services	102
te-latency	103

---

**CHAPTER 3****SRv6 Traffic Engineering 105**

accounting prefixes ipv6 mode	106
policy srv6 locator	107
segment-routing traffic-eng srv6	108
srv6 locator	109
srv6 maximum-sid-depth	110
segment-lists segment-list	111
segment-lists srv6	112





## Preface

This guide consists of information regarding the commands for Segment Routing in Cisco IOS XR Software. The *Cisco 8000 Series Router Segment Routing Command Reference Guide* preface contains these sections:

- [Changes to This Document, on page vii](#)
- [Communications, Services, and Additional Information, on page vii](#)

## Changes to This Document

This table lists the changes made to this document since it was first printed.

Date	Change Summary
January 2024	Republished for Cisco IOS XR Release 7.3.6.
August 2023	Republished for Cisco IOS XR Release 7.3.5.
October 2020	Republished for Cisco IOS XR Release 7.2.12.
August 2020	Republished with documentation updates for Cisco IOS XR Release 7.0.14.
March 2020	Initial release of this document

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### **Cisco Bug Search Tool**

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.





# Segment Routing Commands

This chapter describes the commands used to configure and use Segment Routing.

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

- [adjacency-sid](#), on page 3
- [bgp best-path sr-policy](#), on page 4
- [clear segment-routing local-block discrepancy all](#), on page 5
- [distribute link-state \(IS-IS\)](#), on page 6
- [fast-reroute](#), on page 7
- [hw-module profile segment-routing srv6 mode](#), on page 9
- [isis prefix-attributes n-flag-clear](#), on page 11
- [l2-adjacency sid](#), on page 12
- [microloop avoidance rib-update-delay](#), on page 13
- [microloop avoidance segment-routing](#), on page 15
- [performance-measurement interface](#), on page 16
- [performance-measurement liveness-detection](#), on page 17
- [performance-measurement liveness-profile](#), on page 19
- [performance-measurement delay-profile](#), on page 21
- [performance-measurement protocol twamp-light measurement delay](#), on page 24
- [ping mpls nil-fec labels](#), on page 26
- [ping sr-mpls](#), on page 28
- [prefix-sid](#), on page 30
- [prefix-unreachable](#), on page 32
- [partition-detect](#), on page 34
- [summary-prefix](#), on page 35
- [segment-routing bundle-member-adj-sid](#), on page 37
- [segment-routing global-block](#), on page 38
- [segment-routing local-block](#), on page 40
- [segment-routing mapping-server](#), on page 42
- [segment-routing mpls](#), on page 44
- [segment-routing prefix-sid-map advertise-local](#), on page 45
- [segment-routing prefix-sid-map receive disable](#), on page 47
- [show isis segment-routing prefix-sid-map](#), on page 49

- [show mrib nsf private](#), on page 51
- [show ospf route flex-algo](#), on page 53
- [show ospf segment-routing prefix-sid-map](#), on page 59
- [show performance-measurement history](#), on page 61
- [show segment-routing srv6 sid](#), on page 64
- [show segment-routing local-block inconsistencies](#), on page 65
- [show segment-routing mapping-server prefix-sid-map](#), on page 66
- [traceroute mpls nil-fec labels](#), on page 68
- [traceroute sr-mpls](#), on page 70

# adjacency-sid

To manually allocate an adjacency segment ID (Adj-SID) on an interface, use the **adjacency-sid** command in IS-IS interface address family configuration mode. To remove the Adj-SID, use the **no** form of the command.

**adjacency-sid** {**index** *adj-sid-index* | **absolute** *adj-sid-value*} [**protected**]

Syntax Description	
<b>index</b> <i>adj-sid-index</i>	Specifies the Adj-SID for each link based on the lower boundary of the SRLB + the index.
<b>absolute</b> <i>adj-sid-value</i>	Specifies the specific Adj-SID for each link within the SRLB.
<b>protected</b>	Specify if the Adj-SID is protected. For each primary path, if the Adj-SID is protected on the primary interface and a backup path is available, a backup path is installed. By default, manual Adj-SIDs are not protected.

**Command Default** Adjacency SID is not protected.

**Command Modes** IS-IS interface address-family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Segment routing must be configured on the IS-IS instance before configuring adjacency SID value. Manually allocated Adj-SIDs are supported on point-to-point (P2P) interfaces.

Task ID	Task ID	Operations
	isis	read, write

## Examples

This example shows how to configure an Adj-SID.

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# router isis 100
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet0/0/0/7
RP/0/RSP0/CPU0:router(config-isis-if)# point-to-point
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# adjacency-sid index 10
```

Related Commands	Command	Description
	<a href="#">segment-routing local-block, on page 40</a>	Configures the segment routing local block (SRLB).

# bgp best-path sr-policy

To select the best path, backup, or multipath resolving over nexthop using SR policies, use the **bgp best-path sr-policy** command in BGP configuration mode. To remove the configuration, use the **no** form of the command.

**bgp best-path sr-policy** { **force** | **prefer** }

## Syntax Description

**force** When force mode is enabled, only SR policy paths are considered for best path calculation.

**prefer** When prefer mode is enabled, SR policy paths and eBGP non-color paths are eligible for best path calculation.

## Command Default

None.

## Command Modes

BGP configuration mode

## Command History

Release	Modification
Release 7.5.2	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Example

The following example shows how to enable the force mode:

```
Router(config)#router bgp 100
Router(config-bgp)#bgp router-id 10.1.1.2
Router(config-bgp)#bgp best-path sr-policy force
```

# clear segment-routing local-block discrepancy all

Clears segment routing local block (SRLB) label conflicts.

**clear segment-routing local-block discrepancy all**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** When you define a new SRLB range, there might be a label conflict (for example, if labels are already allocated, statically or dynamically, in the new SRLB range). In this case, the new SRLB range will be accepted, but not applied (pending). The previous SRLB range (active) will continue to be in use until one of the following occurs:

- Reload the router to release the currently allocated labels and allocate the new SRLB
- Use the **clear segment-routing local-block discrepancy all** command to clear the label conflicts

Task ID	Task	Operation
		ID

This example shows how to clear SRLB label conflicts.

```
RP/0/RSP0/CPU0:router(config)# clear segment-routing local-block discrepancy all
```

Related Commands	Command	Description
	<a href="#">show segment-routing local-block inconsistencies, on page 65</a>	
<a href="#">segment-routing local-block, on page 40</a>		Configures the SRLB

# distribute link-state (IS-IS)

To configure filters for IS-IS advertisements to BGP-LS, use the **distribute link-state** command in the IS-IS configuration mode.

**distribute link-state** [ **exclude-external** **exclude-interarea** **route-policy** *name* ]

*Table 1: Syntax Description:*

Syntax	Description
<b>exclude-external</b>	Set filter to exclude information for external prefixes and specify a route-policy name to filter based on a set of destination prefixes.
<b>exclude-interarea</b>	Set filter to exclude information for interarea prefixes and specify a route-policy name to filter based on a set of destination prefixes.
<b>route-policy</b> <i>name</i>	Distribute prefixes based on the route policy name set.

**Command Modes** IS-IS Configuration

## Command History

Release	Modification
Release 7.10.1	New keywords were introduced under <b>distribute link-state</b> .

## Example

This example shows how to configure different filters for IS-IS advertisements to BGP-LS:

```
Router#config
Router(config)#router isis 1
Router(config-isis)#distribute link-state exclude-external
Router(config-isis)#commit
```

```
Router#config
Router(config)#router isis 1
Router(config-isis)#distribute link-state exclude-interarea
Router(config-isis)#commit
```

```
Router# config
Router(config)# router isis 1
Router(config-isis)#distribute link-state route-policy isis-rp-1
Router(config-isis)#commit
```

# fast-reroute

To enable Topology Independent Loop Free Alternate (TI-LFA) path using the IP Fast Reroute (FRR) mechanism, use the **fast-reroute** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

## fast-reroute per-prefix ti-lfa

Syntax Description	per-prefix	Specifies an alternate path for every prefix on the specified interface.
	ti-lfa	Enables link-protecting TI-LFA.

Command Default	FRR is disabled. Link protection is disabled.
-----------------	--

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** When a protected link used by the fast-reroutable label switched path (LSP) fails, the traffic is rerouted to a previously assigned backup tunnel. Configuring FRR on the tunnel informs all the nodes that the LSP is traversing that this LSP desires link/bandwidth protection.

You must verify the redundancy is ready after an RP switchover before triggering FRR on standby RP to synchronize with the active RP (verified using the **show redundancy** command). All TE tunnels must be in the recovered state and the database must be in the ready state for all ingress and egress line cards. To verify this information, use the **show mpls traffic-eng tunnels** and **show mpls traffic-eng fast-reroute database** commands.



**Note** We recommend that you wait approximately 60 seconds before triggering FRR after verifying the database state.

If the priority associated with the specified tiebreaker is higher than any other tiebreakers, then the specified post-convergence backup path will be selected, if it is available.

Task ID	Task ID	Operations
	isis	read, write
	ospf	

## Examples

The following example shows how to enable FRR on an interface:

```
RP/0/RSP0/CPU0:R1(config)# router isis 1  
RP/0/RSP0/CPU0:R1(config-isis)# interface TenGigE0/0/0/2/1  
RP/0/RSP0/CPU0:R1(config-isis-if)# point-to-point  
RP/0/RSP0/CPU0:R1(config-isis-if)# address-family ipv4 unicast  
RP/0/RSP0/CPU0:R1(config-isis-if)# fast-reroute per-prefix  
RP/0/RSP0/CPU0:R1(config-isis-if)# fast-reroute per-prefix ti-lfa  
RP/0/RSP0/CPU0:R1(config-isis-if)# exit
```



# hw-module profile segment-routing srv6 mode

To enable Segment Routing over IPv6, use the **hw-module profile segment-routing srv6** command in XR Config mode.



**Note** Use the mandatory keyword **mode** from release 7.7.1 onwards.

```
hw-module profile segment-routing srv6 mode [ { base f1 } | { micro-segment format f3216 } | [ { path-mtu } ] ]
```

<b>Syntax Description</b>	<p><b>Mode</b> Defines the SRV6 format that are supported:</p> <ul style="list-style-type: none"> <li>• Base: f1 (represents the base format 1).</li> <li>• Micro-segment format: f3216 (represents the format 3216, which is 32-bit block and 16-bit IDs).</li> </ul> <p><b>path-mtu</b> Enables Path MTU Discovery over Ingress, Egress, and P or Transit nodes (with IPv6 role).</p>
---------------------------	---

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR Config

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.1.1	The <b>path-mtu</b> keyword was introduced.
	Release 7.7.1	<b>Mode</b> keyword is mandatory from release 7.7.1 onwards.
	Release 6.6.1	This command was introduced.

**Usage Guidelines** Use the mandatory keyword **mode** from release 7.7.1 onwards.  
Do not use the keyword **mode** prior to release 7.7.1.  
The router must be reloaded for the **hw-module profile segment-routing srv6** feature to be functional.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	system	read, write

## Example

The following example shows how to enable Segment Routing over IPv6 for micro-segment format, from release 7.7.1 onwards:

```
Router(config)# hw-module profile segment-routing srv6 mode base f1
Router(config-srv6)# encapsulation
Router(config-srv6-encap)# l2-traffic
Router(config-srv6-encap-l2)# traffic-class propagate
In order to activate/deactivate this srv6 profile, you must manually reload the chassis/all
line cards
```

The following example shows how to enable Segment Routing over IPv6 for base, from release 7.7.1 onwards:

```
Router(config)# hw-module profile segment-routing srv6 mode micro-segment format f3216
Router(config-srv6)# encapsulation
Router(config-srv6-encap)# l3-traffic
Router(config-srv6-encap-l3)# traffic-class policy-map
In order to activate/deactivate this srv6 profile, you must manually reload the chassis/all
line cards
```

The following example shows how to enable Segment Routing over IPv6, prior to release 7.7.1:

```
Router# configure
Router(config)# hw-module profile segment-routing srv6
```

# isis prefix-attributes n-flag-clear

To set the N-flag in the Prefix Attribute Flags sub-TLV to 0, use the **isis prefix-attributes n-flag-clear** command.

**isis prefix-attributes n-flag-clear** [level-1 | level-2]

## Syntax Description

**level-1** Clears the N-flag for level-1.

**level-2** Clears the N-flag for level-2.

## Command Default

The N-flag is set to 1 for host prefixes (/32 for IPv4 and /128 for IPv6).

## Command Modes

Interface configuration

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

The Prefix Attributes Flag sub Type Length Value (TLV) supports the advertisement of attribute flags associated with prefix advertisements. By default, the N-flag is set by IS-IS when advertising a SID that is associated with a loopback address. The advertising router may choose to not set this flag. When the N-flag is cleared, the N-flag is set to 0 in the Prefix Attribute Flags sub-TLV.

Prefix attributes are only added when wide metric is used.

## Task ID

Task ID	Operation

This example shows how to clear the N-flag:

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# interface loopback0
RP/0/RSP0/CPU0:router(config-if)# isis prefix-attributes n-flag-clear
```

## I2-adjacency sid

To manually configure a Layer 2 adjacency segment ID (Adj-SID) on an interface, use the **I2-adjacency sid** in adjacency SID interface address-family configuration mode. To remove the Layer 2 Adj-SID, use the **no** form of this command.

**I2-adjacency sid** {**index** *adj-SID-index* | **absolute** *adj-SID-value*} [**next-hop** *ipv4\_address*]

Syntax Description	
<b>index</b> <i>adj-SID-index</i>	Specifies the Adj-SID for each link based on the lower boundary of the SRLB + the index.
<b>absolute</b> <i>adj-SID-value</i>	Specifies the specific Adj-SID for each link within the SRLB.
<b>next-hop</b> <i>ipv4_address</i>	(Optional) Specifies the next-hop neighbor IPv4 address.

**Command Default** None

**Command Modes** Adjacency SID interface address-family

Command History	Release	Modification
	Release 7.0.14	This command was introduced.

**Usage Guidelines**

For point-to-point interfaces, you are not required to specify a next-hop. However, if you do specify the next-hop, the Layer 2 Adj-SID will be used only if the specified next-hop matches the neighbor address.

For LAN interfaces, you must configure the next-hop IPv4 address. If you do not configure the next-hop, the Layer 2 Adj-SID will not be used for LAN interface.

Task ID	Task ID	Operation

### Example

This example shows how to configure a Layer 2 Adj-SID on an interface:

```
RP/0/RP0/CPU0:ios(config)# segment-routing
RP/0/RP0/CPU0:ios(config-sr)# adjacency-sid
RP/0/RP0/CPU0:ios(config-sr-adj)# interface gigabitEthernet 0/0/0/3
RP/0/RP0/CPU0:ios(config-sr-adj-intf)# address-family ipv4 unicast
RP/0/RP0/CPU0:ios(config-sr-adj-intf-af)# I2-adjacency-sid index 300 next-hop 1.1.1.4
```

# microloop avoidance rib-update-delay

To set the Routing Information Base (RIB) update delay value to avoid microloops in the network, use the **microloop avoidance rib-update-delay** command. To disable the RIB update delay, use the **no** form of this command.

**microloop avoidance rib-update-delay** *delay-time*

<b>Syntax Description</b>	<i>delay-time</i> Specifies the amount of time the node uses the microloop avoidance policy before updating its forwarding table. The <i>delay-time</i> is in milliseconds. The range is from 1-60000.						
<b>Command Default</b>	The default value is 5000 milliseconds.						
<b>Command Modes</b>	IPv4 address family configuration Router configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	Use this command with the <b>microloop avoidance segment-routing</b> command to specify how long the path to the destination is used. After the RIB update delay timer expires, the path is replaced with regular forwarding paths.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>ospf</td> <td>read, write</td> </tr> <tr> <td>isis</td> <td></td> </tr> </tbody> </table>	Task ID	Operation	ospf	read, write	isis	
Task ID	Operation						
ospf	read, write						
isis							

## Example

This example shows how to set the Routing Information Base (RIB) update delay value for OSPF:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router ospf 1
RP/0/RSP0/CPU0:router(config-ospf)# microloop avoidance segment-routing
RP/0/RSP0/CPU0:router(config-ospf)# microloop avoidance rib-update-delay 3000
```

This example shows how to set the Routing Information Base (RIB) update delay value for IS-IS:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router isis 1
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# microloop avoidance segment-routing
```

```
RP/0/RSP0/CPU0:router(config-isis-af)# microloop avoidance rib-update-delay 3000
```

# microloop avoidance segment-routing

To enable the segment routing microloop avoidance and set the Routing Information Base (RIB) update delay value, use the **microloop avoidance** command. To disable segment routing microloop avoidance, use the **no** form of this command.

## microloop avoidance segment-routing

### Command Default

Disabled.

### Command Modes

IPv4 address family configuration  
Router configuration

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

The Segment Routing Microloop Avoidance feature detects if microloops are possible following a topology change. If a node computes that a microloop could occur on the new topology, the node creates a loop-free path to the destination using a list of segments. After the RIB update delay timer expires, the path is replaced with regular forwarding paths.

### Task ID

Task ID	Operation
ospf	read,
isis	write

### Example

This example shows how to enable Segment Routing Microloop Avoidance for OSPF:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router ospf 1
RP/0/RSP0/CPU0:router(config-ospf)# microloop avoidance segment-routing
RP/0/RSP0/CPU0:router(config-ospf)# microloop avoidance rib-update-delay 3000
```

This example shows how to enable Segment Routing Microloop Avoidance for IS-IS:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router isis 1
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# microloop avoidance segment-routing
RP/0/RSP0/CPU0:router(config-isis-af)# microloop avoidance rib-update-delay 3000
```

# performance-measurement interface

This command helps you configure the target interface with probe packets that transit Interface ID and timestamp templates within a network.

```
performance-measurement interface GigE 0/1/0/1
{ path-tracing { { interface-id {1-4095} | timestamp template {st0 / st1 / st2 / st3} } } }
```

Syntax Description	path-tracing	Enables path-tracing for the interface for tracing short timestamp, interface-id and interface load on source, midpoint and sink nodes in PT probes.
	<b>interface-id</b>	Enter interface ID that is between 1-4095.  Default value is none. Interface ID value 0 is used internally to indicate PT is disabled on the interface.
	<b>Timestamp template</b> {st0 / st1 / st2 / st3}	Enter the Timestamp template you want to configure.  You can apply global template type for short timestamp to st1 to overwrite the default value.

Command Default	Path tracing is disabled by default.  The default value for Interface ID is set to None.  The default value for timestamp template is set to st2.
-----------------	---

Command Modes	XR Config
---------------	-----------

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Usage Guidelines	Enable path-tracing for the interface for tracing short timestamp, interface-id and interface load on source, midpoint and sink nodes in PT probes.
------------------	---

Examples	This example shows how to configure Path Tracing midpoint with InterfaceID and time-stamp:
----------	--

```
Router(config)# performance-measurement
Router(config-pm)# interface FourHundredGigE0/0/0/1
Router(config-pm-interf)# path-tracing
Router(config-pm-interf-interf-id)# interface-id 200
Router(config-pm-interf-time)# timestamp template st3
Router(config-pm-interf-time)# exit
```



# performance-measurement liveness-detection

To apply an SR performance measurement liveness profile to an SR-TE or an SRv6-TE policy, use the **performance-measurement liveness-detection** command in the SR-TE policy configuration mode. To disassociate the profile from the SR-TE policy, use the **no** form of the command.

```
performance-measurement liveness-detection [{ liveness-profile [backup] name profile |
validation-cp minimum-active segment-lists [{ 1-128 | all } ] }
```

Syntax Description	
<b>liveness-profile</b> [backup] <b>name</b> <i>profile</i>	(Optional) Specifies the liveness profile that is to be associated with the SR-TE policy.  The <b>name</b> <i>profile</i> command form specifies the liveness profile, and the <b>backup name</b> <i>profile</i> command form specifies the backup liveness profile.
<b>validation-cp</b> <b>minimum-active</b>	(Optional) Validates the activeness of the candidate-path based on minimum number of active segment-lists.
<b>segment-lists</b>	Indicates the number of active segment-lists.
<i>1-128</i>   <b>all</b>	<ul style="list-style-type: none"> <li>• 1-128: Indicates the minimum number of segment-lists to have the PM liveness session up.</li> <li>• all: Indicates that all the segment-lists should be active to have the PM liveness session up.</li> </ul>

**Command Default** The Default performance measurement liveness profile is associated with an SR-TE policy.

**Command Modes** SR-TE policy configuration (config-sr-te-policy)  
On-Demand SR-TE policy configuration (config-sr-te-color)

Command History	Release	Modification
	Release 7.11.1	The validation-cp minimum-active segment-lists option was introduced.
	Release 7.4.2	The <b>backup</b> keyword was added to the command.
	Release 7.3.1	This command was introduced.

**Usage Guidelines** Path protection policies do not fully support PCE reporting of the standby LSP.

## Example

This example shows how to associate a liveness profile to an SR-TE policy:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#policy TRST2
Router(config-sr-te-policy)#color 40 end-point ipv4 20.20.20.20
Router(config-sr-te-policy)#performance-measurement liveness-detection liveness-profile
name profile3
```

```

Router(config)#segment-routing traffic-eng
Router(config-sr-te)#on-demand color 30
Router(config-sr-te-color)#performance-measurement liveness-detection liveness-profile name
profile3
Router(config-sr-te-color)#commit

```

This example shows how to associate a backup liveness profile to an SR-TE policy:

```

RP/0/RSP0/CPU0:ios# configure
RP/0/RSP0/CPU0:ios(config)#segment-routing traffic-eng
RP/0/RSP0/CPU0:ios(config-sr-te)#policy foo
RP/0/RSP0/CPU0:ios(config-sr-te-policy)# color 10 end-point ipv4 192.168.0.3
RP/0/RSP0/CPU0:ios(config-sr-te-policy)# performance-measurement
RP/0/RSP0/CPU0:ios(config-sr-te-policy-perf-meas)# liveness-detection
RP/0/RSP0/CPU0:ios(config-sr-te-policy-live-detect)# liveness-profile name profile-WORKING

RP/0/RSP0/CPU0:ios(config-sr-te-policy-live-detect)# liveness-profile backup name
profile-PROTECT
RP/0/RSP0/CPU0:ios(config-sr-te-policy-live-detect)# commit

```

This example shows how to activate two segment-lists to have the PM liveness session up:

```

Router(config)#segment-routing
Router(config-sr)#traffic-eng
Router(config-sr-te)#policy po-103
Router(config-sr-te-policy)#performance-measurement
Router(config-sr-te-policy-perf-meas)#liveness-detection
Router(config-sr-te-policy-live-detect)#validation-cp minimum-active segment-lists 2

```

# performance-measurement liveness-profile

To create a unique Segment Routing performance measurement liveness profile, use the **performance-measurement liveness-profile** command in global configuration mode. To remove the profile, use the **no** form of the command.

```
performance-measurement liveness-profile [{ name [ name npu-offload enable ] | probe
flow-label [{ explicit | from }]]
```

*Table 2: Syntax Description*

Syntax	Description
<b>name</b> <i>name</i>	Specifies the Segment Routing performance measurement liveness profile name.
<b>npu-offload</b>	Enables performance measurement liveness hardware (NPU) offload feature in the SR
<b>probe</b>	Enter the liveness detection probe sub mode.
<b>flow-label</b>	Indicates the flow labels associated with SRv6 header.
<b>explicit   from</b>	Specify explicit flow label values or enter a range of flow labels that you want to configure. You can configure flow labels in the 0 to 1048575 range.

**Command Default** No user created performance measurement liveness profile exists.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Release 7.11.1	This command was introduced on Cisco 8011-2X2XP4L PLE Service Endpoint Router.
	Release 7.11.1	The <b>flow-label</b> keyword was introduced.

**Usage Guidelines** The **performance-measurement** command is also available in SR-TE specific configuration.

## Example

This example shows how to create a unique Segment Routing performance measurement liveness profile:

```
Router(config)# performance-measurement liveness-profile name profile1
Router(config)# commit
```

This example shows how to configure flow labels in the SRv6 header:

```
Router#configure
Router(config)#performance-measurement
```

```
Router(config-perf-meas)#liveness-profile name profile-sweeping
Router(config-pm-ld-profile)# flow-label from 0 to 1000000 increment 12345
Routerconfig-pm-ld-profile)#commit
```

This example shows how to configure a range of flow labels in the SRv6 header:

```
Router#configure
Router(config)#performance-measurement
Router(config-perf-meas)#liveness-profile name name1
Router(config-pm-ld-profile)# probe flow-label from 0 to 1000000 increment 10
Routerconfig-pm-ld-profile)#commit
```

This example shows how to explicitly configure flow labels in the SRv6 header:

```
Router#configure
Router(config)#performance-measurement
Router(config-perf-meas)#liveness-profile name name1
Router(config-pm-ld-profile)# probe flow-label explicit 100 200 300 400 500
Routerconfig-pm-ld-profile)#commit
```

# performance-measurement delay-profile

To create a unique Segment Routing performance measurement delay profile, use the **performance-measurement delay-profile** command in global configuration mode.

```
performance-measurement delay-profile { sr-policy default } { endpoint default } { interface default }
{ { name string name } advertisement { anomaly-loss } { anomaly-check } upper-bound <1-99>
lower-bound <number lower than the upper bound (0-98)>
```



**Note** Synthetic Loss Measurement is an inbuilt feature of delay measurement. To get the packet loss information for delay-measurement sessions, you only need to configure the delay sessions. No additional configuration is required for Synthetic Loss Measurement.

## Syntax Description

<b>name</b> <i>string name</i>	(Optional) Specifies the Segment Routing performance measurement delay profile name.
<b>sr-policy default</b>	(Optional) Specifies the Segment Routing performance measurement default sr-policy name.
<b>endpoint default</b>	(Optional) Specifies the Segment Routing performance measurement default endpoint name.
<b>interface default</b>	(Optional) Specifies the Segment Routing performance measurement default interface.
<b>advertisement</b>	Specifies the Segment Routing performance measurement advertisement you want to configure.
<b>anomaly-check</b>	(optional) It checks the delay metrics, for example if the min delay changes exceed the configured threshold, it advertises ANOM-MIN-DYN; if you configured the anomaly-check and the static delay, and the configured static delay exceed the threshold, it advertises ANOM-MIN-STA.

You can configure the anomaly loss with **upper-bound** and **lower-bound** values.

- **upper-bound** specifies the upper limit for the anomaly check. It must be between 2-200000
- **lower-bound** specifies the lower limit for the anomaly check. It must be between 1-199999 and lower than the **upper-bound** value.

**anomaly-loss** (optional) Once the packet loss exceed the configured threshold, it advertises ANOM-PKT-LOSS.

You can configure the anomaly loss with **upper-bound** and **lower-bound** values.

- **upper-bound** specifies the upper limit for the anomaly loss. It must be between 1-99
- **lower-bound** specifies the lower limit for the anomaly loss. It must be between 0-98 and lower than the **upper-bound** value.

If both **anomaly-check** and **anomaly-loss** are triggered, then it advertises for anomaly-check, because it has a higher priority than anomaly-loss

- min delay changes = current min delay - previous min delay
- packet loss = (expected packet number - received packet number) / expect packet number \* 100%

**Command Default** No user created performance measurement delay profile exists.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Release 24.1.1	This command was introduced.

Task ID	Task ID	Operation
	performance-measurement	write/read

**Usage Guidelines** The **performance-measurement** command is also available in SR-TE specific configuration.

### Example

This example shows how to create a unique Segment Routing performance measurement delay profile:

```
Router(config)# performance-measurement delay-profile sr-policy name profile1
Router(config)# commit
```

This example shows the example of anomaly-loss:

```
Router(config)#performance-measurement
Router(config-perf-meas)#delay-profile sr-policy default
Router(config-pm-dm-srpolicy)#advertisement
Router(config-pm-dm-srpolicy-adv)#anomaly-loss
Router(config-pm-dm-srpolicy-adv-anom-loss)#upper-bound 30 lower-bound 20
Router(config-pm-dm-srpolicy-adv-anom-loss)#commit
```

This example shows the example of anomaly-check:

```
Router(config)#performance-measurement
```

```
Router(config-perf-meas)#delay-profile sr-policy default
Router(config-pm-dm-srpolicy)#advertisement
Router(config-pm-dm-srpolicy-adv)#anomaly-check
Router(config-pm-dm-srpolicy-adv-anom-loss)#upper-bound 2000 lower-bound 20
Router(config-pm-dm-srpolicy-adv-anom-loss)#commit
```

# performance-measurement protocol twamp-light measurement delay

To configure the querier or responder nodes to accept packets from specific IP addresses on the network, use the **performance-measurement protocol twamp-light measurement delay** command in the global configuration mode. To remove the IP addresses, use the **no** form of the command.

```
performance-measurement protocol twamp-light measurement delay { querier allow
responder address { ipv4 | ipv6 } | responder allow querier address { ipv4 | ipv6 } |
unauthenticated { ipv4 | ipv6 | querier-dst-port | querier-src-port } }
```

Syntax Description		
<b>querier</b>	Enter the querier submode to configure the IP addresses on a querier node.	
<b>responder</b>	Enter the responder submode to configure the IP address on a responder node.	
<b>allow responder</b>	Specifies the allowed responder address on the querier node. The configuration is applicable to delay measurement sessions.	
<b>allow querier</b>	Specifies the allowed querier addresses on the responder node. The configuration is applicable to delay measurement sessions.	
<b>address</b>	Specifies the querier or responder IP addresses that are configured.	
<b>{ ipv4   ipv6 }</b>	Configure the allowed querier or responder ipv4 or ipv6 addresses. You can specify the prefix for the IP addresses.	
<b>unauthenticated</b>	Enter the unauthenticated submode to configure the IP address timestamp or the source and destination UDP ports.	
<b>ipv4   ipv6</b>	Configure the timestamp for ipv4 or ipv6 addresses.	
<b>querier-dst-port</b>	Configure the UDP port to process queries. By default, the TWAMP reserved UDP destination port is 862.	
<b>querier-src-port</b>	UDP port on Route Processor used as source port in queries.	
<b>Command Default</b>	None.	
<b>Command Modes</b>	Global Configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.11.1	The <b>querier</b> and <b>responder</b> keywords were introduced.
	Release 7.0.1	This command was introduced.



---

**Usage Guidelines** None.

This example shows how to configure the IP address of a querier on a responder node for delay measurement.

```
Router#configure
Router (config) #performance-measurement
Router (config-perf-meas) #protocol twamp-light
Router (config-pm-protocol) #measurement delay
Router (config-pm-proto-meas) #responder
Router (config-pm-proto-responder) #allow-querier
Router (config-pm-allowed-querier) #address ipv4 10.10.10.1
Router (config-sr-te-color) #commit
```

# ping mpls nil-fec labels

To check network connectivity and identify LSP breakages, use the **ping mpls nil-fec labels** command.

```
ping mpls nil-fec labels {label[,label...]} [output {interface tx-interface} [nexthop
next-hop-ip-address]]
```

Syntax Description	Labels	Description
<b>labels</b> <i>label,label...</i>		Specifies the label stack. Use commas to separate the each <i>label</i> .
<b>output interface</b> <i>tx-interface</i>		Specifies the output interface.
<b>nexthop</b> <i>next-hop-ip-address</i>		(Optional) Causes packets to go through the specified next-hop address.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task	Operation
	mpls-te	read, write

## Example

This example shows how to check connectivity for a known label stack using a specific output interface and next-hop address:

```
RP/0/RSP0/CPU0:router# ping mpls nil-fec labels 16005,16007 output interface GigabitEthernet
0/2/0/1 nexthop 10.1.1.4 repeat 1
Sending 1, 72-byte MPLS Echos with Nil FEC labels 16005,16007,
timeout is 2 seconds, send interval is 0 msec:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no label entry,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'd' - see DDMAP for return code,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
!  
Success rate is 100 percent (1/1), round-trip min/avg/max = 1/1/1 ms  
Total Time Elapsed 0 ms
```

**Related Commands**

Command	Description
<a href="#">traceroute mpls nil-fec labels, on page 68</a>	Checks network connectivity and identifying LSP breakages.

## ping sr-mpls

To check the connectivity of the segment routing control plane, use the **ping sr-mpls** command in XR EXEC mode mode.

```
ping sr-mpls { ipv4-address/mask | ipv6-address/mask [ fec-type { bgp | generic | igp {
ospf | isis } } ] | nil-fec | dataplane-only { labels { label1 [ , label2... ] ipv4-address/mask
| ipv6-address/mask | policy } } { output { interface interface-path-id } } | { nexthop
next-hop-ip-address } }
```

<b>Syntax Description</b>	<i>ipv4-address/mask</i> or <i>ipv6-address/mask</i>	Address prefix of the target and number of bits in the target address network mask.
	<b>fec-type</b>	(Optional) Specifies the FEC type to be used. The default FEC type is generic.
	<b>bgp</b>	Use FEC type as BGP.
	<b>generic</b>	Use FEC type as generic
	<b>igp</b>	Use FEC type as OSPF or IS-IS.
	<b>labels</b> <i>label1, label2...</i>	Specifies the label stack. Use commas to separate each label.
	<b>output interface</b> <i>interface-path-id</i>	Specifies the output interface where echo request packets are sent.
	<b>nexthop</b> <i>next-hop-ip-address</i>	Causes packets to go through the specified IPv4 or IPv6 next-hop address.

**Command Default** fec-type : generic

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-te	read, write

### Example

These examples show how to use segment routing ping to test the connectivity of the segment routing control plane. In the first example, the FEC type is not specified. You can also specify the FEC type as shown in the second example.

```
RP/0/RP0/CPU0:router# ping sr-mpls 10.1.1.2/32

Sending 5, 100-byte MPLS Echos to 10.1.1.2/32,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/2/5 ms
RP/0/RP0/CPU0:router# ping sr-mpls 10.1.1.2/32 fec-type igp ospf

Sending 5, 100-byte MPLS Echos to 10.1.1.2/32,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/1/2 ms
```

## prefix-sid

To specify or advertise prefix (node) segment ID (SID) on all routers, use the **prefix-sid** command in IS-IS interface address family or OSPF interface configuration mode. To stop advertising prefix SID, use the **no** form of this command.

```
prefix-sid [strict-spf] { index sid-index | absolute sid-value } [n-flag-clear] [explicit-null] [php-disable]
```

Syntax Description		
<b>strict-spf</b>		Specifies that the prefix-SID should use the SPF path.
<b>index</b> <i>sid-index</i>		Specifies the prefix SID based on the lower boundary of the SRGB + the index.
<b>absolute</b> <i>sid-value</i>		Specifies the specific prefix SID value within the SRGB.
<b>n-flag-clear</b>		Specifies that the prefix-SID is not a node-SID by setting the N flag in the prefix-SID sub Type Length Value (TLV) to 0.
<b>explicit-null</b>		Adds an explicit-Null label by setting the E flag in the prefix-SID sub TLV to 1. Automatically disables penultimate-hop-popping (PHP) by setting the P flag (IS-IS) or NP flag (OSPF) to 1.
<b>php-disable</b>		Disables penultimate-hop-popping (PHP) by setting the P flag (IS-IS) to 1.

**Command Default**

Prefix SID is a node SID (N-flag is set to 1).  
 Explicit-Null label is not set (E-flag is set to 0).  
 Penultimate-hop-popping (PHP) is not set (P-flag is set to 0).

**Command Modes**

IS-IS interface address-family configuration  
 OSPF interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.5.4	The <b>php-disable</b> keyword was introduced for IS-IS.

**Usage Guidelines**

Segment routing must be configured on the ISIS instance or on the OSPF process, area, or interface before configuring prefix SID value.

Strict-SPF SIDs are used to forward traffic strictly along the SPF path. Strict-SPF SIDs are not forwarded to SR-TE policies. IS-IS advertises the SR Algorithm sub Type Length Value (TLV) (in the SR Router Capability SubTLV) to include both algorithm 0 (SPF) and algorithm 1 (Strict-SPF). When the IS-IS area or level is Strict-SPF TE-capable, Strict-SPF SIDs are used to build the SR-TE Strict-SPF tunnels. Strict-SPF SIDs are also used to program the backup paths for prefixes, node SIDs, and adjacency SIDs.



**Note** The same SRGB is used for both regular SIDs and strict-SPF SIDs.

The **explicit-null** keyword disables penultimate-hop-popping (PHP) and adds an explicit-Null label. Any upstream neighbor of the Prefix-SID originator replaces the Prefix-SID with a Prefix-SID having an Explicit NULL value.

The **php-disable** keyword disables penultimate-hop-popping (PHP) for IS-IS. The penultimate hop will not pop the Prefix-SID before delivering the packet to the node that advertised the Prefix-SID.

### Task ID

Task ID	Operations
---------	------------

isis	read, write
------	-------------

ospf	
------	--

### Examples

This example shows how to configure a prefix SID.

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# router isis 100
RP/0/RSP0/CPU0:router(config-isis)# interface loopback0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# prefix-sid index 1001
```

This example shows how to configure an absolute prefix SID on an OSPF interface.

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# router ospf 1
RP/0/RSP0/CPU0:router(config-ospf)# area 0
RP/0/RSP0/CPU0:router(config-ospf-ar)# interface loopback0
RP/0/RSP0/CPU0:router(config-ospf-ar-if)# prefix-sid absolute 16041
```

### Related Commands

Command	Description
<a href="#">segment-routing global-block, on page 38</a>	Configures the segment routing global block (SRGB).

## prefix-unreachable

Use this command for UPA advertisements by enabling individual control parameters.

The new **prefix-unreachable** command under IS-IS address-family submode includes several command-options that control various parameters for UPAs originated by the router.

```
prefix-unreachable { adv-lifetime <value> | adv-metric <value> | adv-maximum <value> | rx-process-enable }
```

Syntax Description	Keyword	Details
	<b>prefix-unreachable</b>	Lists the control options of UPA.
	<b>adv-lifetime</b>	<ul style="list-style-type: none"> <li>This command is optional.</li> <li>Amount of time the UPA will be advertised after the prefix becomes unreachable. Range of values is 30–65535 seconds.</li> <li>Default value is 180 seconds.</li> </ul>
	<b>adv-metric</b>	<ul style="list-style-type: none"> <li>This command is optional.</li> <li>Metric used when advertising UPA. Range of values is 4261412865–4294967294 (0xFE000001 to 0xFFFFFFF0).</li> <li>Default value is 4261412865 (0xFE000001).</li> </ul>
	<b>adv-maximum</b>	<ul style="list-style-type: none"> <li>This command is optional.</li> <li>UPAs that are leaked or propagated are not counted against this limit.</li> <li>Maximum number of UPAs that the router is allowed to generate to any of its attached areas or domains. UPAs that are leaked, propagate, or redistributed are not counted against this limit. Range of values is 1–65535.</li> <li>Default value is 32.</li> </ul>
	<b>rx-process-enable</b>	<ul style="list-style-type: none"> <li>This command is optional.</li> <li>If enabled, the UPA received by the router is sent to RIB and is used to trigger the BGP PIC.</li> <li>It is disabled by default.</li> </ul>



**Command Default** None.

**Command Modes** IS-IS interface address-family configuration

Task ID	Task ID	Operations
	IS-IS	read, write

### Examples

This example shows how to configure UPA.

```
Router(config)#router isis 1
Router(config-isis)#address-family ipv6 un
Router(config-isis-af)#prefix-unreachable
Router(config-isis-prefix-unreachable)#adv-lifetime 500
Router(config-isis-prefix-unreachable)#adv-metric 4261412866
Router(config-isis-prefix-unreachable)#adv-maximum 77
Router(config-isis-prefix-unreachable)#rx-process-enable
Router(config-isis-prefix-unreachable)#commit
```

# partition-detect

Use **partition-detect** command for an area or domain partition detection. It is a new command under IS-IS address-family sub-mode.

**partition-detect** { **track** *IPv4 address / IPv6 address [external-id IPv4 -address / IPv6 address ]*

Syntax Description	Keyword	Details
	<b>track</b> <i>IPv4 address / IPv6 address [external-id IPv4 -address / IPv6 address ]</i>	Tracks the reachability of the specific ABR or ASBR. This command is under the partition-detect sub-mode. <ul style="list-style-type: none"> <li>• Only IPv4 address is allowed under IPv4 address-family sub-mode and only IPv6 address is allowed under IPv6 address-family sub-mode.</li> <li>• external-id is only used for ASBR tracking. External-id is the address of the ASBR, in other domain.</li> </ul>

**Command Default** None.

**Command Modes** IS-IS interface address-family configuration

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Task ID	Task ID	Operations
	IS-IS	read, write

**Examples** This example shows how to configure partition-detect.

```
Router(config)#router isis 1
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#router-id 2001:DB8:4::4
Router(config-isis-af)#partition-detect
Router(config-isis-af)#track 2001:DB8:1::1
Router(config-isis-af)#commit
```

# summary-prefix

Use the exiting **summary-prefix** command for UPA advertisement.

```
summary-prefix prefix/mask level 1 or 2 [ tag value ] [ adv-unreachable { unreachable-component-tag value partition-repair } ]
```

Syntax Description	Keyword	Details
	<b>level</b> <i>1 or 2</i>	Enter the border router values 1 or 2. To set the border router level for UPA.
	<b>tag</b> <i>value</i>	Enter the tag value for which you want to enable the UPA.
	<b>adv-unreachable</b>	The new keyword <b>adv-unreachable</b> controls the UPA advertisement for the components of the summary.  The new <b>adv-unreachable</b> keyword is optional and disabled by default.
	<b>unreachable-component-tag</b> <i>value</i>	The <b>unreachable-component-tag</b> is used to limit UPAs to those components of the summary that are advertised with a specific tag value.  The <b>unreachable-component-tag</b> keyword is disabled by default and UPA is generated for all components of the summary if enabled by the <b>adv-unreachable</b> keyword.
	<b>partition-repair</b>	In case the area (domain) partition is detected, the summary is suppressed, and more specific prefixes are advertised.

**Command Default** None.

**Command Modes** IS-IS address-family configuration

Command History	Release	Modification
	Release 7.10.1	The <b>partition-repair</b> keyword was introduced.
	Release 7.8.1	This command was introduced.

**Usage Guidelines** New commands are added under the exiting IS-IS address-family sub-mode **summary-prefix** command.

Task ID	Task ID	Operations
	IS-IS	read, write

### Examples

This example shows how to configure Summary-Prefix for UPA.

```
Router(config)#router isis 1
Router(config)#router isis 1
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#router-id 2001:DB8:4::4
Router(config-isis-af)#summary-prefix 2001:DB8::/32 level 2 partition-repair
Router(config-isis-af)#summary-prefix 2001:DB9::/32 level 2 algorithm 128 partition-repair
```

# segment-routing bundle-member-adj-sid

To program the dynamic Layer 2 Adj-SIDs, and advertise either manual and dynamic Layer 2 Adj-SIDs, use the **segment-routing bundle-member-adj-sid** in IS-IS interface address-family configuration mode. To disable this command, use the **no** form of this command.

## segment-routing bundle-member-adj-sid

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** IS-IS interface address-family configuration

Command History	Release	Modification
	Release 7.0.14	This command was introduced.

**Usage Guidelines** This command is not required to program manual L2 Adj-SID, but is required to program the dynamic Layer 2 Adj-SIDs and to advertise either manual and dynamic Layer 2 Adj-SIDs.

If manual Adj-SIDs are configured on the bundle interface members, IS-IS advertises the manual Adj-SID.

If manual Adj-SIDs are not configured for the bundle member interface, IS-IS advertises the dynamic Adj-SID.

## Example

This example shows how to program the dynamic Layer 2 Adj-SIDs, and advertise either manual and dynamic Layer 2 Adj-SIDs:

```
RP/0/RP0/CPU0:ios(config)# router isis 1
RP/0/RP0/CPU0:ios(config-isis)# address-family ipv4 unicast
RP/0/RP0/CPU0:ios(config-isis-af)# segment-routing bundle-member-adj-sid
RP/0/RP0/CPU0:ios(config-isis-af)#
```

# segment-routing global-block

To configure the segment routing global block (SRGB), use the **segment-routing global-block** command in XR Config mode.

**segment-routing global-block** *starting\_value ending\_value*

<b>Syntax Description</b>	<i>starting_value ending_value</i> Specifies the block of segment routing IDs that are allocated for the routers in the network. Ranges from 16000 to 1048574.
---------------------------	--

<b>Command Default</b>	Default SRGB range is 16000 to 23999.
------------------------	---------------------------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	To keep the segment routing configuration simple and to make it easier to troubleshoot segment routing issues, we recommend that you use the default SRGB range on each node in the domain. However, there are instances when you might need to define a different range:
-------------------------	---

- The nodes of another vendor support a label range that is different from the default SRGB, and you want to use the same SRGB on all nodes.
- The default range is too small.
- To specify separate SRGBs for IS-IS and OSPF protocols, as long as the ranges do not overlap.

Because the values assigned from the range have domain-wide significance, we recommend that all routers within the domain be configured with the same range of values.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	mpls-te	read, write

## Example

This example shows how to configure the SRGB range:

```
RP/0/RSP0/CPU0:router(config)# segment-routing global-block 17000 20000
```

**Related Commands**

Command	Description
<a href="#">prefix-sid, on page 30</a>	Configures the segment ID (SID).

# segment-routing local-block

To configure the segment routing local block (SRLB), use the **segment-routing local-block** command in XR Config mode.

**segment-routing local-block** *starting\_value ending\_value*

<b>Syntax Description</b>	<i>starting_value ending_value</i> Specifies the block of labels that are reserved for manual allocation of adjacency segment IDs (Adj-SIDs). Ranges from 15000 to 1048574.
---------------------------	---

<b>Command Default</b>	Default SRLB range is 15000 to 15999.
------------------------	---------------------------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** When you define a new SRLB range, there might be a label conflict (for example, if labels are already allocated, statically or dynamically, in the new SRLB range). In this case, the new SRLB range will be accepted, but not applied (pending). The previous SRLB range (active) will continue to be in use until one of the following occurs:

- Reload the router to release the currently allocated labels and allocate the new SRLB
- Use the **clear segment-routing local-block discrepancy all** command to clear the label conflicts

The SRLB size cannot be more than 262,143.

To keep the segment routing configuration simple and to make it easier to troubleshoot segment routing issues, we recommend that you use the default SRLB range on each node in the domain. However, there are instances when you might need to define a different range:

- The nodes of another vendor support a label range that is different from the default SRLB, and you want to use the same SRLB on all nodes.
- The default range is too small.

Because the values assigned from the range have domain-wide significance, we recommend that all routers within the domain be configured with the same range of values.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	mpls-te	read, write

This example shows how to configure the SRLB range:



```
RP/0/RSP0/CPU0:router(config)# segment-routing local-block 18000 19999
```

Related Commands	Command	Description
	<a href="#">clear segment-routing local-block discrepancy all, on page 5</a>	Clears SRLB label conflicts
	<a href="#">show segment-routing local-block inconsistencies, on page 65</a>	Displays SRLB label conflicts

# segment-routing mapping-server

To configure the segment routing mapping server (SRMS), use the **segment-routing mapping-server** command in XR Config mode.

```
segment-routing mapping-server prefix-sid-map address-family { ipv4 | ipv6 } ip_address/subnet_mask
SID_start_value range range
```

## Syntax Description

**address-family** { **ipv4** | **ipv6** } Configures the address family for IS-IS.

*ip\_address/subnet\_mask* Specifies the prefix and mask.

*SID\_start\_value* Specifies the first prefix SID in the range.

**range** *range* Specifies the size of the range.

## Command Default

None

## Command Modes

XR Config mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

The position of the mapping server in the network is not important. However, since the mapping advertisements are distributed in IGP using the regular IGP advertisement mechanism, the mapping server needs an IGP adjacency to the network.

The role of the mapping server is crucial. For redundancy purposes, you should configure multiple mapping servers in the networks.

## Task ID

Task ID	Operation
mpls-te	read, write

## Example

This example shows how to configure the mapping server and add prefix-SID mapping entries in the active local mapping policy:

```
RP/0/RSP0/CPU0:router(config)# segment-routing mapping-server prefix-sid-map address-family
ipv4 10.1.1.1/32 17000 range 100
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">segment-routing prefix-sid-map advertise-local, on page 45</a>	Enables the router to advertise the SRMS entries that are locally configured.
<a href="#">segment-routing prefix-sid-map receive disable, on page 47</a>	Disables mapping client functionality.
<a href="#">show segment-routing mapping-server prefix-sid-map, on page 66</a>	Displays the active and backup prefix-to-SID mappings for IS-IS.
<a href="#">show ospf segment-routing prefix-sid-map, on page 59</a>	Displays the active and backup prefix-to-SID mappings for OSPF.
<a href="#">show segment-routing mapping-server prefix-sid-map, on page 66</a>	Displays the locally configured prefix-to-SID mappings.

# segment-routing mpls

To enable segment routing for IPv4 addresses with MPLS data plane, use the **segment-routing mpls** command in IPv4 address family configuration mode. To disable segment routing, use the **no** form of this command.

## segment-routing mpls

<b>Syntax Description</b>	<b>mpls</b> Enables segment routing for IPv4 addresses with MPLS data plane.
---------------------------	--

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

<b>Command Modes</b>	IPv4 address family configuration Router configuration Area configuration
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	mpls-te	read, write

## Example

This example shows how to enable segment routing with MPLS data plane.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router isis 100
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# segment-routing mpls
```

# segment-routing prefix-sid-map advertise-local

To enable the router to advertise the segment routing mapping server (SRMS) entries that are locally configured, use the **segment-routing prefix-sid-map advertise-local** command. In addition to advertising these local SRMS entries, these mapping entries are also used to calculate segment ID (SID).

## segment-routing prefix-sid-map advertise-local

<b>Syntax Description</b>	<b>advertise-local</b> Advertises the SRMS mapping entries that are locally configured.
---------------------------	---

<b>Command Default</b>	Disabled.
------------------------	-----------

<b>Command Modes</b>	IPv4 address family configuration Router configuration
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ospf	read, write
	isis	

### Example

This example shows how to enable the router to advertise the locally configured SRMS entries:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router ospf 1
RP/0/RSP0/CPU0:router(config-ospf)# segment-routing prefix-sid-map advertise-local
```

Related Commands	Command	Description
	<a href="#">segment-routing mapping-server, on page 42</a>	Configures the segment routing mapping server (SRMS).
	<a href="#">segment-routing prefix-sid-map receive disable, on page 47</a>	Disables mapping client functionality.
	<a href="#">show isis segment-routing prefix-sid-map, on page 49</a>	Displays the active and backup prefix-to-SID mappings for IS-IS.

Command	Description
<a href="#">show ospf segment-routing prefix-sid-map</a> , on page 59	Displays the active and backup prefix-to-SID mappings for OSPF.
<a href="#">show segment-routing mapping-server prefix-sid-map</a> , on page 66	Displays the locally configured prefix-to-SID mappings.

# segment-routing prefix-sid-map receive disable

To disable mapping client functionality, use the **segment-routing prefix-sid-map receive disable** command. To reenable client functionality, use the **segment-routing prefix-sid-map receive** command.

**segment-routing prefix-sid-map receive** [**disable**]

<b>Syntax Description</b>	<b>receive</b> Only remote SRMS mapping entries are used for SID calculation.
	<b>disable</b> Disable remote SRMS mapping entries received by flooding.

**Command Default** Enabled.

**Command Modes** IPv4 address family configuration  
Router configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The mapping client functionality is enabled by default. When you disable client functionality, the SRMS active policy is calculated without remote SRMS entries.

You can use this command with the **segment-routing prefix-sid-map advertise-local** command simultaneously.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ospf isis	read, write

## Example

This example shows how to disable the mapping server client functionality:

```
RP/0/RSP0/CPU0:router(config)# router isis 1
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# segment-routing prefix-sid-map receive disable
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">segment-routing mapping-server, on page 42</a>	Configures the segment routing mapping server (SRMS).

Command	Description
<a href="#">segment-routing prefix-sid-map advertise-local, on page 45</a>	Enables the router to advertise the SRMS entries that are locally configured.
<a href="#">show isis segment-routing prefix-sid-map, on page 49</a>	Displays the active and backup prefix-to-SID mappings for IS-IS.
<a href="#">show ospf segment-routing prefix-sid-map, on page 59</a>	Displays the active and backup prefix-to-SID mappings for OSPF.
<a href="#">show segment-routing mapping-server prefix-sid-map, on page 66</a>	Displays the locally configured prefix-to-SID mappings.



# show isis segment-routing prefix-sid-map

To verify the active and backup prefix-to-SID mappings for IS-IS, use the **show isis segment-routing prefix-sid-map** command in XR EXEC mode.

**show isis segment-routing prefix-sid-map** [**active-policy** | **backup-policy**]

Syntax Description	
	<b>active-policy</b> (Optional) Specifies the active mapping policy.
	<b>backup-policy</b> (Optional) Specifies the backup mapping policy.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	isis	read

## Example

The example shows how to verify the active mapping policy on IS-IS:

```
RP/0/0/CPU0:router# show isis segment-routing prefix-sid-map active-policy
```

```
IS-IS 1 active policy
Prefix          SID Index  Range      Flags
1.1.1.100/32    100       20
1.1.1.150/32    150       10
```

```
Number of mapping entries: 2
```

The example shows how to verify the backup mapping policy on IS-IS:

```
RP/0/0/CPU0:router# show isis segment-routing prefix-sid-map backup-policy
```

```
IS-IS 1 backup policy
Prefix          SID Index  Range      Flags
1.1.1.100/32    100       20
1.1.1.150/32    150       10
```

Number of mapping entries: 2

### Related Commands

Command	Description
<a href="#">segment-routing mapping-server, on page 42</a>	Configures the segment routing mapping server (SRMS).
<a href="#">segment-routing prefix-sid-map advertise-local, on page 45</a>	Enables the router to advertise the SRMS entries that are locally configured.
<a href="#">segment-routing prefix-sid-map receive disable, on page 47</a>	Disables mapping client functionality.
<a href="#">show ospf segment-routing prefix-sid-map, on page 59</a>	Displays the active and backup prefix-to-SID mappings for OSPF.
<a href="#">show segment-routing mapping-server prefix-sid-map, on page 66</a>	Displays the locally configured prefix-to-SID mappings.

# show mrib nsf private

To display the state of nonstop forwarding (NSF) operation in the Multicast Routing Information Base (MRIB), use the **show mrib nsf private** command in the appropriate mode.

**show mrib nsf private**

<b>Syntax Description</b>	<b>show mrib nsf private</b> Displays the state of NSF operation in the MRIB.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

*Table 3: Release History*

Release	Modification
Release 7.10.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show mrib nsf private** command displays the current multicast NSF state for the MRIB. The state may be normal or activated for NSF. The activated state indicates that recovery is in progress due to a failure in MRIB or Protocol Independent Multicast (PIM). The total NSF timeout and time remaining are displayed until NSF expiration.

*Table 4: Task ID*

Release	Modification
multicast	read

## Example

The example shows how to verify the Non Stop Forwarding:

```
Router#show mrib nsf private
IP MRIB Non-Stop Forwarding Status:
Multicast routing state: Normal
  NSF Lifetime:          00:03:00
  Respawn Count: 6
  Last NSF On triggered: Tue Jul 25 13:20:49 2023, 6d00h
  Last NSF Off triggered: Tue Jul 25 13:22:49 2023, 6d00h
  Last NSF ICD Notification sent: Tue Jul 25 13:22:49 2023, 6d00h
  Last Remote NSF On triggered: Tue Jul 25 13:10:18 2023, 6d00h
  Last Remote NSF Off triggered: Tue Jul 25 13:10:27 2023, 6d00h
  Last Label TE NSF On triggered: Tue Jul 25 13:10:18 2023, 6d00h
  Last Label TE NSF Off triggered: Tue Jul 25 13:10:27 2023, 6d00h
  Last Label mLDP NSF On triggered: Tue Jul 25 13:10:18 2023, 6d00h
  Last Label mLDP NSF Off triggered: Tue Jul 25 13:10:27 2023, 6d00h
```

```
Last Label PIM NSF On triggered: Tue Jul 25 13:20:49 2023, 6d00h
Last Label PIM NSF Off triggered: Tue Jul 25 13:22:49 2023, 6d00h
Last Label PIM6 NSF On triggered: Tue Jul 25 13:31:22 2023, 5d23h
Last Label PIM6 NSF Off triggered: Tue Jul 25 13:33:22 2023, 5d23h
Last Label XTC NSF On triggered: Tue Jul 25 13:41:51 2023, 5d23h
Last Label XTC NSF Off triggered: Tue Jul 25 13:41:52 2023, 5d23h

IP NSF :- Active: N, Assume N
MRIB connect timer: Inactive
NSF statistics:
    Enabled Cnt - 4, Disabled Cnt - 4
    Last Enabled: 6d00h, Last Disabled: 6d00h
Multicast COFO routing state: Normal
Current LMRIB clients: LDP RSVP_TE PIM PIM6 XTC
LMRIB NSF clients: LDP RSVP_TE PIM PIM6 XTC
Converged LMRIB clients: LDP RSVP_TE PIM PIM6 XTC
RP/0/RSP0/CPU0:tb8-R2#
```

# show ospf route flex-algo

To display the OSPF routing table for flexible algorithm, use the **show ospf routes flex-algo** command in the EXEC mode.

```
show ospf routes flex-algo [number] [{ prefix / prefix_len | route-type { external | inter
| intra } }] [backup-path] [detail]
```

Syntax Description		
<b>number</b>	Specifies the flexible algorithm number. The range is from 128 to 255.	
<b>IP address/prefix</b>	Specifies IP address along with the subnet mask.	
<b>backup-path</b>	Displays the backup-path information of the OSPF routes.	
<b>detail</b>	Displays the detailed information of the OSPF routes.	
<b>route-typeexternal</b>	Displays OSPF external routes.	
<b>route-typeinter</b>	Display OSPF inter area routes.	
<b>route-typeintra</b>	Displays OSPF intra area routes.	

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 7.5.1	This command was introduced.

**Usage Guidelines** Use the **show ospf routes flex-algo** command to display the OSPF private routing table for flexible algorithm (which contains only flexible algorithm routes calculated by OSPF). If there is something wrong with a route in the MPLS forwarding table and RIB, then it is useful to check the OSPF copy of the route to determine if it matches the RIB and MPLS forwarding entries. If it does not match, there is a synchronization problem between OSPF and the MPLS. If the routes match and the route is incorrect, OSPF has made an error in its routing calculation.

## Example

This following show output displays the external route type configured:

```
Router#show ospf routes flex-algo 240 route-type external detail
Route Table of ospf-1 with router ID 192.168.0.2 (VRF default)

Algorithm 240

Route entry for 192.168.4.3/32, Metric 220, SID 536, Label 16536
Priority : Medium

Route type : Extern Type 1
```

```

Last updated : Apr 25 14:30:12.718
Flags: Inuse

Prefix Contrib Algo 240 SID 536
From 192.168.0.4 Route-type 5
Total Metric : 220 Base metric 20 FAPM 20
Contrib Flags : Inuse, Reachable
SID Flags : PHP off, Index, Global, Valid

Path: 10.1.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2
Out Label : 16536
Weight : 0
Area : 0

Path: 10.1.2.3, from 192.168.0.4, via GigabitEthernet0/2/0/3
Out Label : 16536
Weight : 0
Area : 0

Path: 10.2.1.5, from 192.168.0.4, via GigabitEthernet0/2/0/4
Out Label : 16536
Weight : 0
Area : 0

Route entry for 192.168.4.5/32, Metric 120, SID 556, Label 16556
Priority : Medium

Route type : Extern Type 1
Last updated : Apr 25 14:30:12.724
Flags: Inuse

Prefix Contrib Algo 240 SID 556
From 192.168.0.3 Route-type 5
Total Metric : 120 Base metric 1 FAPM 20
Contrib Flags : Inuse, Reachable
SID Flags : PHP off, Index, Global, Valid

Path: 10.1.1.3, from 192.168.0.3, via GigabitEthernet0/2/0/2
Out Label : 16556
Weight : 0
Area : 0

Path: 10.1.2.3, from 192.168.0.3, via GigabitEthernet0/2/0/3
Out Label : 16556
Weight : 0
Area : 0

```

The following show output displays label information for flexible algorithm and its corresponding metric as added in RIB:

```

RP/0/RP0/CPU0:ios# show route 192.168.0.2/32 detail
Wed Apr 6 16:24:46.021 IST

Routing entry for 192.168.0.2/32
Known via "ospf 1", distance 110, metric 2, labeled SR, type intra area
Installed Apr 6 15:51:57.973 for 00:32:48
Routing Descriptor Blocks
 10.10.10.2, from 192.168.0.2, via GigabitEthernet0/2/0/0, Protected
  Route metric is 2
  Label: 0x3 (3)
  Tunnel ID: None
  Binding Label: None
  Extended communities count: 0
  Path id:1 Path ref count:0

```

```

    NHID:0x1(Ref:1)
    Backup path id:65
    OSPF area: 1
10.11.11.2, from 192.168.0.2, via GigabitEthernet0/2/0/1, Backup (Local-LFA)
    Route metric is 6
    Label: 0x3 (3)
    Tunnel ID: None
    Binding Label: None
    Extended communities count: 0
    Path id:65          Path ref count:1
    NHID:0x2(Ref:1)
    OSPF area:
Route version is 0x12 (18)
Local Label: 0x3ee6 (16102)
Local Label Algo Set (ID, Label, Metric): (1, 16202, 0), (128, 17282, 2)
IP Precedence: Not Set
QoS Group ID: Not Set
Flow-tag: Not Set
Fwd-class: Not Set
Route Priority: RIB_PRIORITY_NON_RECURSIVE_MEDIUM (7) SVD Type RIB_SVD_TYPE_LOCAL
Download Priority 1, Download Version 38
No advertising protos.

```

The following example shows the backup path for each path:

```
Router#show ospf routes flex-algo 240 route-type external backup-path
```

```
Route Table of ospf-1 with router ID 192.168.0.2 (VRF default)
```

```

Algorithm 240

192.168.4.3/32, Metric 220, SID 536, Label 16536
  10.1.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2
    Backup path:
      10.23.2.3, from 192.168.0.4, via GigabitEthernet0/2/0/3,
      Out Label: 16536
      Attributes: Metric: 220, Primary , Downstream, Interface Disjoint, SRLG
Disjoint
  10.1.2.3, from 192.168.0.4, via GigabitEthernet0/2/0/3
    Backup path:
      10.23.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2,
      Out Label: 16536
      Attributes: Metric: 220, Primary , Downstream, Interface Disjoint, SRLG
Disjoint
  10.1.1.5, from 192.168.0.4, via GigabitEthernet0/2/0/4
    Backup path:
      10.23.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2,
      Out Label: 16536
      Attributes: Metric: 220, Primary , Downstream, Node Protect, Interface Disjoint,
SRLG Disjoint
192.168.4.5/32, Metric 120, SID 556, Label 16556
  10.1.1.3, from 192.168.0.3, via GigabitEthernet0/2/0/2
    Backup path:
      10.23.2.3, from 192.168.0.3, via GigabitEthernet0/2/0/3,
      Out Label: 16556
      Attributes: Metric: 120, Primary , Downstream, Interface Disjoint, SRLG
Disjoint
  10.1.2.3, from 192.168.0.3, via GigabitEthernet0/2/0/3
    Backup path:
      10.1.1.3, from 192.168.0.3, via GigabitEthernet0/2/0/2,
      Out Label: 16556
      Attributes: Metric: 120, Primary , Downstream, Interface Disjoint, SRLG
Disjoint

```

The following example shows details of the route, but not the backup paths:

```
Router#show ospf routes flex-algo 240 route-type external detail

Route Table of ospf-1 with router ID 192.168.0.2 (VRF default)

Algorithm 240

Route entry for 192.168.4.3/32, Metric 220, SID 536, Label 16536
Priority : Medium

Route type : Extern Type 1
Last updated : Apr 25 14:30:12.718
Flags: Inuse

Prefix Contrib Algo 240 SID 536
From 192.168.0.4 Route-type 5
Total Metric : 220 Base metric 20 FAPM 20
Contrib Flags : Inuse, Reachable
SID Flags : PHP off, Index, Global, Valid

Path: 10.1.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2
Out Label : 16536
Weight : 0
Area : 0

Path: 10.1.2.3, from 192.168.0.4, via GigabitEthernet0/2/0/3
Out Label : 16536
Weight : 0
Area : 0

Path: 10.2.1.5, from 192.168.0.4, via GigabitEthernet0/2/0/4
Out Label : 16536
Weight : 0
Area : 0

Route entry for 192.168.4.5/32, Metric 120, SID 556, Label 16556
Priority : Medium

Route type : Extern Type 1
Last updated : Apr 25 14:30:12.724
Flags: Inuse

Prefix Contrib Algo 240 SID 556
From 192.168.0.3 Route-type 5
Total Metric : 120 Base metric 1 FAPM 20
Contrib Flags : Inuse, Reachable
SID Flags : PHP off, Index, Global, Valid

Path: 10.1.1.3, from 192.168.0.3, via GigabitEthernet0/2/0/2
Out Label : 16556
Weight : 0
Area : 0

Path: 10.1.2.3, from 192.168.0.3, via GigabitEthernet0/2/0/3
Out Label : 16556
Weight : 0
Area : 0
```

The following example shows details of the route and backup paths:

```
Router#show ospf routes flex-algo 240 route-type external backup-path detail
```



Route Table of ospf-1 with router ID 192.168.0.2 (VRF default)

Algorithm 240

Route entry for 192.168.4.3/32, Metric 220, SID 536, Label 16536  
Priority : Medium

Route type : Extern Type 1  
Last updated : Apr 25 14:30:12.718  
Flags: Inuse

Prefix Contrib Algo 240 SID 536  
From 192.168.0.4 Route-type 5  
Total Metric : 220 Base metric 20 FAPM 20  
Contrib Flags : Inuse, Reachable  
SID Flags : PHP off, Index, Global, Valid

Path: 10.1.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2  
Out Label : 16536  
Weight : 0  
Area : 0

Backup path:

10.1.2.3, from 192.168.0.4, via GigabitEthernet0/2/0/3,  
Out Label: 16536

Attributes: Metric: 220, Primary , Downstream, Interface Disjoint, SRLG

Disjoint

Path: 23.23.2.3, from 192.168.0.4, via GigabitEthernet0/2/0/3  
Out Label : 16536  
Weight : 0  
Area : 0

Backup path:

10.1.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2,  
Out Label: 16536

Attributes: Metric: 220, Primary , Downstream, Interface Disjoint, SRLG

Disjoint

Path: 25.25.1.5, from 192.168.0.4, via GigabitEthernet0/2/0/4  
Out Label : 16536  
Weight : 0  
Area : 0

Backup path:

10.1.1.3, from 192.168.0.4, via GigabitEthernet0/2/0/2,  
Out Label: 16536

Attributes: Metric: 220, Primary , Downstream, Node Protect, Interface Disjoint,  
SRLG Disjoint

Route entry for 192.168.4.5/32, Metric 120, SID 556, Label 16556  
Priority : Medium

Route type : Extern Type 1  
Last updated : Apr 25 14:30:12.724  
Flags: Inuse

Prefix Contrib Algo 240 SID 556  
From 192.168.0.3 Route-type 5  
Total Metric : 120 Base metric 1 FAPM 20  
Contrib Flags : Inuse, Reachable  
SID Flags : PHP off, Index, Global, Valid

Path: 10.1.1.3, from 192.168.0.3, via GigabitEthernet0/2/0/2

```
show ospf route flex-algo
```

```
Out Label : 16556
Weight    : 0
Area      : 0

Backup path:
  10.1.2.3, from 192.168.0.3, via GigabitEthernet0/2/0/3,
  Out Label: 16556
  Attributes: Metric: 120, Primary , Downstream, Interface Disjoint, SRLG
Disjoint

Path: 10.1.2.3, from 192.168.0.3, via GigabitEthernet0/2/0/3
Out Label : 16556
Weight    : 0
Area      : 0

Backup path:
  10.1.1.3, from 192.168.0.3, via GigabitEthernet0/2/0/2,
  Out Label: 16556
  Attributes: Metric: 120, Primary , Downstream, Interface Disjoint, SRLG
Disjoint
```

# show ospf segment-routing prefix-sid-map

To verify the active and backup prefix-to-SID mappings for OSPF, use the **show ospf segment-routing prefix-sid-map** command in XR EXEC mode.

```
show ospf segment-routing prefix-sid-map [active-policy | backup-policy]
```

Syntax Description	
	<b>active-policy</b> (Optional) Specifies the active mapping policy.
	<b>backup-policy</b> (Optional) Specifies the backup mapping policy.

Command Default	None
-----------------	------

Command Modes	XR EXEC mode
---------------	--------------

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
------------------	--

Task ID	Task ID	Operation
	ospf	read

## Example

The example shows how to verify the active mapping policy on OSPF:

```
RP/0/0/CPU0:router# show ospf segment-routing prefix-sid-map active-policy
```

```
SRMS active policy for Process ID 1
```

Prefix	SID Index	Range	Flags
1.1.1.100/32	100	20	
1.1.1.150/32	150	10	

```
Number of mapping entries: 2
```

The example shows how to verify the backup mapping policy on OSPF:

```
RP/0/0/CPU0:router# show ospf segment-routing prefix-sid-map backup-policy
```

```
SRMS backup policy for Process ID 1
```

Prefix	SID Index	Range	Flags
1.1.1.100/32	100	20	
1.1.1.150/32	150	10	

```
show ospf segment-routing prefix-sid-map
```

```
Number of mapping entries: 2
```

### Related Commands

Command	Description
<a href="#">segment-routing mapping-server, on page 42</a>	Configures the segment routing mapping server (SRMS).
<a href="#">segment-routing prefix-sid-map advertise-local, on page 45</a>	Enables the router to advertise the SRMS entries that are locally configured.
<a href="#">segment-routing prefix-sid-map receive disable, on page 47</a>	Disables mapping client functionality.
<a href="#">show isis segment-routing prefix-sid-map, on page 49</a>	Displays the active and backup prefix-to-SID mappings for IS-IS.
<a href="#">show segment-routing mapping-server prefix-sid-map, on page 66</a>	Displays the locally configured prefix-to-SID mappings.

# show performance-measurement history

To display the history for delay-measurement, use the **performance-measurement history** show command in XR EXEC mode.

```
show performance-measurement history { probe-computation | advertisement | aggregation } {
interfaces | endpoint | rsvp-te | sr-policy }
```

Syntax Description	
<b>probe-computation</b>	(Optional) Displays information for the delay metric computation result within each probe interval.
<b>advertisement</b>	(Optional) Displays information for the delay metric computation result within each advertisement interval.
<b>aggregation</b>	(Optional) Displays information for the delay metric computation result within each aggregation interval.
<b>interface</b>	(Optional) Displays information on the specified interface.
<b>endpoint</b>	(Optional) Displays information on the specified endpoint.
<b>rsvp-te</b>	(Optional) Displays information on the specified Resource Reservation Protocol - Traffic Engineering (RSVP-TE).
<b>sr-policy</b>	(Optional) Displays information on the specified sr-policy.

**Command Default** No default

**Command Modes** XR EXEC

Command History	Release	Modification
	Release 24.1.1	This command was updated with synthetic and anomaly loss information.
	Release 7.3.1	This command was introduced.

Task ID	Task ID	Operation
	performance-measurement	write/read

```
Router# show performance-measurement history probe-computation interfaces
Interface Name: GigabitEthernet0/2/0/0 (ifh: 0x1000020)
Delay-Measurement history (uSec):
  Probe Start Timestamp      Pkt(TX/RX)   Average      Min      Max
Aug 01 2023 08:04:15.230    10/10        704          651     779
```

```
Router# show performance-measurement history probe-computation endpoint
Endpoint name: IPv4-192.168.0.4-vrf-default
...
```

## show performance-measurement history

```

Segment-List          : None
Delay-Measurement history (uSec):
  Probe Start Timestamp   Pkt (TX/RX)   Average   Min   Max
Aug 01 2023 08:26:48.823    10/10       3399     2962  3808

```

**Router# show performance-measurement history aggregation rsvp-te**

```

...
Delay-Measurement history (uSec):
  Aggregation Timestamp   Pkt (TX/RX)   Average   Min   Max
Aug 01 2023 08:37:23.702    40/40       3372     3172  4109

```

**Router# show performance-measurement history advertisement sr-policy**

```

...
Delay-Measurement history (uSec):
  Advertisement Timestamp   Pkt (TX/RX)   Average   Min   Max   Reason
Aug 01 2023 10:05:14.072    24/24       3408     3408  3408  ACCEL-MAX

```

**Table 5: This table gives show performance-measurement history field descriptions:**

Field	Description
TX	Number of packets sent.
RX	Number of packets received.
Average	Average delay of all the delay measures within one probe.
Max	Maximum delay of all the delay measures within one probe.
Min	Minimum delay of all the delay measures within one probe.

Reason	<p>Provides the reason for the delay in packets:"</p> <ul style="list-style-type: none"> <li>• NONE : No advertisements occurred</li> <li>• PER-AVG : Periodic timer, average delay threshold crossed</li> <li>• PER-MIN : Periodic timer, min delay threshold crossed</li> <li>• PER-MAX : Periodic timer, max delay threshold crossed</li> <li>• ACCEL-AVG : Accelerated threshold crossed, average delay threshold crossed</li> <li>• ACCEL-MIN : Accelerated threshold crossed, min delay threshold crossed</li> <li>• ACCEL-MAX : Accelerated threshold crossed, max delay threshold crossed</li> <li>• ACCEL-UP-AVG : Accelerated threshold crossed, average delay upper-bound crossed</li> <li>• ACCEL-UP-MIN : Accelerated threshold crossed, min delay upper-bound crossed</li> <li>• ACCEL-UP-MAX : Accelerated threshold crossed, max delay upper-bound crossed</li> <li>• ANOM-MIN-DYN : Min delay A flag toggled and dynamic delay is in effect</li> <li>• ANOM-MIN-STA : Min delay A flag toggled and static delay is in effect</li> <li>• FIRST : First advertisement</li> <li>• NEW-SESSION : New child session</li> <li>• ENABLE : Advertisement enabled</li> <li>• DISABLE : Advertisement disabled</li> <li>• DELETE : Session deleted</li> <li>• EXEC-CLEAR : Cleared through exec command</li> <li>• ADV-CFG : Advertise delay config</li> <li>• ADV-UNCFG : Advertise delay unconfig</li> <li>• ERROR : Control code error</li> <li>• LINK-DOWN : Link state changed to down</li> <li>• SESSION-ERROR : Performance measurement session error</li> <li>• DYN-DM : Dynamic delay advertisement is in effect</li> <li>• PT-CFG : Path tracing config</li> <li>• PT-UNCFG : Path tracing unconfig</li> <li>• PT-INTF_READY : Path tracing interface ready</li> <li>• PKT-LOSS : Packet loss detected</li> <li>• ANOM-PKT-LOSS : PM session anomaly due to packet loss</li> <li>• N/A : Invalid advertisement reason</li> </ul>
--------	---

# show segment-routing srv6 sid

You can use the **show segment-routing srv6 sid** command to verify the SRv6 global and locator configuration.

## show segment-routing srv6 sid

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.8.1	This command output was modified.
Release 7.0.12	This command was introduced.	

**Usage Guidelines** The command displays SID information across locators. By default, only “active” (i.e. non-stale) SIDs are displayed.

From IOS XR Release 7.8.1, IOS XR nodes with SRv6 Micro-SID F3216 format will accept and allow service SIDs received from non-IOS XR node peers with SRv6 base F128. Non-IOS XR node peers can be without SID Struct TLV (SSTLV), or with an incompatible SSTLV having an SID that is F3216 compatible. This allows for interoperability without any IETF extension or configuration changes on the Non-IOS XR peer node.

The following example shows how to display detailed information on the remote side, with the allocation type:

```
Router# show segment-routing srv6 locator usid sid fccc:cccl:1:e00f::
Mon Dec 13 15:58:53.640 EST
SID                               Behavior      Context      Owner
      State  RW
-----  -
fccc:cccl:1:e00f::                uDT46        '**iid'
rib_lib_test_xtf      InUse  Y
  SID Function: 0xe00f
  SID context: { '**iid' }
  App data: [0000000000000000]
  Locator: 'usid'
  Allocation type: Dynamic | Explicit
```



# show segment-routing local-block inconsistencies

Displays any segment routing local block (SRLB) label inconsistencies.

**show segment-routing local-block inconsistencies**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** When a new SRLB range is defined, there might be a label conflict (for example, if labels are already allocated, statically or dynamically, in the new SRLB range). In this case, the new SRLB range will be accepted, but not applied (pending). The previous SRLB range (active) will continue to be in use until one of the following occurs:

- Reload the router to release the currently allocated labels and allocate the new SRLB
- Use the **clear segment-routing local-block discrepancy all** command to clear the label conflicts

Task ID	Task	Operation
	ID	

## Example

This example shows how to display the SRGB inconsistencies:

```
RP/0/RSP0/CPU0:router(config)# show segment-routing local-block inconsistencies
Tue Aug 15 13:53:30.555 EDT
SRLB inconsistencies range: Start/End: 30000/30009
```

Related Commands	Command	Description
	<a href="#">clear segment-routing local-block discrepancy all</a>	Clears SRLB label conflicts
	<a href="#">segment-routing local-block</a>	Configures the SRLB

# show segment-routing mapping-server prefix-sid-map

To verify the locally configured prefix-to-SID mappings, use the **show segment-routing mapping-server prefix-sid-map** command in XR EXEC mode.

**show segment-routing mapping-server prefix-sid-map** [**ipv4** | **ipv6**] [*prefix*] [**detail**]

Syntax Description	
<b>ipv4</b>	(Optional) Specifies an IPv4 address family.
<b>ipv6</b>	(Optional) Specifies an IPv6 address family.
<i>prefix</i>	(Optional) Specifies a prefix.
<b>detail</b>	(Optional) Displays detailed information on the prefix-to-SID mappings.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
		read

## Example

The example shows how to verify the IPv4 prefix-to-SID mappings:

```
RP/0/0/CPU0:router# show segment-routing mapping-server prefix-sid-map ipv4
Prefix          SID Index  Range  Flags
20.1.1.0/24     400        300
10.1.1.1/32     10         200
Number of mapping entries: 2
```

The example shows how to display detailed information on the IPv4 prefix-to-SID mappings:

```
RP/0/0/CPU0:router# show segment-routing mapping-server prefix-sid-map ipv4 detail
Prefix
20.1.1.0/24
  SID Index:      400
  Range:          300
  Last Prefix:    20.2.44.0/24
  Last SID Index: 699
```

```

Flags:
10.1.1.1/32
  SID Index:      10
  Range:          200
  Last Prefix:    10.1.1.200/32
  Last SID Index: 209
Flags:
Number of mapping entries: 2

```

**Related Commands**

Command	Description
<a href="#">segment-routing mapping-server, on page 42</a>	Configures the segment routing mapping server (SRMS).
<a href="#">segment-routing prefix-sid-map advertise-local, on page 45</a>	Enables the router to advertise the SRMS entries that are locally configured.
<a href="#">segment-routing prefix-sid-map receive disable, on page 47</a>	Disables mapping client functionality.
<a href="#">show isis segment-routing prefix-sid-map, on page 49</a>	Displays the active and backup prefix-to-SID mappings for IS-IS.
<a href="#">show ospf segment-routing prefix-sid-map, on page 59</a>	Displays the active and backup prefix-to-SID mappings for OSPF.

## traceroute mpls nil-fec labels

To check network connectivity and identify LSP breakages, use the **traceroute mpls nil-fec labels** command in XR EXEC mode.

**traceroute mpls nil-fec labels** {*label* [,*label*...]} [**output** {**interface** *tx-interface*} [**nexthop** *next-hop-ip-address*]]

<b>Syntax Description</b>	<b>labels</b> <i>label, label...</i>	Specifies the label stack. Use commas to separate the each <i>label</i> .
	<b>output interface</b> <i>tx-interface</i>	Specifies the output interface.
	<b>nexthop</b> <i>next-hop-ip-address</i>	(Optional) Causes packets to go through the specified next-hop address.
<b>Command Default</b>	None	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	mpls-te	read, write

### Example

This example shows how to check connectivity for a known label stack using a specific output interface and next-hop address:

```
RP/0/RSP0/CPU0:router# traceroute mpls nil-fec labels 16005,16007 output interface
GigabitEthernet 0/2/0/1 nexthop 10.1.1.4
Tracing MPLS Label Switched Path with Nil FEC labels 16005,16007, timeout is 2 seconds
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no label entry,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'd' - see DDMAP for return code,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
0 10.1.1.3 MRU 1500 [Labels: 16005/16007/explicit-null Exp: 0/0/0]
L 1 10.1.1.4 MRU 1500 [Labels: implicit-null/16007/explicit-null Exp: 0/0/0] 1 ms
L 2 10.1.1.5 MRU 1500 [Labels: implicit-null/explicit-null Exp: 0/0] 1 ms
! 3 10.1.1.7 1 ms
```

**Related Commands**

Command	Description
<a href="#">ping mpls nil-fec labels, on page 26</a>	Checks network connectivity and identifying LSP breakages.

## tracertoute sr-mpls

To trace the routes to a destination in a segment routing network, use the **tracertoute sr-mpls** command in XR EXEC mode.

```
tracertoute sr-mpls { ipv4-address/mask | ipv6-address/mask [ fec-type { bgp | generic | igp { ospf | isis } } ] | multipath { ipv4-address/mask | ipv6-address/mask [ fec-type { bgp | generic | igp { ospf | isis } } } | nil-fec | dataplane-only { labels { label1 [ , label2... ] ipv4-address/mask | ipv6-address/mask | policy } } } { output { interface interface-path-id } } } { nexthop next-hop-ip-address } }
```

<b>Syntax Description</b>	<i>ipv4 address/mask</i> or <i>ipv6 address/mask</i>	Address prefix of the target and number of bits in the target address network mask.
<b>fec-type</b>		(Optional) Specifies FEC type to be used. Default FEC type is generic.  <b>bgp</b> Use FEC type as BGP.  <b>generic</b> Use FEC type as generic.  <b>igp</b> Use FEC type as OSPF or ISIS.
<b>labels</b> <i>label,label...</i>		Specifies the label stack. Use commas to separate each label.
<b>output interface</b> <i>interface-path-id</i>		Specifies the output interface where echo request packets are sent.
<b>nexthop</b> <i>next-hop-ip-address</i>		Causes packets to go through the specified IPv4 or IPv6 next-hop address.

**Command Default**    **fec-type** : generic

**Command Modes**    XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines**    No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write

### Example

These examples show how to use segment routing traceroute to trace the LSP for a specified IPv4 prefix segment routing id (SID). In the first example, FEC type is not specified. You can also specify the FEC type as shown in the second example. The third example uses multipath traceroute to discover all the possible paths for a IPv4 prefix SID.

```
RP/0/RP0/CPU0:router# traceroute sr-mpls 10.1.1.2/32
```

```
Tracing MPLS Label Switched Path to 10.1.1.2/32, timeout is 2 seconds
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
 0 10.12.12.1 MRU 1500 [Labels: implicit-null Exp: 0]
! 1 10.12.12.2 3 ms
```

```
RP/0/RP0/CPU0:router# traceroute sr-mpls 10.1.1.2/32 fec-type igp ospf
```

```
Tracing MPLS Label Switched Path to 10.1.1.2/32, timeout is 2 seconds
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
 0 10.12.12.1 MRU 1500 [Labels: implicit-null Exp: 0]
! 1 10.12.12.2 2 ms
```

```
RP/0/RP0/CPU0:router# traceroute sr-mpls multipath 10.1.1.2/32
```

```
Starting LSP Path Discovery for 10.1.1.2/32
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
!  
Path 0 found,  
  output interface GigabitEthernet0/0/0/2 nexthop 10.13.13.2  
source 10.13.13.1 destination 127.0.0.0  
!  
Path 1 found,  
  output interface Bundle-Ether1 nexthop 10.12.12.2  
source 10.12.12.1 destination 127.0.0.0  
  
Paths (found/broken/unexplored) (2/0/0)  
Echo Request (sent/fail) (2/0)  
Echo Reply (received/timeout) (2/0)  
Total Time Elapsed 14 ms
```





## Segment Routing Traffic Engineering Commands

This chapter describes the commands used to configure and use Segment Routing Traffic Engineering (SR-TE).

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

- [affinity-map](#), on page 74
- [autoroute include ipv6 all](#), on page 75
- [bgp prefix-path-label ignore](#), on page 76
- [binding-sid](#), on page 77
- [distribute link-state \(SRTE\)](#), on page 78
- [distribute link-state](#), on page 79
- [hw-module profile cef sropt enable](#), on page 80
- [kshortest-paths](#), on page 82
- [neighbor sr-policy name targeted](#), on page 83
- [on-demand constraints](#), on page 84
- [on-demand dynamic affinity sid-algorithm](#), on page 85
- [on-demand dynamic affinity disjoint-path](#), on page 86
- [on-demand maximum-sid-depth](#), on page 88
- [on-demand source-address](#), on page 89
- [on-demand steering](#), on page 90
- [policy binding-sid](#), on page 91
- [policy candidate-paths](#), on page 92
- [policy candidate-paths constraints disjoint-path](#), on page 93
- [policy candidate-paths constraints resources](#), on page 95
- [policy color](#), on page 96
- [policy source-address](#), on page 97
- [policy steering](#), on page 98
- [resource-list](#), on page 99
- [segment-list](#), on page 100
- [separate-next-hop](#), on page 101
- [steering labeled-services](#), on page 102
- [te-latency](#), on page 103

# affinity-map

To define an affinity map, use the **affinity-map name name bit-position bit-position** command in SR-TE sub-mode.

**affinity-map name name bit-position bit-position**

## Syntax Description

<b>name name</b>	Specify the name of the affinity-map.
<b>bit-position bit-position</b>	Specify the bit position in the Extended Admin Group bitmask.

## Command Default

None

## Command Modes

SR-TE configuration

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

Configure affinity maps on the following routers:

- Routers with interfaces that have an associated admin group attribute.
- Routers that act as SR-TE head-ends for SR policies that include affinity constraints.

## Example

This example shows how to define an affinity map:

```
Router# configure
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# affinity-map
Router(config-sr-te-affinity-map)# name RED bit-position 23
```

# autoroute include ipv6 all

To enable IPv6 autoroute support for SR-TE policies with IPv4 endpoints, use the **autoroute include ipv6 all** command in the SR-TE policy and PCC profile modes. To disable this feature, use the **no** form of this command.

**autoroute include ipv6 all**  
**no autoroute include ipv6 all**

**Syntax Description** This command has no keywords or arguments.

**Command Default** IPv6 autoroute support is disabled.

**Command Modes** SR-TE policy  
 PCC profile

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

**Usage Guidelines** The **include ipv6 all** command form enables autoroute support for IPv6 prefixes, for a specified SR-TE policy. This command can be used in the SR-TE policy and PCC profile modes.

## Example

The following example shows how to configure the IPv6 autoroute function for an SR-TE policy with an IPv4 endpoint:

```
Router# configure
Router(config)# segment-routing traffic-eng policy pol12
Router(config-sr-te-policy)# autoroute include ipv6 all
Router(config-sr-te-policy)# commit
```

The following example shows how to configure the IPv6 autoroute function for a PCE-instantiated SR-TE policy with an IPv4 endpoint:

```
Router# configure
Router(config)# segment-routing traffic-eng pcc profile 10
Router(config-pcc-prof)# autoroute include ipv6 all
Router(config-pcc-prof)# commit
```

## bgp prefix-path-label ignore

To indicate BGP to ignore the programming of the service route's prefix label when recursing onto the BSID of an SR-TE policy, use the **bgp prefix-path-label ignore** command in SR-TE policy steering config mode.

**bgp prefix-path-label ignore**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** SR-TE policy steering

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

**Usage Guidelines** This command can be configured for manual SR policies.

### Example

The following example shows how to configure BGP to ignore the programming of the service route's prefix label when recursing onto the BSID of an SR-TE policy:

```
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# policy POLICY1
Router(config-sr-te-policy)# steering
Router(config-sr-te-policy-steering)# bgp prefix-path-label ignore
```

# binding-sid

To specify the binding SID (BSID) allocation behavior, use the **binding-sid** command in SR-TE sub-mode.

```
binding-sid { dynamic disable | explicit { enforce-srlb | fallback-dynamic } }
```

## Syntax Description

<b>dynamic disable</b>	Disables dynamic binding SID allocation. Candidate paths without an explicit BSID will be considered invalid.
<b>explicit enforce-srlb</b>	Specifies strict SRLB enforcement. If the BSID is not within the SRLB, the policy stays down.
<b>explicitfallback-dynamic</b>	Specifies that, if the BSID is not available, the BSID is allocated dynamically and the policy comes up.

## Command Default

Binding SIDs are dynamically allocated

## Command Modes

SR-TE configuration

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

Explicit BSIDs are allocated from the segment routing local block (SRLB) or the dynamic range of labels. A best-effort is made to request and obtain the BSID for the SR-TE policy. If requested BSID is not available (if it does not fall within the available SRLB or is already used by another application or SR-TE policy), the policy stays down.

This command specifies how the BSID allocation behaves if the BSID value is not available:

- Fallback to dynamic allocation – If the BSID is not available, the BSID is allocated dynamically and the policy comes up.
- Strict SRLB enforcement – If the BSID is not within the SRLB, the policy stays down.

## Example

This example shows how to configure an SR policy to use an explicit BSID of 1000. If the BSID is not available, the BSID is allocated dynamically and the policy comes up.

```
Router# configure
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# binding-sid explicit fallback-dynamic
Router(config-sr-te)# policy goo
Router(config-sr-te-policy)# binding-sid mpls 1000
```

## distribute link-state (SRTE)

To enable reporting of SRTE policies, use the **distribute link-state** command in the SR-TE configuration mode.

**distribute link-state** [ **report-candidate-path-inactive** ]

*Table 6: Syntax Description:*

Syntax	Description
<b>report-candidate-path-inactive</b>	Enables reporting of SRTE policies using BGP-LS.

**Command Default** The reporting of policies to BGP-LS is disabled by default.

**Command Modes** SR-TE configuration (config-sr-te)

Command History	Release	Modification
	Release 24.1.1	Supports reporting of SR-TE policies using BGP- Link State for SRv6.
	Release 7.10.1	This command was introduced and supports reporting of SR-TE policies using BGP- Link State for SR-MPLS.

Task ID	Task ID	Operation
	distribute link-state	write/read

### Example

This example shows how to enable BGP-LS reporting and syncing of SRTE Policies:

```
Router# config
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# distribute link-state
Router(config-sr-te-distribute-ls)# report-candidate-path-inactive
Router(config-sr-te-distribute-ls)# exit
```

# distribute link-state

To enable reporting of SRTE policies, use the **distribute link-state** command in the SR-TE configuration mode.

**distribute link-state** [ **report-candidate-path-inactive** ]

*Table 7. Syntax Description:*

Syntax	Description
<b>report-candidate-path-inactive</b>	Enables reporting of SRTE policies using BGP-LS.

**Command Default** The reporting of policies to BGP-LS is disabled by default.

**Command Modes** SR-TE configuration (config-sr-te)

Command History	Release	Modification
	Release 24.1.1	Supports reporting of SR-TE policies using BGP- Link State for SRv6.
	Release 7.10.1	This command was introduced and supports reporting of SR-TE policies using BGP- Link State for SR-MPLS.

Task ID	Task ID	Operation
	distribute link-state	write/read

## Example

This example shows how to enable BGP-LS reporting and syncing of SRTE Policies:

```
Router# config
Router(config)# segment-routing
Router(config-sr)# traffic-eng
Router(config-sr-te)# distribute link-state
Router(config-sr-te-distribute-ls)# report-candidate-path-inactive
Router(config-sr-te-distribute-ls)# exit
```

## hw-module profile cef sropt enable

To enable Segment Routing Encap object optimization, use the **hw-module profile cef sropt enable** command in XR Config mode.

### hw-module profile cef sropt enable

**Syntax Description** This command has no keywords or arguments.

**Command Default** Segment Routing Encap object optimization is disabled.

**Command Modes** XR Configuration

Command History	Release	Modification
	Release 7.5.4	This command was introduced.

**Usage Guidelines** After you enter this command, you must reload the router.

Segment Routing Encap object optimization minimizes the Encap resource consumption of the forwarding ASIC. With this feature, instead of consuming an Encap entry for each outgoing path, the forwarding chain of a labeled prefix with ECMP consumes only a single global Encap entry.

SR Encap object optimization is triggered only when all ECMP paths of a labeled prefix (primary and backup) perform the same egress action (either all pop or all swap); and have the same outgoing label for the swap egress action. If this condition is not met, then the prefix is programmed with a dedicated Encap object per outgoing path.

SR Encap object optimization is supported for both labeled IPv4 /32 (SR-MPLSv4) and labeled IPv6 /128 (SR-MPLSv6).

All paths associated with the prefix (primary and backup) must have the same outgoing label value for SR Encap object optimization to be triggered. For example:

- For prefixes with LFA backup paths, the SR Encap object optimization is triggered because these backup paths do not require an extra label to be pushed.
- For prefixes with TI-LFA backup paths requiring extra labels to be pushed, the SR Encap object optimization is not triggered because all the paths associated with the prefix do not have the same outgoing label value.

Per-label per-interface egress counters are not supported when SR Encap object optimization is enabled. Instead, per-label aggregate egress counters are supported.

SR MicroLoop Avoidance is not supported when SR Encap object optimization is enabled.

### Example

This example shows how to enable Segment Routing Encap object optimization:

```
Router(config)# hw-module profile cef sropt enable
```



In order to activate/deactivate SROPT feature, you must manually reload the chassis/all line cards

```
Router(config)# commit
Router(config)# end
```

```
Router# reload location all
Proceed with reload? [confirm] y
```

```
Router# show hw-module profile cef
```

```
-----
Knob                               Status           Applied          Action
-----
CBF Enable                         Unconfigured     N/A             None
CBF forward-class-list             Unconfigured     N/A             None
BGPLU                               Unconfigured     N/A             None
LPTS ACL                           Unconfigured     N/A             None
Dark Bandwidth                    Unconfigured     N/A             None
SR-OPT Enable                     Configured     Yes           None
IP Redirect Punt                   Unconfigured     N/A             None
IPv6 Hop-limit Punt                Unconfigured     N/A             None
MPLS Per Path Stats                Unconfigured     N/A             None
Tunnel TTL Decrement               Unconfigured     N/A             None
High-Scale No-LDP-Over-TE          Unconfigured     N/A             None
Label over TE counters             Unconfigured     N/A             None
Highscale LDPoTE No SRoTE          Unconfigured     N/A             None
LPTS Pifib Entry Counters          Unconfigured     N/A             None
-----
```

## kshortest-paths

To set the maximum number of attempts for SRTE to compute paths that satisfy cumulative metric bounds criteria, use the **kshortest-paths** command in SR-TE configuration mode. To revert to the default number of attempts (100), use the **no** form of the command.

**kshortest-paths** *max-attempts*

**no kshortest-paths**

---

### Syntax Description

*max-attempts* Maximum number of attempts.  
Choose a value between 1 and 200.

---

### Command Default

100 attempts are made to compute paths that satisfy the cumulative metric bounds criteria.

### Command Modes

SR-TE configuration (config-sr-te)

### Command History

Release	Modification
Release 7.3.1	This command was introduced.

---

### Usage Guidelines

By default, a maximum of 100 attempts are made. To update the value, you can use this command.

You can use the **show segment-routing traffic-eng policy color** command (**Number of K-shortest-paths** field) to see the K-shortest path algorithm computation result. For example, if the **Number of K-shortest-paths** field displays 4, it means that the K-shortest path algorithm took 4 computations to find the right path. The 4 shortest paths that are computed using K-shortest path algorithm did not respect the cumulative bounds, and the fifth shortest path was valid against the bounds.

### Example

This example shows how to set the maximum number of attempts for computing paths that satisfy the cumulative metric bounds criteria:

```
Router# configure terminal
Router(config)# segment-routing traffic-eng
Router(config-sr-te)# kshortest-paths 120
Router(config-sr-te)# commit
```

# neighbor sr-policy name targeted

To configure the SR policy name under LDP, use the **neighbor sr-policy *name* targeted** command in SR-TE configuration mode.

**neighbor sr-policy *name* targeted**

*Table 8: Syntax Description*

Syntax	Description
<i>name</i>	<p>Use the command to configure the SR policy name under LDP</p> <p><i>name</i> is the auto-generated SR policy name assigned by the router when creating an LDP targeted adjacency over an SR policy.</p> <p><b>Note</b> You can use the <b>show segment-routing traffic-eng policy</b> command to display the auto generated SR policy name. Auto-generated SR policy name uses the following naming convention: <b>srte_c_color_val_ep_endpoint-address</b>. For example, srte_c_1000_ep_10.1.1.2.</p>

**Command Default** None

**Command Modes** SR-TE configuration mode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

## Example

The following example shows how to configure the SR policy name under LDP:

```
Router(config)# mpls ldp
Router(config-ldp)# address-family ipv4
Router(config-ldp-af)# neighbor sr-policy srte_c_1000_ep_10.1.1.2 targeted
Router(config-ldp-af)#commit
```

# on-demand constraints



**Note** From Cisco IOS XR Release 7.9.1, you must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use the [on-demand dynamic sid-algorithm](#) with this command.

To configure the SR Flexible Algorithm constraints, use the **constraints segments sid-algorithm** command in SR-TE sub-mode.

```
on-demand color color constraints { segments sid-algorithm algo | resources { exclude resource-list name | exclude-group group_name | apply-group group_name } }
```

## Syntax Description

<b>segments</b>	Specify constraints for segments of a path in a network.
<b>sid-algorithm</b> <i>algo</i>	Specify the SR Flexible Algorithm value. The <i>algo</i> range is from 128 to 255.
<b>resources</b>	Specify resource constraints for path computation.
<b>exclude</b>	Exclude resources from path computation.
<b>resource-list</b> <i>name</i>	Specify the name of the resource-list to exclude from the path computation.

## Command Default

None

## Command Modes

SR-TE configuration

## Command History

Release	Modification
Release 24.1.1	The resources option was introduced.
Release 7.9.1	You must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use the <a href="#">on-demand dynamic sid-algorithm</a> with this command.
Release 7.4.1	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Example

The following example shows how to add an SR Flexible Algorithm constraint:

```
Router(config-sr-te-color)# constraints segments sid-algorithm 128
```

The following example shows how to associate the excluded IPv4 addresses for ODN SR-TE policies:

```
Router(config)#segment-routing
Router(config-sr)#traffic-eng
Router(config-sr-te)#on-demand color 7001
Routerconfig-sr-te-color)#constraints resources exclude resource-list node_resc_list
```

# on-demand dynamic affinity sid-algorithm



**Note** You must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use this command with the [constraints segments sid-algorithm algo](#) command.

To configure the SR Flexible Algorithm constraints, use the **on-demand dynamic sid-algorithm** command in SR-TE sub-mode.

**on-demand color** *color* **dynamic sid-algorithm** *algo*

**Syntax Description** **sid-algorithm***algo* Specify the SR Flexible Algorithm value . The *algo* range is from 128 to 255.

**Command Default** None

**Command Modes** SR-TE configuration

Command History	Release	Modification
	Release 6.3.1	This command was introduced.
	Release 7.4.1	This command was replaced by the <a href="#">constraints segments sid-algorithm algo</a> command.
	Release 7.9.1	You must reconfigure all SR-ODN configurations with Flexible Algorithm constraints that use this command with the <a href="#">constraints segments sid-algorithm algo</a> command.

**Usage Guidelines** This command was replaced by the [constraints segments sid-algorithm algo](#) command.

## Example

```
Router(config-sr-te-color-dyn)# sid-algorithm 128
```

## on-demand dynamic affinity disjoint-path

To configure the disjoint-path constraints, use the **on-demand dynamic disjoint-path** command in SR-TE sub-mode.

```
on-demand color color dynamic disjoint-path group-id id type { link | node | srlg | srlg-node } [ { sub-id sub_id | fallback disable } ]
```

Syntax Description		
<b>group-id</b> <i>id</i>		Specify the group ID of the disjoint path. Valid values are from 1 to 65535.
<b>type</b> { <b>link</b>   <b>node</b>   <b>srlg</b>   <b>srlg-node</b> }		Specify the type of disjointness.
<b>sub-id</b> <i>id</i>		Specify the sub-group ID of the disjoint path. Valid values are from 1 to 65535.
<b>fallback disable</b>		Disable all fallback behavior in case the requested disjointness cannot be achieved.

**Command Default** None

**Command Modes** SR-TE configuration

Command History	Release	Modification
	Release 24.1.1	The <b>fallback disable</b> keyword was introduced.
	Release 6.3.1	This command was introduced.

**Usage Guidelines** Configures the disjoint group ID and defines the preferred level of disjointness (the type of resources that should not be shared by the two paths):

- **link**—Specifies that links are not shared on the computed paths.
- **node**—Specifies that nodes are not shared on the computed paths.
- **srlg**—Specifies that links with the same SRLG value are not shared on the computed paths
- **srlg-node**—Specifies that SRLG and nodes are not shared on the computed paths.

If a pair of paths that meet the requested disjointness level cannot be found, then the paths will automatically fallback to a lower level:

- If the requested disjointness level is SRLG or node, then link-disjoint paths will be computed.
- If the requested disjointness level was link, or if the first fallback from SRLG or node disjointness failed, then the lists of segments encoding two shortest paths, without any disjointness constraint, will be computed.

### Example

```
Router(config-sr-te-color-dyn)# disjoint-path group-id 775 type link
```

The following example indicates how to configure strict disjointness for an ODN SR-TE policy:

```
Router(config)#segment-routing traffic-eng  
Router(config-sr-te)#on-demand color 4  
Router(config-sr-te-color)#dynamic  
Router(config-sr-te-color-dyn)#disjoint-path group-id 1 type node fallback disable  
Router(config-sr-te-color-dyn)#commit
```

# on-demand maximum-sid-depth

Syntax Description

Command Default

Command Modes

Command History

Release Modification

Usage Guidelines

Task ID

Task Operation ID

Example



# on-demand source-address

**Syntax Description** 

**Command Default**

**Command Modes**

**Command History** Release Modification

**Usage Guidelines**

<b>Task ID</b>	<b>Task</b>	<b>Operation ID</b>

**Example**

# on-demand steering

---

## Syntax Description




---

## Command Default

---

## Command Modes

---

## Command History

---

Release	Modification
---------	--------------

---



---

## Usage Guidelines

---

### Task ID

---

Task ID	Operation ID
---------	--------------

---

## Example

# policy binding-sid

---

**Syntax Description** 

---

**Command Default**

---

**Command Modes**

---

**Command History** 

---

**Release** **Modification** 

---

---

**Usage Guidelines**

---

**Task ID** 

---

**Task** **Operation** **ID** 

---

**Example**

# policy candidate-paths

---

**Syntax Description**




---

**Command Default**

---

**Command Modes**

---

**Command History**

---

Release	Modification
---------	--------------

---



---

**Usage Guidelines**

---

**Task ID**

---

Task ID	Operation ID
---------	--------------

---

**Example**

# policy candidate-paths constraints disjoint-path

To configure the disjoint-path constraints, use the **on-demand dynamic disjoint-path** command in SR-TE sub-mode.

```
policy policy candidate-paths preference preference constraints disjoint-path group-id
id type { link | node | srlg | srlg-node } [ { sub-id sub_id | shortest-path | fallback disable } ]
```

Syntax Description		
<b>group-id</b> <i>id</i>		Specify the group ID of the disjoint path. Valid values are from 1 to 65535.
<b>type</b> { <b>link</b>   <b>node</b>   <b>srlg</b>   <b>srlg-node</b> }		Specify the type of disjointness.
<b>sub-id</b> <i>id</i>		Specify the sub-group ID of the disjoint path. Valid values are from 1 to 65535.
<b>shortest-path</b>		Enable shortest path computation for the selected candidate path.
<b>fallback disable</b>		Disable all fallback behavior in case the requested disjointness cannot be achieved.

**Command Default** None

**Command Modes** SR-TE configuration

Command History	Release	Modification
	Release 24.1.1	The <b>shortest-path</b> and <b>fallback disable</b> keywords were introduced.
	Release 6.3.1	This command was introduced.

**Usage Guidelines** Configures the disjoint group ID and defines the preferred level of disjointness (the type of resources that should not be shared by the two paths):

- **link**—Specifies that links are not shared on the computed paths.
- **node**—Specifies that nodes are not shared on the computed paths.
- **srlg**—Specifies that links with the same SRLG value are not shared on the computed paths
- **srlg-node**—Specifies that SRLG and nodes are not shared on the computed paths.

If a pair of paths that meet the requested disjointness level cannot be found, then the paths will automatically fallback to a lower level:

- If the requested disjointness level is SRLG or node, then link-disjoint paths will be computed.
- If the requested disjointness level was link, or if the first fallback from SRLG or node disjointness failed, then the lists of segments encoding two shortest paths, without any disjointness constraint, will be computed.

## Example

```
Router(config-sr-te)# policy FOO
Router(config-sr-te-policy)# candidate-paths preference 100
Router(config-sr-te-poliililokl,.cy-path-pref)# constraints disjoint-path group-id 775 type
link
```

The following example indicates how to configure the shortest path preference for a disjoint path:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#policy dynamic_pcep_policy_disjoint
Router(config-sr-te-policy)#candidate-paths
Router(config-sr-te-policy-path)#preference 100
Router(config-sr-te-policy-path-pref)#constraints disjoint-path group-id 1 type link
shortest-path
```

The following example indicates how to configure strict disjointness for a SR-TE policy:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#policy foo
Router(config-sr-te-policy)#color 1 end-point ipv4 10.10.10.1
Router(config-sr-te-policy)#candidate-paths preference 100
Router(config-sr-te-policy-path-pref)#constraints disjoint-path group-id 1 type node fallback
disable
Router(config-sr-te-policy-path-pref)#commit
```

# policy candidate-paths constraints resources

To exclude IP addresses from the path computation for SR-TE policies, use the **policy candidate-paths constraints resources** command in the SR-TE configuration mode.

```
policy policy candidate-paths preference preference constraints resources { exclude
resource-list name | exclude-group group_name | apply-group group_name }
```

<b>Syntax Description</b>	<b>resources</b> { <b>exclude-group</b>   <b>exclude</b>   <b>apply-group</b> }	Specify the resource constraints for path computation: <ul style="list-style-type: none"> <li>• <b>exclude</b>. Excludes resources from the path computation.</li> <li>• <b>exclude-group</b>. Excludes the apply-group configuration from the group.</li> <li>• <b>apply-group</b>. Applies configuration from a group.</li> </ul>
	<b>resource-list</b> <i>name</i>	Specify the name of the resource-list to exclude from the path computation.
<b>Command Default</b>	None	
<b>Command Modes</b>	SR-TE configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.1.1	This command was introduced.
<b>Usage Guidelines</b>	None.	

## Example

The following example shows how to exclude a list of IPv4 addresses from the network resource list:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#resource-list node_resc_list
Router(config-sr-te-rl)#index 1 ipv4 10.10.10.1
Router(config-sr-te-rl)#index 2 ipv4 10.10.10.8
```

The following example shows how to associate the excluded IPv4 addresses to one or more candidate paths for SR-TE policies:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#policy dynamic pcep_policy
Router(config-sr-te-policy)#candidate-paths
Router(config-sr-te-policy-path)#preference 100
Router(config-sr-te-policy-path-pref)#constraints resources exclude resource-list
node_resc_list
```

# policy color

---

## Syntax Description




---

## Command Default

---

## Command Modes

---

## Command History

---

Release	Modification
---------	--------------

---



---

## Usage Guidelines

---

### Task ID

---

Task ID	Operation ID
---------	--------------

---

## Example



# policy source-address

---

**Syntax Description** 

---

**Command Default**

---

**Command Modes**

---

**Command History** 

---

**Release** **Modification** 

---

---

**Usage Guidelines**

---

**Task ID** 

---

**Task** **Operation** **ID** 

---

**Example**

# policy steering

**Syntax Description**



**Command Default**

**Command Modes**

**Command History**

**Release Modification**

**Usage Guidelines**

**Task ID**

**Task Operation ID**

**Example**

# resource-list

To configure a list of IPv4 addresses that you want to exclude from the network resource list for a candidate path, use the **resource-list** command in SR-TE configuration mode.

```
resource-list name index "1-65535" ipv4 ipv4-addr
```

<b>Syntax Description</b>	<p><b>resource-list</b> <i>name</i> Specify the resource-list name to exclude from the path computation.</p> <p><b>index</b> <i>1-65535</i> Specify the index entry. Ranges from 1–65535.</p> <p><b>ipv4</b> <i>ipv4-addr</i> Specify the IPv4 address that you want to exclude from the network resource list.</p>				
<b>Command Default</b>	None				
<b>Command Modes</b>	SR-TE configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 24.1.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 24.1.1	This command was introduced.
Release	Modification				
Release 24.1.1	This command was introduced.				
<b>Usage Guidelines</b>	None.				

## Example

The following example shows how to configure a list of IPv4 addresses that you want to exclude from the network resource list:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#resource-list node_resc_list
Router(config-sr-te-rl)#index 1 ipv4 10.10.10.1
Router(config-sr-te-rl)#index 2 ipv4 10.10.10.8
```

# segment-list

**Syntax Description**



**Command Default**

**Command Modes**

**Command History**

**Release    Modification**

**Usage Guidelines**

**Task ID**

**Task    Operation  
ID**

**Example**

# separate-next-hop

To enable SR-TE with next-hop independent scaling optimization, use the **separate-next-hop** command in ST-TE configuration mode.

## **segment-routing traffic-eng separate-next-hop**

This command has no keywords or arguments.

---

**Command Default** None

---

**Command Modes** SR-TE configuration

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

---

---

**Usage Guidelines**

**Example**

# steering labeled-services

Syntax Description 

Command Default

Command Modes

Command History **Release** **Modification**

Usage Guidelines

Task ID **Task** **Operation**  
**ID**

Example

# te-latency

---

**Syntax Description**

---

---

**Command Default**

---

---

**Command Modes**

---

---

**Command History**

---

---

**Release** **Modification**

---

---

**Usage Guidelines**

---

---

**Task ID**

---

---

**Task** **Operation**  
**ID**

---

**Example**

te-latency





## SRv6 Traffic Engineering

---

This chapter describes the commands used to configure and use SRv6 Traffic Engineering.

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

- [accounting prefixes ipv6 mode](#), on page 106
- [policy srv6 locator](#) , on page 107
- [segment-routing traffic-eng srv6](#), on page 108
- [srv6 locator](#) , on page 109
- [srv6 maximum-sid-depth](#), on page 110
- [segment-lists segment-list](#), on page 111
- [segment-lists srv6](#) , on page 112

## accounting prefixes ipv6 mode

To enable SRv6 traffic accounting, use the **accounting prefixes ipv6 mode** command in XR Config mode.

```
accounting prefixes ipv6 mode per-prefix per-nextthop srv6-locator
```

### Syntax Description

<b>per-prefix</b>	Enables accounting for every prefix.
<b>per-nextthop</b>	Enables accounting for every prefix and nextthop.
<b>srv6-locator</b>	Enables accounting only for Segment-routing SRv6 locator.

### Command Default

None

### Command Modes

XR Config

### Command History

Release	Modification
Release 7.10.1	This command was introduced.

### Usage Guidelines

No specific guidelines impact the use of this command.

The following example shows how to enable SRv6 traffic accounting:

```
Router(config)#accounting prefixes ipv6 mode per-prefix per-nextthop srv6-locators
```

# policy srv6 locator

To create the SRv6-TE policy and configure customized per-policy locator and BSID behavior, use the **policy srv6 locator** command in the SR-TE interface submode.

```
policy policy-name srv6 locator locatorname binding-sid dynamic behavior
ub6-encaps-reduced Binding-SID
```

Syntax Description		
<b>policy</b> <i>policy-name</i>		Specifies the policy name. The name can be a maximum of 59 characters.
<b>locator</b> <i>locator</i>		Specifies the locator name. The locator name can be a maximum of 64 characters.
<b>binding-sid dynamicbehavior</b>		Configures the BSID dynamic behavior.
<b>ub6-encaps-reduced</b>		Configures BSID with reduced encapsulation behavior. Reduces the length of the SRH by excluding the first SID in the IPv6 header.
<b>ub6-insert-reduced</b>		Configures BSID with insert reduced behavior.

**Command Default** None

**Command Modes** SR-TE interface submode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

**Usage Guidelines** If you don't specify a customized per-policy locator and BSID behavior, the policy uses the global locator and BSID behavior.

The following example shows how to create the SRv6-TE policy and configure customized per-policy locator and BSID behavior:

```
RP/0/RP0/CPU0:ios (config-sr-te) #policy name
RP/0/RP0/CPU0:ios (config-sr-te-policy) #srv6
RP/0/RP0/CPU0:ios (config-sr-te-policy-srv6) #locator loc1 binding-sid dynamic behavior
ub6-encaps-reduced
RP/0/RP0/CPU0:ios (config-sr-te-policy-srv6) #
```

## segment-routing traffic-eng srv6

To configure SRv6-TE, use the **segment-routing srv6** command in the SR-TE interface submode. To disable SRv6-TE, use the **no** form of this command.

```
segment-routing traffic-eng srv6
```

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	SR-TE interface submode
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.10.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

The following example shows how to configure SRv6-TE.

```
Router (config) #segment-routing traffic-eng
Router (config-sr-te) #srv6
Router (config-sr-te-srv6) #exit
Router (config-sr-te) #
```

## srv6 locator

To configure SRv6-TE locator and binding SID (BSID) behavior, use the **srv6 locator** command in the SR-TE interface submode.

```
Srv6 locator locatorname binding-sid dynamic behavior { ub6-encaps-reduced | ub6-insert-reduced }
```

Syntax Description	locator <i>locator</i>	Specifies the locator name. The locator name can be a maximum of 64 characters.
	<b>binding-sid</b> <b>dynamicbehavior</b>	Configures the BSID dynamic behavior.
	<b>ub6-encaps-reduced</b>	Configures BSID with reduced encapsulation behavior. Reduces the length of the SRH by excluding the first SID in the SRH of the pushed IPv6 header.
	<b>ub6-insert-reduced</b>	Configures BSID with insert reduced behavior.

**Command Default** None

**Command Modes** SR-TE interface submode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

**Usage Guidelines** If you don't specify a customized per-policy locator and BSID behavior, the policy uses the global locator and BSID behavior.

The following example shows how to configure SRv6-TE locator and binding SID (BSID) behavior.

```
Router#configure
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#srv6 locator loc1 binding-sid dynamic behavior ub6-encaps-reduced
```

## srv6 maximum-sid-depth

To customize the Maximum SID Depth (MSD) signaled by PCC during PCEP session establishment, use the **srv6 maximum-sid-depth** command in SR-TE srv6 submode.

**maximum-sid-depth** *value*

### Syntax Description

<b>maximum-sid-depth</b> <i>value</i>	Specifies the Maximum SID Depth (MSD) value.  The MSD is expressed as a number uSIDs. The number of uSID is expressed as a number of carriers and the number of uSID per carrier. The range is from 1-255.
--	--

### Command Default

None

### Command Modes

SR-TE srv6 submode

### Command History

Release	Modification
Release 7.10.1	This command was introduced.

### Usage Guidelines

No specific guidelines impact the use of this command.

The following example shows how to customize the MSID:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#srv6
Router(config-sr-te-srv6)#maximum-sid-depth 13
Router(config-sr-te-srv6)#exit
Router(config-sr-te)#
```

## segment-lists segment-list

To configure SRv6 explicit segment list, use the **segment-lists segment-list** command in SR-TE interface submode.

```
segment-lists segment-list name srv6 [{ index number sid sid-id | topology-check }]
```

Syntax Description	Parameter	Description
	<i>name</i>	Specifies the name for the segment list.
	<b>srv6</b>	Enables the SRv6 segment-list configuration.
	<b>indexnumber</b>	Specifies the index number. The range is from 1-65535.
	<b>sidsid-id</b>	Specifies the SRv6 SID
	<b>topology-check locator</b>	Enables SID verification.

**Command Default** None

**Command Modes** SR-TE interface submode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

The following example shows how to configure SRv6 explicit segment list:

```
Router(config)# segment-routing traffic-eng
Router(config-sr-te)# segment-lists
Router(config-sr-te-segment-lists)# srv6
Router(config-sr-te-sl-global-srv6)# sid-format usid-f3216
Router(config-sr-te-sl-global-srv6)# exit
Router(config-sr-te-segment-lists)# segment-list p1_r8_1
Router(config-sr-te-sl-srv6)# index 10 sid FCBB:BB00:10:feff::
Router(config-sr-te-sl-srv6)# index 15 sid FCBB:BB00:100:fe00::
Router(config-sr-te-sl-srv6)# index 20 sid FCBB:BB00:1::
Router(config-sr-te-sl-srv6)# index 30 sid FCBB:BB00:1:fe00::
Router(config-sr-te-sl-srv6)# index 40 sid FCBB:BB00:fe00::
Router(config-sr-te-sl-srv6)# index 50 sid FCBB:BB00:5::
Router(config-sr-te-sl-srv6)# index 60 sid FCBB:BB00:6::
```

## segment-lists srv6

To enable SID validation globally for all SRv6 explicit segment lists, use the **segment-lists srv6** command in SR-TE interface submode.

```
segment-lists  srv6  [{ sid-format  usid-f3216 | topology-check  }]
```

Syntax Description	
<b>sid-format usid-f3216</b>	Specifies SID format F3216 micro SID.
<b>topology-check</b> <i>locator</i>	Enables SID verification.

**Command Default** None

**Command Modes** SR-TE interface submode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

The following example shows how to specify SID format for all SRv6 explicit segment lists:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#segment-lists
Router(config-sr-te-segment-lists)#srv6
Router(config-sr-te-sl-global-srv6)#sid-format usid-f3216
Router(config-sr-te-sl-global-srv6)#exit
Router(config-sr-te-segment-lists)#
```

The following example shows how to enable SID verification:

```
Router(config)#segment-routing traffic-eng
Router(config-sr-te)#segment-lists
Router(config-sr-te-segment-lists)#srv6
Router(config-sr-te-sl-global-srv6)#topology-check
Router(config-sr-te-sl-global-srv6)#exit
Router(config-sr-te-segment-lists)#
```