

# Release Notes for Cisco IoT Device Manager 5.6.1

---

**First Published:** 2021-12-22

## Release Notes for Cisco IoT Device Manager 5.6.1



---

**Note** The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

---

## IoT Device Manager

Cisco IoT Device Manager (IoT-DM or Device Manager) is a Windows-based application that field technicians can use to manage the Cisco 1000 Series Connected Grid Routers (CGR 1000) running Cisco IOS, the Cisco 800 Series Industrial Integrated Services Routers (IR800), and the Cisco 500 Series WPAN Industrial Routers (IR500).

Cisco IoT-DM does not manage CGR 1000 routers running CG-OS.



---

**Note** This application was previously named Cisco Connected Grid Device Manager (CG-DM).

---



---

**Note** *You must uninstall any instance of CG-DM Release 4.x or earlier, before you install IoT-DM 5.x on your laptop. The installer will not recognize the older installation given the different product name.*

---

Cisco 1000 Series Connected Grid Routers (CGR 1000) are multi-service communications platforms designed for use in field area networks (FANs). The portfolio consists of two models—Cisco CGR 1240 and Cisco CGR 1120—both ruggedized to varying degrees for outdoor and indoor deployments. Both models are modular and support a wide range of communications interfaces such as 2G/3G/4G LTE, Ethernet, and WiFi. Device Manager connects to the CGR 1000 by using a secure Ethernet or WiFi link.

The Cisco 800 Series Industrial Integrated Services Routers are compact, ruggedized, Cisco IOS Software routers. They offer support for integrated 4G LTE wireless WAN (both 809 and 829 models) and wireless LAN capabilities (829 model only). Device Manager connects to the IR809 by using a secure Ethernet link, and to the IR829 by using a secure Ethernet or WiFi link. The IR809 must have IPv6 option enabled to connect with work order.

Cisco IR500 is a distribution automation (DA) gateway that provides secure IPv4/IPv6 connectivity over the IPv6-based Cisco Resilient Mesh (formerly known as CG-Mesh) to DA devices such as capacitor bank controllers, reclosers, or other SCADA devices. Device Manager connects to the IR500 directly over the laptop COM port.

For some activities on the CGR 1000, IR800, and IR500, IoT-DM connects to the Cisco IoT Field Network Director (Cisco IoT-FND).

## Conventions

This document uses the following conventions.

Conventions	Indication
<b>bold font</b>	Commands and keywords and user-entered text appear in <b>bold font</b> .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[ ]	Elements in square brackets are optional.
{x   y   z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
courier font	Terminal sessions and information the system displays appear in courier font.
<>	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



### Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



### Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



---

**Danger** **IMPORTANT SAFETY INSTRUCTIONS** Means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. **SAVE THESE INSTRUCTIONS**

---

**Regulatory:** Provided for additional information and to comply with regulatory and customer requirements.

## System Requirements

### Laptop

- Microsoft Windows 10 or Microsoft Windows 7 Enterprise.
- 2 GHz or faster processor recommended.
- 1 GB RAM minimum (for potential large log file processing).
- WiFi or Ethernet interface.
- 4 GB disk storage space.
- Windows login enabled.
- Utility-signed Certificate Authority (CA) and Client Certificate for router authentication (obtained from your network administrator).
- Customer-specific IT security hardening to keep the Device Manager laptop secure.

### CGR 1000

- Cisco IOS Release 15.9(3)M1 or greater to support connectivity to the 4G LTE module.



---

**Note** The CGR 1000 must run Cisco IOS Release 15.5(1)T1 or greater to support connectivity to the IR500.

---

### IR800

- Cisco IOS Release 15.9(3)M1 or greater.

### IR500

- Firmware version 6.2 (cg-mesh-dagw-6.2-6219-ir510-1bf449d.bin) or greater.
- Cisco IOS Release 15.9(3)M1 or greater.

**IoT-FND**

- Cisco IoT-FND Release 4.6 or greater.

## Important Notes

Cisco IoT-DM does not support CGR 1000 routers running CG-OS.

## Caveats

This section addresses the open caveats in this release and provides information on how to use the Bug Search Tool to find further details on those caveats. This section includes the following topics.

## Resolved Caveats

- CSCvt97773  
Getting "java.lang.NullPointerException" when "ip http secure-client-auth" CLI is configured.




---

**Note** Additional security fixes are available.

---

## Related Documentation

*Table 1: Related Documentation*

Device or Feature	Related Documents
Cisco 1000 Series Connected Grid Routers	Configuration and Installation Guides: <a href="http://www.cisco.com/go/cgr1000-docs">http://www.cisco.com/go/cgr1000-docs</a>
Cisco 800 Series Industrial Integrated Services Routers (IR800)	<a href="http://www.cisco.com/c/en/us/support/routers/800-series-industrial-routers/tsd-products-support-series-home.html">http://www.cisco.com/c/en/us/support/routers/800-series-industrial-routers/tsd-products-support-series-home.html</a>
IR500	Cisco IR 500 Series WPAN Gateway and Range Extender Installation and Configuration Guide <a href="http://www.cisco.com/go/ir500">http://www.cisco.com/go/ir500</a>
IoT-FND	<a href="#">Cisco IoT Field Network Director User Guide 4.0.x</a> <a href="#">North Bound API User Guide for the Cisco IoT Field Network Director 3.0</a>

Device or Feature	Related Documents
WPAN and Cisco Resilient Mesh	<a href="#">Cisco Connected Grid WPAN Module for CGR 1000 Series Installation and Cisco Resilient Mesh Configuration Guide (Cisco IOS)</a>
Raw Socket	<a href="#">Raw Socket Transport Software Configuration Guide for Cisco 1000 Series Connected Grid Routers (Cisco IOS)</a> <a href="#">Configuring Raw Socket Protocol on the CGR 2010 Router</a>

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions, and services, visit [Cisco DevNet](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a gateway to the Cisco bug-tracking system, which maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. The BST provides you with detailed defect information about your products and software.

### Documentation Feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.

---

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2021 Cisco Systems, Inc. All rights reserved.